


SERVICE MANUAL

BG-3S_{CHASSIS}

<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>	<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>
KV-PF21DK7	RM-952	ME	SCC-U30G-A				
KV-PF21M70	RM-952	E	SCC-U13E-A				
KV-PF21N70	RM-915	Taiwan	SCC-P13F-A				
KV-PF21P70	RM-952	E	SCC-U13F-A				
KV-PF21Q40	RM-952	GE	SCC-U12P-A				
KV-PF21Q70	RM-952	E	SCC-U13H-A				
KV-PF51P40	RM-952	Indonesia	SCC-U20N-A				



SPECIFICATIONS
(except KV-PF21N70)

		Note
Power requirements	110-240 V AC, 50/60 Hz	
Power consumption (W)	Indicated on the rear of the TV	
Television system	B/G, I, D/K, M	KV-PF21M70
	B/G, D/K	KV-PF21DK7
	B/G	KV-PF21P70/PF21Q70 KV-PF21Q40/PF21P40
Color system	PAL, PAL60, SECAM, NTSC4.43, NTSC3.58	KV-PF21M70
	PAL, PAL60, NTSC4.43, NTSC3.58 (AV IN)	KV-PF21P70/PF21P40
	PAL, PAL60, SECAM, NTSC4.43	KV-PF21Q70/PF21Q40 KV-PF21DK7
Channel coverage		
B/G	VHF : E2 to E12/ UHF : E21 to E69/ CATV : S01 to S03, S1 to S41	
I	UHF : B21 to B68/ CATV : S01 to S03, S1 to S41	KV-PF21M70 only
D/K	VHF : C1 to C12, R1 to R12/ UHF : C13 to C57, R21 to R60 CATV: S01 to S03, S1 to S41, Z1 to Z39	KV-PF21M70/PF21DK7
M	VHF : A2 to A3/ UHF : A14 to A79/ CATV : A-8 to A-2, A to W+4, W+6 to W+84	KV-PF21M70 only
⌋ (Antenna)	75-ohm external terinal	
Audio output	3W	
Number of terminal		
📺 (Video)	Input : 2 Output : 1 Phono jacks; 1 Vp-p, 75 ohms	
🎵 (Audio)	Input : 2 Output : 1 Phono jacks; 500 mVrms	
📞 (Earphone)	Output : 1 Minijack	
Picture tube	21 inch	
Tube size (cm)	54	Measured diagonally
Screen size (cm)	51	Measured diagonally
Dimension (w/h/d, mm)	490 x 458 x 487	
Mass (kg)	25	

Design and specifications are subject to change without notice.

CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK ⚠ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

**SPECIFICATIONS
(KV-PF21N70 only)**

		Note
Power requirements	110V AC, 50/60 Hz	
Power consumption (W)	Indicated on the rear of the TV	
Television system	M	
Color system	PAL, PAL60, NTSC4.43, NTSC3.58 (AV IN)	
Channel coverage M	VHF : A2 to A13/ UHF : A14 to A69/ CATV : A-8 to A-1, A-W, W+1 to W+84	
⏏ (Antenna)	75-ohm external terinal	
Audio output	3W	
Number of terminal		
📺 (Video)	Input : 2 Output : 1 Phono jacks; 1 Vp-p, 75 ohms	
🎵 (Audio)	Input : 2 Output : 1 Phono jacks; 500 mVrms	
🎧 (Earphone)	Output : 1 Minijack	
Picture tube	21 inch	
Tube size (cm)	54	Measured diagonally
Screen size (cm)	51	Measured diagonally
Dimension (w/h/d, mm)	490 x 458 x 487	
Mass (kg)	25	

Design and specifications are subject to change without notice.

CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK △ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
	SELF DIAGNOSIS FUNCTION	4		5. DIAGRAMS	
1. GENERAL		9	5-1	Block Diagram	51
2. DISASSEMBLY			5-2	Frame Schematic Diagram	54
2-1.	Rear Cover Removal	35	5-3	Circuit Boards Location	56
2-2.	Chassis Assy Removal	35	5-4	Schematic Diagrams and Printed Wiring Boards ...	57
2-3.	F Bracket Removal	35	(1)	Schematic Diagram of A(1/2) Board	59
2-4.	Service Position	35	(2)	Schematic Diagram of A(2/2) Board	63
2-5.	Replacement of Parts	36	(3)	Schematic Diagrams of C3 and F Boards	71
2-5-1.	Replacement of Control Button	36	5-5	Semiconductors	75
2-5-2.	Replacement of Bar Control	36			
2-6.	Terminal Bracket Removal	36	6. EXPLODED VIEW		
2-7.	Degauss Coil Removal	36	6-1.	Chassis	77
2-8.	Picture Tube Removal	37			
3. SET-UP ADJUSTMENTS			7. ELECTRICAL PARTS LIST		79
3-1.	Beam Landing	38			
3-2.	Convergence	39			
3-3.	Focus Adjustment	41			
3-4.	G2 (Screen) and White Balance Adjustments	41			
4. CIRCUIT ADJUSTMENTS					
4-1.	Adjustments with Commander	42			
4-2.	Adjustment Method	43			
4-3.	Picture Quality Adjustments	48			
4-4.	A Board Adjustment After IC003 (Memory) Replacement	48			
4-5.	Picture Distortion Adjustment	49			

SELF DIAGNOSTIC FUNCTION

The units in this manual contain a self-diagnostic function. If an error occurs, the STANDBY/TIMER lamp will automatically begin to flash.

The number of times the lamp flashes translates to a probable source of the problem. A definition of the STANDBY/TIMER lamp flash indicators is listed in the instruction manual for the user's knowledge and reference. If an error symptom cannot be reproduced, the remote commander can be used to review the failure occurrence data stored in memory to reveal past problems and how often these problems occur.

1. DIAGNOSTIC TEST INDICATORS

When an errors occurs, the STANDBY/TIMER lamp will flash a set number of times to indicate the possible cause of the problem. If there is more than one error, the lamp will identify the first of the problem areas.

Result for all of the following diagnostic items are displayed on screen. No error has occurred if the screen displays a "0".


Diagnostic Item Description	No. of times STANDBY/TIMER lamp flashes	Self-diagnostic display/Diagnostic result	Probable Cause Location	Detected Symptoms
• Power does not turn on	Does not light	—	• Power cord is not plugged in. • Fuse is burned out F4601 (F Board)	• Power does not come on. • No power is supplied to the TV. • AC power supply is faulty.
• +B overcurrent (OCP) or overvoltage (OVP) • Vertical deflection stopped • Horizontal deflection overdrive	2 times	002:000 or 002:001~255 003:001~255 004:001~255 at the same time	• H.OUT Q511 is shorted. (A board) • -13V is not supplied. (A board) • IC 503 faulty (A board) • IC 301 faulty (A board)	• Power does not come on. • Load on power line is shorted. • Has entered standby state after horizontal raster. • Vertical deflection pulse is stopped. • Power line is shorted or power supply is stopped.
• White balance failure (no PICTURE)	5 times	005:000 or 005:001~225	• G2 is improperly adjusted. (Note 2) • CRT problem. • IC301 is faulty. (A board) • No connection A board to C3 board.	• No raster is generated. • CRT cathode current detection reference pulse output is small.
• Micro reset	—	101:00 or 101:001~225	• Discharge CRT (C3 Board) • Static discharge • External noise	• Power is shut down shortly, after this return back to normal. • Detect Micro latch up.

Note 1: If a + B overcurrent is detected, stoppage of the vertical deflection is detected simultaneously.

The symptom that is diagnosed first by the microcontroller is displayed on the screen.

Note 2: Refer to screen (G2) Adjustment in section 3-4 of this manual.

2. DISPLAY OF STANDBY/TIMER LIGHT FLASH COUNT



<u>Diagnostic Item</u>	<u>Flash Count*</u>
+B overcurrent/overvoltage Vertical deflection stopped	2 times
White balance failure	5 times

* One flash count is not used for self-diagnostic.

3. STOPPING THE STANDBY/TIMER FLASH

Turn off the power switch on the TV main unit or unplug the power cord from the outlet to stop the STANDBY/TIMER lamp from flashing.

4. SELF-DIAGNOSTIC SCREEN DISPLAY

For errors with symptoms such as “power sometimes shuts off” or “screen sometimes goes out” that cannot be confirmed, it is possible to bring up past occurrences of failure for confirmation on the screen:


[To Bring Up Screen Test]

In standby mode, press buttons on the remote commander sequentially in rapid succession as shown below:

Screen display → channel [5] → Sound volume [] → Power ON
 ↑

Note that this differs from entering the service mode (mode volume [+]).

Self-Diagnosis screen display



5. HANDLING OF SELF-DIAGNOSTIC SCREEN DISPLAY

Since the diagnostic results displayed on the screen are not automatically cleared, always check the self-diagnostic screen during repairs. When you have completed the repairs, clear the result display to “0”.

Unless the result display is cleared to “0”, the self-diagnostic function will not be able to detect subsequent faults after completion of the repairs.


[Clearing the result display]

To clear the result display to “0”, press buttons on the remote commander sequentially as shown below when the diagnostic screen is being displayed.

Channel [8] → 0

[Quitting Self-diagnostic screen]

To quit the entire self-diagnostic screen, turn off the power switch on the remote commander or the main unit.



Occurs when an overcurrent on the +B(135) line is detected by Q604. If Q604 go to ON and the voltage to pin 18 of IC301 should go down when V.SYNC is more than seven verticals in a period, the unit will automatically turn off.

Occurs when an absence of the vertical deflection pulse is detected by Q509 and IC001 shut down the power supply.

Occurs when an overcurrent on V drive line is detected by Q507. Power supply will be shut down when detect this by IC001.

If the RGB levels* do not balance or become low level within 5 seconds, this error will be detected by IC301. TV will stay on, but there will be no picture.











* (Refers to the RGB levels of the AKB detection Ref pulse that detects IK.)

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

SECTION 1-1 GENERAL (Except KV-PF21N70)

WARNING

- Dangerously high voltages are present inside the TV.

 Do not open the cabinet and the rear cover of the TV. Refer servicing to qualified personnel.	 Install the TV in a stable position. Do not allow children to climb onto it.
 To prevent fire or shock hazard, do not expose the TV to rain or moisture.	 Do not operate the TV if any liquid or solid object falls into it. Have it checked immediately by qualified personnel only.
 Do not install the TV in a confined space, such as a bookcase or built-in cabinet. Do not block the ventilation openings of the TV.	 Clean the TV with a dry and soft cloth. Do not use benzine, thinner, or any other chemicals to clean the TV. Do not scratch the picture tube.
 Do not pull the power cord to disconnect the TV. Pull it out by the plug.	 Do not plug in too many appliances to the same power socket. Do not damage the power cord.
 Disconnect the power cord during lightning storms or if you are not going to use the TV for several days.	 Do not install the TV in hot, humid or excessively dusty places.


Using Your New TV

Getting Started

Step 1


Connect the antenna

If you wish to connect a VCR, see the "Connecting a VCR" diagram below.



Connecting a VCR

To watch the video, press  (see page 12).



Notes


- If you connect a stereo VCR, connect the yellow plug to (the yellow jack) and the white plug to (the black jack).
- If you connect a VCR to the (antenna) terminal, preset the signal output from the VCR to the program number 0 on the TV.
- When no signal is input to the connected video equipment, the TV screen becomes blue.

CAUTION

Do not connect the power cord until you have completed making all other connections; otherwise a minimum leakage current might flow through the antenna and other terminals to ground.

Step 2

Insert the batteries into the remote




Note

- Do not use old batteries nor use different types of batteries together.

Step 3

Preset the channels automatically



Tips

- If you want to stop automatic channel presetting, press SELECT twice.
- If your TV has preset an unwanted channel or cannot preset a particular channel, then preset your TV manually (see page 9).

Note (KV-PF21M70 only)

- During automatic channel presetting, your TV screen will indicate "B/G", "I", "D/K" or "M" for the TV system.

Now You Are Ready. . .

To watch your TV, see page 11.




Connecting optional components

You can connect optional video components, such as a VCR, multi disc player, camcorder or video game.

To watch the picture of the connected equipment, press (see page 12).


Connecting a camcorder/video game equipment using the (video input) jacks



Note

- You can also connect video equipment to the (video input) jacks at the rear of your TV.

Connecting video equipment using the (monitor output) jacks



Note

- When connecting a stereo VCR, connect the yellow plug to (the yellow jack) and the white plug to (the black jack).


Securing the TV

To prevent the TV from falling, secure the TV using one of the following methods:

- A** With the supplied screws, attach the band to the TV stand and to the rear of the TV using the provided hole.

or

- B** Put the cord or chain through the clamps to secure the TV against a wall or pillar.




Note
• Use only the supplied screws. Use of other screws may damage the TV.

Using Your New TV

Presetting channels

You can preset up to 100 TV channels in numerical sequence from program number 1 using the remote and the buttons on your TV as well.



Presetting channels automatically

- 1** Press ① to turn on the TV.



- 2** Press AUTO PROGRAM.



Note (KV-PF21M70)
• During automatic channel presetting, your TV screen will indicate “B/G”, “I”, “D/K” or “M” for the TV system.

To preset channels automatically from a specified program number



- (1) Press SELECT until “AUTO PROGRAM” appears.
- (2) Press + or –.
The on-screen display will start flashing.
- (3) Press PROG +/– or the number buttons until the desired program number appears.
- (4) Press + or –.

- 8** Using Your New TV

Presetting channels manually

- Press SELECT until "MANUAL PROGRAM" appears.

- Press + or –.

- Press PROGR +/- or the number buttons until the desired program number appears.

- Press + or – until the desired channel picture appears.

- Press SELECT.


Using Your New TV

To change the color system setting

If the color is abnormal when receiving programs through the ㄗ (antenna) terminal or the ㊤ (video input) jack

- Press SELECT until "COL SYS" appears.

COL SYS: AUTO

- Press + or – to select the appropriate color system until the color is optimal.

AUTO → PAL → SECAM
 NTSC 4.43 ← NTSC 3.58 ←

Tip

- Normally set "COL SYS" to "AUTO".

Note

- The color system "SECAM" is not available for KV-PF21P70.
- The color system "NTSC3.58" is not available for KV-PF21Q70 and KV-PF21Q40.

continued

Using Your New TV | 9

Presetting channels (continued)

To change the TV system setting (KV-PF21M70/PF21DK7 only)

If the picture or sound is abnormal when receiving programs through the ㄗ (antenna) terminal

- Press SELECT until "TV SYS" appears.

TV SYS: B/G

- Press + or – to select the appropriate TV system until the picture or sound quality is optimal.

B/G → I → D/K → M

*KV-PF21DK7 has B/G and D/K system only

Skipping program numbers

- Press PROGR +/- or the number buttons until the unused or unwanted program number appears.
- Press SELECT until "MANUAL PROGRAM" appears.
- Press + or –.
- Press PIC MODE.
- Press SELECT.

To preset the skipped program number again

Preset the channel automatically or manually.

Tip

- You can also use SELECT and ㄡ +/- on the TV to preset channels and skip program numbers.

To use the fine tuning (FINE) function

The fine tuning (FINE) function may help to reduce the following problems: double images and lines moving across the TV screen.


You can use the fine tuning function as below:

- Select the program number you want to adjust.
- Press SELECT until "MANUAL PROGRAM" appears on the screen.
- Press + or – on the remote control once.
- Press ㊤ ㊤ to display "FINE" on the screen.
- Press + or – continuously until the above problems are minimized.
 The + or – icon on the screen flashes while tuning.
- Press SELECT to return to normal screen.

10 | Using Your New TV

Watching the TV

This section explains functions used while watching the TV. Most operations can be done using the remote.




1 Press ① to turn on the TV.

When the TV is in the standby mode (the ① indicator on the TV is lit red), press ① on the remote or PROGR +/- on the TV.



2 Press PROGR +/- or the number buttons to select the TV program.

For double digit numbers, press +/-, then the number (e.g., for 25, press +/-, then 2 and 5).



3 Press ④ +/- to adjust the volume.



Watching the TV (continued)

Additional tasks

To	Do this
Turn off temporarily	Press ①. The ① indicator on the TV lights up red.
Turn off completely	Press ① on the TV.
Mute the sound	Press ④.
Watch the video input (VCR, camcorder, etc.)	Press ⑤ to select "VIDEO 1" or "VIDEO 2". To return to the TV program, press ①.
Jump back to the previous channel	Press JUMP.
Display the on-screen information*	Press ⑥.
Adjust the volume of each TV program automatically	Press SELECT repeatedly until "INTELLIGENT VOL" appears, then press + or - to select "ON". To cancel, select "OFF".

* The picture, sound, and either the program number or video mode are displayed. The on-screen display for the picture and sound information disappears after about 3 seconds.

Changing the on-screen display language (except KV-PF21DK7)

1 Press SELECT until "LANGUAGE / 语言:" appears on the screen.



2 Press + or - to select "中文".



Tip

- You can also use SELECT and ④ +/- on the TV to select the on-screen display language.

continued

Watching the TV (continued)

Additional tasks

To	Do this
Turn off temporarily	Press . The indicator on the TV lights up red.
Turn off completely	Press on the TV.
Mute the sound	Press .
Watch the video input (VCR, camcorder, etc.)	Press to select "VIDEO 1" or "VIDEO 2". To return to the TV program, press .
Jump back to the previous channel	Press JUMP.
Display the on-screen information*	Press .
Adjust the volume of each TV program automatically	Press SELECT repeatedly until "INTELLIGENT VOL" appears, then press + or – to select "ON". To cancel, select "OFF".

* The picture, sound, and either the program number or video mode are displayed. The on-screen display for the picture and sound information disappears after about 3 seconds.

Changing the on-screen display language (KV-PF21DK7 only)

1 Press SELECT until "LANGUAGE / اللغة : ENGLISH" appears on the screen.

2 Press + or – to select "عربي".

Tip

- You can also use SELECT and on the TV to select the on-screen display language.

Setting the Wake Up timer

1 Press until the desired period of time appears.

2 Select the TV program or video mode you want to display when you wake up.

3 Press or set the Sleep timer if you want the TV to turn off automatically.

The indicator on the TV lights up orange.

To cancel the Wake Up timer

Press until "WAKE UP TIMER: OFF" appears or turn off the TV's main power.

Notes

- The Wake Up timer starts immediately after the on-screen display disappears.
- If no buttons or controls are pressed for more than two hours after the TV is turned on using the Wake Up timer, the TV automatically goes into the standby mode. To continue watching the TV, press any button or control on the TV or the remote.

Setting the Sleep timer

Press until the desired period of time appears.

To cancel the Sleep timer


Press until "SLEEP TIMER: OFF" appears or turn the TV off.

Using Your New TV

Advanced Operations

Customizing the picture and sound


You can customize the picture and sound by selecting the picture and sound modes or by adjusting its settings.



Selecting the picture and sound modes

To select the picture mode

Press PIC MODE repeatedly until you get the desired picture mode.



Select	To
DYNAMIC	receive high contrast pictures.
STANDARD	receive normal contrast pictures.
SOFT	receive mild pictures.

To select the sound mode


Press SOUND MODE repeatedly until you get the desired sound mode.



Select	To
DYNAMIC	listen to dynamic and clear sound that emphasizes the low and high sound.
DRAMA	listen to sound that emphasizes vocals and background music.
SOFT	receive soft sound.

Adjusting the picture and sound settings

- 1 Press SELECT until the desired setting appears.



Each time you press SELECT, the setting item will change as follows:

- 2 Press + or - to adjust the item.



- 3 To adjust other items, repeat steps 1 to 2.


* "HUE" can be adjusted for the NTSC system only.

Notes

- When you select a picture or sound mode, the adjusted settings will be reset according to the selected mode.
- You can also use SELECT and $\triangle$ +/- on the TV to adjust the picture and sound settings.

Blocking the channels (CHILD LOCK)

You can prevent a child from watching certain programs by using the buttons on the remote control.



1 Select the TV program you want to lock.


2 Press SELECT until "CHILD LOCK" appears on the screen.



3 Press + or - to select "ON".

The  symbol appears on the screen.

To unlock the channel, press + or - to select "OFF". The  symbol disappears from the screen.




Note

- If you preset a locked channel, that particular channel will be unlocked automatically.

Additional Information

Self-diagnosis function

Your TV is equipped with a self-diagnosis function. If there is a problem with your TV, the  indicator flashes red. The number of times the  indicator flashes indicates the possible causes.




- 1 Check that the  indicator flashes red a number of times between 3-second intervals.
- 2 Count the number of times the  indicator flashes.
- 3 Press  (main power) to turn off your TV.
- 4 Inform your nearest Sony service center about the number of times the  indicator flashes. Be sure to note the model name and serial number located on the rear of your TV.

Additional Information

Troubleshooting Shortcuts

(KV-PF51P40 only)


For better viewing, please check the following connections.



For more information, please see "Troubleshooting" on page 22, 23 and 24 or consult your dealer for guidance.


Troubleshooting (except KV-PF21DK7/PF51P40)

If you find any problem while viewing your TV, please check the following guide. If any problem persists, contact your Sony dealer.

Symptom	Solutions	Possible cause
Snowy picture 	- Check the antenna cable and connection on the TV, VCR and on the wall. (page 4) - Press SELECT until "MANUAL PROGRAM" appears on the screen then preset the channel again. (page 9)	- Connection is loose or the cable is damaged. - Channel presetting is inappropriate or incomplete.
Noisy sound 	- Check the antenna type (VHF/UHF). Contact a Sony dealer for advice. - Adjust the antenna direction. Contact a Sony dealer for advice. - Try using a booster.	- The antenna type is inappropriate. - The antenna direction is inappropriate. - Signal transmission is low.
Distorted picture 	Turn off or disconnect the booster if it is in use.	Broadcast signals are too strong.
Noisy sound 		
Good picture 	- If the sound of all the channels are noisy, check the TV system (TV SYS) setting (page 10), then press AUTO PROGR to preset the channels again (page 8). - If the sound of some channels are noisy, select the channel, then select the appropriate TV system (TV SYS). (page 10)	The TV system setting or channel presetting is inappropriate or incomplete.
Noisy sound 		
No picture 	- Check the power cord, antenna and the VCR connections. - Press (power). - Press (main power) on the TV to turn off the TV for about five seconds, then turn it on again.	- The power cord, antenna or VCR is not connected. - The TV is not turned on.
No sound 		


Troubleshooting (KV-PF21DK7 only)

If you find any problem while viewing your TV, please check the following guide. If any problem persists, contact your Sony dealer.

Symptom	Solutions	Possible cause
Snowy picture 	- Check the antenna cable and connection on the TV, VCR and on the wall. (page 4) - Press SELECT until "MANUAL PROGRAM" appears on the screen then preset the channel again. (page 9)	- Connection is loose or the cable is damaged. - Channel presetting is inappropriate or incomplete.
Noisy sound 	- Check the antenna type (VHF/UHF). Contact a Sony dealer for advice. - Adjust the antenna direction. Contact a Sony dealer for advice. - Try using a booster.	- The antenna type is inappropriate. - The antenna direction is inappropriate. - Signal transmission is low.
Distorted picture 	Turn off or disconnect the booster if it is in use.	Broadcast signals are too strong.
Noisy sound 		
Good picture 	If the sound of some channels are noisy, select the channel, then select the appropriate TV system (TV SYS). (page 10)	The TV system setting is inappropriate.
Noisy sound 		
No picture 	- Check the power cord, antenna and the VCR connections. - Press (power). - Press (main power) on the TV to turn off the TV for about five seconds, then turn it on again.	- The power cord, antenna or VCR is not connected. - The TV is not turned on.
No sound 		

Troubleshooting (KV-PF51P40)

If you find any problem while viewing your TV, please check the following guide. If any problem persists, contact your Sony dealer .

Symptom	Solutions	Possible cause
Snowy picture 	- Check the antenna cable and connection on the TV, VCR and on the wall. (page 4) - Press SELECT until "MANUAL PROGRAM" appears on the screen then preset the channel again. (page 9)	- Connection is loose or the cable is damaged. - Channel presetting is inappropriate or incomplete.
Noisy sound 	- Check the antenna type (VHF / UHF). Contact a Sony dealer for advice. - Adjust the antenna direction. Contact a Sony dealer for advice. - Try using a booster.	- The antenna type is inappropriate. - The antenna direction is inappropriate. - Signal transmission is low.
Distorted picture 	Turn off or disconnect the booster if it is in use.	Broadcast signals are too strong.
Noisy sound 		
No picture 	- Check the power cord, antenna and the VCR connections. - Press (power). - Press ① (main power) on the TV to turn off the TV for about five seconds, then turn it on again.	- The power cord, antenna or VCR is not connected. - The TV is not turned on.
No sound 		

Symptom	Solutions	Possible cause
Good picture 	- Press $\triangle$ + to increase the volume level. - Press $\otimes$ to cancel the muting.	- The volume level is too low. - The sound is muted.
No sound 		
Dotted lines or stripes 	- Do not use a hair dryer or other equipment near the TV. - Adjust the antenna direction for minimum interference. Contact a Sony dealer for advice.	There is local interference from cars, neon signs, hair dryers, power generators, etc.
Double images or "ghosts" 	- Use a highly directional antenna. - Use the fine tuning (FINE) function. (page 10) - Adjust the antenna direction. Contact a Sony dealer for advice. - Turn off or disconnect the booster if it is in use.	- Broadcast signals are reflected by nearby mountains or buildings. - The antenna direction is inappropriate. - Use of a booster is inappropriate.
No color 	- Press SELECT until "COLOR" appears on the screen, then press + or - to adjust the color level. (page 15) - Press SELECT until "COL SYS" appears on the screen, then check the color system setting (usually set this to "AUTO"). (page 9). - Adjust the antenna direction. Contact a Sony dealer for advice.	- The color level setting is too low. - The color system setting is inappropriate. - The antenna direction is inappropriate.
Abnormal color patches 	Keep external speakers or other electrical equipment away from the TV. Do not move the TV while the TV is turned on. Press ① (main power) on the TV to turn off the TV for about five minutes, then turn it on again.	The magnetic disturbance from external speakers or other equipment, or the direction of the earth's magnetic field may affect the TV.

continued

Troubleshooting (continued)

Symptom	Solutions	Possible cause
Lines moving across the TV screen.	Use the fine tuning (FINE) function. (page 10)	There is interference from external sources, e.g., heavy machineries, nearby broadcast station.
The  indicator on your TV flashes red a number of times between 3-second intervals.	Contact your nearest Sony service center. (page 17)	Your TV may need service.
TV cabinet creaks.	—	Changes in room temperature sometimes make the TV cabinet expand or contract, making a noise. This does not indicate a malfunction.
A "boom" sound is heard when the TV is turned on.	—	The TV's demagnetizing function is working. This does not indicate a malfunction.


Troubleshooting (continued) (KV-PF51P40)

Symptom	Solutions	Possible cause
"100" appears on the top of the screen and there is no Teletext display. (not used this models)	—	The channel carries no Teletext broadcast.
Teletext display is incomplete (snowy picture or double images). (not used this models)	- Check the antenna cable and connection on the TV, VCR, and at the wall. (page 4) - Adjust the antenna direction. Contact a Sony dealer for advice. - Try using a booster. - Use the fine tuning (FINE) function. (page 10)	- Connection is loose or the cable is damaged. - The antenna direction is inappropriate. - Signal transmission is too low.
Lines moving across the TV screen.	Use the fine tuning (FINE) function. (page 10)	There is interference from external sources, e.g., heavy machineries, nearby broadcast station.
The  indicator on your TV flashes red a number of times between 3-second intervals.	Contact your nearest Sony service center. (page 19)	Your TV may need service.
TV cabinet creaks.	—	Changes in room temperature sometimes make the TV cabinet expand or contract, making a noise. This does not indicate a malfunction.
A "boom" sound is heard when the TV is turned on.	—	The TV's demagnetizing function is working. This does not indicate a malfunction.

Identifying parts and controls

Refer to the pages indicated in parentheses () for details.


Front panel




- 1 ① (main power) button (5)
- 2 PROGR +/- (program) buttons (11)
- 3 ▲/▼ (volume) buttons (11)
- 4 ↺ (TV/video) button (12)
- 5 AUTO PROGR (program) button (5)
- 6 SELECT button (9)
- 7 □ (earphone) jack

Identifying parts and controls (continued)

Remote Control



- 1 ① (power) button (11)
- 2 □ (TV) button (12)
- 3 Number buttons (11)
- 4 JUMP button (12)
- 5 PROGR +/- buttons (11)
- 6 SELECT button (9)
- 7 PIC MODE button (14)
- 8 + or - buttons (9)
- 9 ② (display) button (12)
- 10 ✖ (muting) button (12)
- 11 ③ (video) button (12)
- 12 ▲/▼ (volume) buttons (11)
- 13 A/B button (not used for this models)
- 14 Timer setting buttons (13)
 - ⌚ (wake up timer)
 - ⌚ (sleep timer)
- 15 FAVORITE button (not used for this models)



- 16 SOUND MODE button (14)
- 17 Teletext operation buttons (not used for this models)
 - Ⓔ (text) Ⓕ (enlarge)
 - Ⓖ (reveal) Ⓖ (hold)
 - Ⓖ (index) Ⓖ (text clear)
 - (FASTEXT: red, green, yellow, blue)

Names/symbols of buttons on the remote are indicated in different colors to represent the available functions.


Label color	Button function
White	For general TV operations
Green	For Teletext operations

continued


SECTION 2

DISASSEMBLY


2-1. REAR COVER REMOVAL



2-3. F BRACKET REMOVAL




2-2. CHASSIS ASSY REMOVAL



2-4. SERVICE POSITION

(Note: Remove F Bracket first.)




KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952


2-5. REPLACEMENT OF PARTS

For replacement of the Multi Button and Bar Optical ,unscrew to exchange with the new parts, and fix them with screws (+BVTP) respectively.


2-5-1. REPLACEMENT OF MULTI BUTTON




2-5-2. REPLACEMENT OF BAR OPTICAL



2-6. TERMINAL BRACKET REMOVAL




2-7. DEGAUSS COIL REMOVAL



2-8. PICTURE TUBE REMOVAL


NOTE : This picture tube for Indonesian model is upside down, and the position for the anode cap and tension springs are change accordingly.




•REMOVAL OF ANODE-CAP

NOTE : After removing the anode, short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT.


•REMOVING PROCEDURES



① Turn up one side of the rubber cap in the direction indicated by the arrow ①.





② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ②.



③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling it up in the direction of the arrow ③.

• HOW TO HANDLE AN ANODE-CAP

- ① Do not damage the surface of anode-caps with sharp shaped objects.
- ② Do not press the rubber too hard so as not to damage the inside of anode-cap. A metal fitting called the shatter-hook terminal is built into the rubber.
- ③ Do not turn the foot of rubber over too hard. The shatter-hook terminal will stick out or damage the rubber.



SECTION 3

SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switches should be set as follows unless otherwise noted:

PICTURE control normal
 BRIGHTNESS control normal

Preparation :

- In order to reduce the influence of geomagnetism on the set's picture tube, face it east or west.
- Switch on the set's power and degauss with the degausser.

3-1. BEAM LANDING

1. Input a white signal with the pattern generator.
 Contrast } normal
 Brightness }
2. Set the pattern generator raster signal to a green raster.
3. Move the deflection yoke to the rear and adjust with the purity control so that the green is at the center and the blue and the red take up equally sized areas on each side.
 (See Figures 3-1 through 3-3.)
4. Move the deflection yoke forward and adjust so that the entire screen is green. (See Figure 3-1.)
5. Switch the raster signal to blue, then to red and verify the condition.
6. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws and DY spacers.
7. If the beam does not land correctly in all the corners, use a magnet to adjust it.
 (See Figure 3-4.)




Fig. 3-1

Perform the adjustments in the following order :

1. Beam Landing
2. Convergence
3. Focus
4. White Balance

Note : Test Equipment Required.

1. Color-bar/Pattern Generator
2. Degausser
3. Oscilloscope




Fig. 3-2




Fig. 3-3





Fig. 3-4

3-2. CONVERGENCE


Preparation :

- Before starting this adjustment, adjust the focus, horizontal size and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.


(1) Horizontal and Vertical Static Convergence




(Moving vertically), adjust the V. STAT magnet so that the red, green and blue dots are on top of each other at the center of the screen.




① V. STAT



② H. STAT VR




③




④ BMC (Hexapole) Magnet.

If the red, green and blue dots are not balanced or aligned, then use the BMC magnet to adjust in the manner described below.






(2) Dynamic Convergence Adjustment**Preparation:**

- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence




on DY

**(3) Screen-corner Convergence**

3-3. FOCUS ADJUSTMENT

Adjust FOCUS control on the flyback transformer for the best focus.




3-4. G2 (SCREEN) AND WHITE BALANCE

ADJUSTMENTS

1. G2 (SCREEN) ADJUSTMENT

- 1) Set the PICTURE to normal.
- 2) Put to VIDEO input mode without signals.
- 3) Connect R, G and B of the C3 board cathode to the oscilloscope.
- 4) Adjust BRIGHTNESS to obtain the cathode voltage to the value below.
- 5) Adjust G2 (Screen) on FBT until picture shows the point before cut-off.




2. WHITE BALANCE ADJUSTMENT

- 1) Set to Service Mode (Refer Section 4-1: ADJUSTMENTS WITH COMMANDER).
- 2) Input white raster signal.
- 3) Set the PICTURE to minimum.
- 4) Select GCT (WHB 4) and BCT (WHB 5) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 5) Set the PICTURE to maximum.
- 6) Select GDR (WHB 1) and BDR (WHB 2) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 7) Write into the memory by pressing [MUTING] then [0].

3. SUB BRIGHT ADJUSTMENT

- 1) Set to service mode.
- 2) Input a staircase signal of black to white from the pattern generator.
- 3) BRIGHTNESS50%.
PICTURE MINIMUM
- 4) Select SBR (WHB7) with [1] and [4], and adjust SBR (WHB7) level with [3] and [6] so that the second stripe from the right is dimly lit.




SECTION 4

CIRCUIT ADJUSTMENTS

4-1. ADJUSTMENTS WITH COMMANDER

Service adjustments are made with the RM-915 or RM-952 that comes with this unit.

a. ENTERING SERVICE MODE



b. METHOD OF CANCELLATION FROM SERVICE MODE

Set the standby condition (Press **POWER** button on the commander), then press **POWER** button again, hereupon it becomes TV mode.



c. METHOD OF WRITE INTO MEMORY

- 1) Set to Service Mode.
- 2) Press **1** (UP) and **4** (DOWN), select an item of adjustment.
- 3) Press **MUTING** button and it will indicate WRITE on the screen.
- 4) Press **0** button to write into memory.


d. MEMORY WRITE CONFIRMATION METHOD

- 1) After adjustment, pull out the plug from AC outlet, and then plug into AC outlet again.
- 2) Turn the power switch ON and set to Service Mode.
- 3) Call the adjusted items again to confirm adjustments were made.


The screen display is :



- 7, 0** All the data becomes the values in memory.
- 8, 0** All user control goes to the standard state.
- 5, 0** Service data initialization (Be sure not to use usually.)
- 2, 0** Write 50Hz adjustment data to 60Hz, or vice versa.



RM-915



RM-952

4-2. ADJUSTMENT METHOD

Item Number 00 of device GEO

This explanation uses H-Position as an example.

1. Select "GEO 00 HPS" with the **[1]** and **[4]** buttons.
2. Raise/lower the data with the **[3]** and **[6]** buttons.
3. Select the optimum state. (The standard is 1F for PAL reception.)
4. Write with the **[MUTING]** button. (The display changes to WRITE.)
5. Execute the writing with the **[0]** button. (The WRITE display will be changed to red color while excuting, and back to SERVICE.)

GEO	00	HPS	1F	SERVICE	50
623S/	1.0C	59	7F	0	000A
622S					
or					
618S					

← GREEN
 Adjusted with **[3]** and **[6]** buttons.

GEO	00	HPS	1F	WRITE	50
623S/	1.0C	59	7F	0	000A
622S					
or					
618S					

← GREEN

Written with **[MUTING]**

GEO	00	HPS	1F	SERVICE	50
623S/	1.0C	59	7F	0	000A
622S					
or					
618S					

← RED
 The WRITE display then the display returns to a green SERVICE.

Write executed with **[0]**

Use the same method for all Items. Use **[1]** and **[4]** to select the adjustment item, use **[3]** and **[6]** to adjust, write with **[MUTING]**, then execute the write with **[0]**.

- Note :**
1. In **[WRITE]**, the data for all items are written into memory together.
 2. For adjustment items that have different standard data between 50Hz or 60Hz, be sure to use the respective input signal after adjustment.

Adjustment Item Table

Category	Functionality		Micro Init	Data Range	Function	Note for Different Data	Register No. (bit)	Slave Address	RAM Address (bit)
	No.	Name							
GEO	0	HPS	7	3F	H Position	50/60HZ	12 (7-2)	CXA2130S(88H)	82 (7-2)
	1	HSZ	1F	3F	H Size	50/60HZ	11 (7-2)		81 (7-2)
	2	PAP	1F	3F	Pin Amp	50/60HZ	13 (7-2)		83 (7-2)
	3	TLT	7	0F	Trapezium	50/60HZ	15 (7-4)		85 (7-4)
	4	VPS	1F	3F	V Position	50/60HZ	0F (7-2)		7F (7-2)
	5	VSZ	1F	3F	V Size	50/60HZ	0E (7-2)		7E (7-2)
	6	SCO	7	0F	S Correction	50/60HZ	10 (7-4)		80 (7-4)
	7	VLN	7	0F	V Linearity	50/60HZ	10 (3-0)		80 (3-0)
	8	BOW	7	0F	AFC Bow	50/60HZ	16 (7-4)		86 (7-4)
	9	AGL	7	0F	AFC-Angle	50/60HZ	16 (3-0)		86 (3-0)
	10	UPN	1F	3F	Upper Pin	50/60HZ	14 (7-2)		84 (7-2)
	11	LPN	1F	3F	Lower Pin	50/60HZ	18 (7-2)		88 (7-2)
	12	HBL	0	1	H Blanking on/off		18 (1)		67 (1)
	13	LBL	7	0F	Left H Blanking	50/60HZ	17 (7-4)		87 (7-4)
	14	RBL	7	0F	Right H Blanking	50/60HZ	17 (3-0)		87 (3-0)
WHB	0	RDR	2A	3F	R Drive	DYNAMIC/others	09 (7-2)	CXA2130S(88H)	8F (7-2)
	1	GDR	2A	3F	G Drive	DYNAMIC/others	0A (7-2)		90 (7-2)
	2	BDR	2A	3F	B Drive	DYNAMIC/others	0B (7-2)		91 (7-2)
	3	RCT	7	0F	R Cutoff	SECAM/others	07 (3-0)		93 (3-0)
	4	GCT	7	0F	G Cutoff	SECAM/others	08 (7-4)		94 (7-4)
	5	BCT	7	0F	B Cutoff	SECAM/others	08 (3-0)		94 (3-0)
	6	BMN	15	1F	Brightness Minimum Data				97
SAJ	7	SBR	28	3F	Sub Brightness Control			CXA2130S(88H)	98
	0	PMX	33	3F	Picture Maximum Data				96
	1	SHU	8	0F	Sub Hue Control	TV/Video			99
	2	SSH	3	0F	Sub Sharpness Control	TV/Video			9A
VP	3	SCL	1F	3F	Sub Color Control	NTSC/others		CXA2130S(88H)	9B
	0	EHT	4	0F	EHT Comp	50/60HZ	15 (3-0)		85 (3-0)
	1	GMA	2	03	Gamma Correction	Refer NVM Map A4	0B (1-0)		1A3 (1-0)
	2	YDL	6	0F	Y Delay	PAL/SECAM/NTSC	0C (3-0)		8C (3-0)
	3	SST	1	03	SECAM ID Start Position		1B (1-0)		6A (1-0)
	4	SSP	1	03	SECAM ID Stop Position		1B (3-2)		6A (3-2)
	5	SLV	2	03	SECAM ID Level		1C (1-0)		6B (1-0)
	6	SBF	22	3F	SECAM BELL fo		1C (7-2)		6B (7-2)
	7	DYC	0	1	Dynamic Color on/off		0A (1)		59 (1)
	8	ABL	1	1	ABL Mode Switching	STANDARD Always 0	09 (1)		58 (1)
	9	VTH	1	1	ABL Detection Vth Switching		09 (0)		58 (0)
	10	SFO	1	1	FO Switching for Sharpness	NTSC/others	05 (1)		198 (1)
	11	DCX	1	1	DC Trans. Ratio Switching		06 (1)		55 (1)
	12	SHT	1	1	Pre-/Overshoot ratio Switch	NTSC/others	06 (0)		199 (0)

Adjustment Item Table

Category	Functionality		Micro Init	Data Range	Function	Note for Different Data	Register No. (bit)	Slave Address	RAM Address (bit)	
	No.	Name								
VP	13	HDW	0	1	H Drive Pulse Width Switch	TV/Video/Text	00 (6)		4F (6)	
	14	AFC	1	03	AFC Gain Control		0F (1-0)		8D (1-0)	
	15	HOS	7	0F	H Oscillation		0C (7-4)		5B (7-4)	
	16	HSS	0	1	Slice Level of H Sync Sep.		0D (1)		5C (1)	
	17	VSS	0	1	Slice Level of V Sync Sep.	50/60Hz	0D (0)		5C (0)	
	18	HMS	0	1	Macro Vision C/m off/on		0E (0)		7E (0)	
	19	YUV	0	1	YUV Switch Control		01 (0)		50 (0)	
	20	CDV	1	3	CD mode for Video		0D (5-4)		1A1 (5-4)	
	21	RON	1	1	R ON	Video only not memorized	01 (3)		50 (3)	
	22	GON	1	1	G ON	not memorized	01 (2)		50 (2)	
	23	BON	1	1	B ON	not memorized	01 (1)		50 (1)	
	24	PON	1	1	P ON	not memorized	00 (7)		4F (7)	
	25	BLK	0	1	BLK Off		12 (0)		61 (0)	
	26	VMC	0	1	VM Off		13 (0)		62 (0)	
AP	0	INF	0	3F	Input Attenuation When surround off		00 (5-0)	TDA7429	19F (5-0)	
	1	INS	0	3F	Input Attenuation When surround on		02		1A0 (5-0)	
	2	PH1	0	3	Phase 1 Register Selection				76 (1-0)	
	3	PH2	0	3	Phase 2 Register Selection				76 (3-2)	
	4	PH3	0	3	Phase 3 Register Selection		#4 (3-0)		76 (5-4)	
	5	PH4	0	3	Phase 4 Register Selection				76 (7-6)	
	6	BCS	2	3	Bass Center Shift				#5 (3-0)	1A8 (1-0)
	7	TCS	2	3	Treble Center Shift		#5 (3-0)		1A9 (1-0)	
8	TRF	2	3	RF Treble Offset		#5 (3-0)	1A9 (5-4)			
MSP	0	WST	15	FF	W/G Stereo Threshold			MSP3415D (84H)	157 (7-0)	
	1	WBT	EA	FF	W/G Bilingual Threshold				158 (7-0)	
	2	WLL	5	FF	W/G Monaural Threshold				159 (7-0)	
	3	WAC	0	0F	W/G Agreement Count				15A (3-0)	
	4	WDL	30	FF	W/G Search Delay				15B (7-0)	
	5	NDL	20	FF	NICAM Search Delay				15C (7-0)	
	6	SDL	10	FF	Stereo status Read Delay				15D (7-0)	
	7	AGC	1	1	AGC Switch Auto/Constant		BB (7)		108 (7)	
	8	REL	28	3F	AGC Gain at Constant Mode		BB (6-1)		108 (6-1)	
	9	CRM	0	1	Carrier muting on/off		BB (9)		107 (1)	
	10	ACO	1	1	Audio Clock out on/off		83 (5)		10C (5)	
	11	FP	1B	7F	FM Prescale for non-M system		0E (7-0)		16C (6-0)	
	12	FPM	32	7F	FM Prescale for M system		0E (7-0)		16D (6-0)	
	13	FH	36	7F	FM Prescale for HDEV		0E (7-0)		16E (6-0)	
	14	FHM	65	7F	FM Prescale for HDEV and M		0E (7-0)		16F (6-0)	
	15	WGP	2A	7F	W/G Prescale		0E (7-0)		170 (6-0)	
	16	NIP	6D	7F	NICAM Prescale		10 (7-0)		138 (6-0)	
	17	ERR	50	FF	Auto FM switch Threshold		21 (10-3)		166 (7-0)	
18	VOL	6D	FF	Loud Speaker gain 7000h to 7f0h	0000 (15-4)	1A7 (7-0)				

Adjustment Item Table

Category	Functionality		Micro Init	Data Range	Function	Note for Different Data	Register No. (bit)	Slava Address	RAM Address (bit)
	No.	Name							
TXT	0	TXH	1	3	Teletext Horizontal Position			(58H)	18D (1-0)
	1	TXV	0	3	Teletext Vertical Position				18D (6-4)
OPM	0	OSH	0A	3F	OSD H Position	Option-Misc			AC (7-2)
	1	COM	0	03	Comb Selection				A5 (7-6)
	2	APC	1	1	APC Switch				A4 (5)
	3	TSY	0	03	TV Sys at Auto TV Sys				A4 (4-3)
	4	MUT	0	1	No Signal Mute				A4 (0)
	5	AFM	0	1	Auto FM switch				A4 (1)
	6	RFB	0	3	C-BPF Control				A5 (5-4)
	7	TV0	0	7	Tilt to V-Angle offset				A5 (2-0)
	8	DBL	0	1	Disable Blueback Function				A4 (2)
OPB	0	OP1	FF	FF	Optional Bits 1 (see below)	Option-Bits			45
	1	OP2	1	FF	Optional Bits 2 (see below)				46
	2	OP3	0	FF	Optional Bits 3 (see below)				47

NOTE

- shaded items are fixed data.
- Standard data listed on the Adjustment Item Table are reference values, therefore it may be different for each model and for each mode.
- Note for Different Data Those are the standard data values written on the microprocessor. Therefore, the data values of the modes and stored respectively in the memory.
 In case of a device replacement, adjustment by rewriting the data value is necessary for some items.

ITEM INFORMATION.

No. OPB0 OP1

Item	XTAL 4.43	XTAL 3.58	SECAM	2nd. Lang	B/G	I	D/K	M
KV-PF21N70	1	1	1	1	0	0	0	1
KV-PF51P40	1	1	0	1	1	0	0	0
KV-PF21P70	1	1	0	1	1	0	0	0
KV-PF21Q40	1	0	1	1	1	0	0	0
KV-PF21Q70	1	0	1	1	1	0	0	0
KV-PF21M70	1	1	1	1	1	1	1	1
KV-PF21DK7	1	0	1	1	1	0	1	0

No. OPB1 OP2

Item	TOP	NICAM	HDEV	Thai Bil	Dis Fav.	DVD Input	AV Input	
KV-PF21N70	0	0	0	0	1	0	1	0
KV-PF51P40	0	0	0	0	1	0	1	0
KV-PF21P70	0	0	0	0	1	0	1	0
KV-PF21Q40	0	0	0	0	1	0	1	0
KV-PF21Q70	0	0	0	0	1	0	1	0
KV-PF21M70	0	0	0	0	1	0	1	0
KV-PF21DK7	0	0	0	0	1	0	1	0


No. OPB2 OP3

Item	Pic Rot	2199 Curve	Auto PIC	Auto TV sys	US ST	AV Mono	11 KEY	Color SW
KV-PF21N70	0	0	1	0	0	1	0	1
KV-PF51P40	0	0	1	0	0	1	0	1
KV-PF21P70	0	0	1	0	0	1	0	1
KV-PF21Q40	0	0	1	0	0	1	0	1
KV-PF21Q70	0	0	1	0	0	1	0	1
KV-PF21M70	0	0	1	0	0	1	0	1
KV-PF21DK7	0	0	1	0	0	1	0	1

4-3. PICTURE QUALITY ADJUSTMENTS


SUB COLOR ADJUSTMENT

1. Input a PAL color-bar.
2. Set to the following condition:
PICTURE 100%, BRIGHTNESS 50%, COLOR 50%
3. Connect an oscilloscope to pin ① (B OUT) of CN305, A board.
4. Set to Service Mode and select SAJ 3 'SCL' with [1] and [4] of the commander then adjust to VB2=VB3=VB4 with [3] and [6].
5. Press [MUTING] → [0] of the commander to write the data.
6. Adjust SAJ 3 'SCL' as step 2 to 5 when receiving NTSC color-bar.



SUB HUE ADJUSTMENT


1. Select Video 1.
2. Input a NTSC color-bar, video into Video 1.
3. Set the following condition:
PICTURE 100%, BRIGHTNESS 50%, COLOR 50%
4. Connect an oscilloscope to pin ① (B OUT) of CN305, A board.
5. Select SAJ 1 'SHU' with [1] and [4] of the commander by setting to Service Mode and adjust to VB1=VB2=VB3=VB4 with [3] and [6].



6. Press [MUTING] → [0] of the commander to write the data.

BELL FILTER ADJUSTMENT

1. Input SECAM color-bar signal.
2. Connect the dual-trace oscilloscope to the pin ⑨ (R-Y) of CN303 (not mounted).
3. Adjust SERVICE MODE, ITEMS 'SBF' as shown below.



4-4. A BOARD ADJUSTMENT AFTER IC003 (MEMORY) REPLACEMENT

When replacing IC003 (MEMORY), be sure to change IC001 (μ-COM) to the following new IC at the same time.

IC001 (μ-CON) : CXP86461-622S (For KV-PF21DK7)

: CXP86461-623S (Except KV-PF21DK7/

PF21N70)


: CXP86461-618S (KV-PF21N70)

1. Enter to Service Mode.
2. Press commander buttons [5] and [0] (Data Initialize), and [2] and [0] (Data Copy) to initialize the data.
3. Call each item number and check if the respective screen shows the normal picture.
In cases where items are not well adjusted, rectify the items with fine adjustment.
Write the data per each item number ([MUTING] + [0]).
4. Select item numbers "OPB0" (OP1), "OPB1" (OP2) and "OPB2" (OP3) and respectively set the bit per model with command buttons [3] and [6].
5. Press commander buttons [8] and [0] (Test Normal) to return to the data that was set on the shipment from the factory.
(This will also cancel Service Mode.)


4-5. PICTURE DISTORTION ADJUSTMENT

Item Number 00-0B


GEO 0 HSH (H POSITION)




GEO 1 HSZ (H SIZE)




GEO 2 PAP (PIN AMP)




GEO 3 TLT (TRAPEZIUM)



GEO 4 VSH (V POSITION)




GEO 5 VSZ (V SIZE)



GEO 6 SCR (VERTICAL S-Correction)




GEO 7 VLN (V LINEARITY)



GEO 8 VROW (AFC.BOW)



GEO 9 AGL (AFC.ANGLE)



GEO 0A UCP (UPPER CORNER PIN)

GEO 0B LCP (LOWER CORNER PIN)




SECTION 5
DIAGRAM

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952


KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952


5-1. BLOCK DIAGRAM



5-2. FRAME SCHEMATIC DIAGRAM



5-3. CIRCUIT BOARDS LOCATION



5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

Note:

- All capacitors are in μF unless otherwise noted.
- All electrolytic capacitors are rated at 50V unless otherwise noted.
- All resistors are in ohms.
 $k = 1000$, $M = 1000k$
- Indication of resistance which does not have rating electrical power is as follows.

Pitch: 5 mm
 Rating electrical power 1/4W (CHIP: 1/10W)

-  : nonflammable resistor.
-  : internal component.
-  : panel designation or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B unless otherwise noted.
- **Readings are taken with a color-bar signal input.**
 no mark : PAL
 () : SECAM
 [] : NTSC 3.58
 « » : NTSC 4.43
- **Readings are taken with a 10 M digital m ultimeter.**
- **Voltage are dc with respect to ground unless otherwise noted.**
- **Voltage variations may be noted due to normal production tolerances.**
- **All voltages are in V.**
- * : Cannot be measured.
- **Circled numbers are waveform references.**
-  : B + bus.
-  : B - bus.
-  : signal path.

Reference information


RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: *	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

Note: The component identified by shading and mark  are critical for safety. Replace only with part number specified.

A BOARD IC001 CXP86461-622S (FOR KV-PF21DK7)

A BOARD IC001 CXP86461-623S (Except KV-PF21DK7)

A BOARD IC001 CXP86461-618S (KV-PF21N70)




KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952

A BOARD WAVEFORMS




A BOARD

IC		D004	D-8	D614	H-7
IC001		D005	B-8	D615	E-7
IC002		D006	A-3	D616	E-9
IC003		D203	C-11	D617	F-8
IC100		D300	A-9	D618	F-9
IC201		D301	B-9	D620	D-8
IC203		D302	B-6	D621	F-8
IC204		D303	B-5	D622	F-7
IC301		D304	B-5	D623	F-12
IC502		D305	B-5	D624	F-12
IC503		D306	C-5	D625	D-12
IC601		D307	C-5	D627	F-8
IC602		D308	B-5	D628	G-5
IC603		D309	B-6	D629	F-9
IC604		D310	A-6	D630	E-9
IC901		D311	C-6	D631	G-12
PH600		D312	C-6	D632	F-12
		D313	A-8	D633	E-12
		D315	B-7	D634	F-11
		D316	C-7	D635	F-12
		D317	B-9	D636	D-12
		D314	A-9	D637	F-11
		D319	C-6	D638	E-11
		D320	C-6	D901	C-13
		D401	D-2	D902	D-13
		D402	C-3	D903	C-13
		D403	B-1	D904	D-13
		D404	C-2	D905	F-13
		D405	C-1	D906	I-13
		D406	B-1		
		D407	C-2		
		D408	C-1		
		D409	A-1		
		D504	D-5		
		D505	H-6		
		D506	F-6		
		D507	F-6		
		D508	I-5		
		D509	E-6		
		D510	F-5		
		D511	F-5		
		D512	G-5		
		D513	I-5		
		D517	F-2		
		D518	F-2		
		D519	F-2		
		D520	E-5		
		D521	I-4		
		D522	J-4		
		D525	F-5		
		D526	F-6		
		D527	F-3		
		D528	F-3		
		D529	F-5		
		D530	F-2		
		D531	E-6		
		D532	E-6		
		D533	D-2		
		D534	E-6		
		D600	G-13		
		D601	I-8		
		D602	G-13		
		D603	F-11		
		D604	J-7		
		D605	G-10		
		D606	E-11		
		D607	F-10		
		D608	E-11		
		D609	H-8		
		D610	J-8		
		D611	I-7		
		D612	F-8		
		D613	I-7		
DIODE					
D001		B-8			
D002		C-8			
D003		C-9			

A [POWER SUPPLY, HV, MICON, Y/C JUNGLE]

PRINTED WIRING BOARD


- A Board -



A BOARD * MARK LIST

	KV-PF21N70 (Taiwan)	KV-PF51P40 (Indonesia)	KV-PF21P70 (E)	KV-PF21Q40 (GE)	KV-PF21Q70 (E)	KV-PF21M70 (E)	KV-PF21DK7 (ME)
C204	0.0068 :PT	0.01 :PP	0.0068 :PT	0.0068 :PT	0.0068 :PT	0.0068 :PT	0.0068 :PT
C209	10	47 16V	10	10	10	10	10
C307	18p :CHIP	18p :CHIP	18p :CHIP	#	#	18p :CHIP	#
C622	0.0015	0.0015	0.0015	0.0015	0.0015	#	0.0015
C624	1500p 2KV	1500p 2KV	1500p 2KV	1500p 2KV	1500p 2KV	#	1500p 2KV
IC001	CXP86449-618S	CXP86449-623S	CXP86449-623S	CXP86449-623S	CXP86449-623S	CXP86449-623S	CXP86449-622S
Q205	#	UN2213	UN2213	UN2213	UN2213	UN2213	UN2213
R208	10K :CHIP	33K :CHIP	10K :CHIP	10K :CHIP	10K :CHIP	10K :CHIP	10K :CHIP
R301	10K :CHIP	10K :CHIP	4.7K :CHIP	4.7K :CHIP	4.7K :CHIP	4.7K :CHIP	4.7K :CHIP
TU101	BTF-FA401	BTF-LG411	BTF-LG411	BTF-LG411	BTF-LG411	BTF-LG433	BTF-LG411
X302	VIBRATOR,CRYSTAL	VIBRATOR,CRYSTAL	VIBRATOR,CRYSTAL	#	#	VIBRATOR,CRYSTAL	#


Note) The parts indicated as “#” in this circuit diagram are not listed here, as they are not used in this models.

 **NOTE:**
The circuit indicated at left contains high voltage of over 600 Vp-p. Please pay attention when inspecting or repairing it to prevent an electric shock.


5.5 SEMICONDUCTORS

DIODE


AK04V0
AU-01Z-V1
EL1Z
ERA22-08
GP08D
RD33EB3T
RGP02-17EL-6433




D4SB60L




ERC04-06SE
ERC06-15S
RN4Z
RS 3FS
31DQ06-FC5




ERD29-08J




D1NS4
D1N20R
RD20ES-B2
RD30ESB2
RD6.8ES-B1
1SS119-25
11EQS04
11ES2-NTA2B




DTZ-TT11-15B
DTZ-10B
MA 111-(K8).SO
RD10S-B
RD5.1SB-T2
RD9.1S-B
UDZS-TE17-5.1B
UDZS-TE17-6.8B
UDZS-TE17-9.1B
1SS355TE-17




5P6M




DA204K




FMU-G26S



EG01CV0




RD9.1ES-L2




LED

SPB-26MVWF




TRANSISTOR


UN2111
UN2211
UN2213
UN2216
2SA1162-G
2SD2114K
2SC2712-YG



2SC2785-HFE




2SA1091-O




2SD2144S-UVW




2SC2611



2SK2845-LB102




2SD2578-CA



2SD774-34




1RF614




IC

CXA2130S (64PIN)
CXP86449-622S (64PIN)
CXP86449-623S (64PIN)
M24C08-BN6 (8PIN)
TDA7429S (42PIN)
ST24C08FB6 (8PIN)




Dual In-line Package
Pin 6~98

MM1319AFBE (7PIN)
NJM2903M (8PIN)




Single In -line Package
Pin 6~98


NJM78M09FA
TA7805S




SBX1981-51



SE-135N




TDA8172




STR-F6654

MARKING SIDE VIEW



Zig-zag In -line Package
Pin 6~99

TA8248K



SECTION 6
EXPLODED VIEW

NOTE:


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark $\triangle$ are critical for safety.
Replace only with part number specified.

6-1. CHASSIS

- : BVTP 3 × 12 7-685-648-79
- : BVTP 4 × 16 7-685-663-71

NOTE : This picture tube for INdonesian model is upside down, and the position for the anode cap and tensions springs are change accordingly.



REF. NO.	PART NO.	DESCRIPTION	REMARK
1	X-4036-748-3	BEZNET ASSY (KV-PF21P70/PF51P40)	3,32,33
	X-4036-748-1	BEZNET ASSY (KV-PF21M70)	3,32,33
	X-4036-758-2	BEZNET ASSY (KV-PF21Q70/PF21Q40)	3,32,33
	X-4036-758-3	BEZNET ASSY (KV-PF21DK7)	3,32,33
	X-4037-022-1	BEZNET ASSY (KV-PF21N70)	3,32,33
2	4-070-291-01	BUTTON, POWER (except KV-PF21DK7)	
	4-070-291-11	BUTTON, POWER (KV-PF21DK7 only)	
3	4-070-290-01	BUTTON, MULTI (except KV-PF21DK7)	
	4-070-290-11	BUTTON, MULTI (KV-PF21DK7)	
4	1-505-740-11	SPEAKER (5X9CM)	
5	4-054-981-01	SCREW, STEP TAPPING	
6	4-365-808-01	SCREW (5), TAPPING	
7	4-046-600-11	SPACER, DY	
8	* 3-704-372-11	HOLDER, HV CABLE	
9	$\triangle$ 8-738-809-05	PICTURE TUBE (A51LPT70X)	
	$\triangle$ 8-738-812-05	PICTURE TUBE (A51LPT70X)	
		(KV-PF21N70/PF51P40)	
10	$\triangle$ 8-451-505-11	DEFLCETION YOKE (Y21RSA-S)	
11	* A-1331-884-A	C3 BOARD MOUNTED	
12	4-369-318-61	SPRING, TENSION	
13	$\triangle$ 1-416-946-11	COIL, DEMAGNETIC (except KV-PF21N70)	
	$\triangle$ 1-416-946-31	COIL, DEMAGNETIC (KV-PF21N70 only)	
14	* 4-067-189-01	PWB(L), GUIDE	
15	* 4-067-187-01	PWB(R), GUIDE	
16	* 8-598-447-00	TUNER, FSS BTF-LG411 (except KV-PF21N70/PF21M70)	
	* 8-598-430-00	TUNER, FSS BTF-FA401 (KV-PF21N70 only)	
	* 8-598-449-10	TUNER, FSS BTF-LG433 (KV-PF21M70 only)	
17	$\triangle$ 1-453-293-11	TRANSFORMER ASSY, FLYBACK (NX-1748/M3A4)	
18	* A-1298-975-A	A BOARD COMPLETE (KV-PF21P70)	
	A-1299-031-A	A BOARD COMPLETE (KV-PF21N70)	
	A-1299-018-A	A BOARD COMPLETE (KV-PF51P40)	
	A-1299-021-A	A BOARD COMPLETE (KV-PF21Q40/PF21Q70)	
	A-1299-026-A	A BOARD COMPLETE (KV-PF21M70)	
	A-1299-028-A	A BOARD COMPLETE (KV-PF21DK7)	
19	4-057-714-01	PIECE ASSY, TLH CORRECTION	
20	4-022-115-00	HOLDER, AC CORD	
21	$\triangle$ 1-574-062-11	CORD, POWER (WITH CONNECTOR) 2.5A/250V	
		(except KV-PF21N70)	
	$\triangle$ 1-575-023-11	CORD, POWER (WITH CONNECTOR) 2.5A/250V	
		(KV-PF21N70 only)	
22	1-452-032-00	MAGNET,DISC	
23	4-051-736-41	PIECE A(90), CONV, CORRECT	
24	4-067-167-21	BRACKET,TERMINAL	
25	1-452-094-00	CIRCULAR DISC MAGNET B	
26	4-069-651-02	BLOTTING SHEET	
27	* A-1241-355-A	F BOARD MOUNTED	
28	$\triangle$ 4-070-300-01	COVER, REAR	
29	4-064-883-11	HOLDER, DGC	
30	* 4-379-189-11	CUSHION, SPEAKER	
31	4-069-652-02	CUSHION (HS BAND)	
32	X-4036-753-3	DOOR ASSY, CONTROL (KV-PF21DK7)	
	X-4036-753-2	DOOR ASSY, CONTROL (KV-PF21Q40/PF21Q70)	
	X-4037-021-1	DOOR ASSY, CONTROL (KV-PF21N70)	
	X-4036-750-1	DOOR ASSY, CONTROL (KV-PF21M70)	
	X-4036-750-3	DOOR ASSY, CONTROL (KV-PF21P70/PF51P40)	
33	4-070-292-01	BAR OPTICAL	

SECTION 7

ELECTRICAL PARTS LIST

A

NOTE:

The components identified by shading and mark $\triangle$ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All resistors are in ohms
- F : nonflammable
- CAPACITORS
- MF : μ F, PF : μ μF
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- COILS
- MMH : mH, UH : μ H

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
	* A-1298-975-A	A BOARD COMPLETE (KV-PF21P70)		C053	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
	* A-1299-031-A	A BOARD COMPLETE (KV-PF21NP70)		C054	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
	* A-1299-018-A	A BOARD COMPLETE (KV-PF51P40)		C055	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
	* A-1299-021-A	A BOARD COMPLETE (KV-PF21Q70/Q40)		C103	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V
	* A-1299-026-A	A BOARD COMPLETE (KV-PF21M70)		C104	1-104-665-11	ELECT 100MF 20%	10V
	* A-1299-028-A	A BOARD COMPLETE (KV-PF21DK7)		C107	1-163-005-11	CERAMIC CHIP 470PF 10%	50V
		*****		C108	1-104-664-11	ELECT 47MF 20%	16V
	* 4-055-304-01	HOLDER, LED		C109	1-163-005-11	CERAMIC CHIP 470PF 10%	50V
	* 4-067-182-02	HOLDER, FBT		C110	1-163-005-11	CERAMIC CHIP 470PF 10%	50V
	4-382-854-11	SCREW (M3X10), P, SW (+)		C111	1-163-005-11	CERAMIC CHIP 470PF 10%	50V
	4-382-854-11	SCREW (M3X10), P, SW (+)		C112	1-104-664-11	ELECT 47MF 20%	16V
	4-382-854-21	SCREW (M3X14), P, SW (+)		C113	1-104-664-11	ELECT 47MF 20%	25V
				C114	1-126-967-11	ELECT 47MF 20%	50V
	7-685-648-79	SCREW +BVTP 3X12 TYPE2 IT-3		C202	1-163-021-91	CERAMIC CHIP 0.01MF 10%	50V
		<CAPACITOR>		C204	1-130-481-00	MYLAR 0.0068MF 5%	50V
C003	1-163-251-11	CERAMIC CHIP 100PF 5%	50V			(except KV-PF51P40)	
C004	1-163-001-11	CERAMIC CHIP 220PF 10%	50V	C204	1-136-153-00	FILM 0.01MF 5%	50V
C005	1-163-001-11	CERAMIC CHIP 220PF 10%	50V			(KV-PF51P40 only)	
C006	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V	C206	1-164-182-11	CERAMIC CHIP 0.0033MF 10%	50V
C007	1-104-664-11	ELECT 47MF 20%	16V	C209	1-126-964-11	ELECT 10MF 20%	50V
						(except KV-PF51P40)	
C008	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C209	1-104-664-11	ELECT 47MF 20%	16V
C010	1-163-251-11	CERAMIC CHIP 100PF 5%	50V			(KV-PF51P40 only)	
C012	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C210	1-126-933-11	ELECT 100MF 20%	16V
C013	1-163-021-91	CERAMIC CHIP 0.01MF 10%	50V	C211	1-126-941-11	ELECT 470MF 20%	25V
C014	1-104-664-11	ELECT 47MF 20%	25V	C212	1-126-933-11	ELECT 100MF 20%	16V
				C215	1-126-942-61	ELECT 1000MF 20%	25V
C015	1-163-009-11	CERAMIC CHIP 0.001MF 10%	50V	C216	1-163-021-91	CERAMIC CHIP 0.01MF 10%	50V
C016	1-163-113-00	CERAMIC CHIP 68PF 5%	50V	C218	1-136-167-00	FILM 0.15MF 5%	50V
C017	1-163-113-00	CERAMIC CHIP 68PF 5%	50V	C220	1-126-942-61	ELECT 1000MF 20%	25V
C019	1-104-664-11	ELECT 47MF 20%	25V	C221	1-126-964-11	ELECT 10MF 20%	50V
C022	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	C223	1-126-965-11	ELECT 22MF 20%	50V
C023	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	C224	1-163-133-00	CERAMIC CHIP 470PF 5%	50V
C024	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	C226	1-109-982-11	CERAMIC CHIP 1MF 10%	10V
C026	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V	C227	1-163-037-11	CERAMIC CHIP 0.022MF 10%	50V
C027	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V	C228	1-163-024-00	CERAMIC CHIP 0.018MF 10%	50V
C028	1-163-037-11	CERAMIC CHIP 0.022MF 10%	50V	C229	1-163-018-00	CERAMIC CHIP 0.0056MF 10%	50V
				C230	1-163-024-00	CERAMIC CHIP 0.018MF 10%	50V
C030	1-126-965-11	ELECT 22MF 20%	50V	C231	1-163-018-00	CERAMIC CHIP 0.0056MF 10%	50V
C031	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V	C232	1-163-037-11	CERAMIC CHIP 0.022MF 10%	50V
C032	1-107-823-11	CERAMIC CHIP 0.47MF 10%	16V	C233	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V
C034	1-163-031-11	CERAMIC CHIP 0.01MF	50V	C234	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V
C041	1-163-251-11	CERAMIC CHIP 100PF 5%	50V				
C042	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C235	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V
C043	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C236	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V
C044	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C238	1-164-505-11	CERAMIC CHIP 2.2MF	16V
C047	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C240	1-164-505-11	CERAMIC CHIP 2.2MF	16V
C048	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C241	1-164-346-11	CERAMIC CHIP 1MF	16V
C050	1-163-251-11	CERAMIC CHIP 100PF 5%	50V				
C051	1-163-251-11	CERAMIC CHIP 100PF 5%	50V				

KV-PF21N70/PF51P40/PF21P70/PF21Q40

RM-915

RM-952

RM-952

RM-952

KV-PF21Q70/PF21M70/PF21DK7

RM-952

RM-952

RM-952

A

The components identified by shading
and mark Δ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK
C242	1-164-505-11	CERAMIC CHIP 2.2MF	16V
C243	1-216-295-91	SHORT 0	
C244	1-164-700-11	CERAMIC CHIP 0.68MF	16V
C245	1-164-346-11	CERAMIC CHIP 1MF	16V
C246	1-163-018-00	CERAMIC CHIP 0.0056MF	10% 50V
C248	1-163-010-11	CERAMIC CHIP 0.0012MF	10% 50V
C249	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C251	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C252	1-164-346-11	CERAMIC CHIP 1MF	16V
C253	1-163-037-11	CERAMIC CHIP 0.022MF	10% 50V
C254	1-126-965-11	ELECT 22MF	20% 50V
C255	1-163-037-11	CERAMIC CHIP 0.022MF	10% 50V
C256	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C259	1-126-933-11	ELECT 100MF	20% 16V
C265	1-164-505-11	CERAMIC CHIP 2.2MF	16V
C301	1-126-935-11	ELECT 470MF	20% 16V
C302	1-163-005-11	CERAMIC CHIP 470PF	10% 50V
C303	1-126-964-11	ELECT 10MF	20% 50V
C304	1-126-967-11	ELECT 47MF	20% 50V
C305	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C306	1-163-233-11	CERAMIC CHIP 18PF	5% 50V
C307	1-163-233-11	CERAMIC CHIP 18PF	5% 50V
C308	1-163-259-91	CERAMIC CHIP 220PF	5% 50V
C309	1-126-957-11	ELECT 0.22MF	20% 50V
C310	1-126-963-11	ELECT 4.7MF	20% 50V
C311	1-126-964-11	ELECT 10MF	20% 50V
C312	1-164-346-11	CERAMIC CHIP 1MF	16V
C313	1-164-346-11	CERAMIC CHIP 1MF	16V
C315	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C316	1-104-664-11	ELECT 47MF	20% 25V
C317	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C318	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C319	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C320	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C322	1-163-005-11	CERAMIC CHIP 470PF	10% 50V
C324	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C325	1-126-960-11	ELECT 1MF	20% 50V
C327	1-126-965-11	ELECT 22MF	20% 50V
C328	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C330	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C332	1-126-963-11	ELECT 4.7MF	20% 50V
C335	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C336	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C337	1-126-961-11	ELECT 2.2MF	20% 50V
C338	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C341	1-115-340-11	CERAMIC CHIP 0.22MF	10% 25V
C342	1-163-259-91	CERAMIC CHIP 220PF	5% 50V
C402	1-164-346-11	CERAMIC CHIP 1MF	16V
C404	1-163-005-11	CERAMIC CHIP 470PF	10% 50V
C405	1-126-935-11	ELECT 470MF	20% 16V
C407	1-164-346-11	CERAMIC CHIP 1MF	16V
C408	1-163-133-00	CERAMIC CHIP 470PF	5% 50V
C409	1-126-963-11	ELECT 4.7MF	20% 50V
C502	1-163-145-00	CERAMIC CHIP 0.0015MF	5% 50V
C506	1-107-638-11	ELECT 33MF	20% 160V
C507	1-161-830-00	CERAMIC 0.0047MF	500V
C510	1-102-112-00	CERAMIC 330PF	10% 50V

REF. NO.	PART NO.	DESCRIPTION	REMARK
C512	1-163-989-11	CERAMIC CHIP 0.033MF	10% 25V
C513	1-163-263-11	CERAMIC CHIP 330PF	5% 50V
C514	1-106-383-00	MYLAR 0.047MF	10% 200V
C517	1-164-182-11	CERAMIC CHIP 0.0033MF	10% 50V
C518	1-104-665-11	ELECT 100MF	20% 10V
C519	1-102-212-00	CERAMIC 820PF	10% 500V
C521	1-126-934-11	ELECT 220MF	20% 16V
C522	1-126-933-11	ELECT 100MF	20% 16V
C523	1-102-002-00	CERAMIC 680PF	10% 500V
C524	1-126-967-11	ELECT 47MF	20% 50V
C526	1-130-495-00	MYLAR 0.1MF	5% 50V
C527	1-102-820-00	CERAMIC 330PF	5% 50V
C528	1-162-134-11	CERAMIC 470PF	10% 2KV
C530	1-137-372-11	FILM 0.022MF	5% 50V
C531	1-126-961-11	ELECT 2.2MF	20% 50V
C532	1-126-941-11	ELECT 470MF	20% 25V
C533	1-126-941-11	ELECT 470MF	20% 25V
C536	1-136-165-00	FILM 0.1MF	5% 50V
C537	1-126-969-11	ELECT 220MF	20% 50V
C538	1-136-076-00	FILM 0.0085MF	3% 2KV
C539	1-129-746-91	FILM 0.039MF	5% 400V
C540	1-136-171-00	FILM 0.33MF	5% 50V
C546	1-165-319-11	CERAMIC CHIP 0.1MF	50V
C549	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C550	1-106-220-00	MYLAR 0.1MF	10% 100V
C551	1-126-960-11	ELECT 1MF	20% 50V
C552	1-162-116-00	CERAMIC 680PF	10% 2KV
C553	1-162-116-00	CERAMIC 680PF	10% 2KV
C554	1-137-417-11	MYLAR 0.0047MF	10% 200V
C556	1-126-941-11	ELECT 470MF	20% 25V
C557	1-126-941-11	ELECT 470MF	20% 25V
C558	1-123-024-21	ELECT 33MF	160V
C560	1-102-228-00	CERAMIC 470PF	10% 500V
C561	1-136-557-11	FILM 0.0033MF	5% 630V
C562	1-102-228-00	CERAMIC 470PF	10% 500V
C564	1-163-038-91	CERAMIC CHIP 0.1MF	25V
C565	1-107-655-11	ELECT 47MF	20% 250V
C566	1-102-244-00	CERAMIC 220PF	10% 500V
C567	1-115-521-11	FILM 0.82MF	5% 250V
C568	1-102-228-00	CERAMIC 470PF	10% 500V
C570	1-115-520-11	FILM 0.68MF	5% 250V
C573	1-106-379-12	MYLAR 0.033MF	10% 200V
C574	1-107-636-11	ELECT 10MF	20% 160V
C576	1-130-495-00	MYLAR 0.1MF	5% 50V
C577	1-106-395-00	MYLAR 0.15MF	10% 200V
C582	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C586	1-216-295-91	SHORT 0	
C600 Δ	1-104-705-11	FILM 0.1MF	20% 250V
C602 Δ	1-104-705-11	FILM 0.1MF	20% 250V
C604	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V
C605 Δ	1-127-942-51	CERAMIC 330PF	10% 250V
C606 Δ	1-127-942-51	CERAMIC 330PF	10% 250V
C607	1-161-830-00	CERAMIC 0.0047MF	99% 500V
C608	1-161-830-00	CERAMIC 0.0047MF	99% 500V
C609	1-126-968-11	ELECT 100MF	20% 50V
C610	1-126-964-11	ELECT 10MF	20% 50V
C611	1-161-830-00	CERAMIC 0.0047MF	99% 500V
C612	1-161-830-00	CERAMIC 0.0047MF	99% 500V

The components identified by shading
and mark $\triangle$ are critical for safety.
Replace only with part number specified.

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952

A

REF. NO.	PART NO.	DESCRIPTION	REMARK
C613	1-117-752-11	ELECT(BLOCK)	330MF 20% 450V
C614	1-126-964-11	ELECT	10MF 20% 50V
C616	1-130-202-00	FILM	0.022MF 10% 400V
C617	1-107-792-11	CERAMIC	100PF 5% 1KV
C618	1-125-893-11	FILM	680PF 3% 1.5KV
C619 $\triangle$	1-119-886-51	CERAMIC	470PF 10% 250V
C620	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
C621	1-102-114-00	CERAMIC	470PF 10% 50V
C622	1-102-119-00	CERAMIC (except KV-PF21M70)	0.0015MF 10% 50V
C623	1-104-665-11	ELECT	100MF 20% 25V
C624	1-125-772-91	CERAMIC (except KV-PF21M70)	1500PF 10% 2KV
C627	1-102-002-00	CERAMIC	680PF 10% 500V
C628	1-126-942-61	ELECT	1000MF 20% 25V
C629	1-126-964-11	ELECT	10MF 20% 50V
C630	1-123-024-21	ELECT	33MF 160V
C633	1-104-999-11	MYLAR	0.1MF 10% 200V
C634	1-126-933-11	ELECT	100MF 20% 16V
C635	1-104-665-11	ELECT	100MF 20% 10V
C636	1-104-760-11	CERAMIC CHIP	0.047MF 10% 50V
C639	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C640	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C641	1-102-002-00	CERAMIC	680PF 10% 500V
C642	1-126-943-11	ELECT	2200MF 20% 25V
C643	1-104-665-11	ELECT	100MF 20% 10V
C644	1-104-331-11	CERAMIC	0.0022MF 10% 1KV
C645	1-137-605-11	FILM	0.01MF 10% 250V
C646	1-107-679-91	ELECT	10MF 20% 450V
C647	1-163-275-11	CERAMIC CHIP	0.001MF 5% 50V
C649	1-126-940-11	ELECT	330MF 20% 25V
C650	1-163-275-11	CERAMIC CHIP	0.001MF 5% 50V
C651	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
C652	1-126-965-11	ELECT	22MF 20% 50V
C653	1-104-664-11	ELECT	47MF 20% 25V
C657	1-101-821-00	CERAMIC	0.0022MF 500V
C658	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C901	1-136-153-00	FILM	0.01MF 5% 50V
C905	1-126-963-11	ELECT	4.7MF 20% 50V
C906	1-164-346-11	CERAMIC CHIP	1MF 16V
C907	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
C910	1-126-967-11	ELECT	47MF 20% 50V
C911	1-126-967-11	ELECT	47MF 20% 50V
C912	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C913	1-104-665-11	ELECT	100MF 20% 10V
C914	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
<CONNECTOR>			
CN104	1-695-915-11	TAB (CONTACT)	
CN202 *	1-785-608-11	PIN, CONNECTOR 4P	
CN203 *	1-564-506-11	PLUG, CONNECTOR 3P	
CN204 *	1-564-506-11	PLUG, CONNECTOR 3P	
CN305 *	1-564-509-11	PLUG, CONNECTOR 6P	
CN505	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P	
CN506	4-352-844-01	PIN, LEAD, COATING	
CN601 *	1-580-843-11	PIN, CONNECTOR (POWER)	

REF. NO.	PART NO.	DESCRIPTION	REMARK
CN602 *	1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P	
CN604 *	1-573-963-11	PIN, CONNECTOR (PC BOARD) 3P	
CN901 *	1-564-506-11	PLUG, CONNECTOR 3P	
<DIODE>			
D001	8-719-988-61	DIODE 1SS355TE-17	
D005	8-719-988-61	DIODE 1SS355TE-17	
D006	8-719-988-61	DIODE 1SS355TE-17	
D203	8-719-914-42	DIODE DA204K	
D300	1-216-295-91	SHORT	0
D301	8-719-988-61	DIODE 1SS355TE-17	
D306	8-719-988-61	DIODE 1SS355TE-17	
D307	8-719-988-61	DIODE 1SS355TE-17	
D308	8-719-988-61	DIODE 1SS355TE-17	
D309	8-719-069-54	DIODE UDZS-TE17-5.1B	
D311	8-719-988-61	DIODE 1SS355TE-17	
D312	8-719-988-61	DIODE 1SS355TE-17	
D313	8-719-988-61	DIODE 1SS355TE-17	
D314	8-719-988-61	DIODE 1SS355TE-17	
D315	8-719-988-61	DIODE 1SS355TE-17	
D316	8-719-069-57	DIODE UDZS-TE17-6.8B	
D320	8-719-069-60	DIODE UDZS-TE17-9.1B	
D321	8-719-069-60	DIODE UDZS-TE17-9.1B	
D402	8-719-069-60	DIODE UDZS-TE17-9.1B	
D403	8-719-069-60	DIODE UDZS-TE17-9.1B	
D405	8-719-069-60	DIODE UDZS-TE17-9.1B	
D406	8-719-069-60	DIODE UDZS-TE17-9.1B	
D504	8-719-302-43	DIODE EL1Z	
D505	8-719-988-61	DIODE 1SS355TE-17	
D506	8-719-911-19	DIODE 1SS119-25	
D507	8-719-988-61	DIODE 1SS355TE-17	
D508	8-719-988-61	DIODE 1SS355TE-17	
D509	1-216-073-00	RES,CHIP 10K	5% 1/10W
D510	8-719-988-61	DIODE 1SS355TE-17	
D511	8-719-988-61	DIODE 1SS355TE-17	
D512	8-719-988-61	DIODE 1SS355TE-17	
D513	8-719-908-03	DIODE GP08D	
D517	8-719-312-71	DIODE RS3FS	
D518	8-719-900-26	DIODE ERD29-08J	
D521	8-719-302-06	DIODE EU2A	
D521	8-719-302-43	DIODE EL1Z	
D522	8-719-302-43	DIODE EL1Z	
D523	8-719-302-43	DIODE EL1Z	
D527	8-719-908-03	DIODE GP08D	
D528	8-719-908-03	DIODE GP08D	
D531	8-719-988-61	DIODE 1SS355TE-17	
D532	8-719-988-61	DIODE 1SS355TE-17	
D534	1-216-295-91	SHORT	0
D602	8-719-911-19	DIODE 1SS119-25	
D603	8-719-150-92	DIODE RD33EB3T	
D604	8-719-028-72	DIODE RGP02-17EL-6433	
D605	8-719-510-53	DIODE D4SB60L	
D606	8-719-108-18	THYRISTOR 5P6M	
D607	8-719-073-01	DIODE MA111-(K8).S0	
D608	8-719-110-53	DIODE RD20ESB2	

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
D609	8-719-311-31	DIODE RU-1P		IC201	8-759-339-60	IC TA8248K	
D610	8-719-210-21	DIODE 11EQS04		IC203	8-759-553-40	IC TDA7429S	
D611	8-719-046-74	DIODE AU-01Z-V1		IC301	8-752-090-41	IC CXA2139S	
D611	8-719-075-73	DIODE 10ELS2N-TB5		IC502	8-759-700-07	IC NJM2903M	
D613	8-719-046-74	DIODE AU-01Z-V1		IC503	8-759-980-58	IC TDA8172	
D613	8-719-075-73	DIODE 10ELS2N-TB5		IC601	8-749-013-75	IC STR-F6654	
D614	8-719-046-74	DIODE AU-01Z-V1		IC602	8-749-920-61	IC SE-135N	
D618	8-719-067-18	DIODE RN4Z		IC603	8-759-701-59	IC NJM78M09FA	
D620	8-719-110-72	DIODE RD30ESB2		IC604	8-759-231-53	IC TA7805S	
D622	8-719-071-39	DIODE FMU-G26S		IC901	8-742-014-11	HYB IC SBX1981-51	
D623	8-719-978-65	DIODE DTZ-TT11-15B					
D624	8-719-073-01	DIODE MA111-(K8).S0				<JACK>	
D625	8-719-977-28	DIODE DTZ10B					
D627	8-719-073-84	DIODE 31DQ06-FC5		J401	1-779-849-11	JACK BLOCK, PIN 4P	
D628	8-719-911-19	DIODE 1SS119-25		J901	1-770-785-11	JACK	
				J902	1-779-205-11	JACK, PIN 2P	
D631	8-719-068-00	DIODE ERC04-06SE					
D632	8-719-068-00	DIODE ERC04-06SE					
D633	8-719-030-25	DIODE EG01CV0				<CHIP CONDUCTOR>	
D633	8-719-948-45	DIODE ERA22-08					
D634	8-719-073-01	DIODE MA111-(K8).S0		JR001	1-216-295-91	SHORT	0
				JR002	1-216-295-91	SHORT	0
D635	8-719-073-01	DIODE MA111-(K8).S0		JR003	1-216-295-91	SHORT	0
D636	8-719-510-02	DIODE D1NS4		JR004	1-216-295-91	SHORT	0
D637	8-719-109-96	DIODE RD6.8ESB1		JR005	1-216-295-91	SHORT	0
D638	8-719-024-99	DIODE 11ES2-NTA2B					
D901	8-719-069-60	DIODE UDZS-TE17-9.1B		JR006	1-216-295-91	SHORT	0
				JR007	1-216-295-91	SHORT	0
D902	8-719-069-60	DIODE UDZS-TE17-9.1B		JR008	1-216-295-91	SHORT	0
D904	8-719-069-60	DIODE UDZS-TE17-9.1B		JR009	1-216-295-91	SHORT	0
D905	8-719-069-60	DIODE UDZS-TE17-9.1B		JR010	1-216-295-91	SHORT	0
D906	8-719-045-19	DIODE SPB-26MVWF					
				JR011	1-216-295-91	SHORT	0
		<CONNECTOR>		JR012	1-216-295-91	SHORT	0
DY1	* 1-580-798-11	CONNECTOR PIN (DY) 6P		JR013	1-216-295-91	SHORT	0
				JR014	1-216-295-91	SHORT	0
				JR015	1-216-295-91	SHORT	0
		<FERRITE BEAD>		JR016	1-216-295-91	SHORT	0
				JR018	1-216-295-91	SHORT	0
FB501	1-410-397-21	FERRITE	1.1UH	JR019	1-216-295-91	SHORT	0
FB502	1-410-397-21	FERRITE	1.1UH	JR102	1-216-295-91	SHORT	0
FB600	1-410-397-21	FERRITE	1.1UH	JR109	1-216-295-91	SHORT	0
FB601	1-410-397-21	FERRITE	1.1UH				
FB602	1-410-397-21	FERRITE	1.1UH	JR202	1-216-295-91	SHORT	0
				JR301	1-216-295-91	SHORT	0
FB603	1-410-397-21	FERRITE	1.1UH	JR303	1-216-295-91	SHORT	0
FB604	1-412-911-31	FERRITE	0UH	JR404	1-216-295-91	SHORT	0
FB607	1-410-397-21	FERRITE	1.1UH	JR405	1-216-295-91	SHORT	0
FB608	1-410-397-21	FERRITE	1.1UH				
FB611	1-410-397-21	FERRITE	1.1UH	JR500	1-216-295-91	SHORT	0
				JR501	1-216-295-91	SHORT	0
FB613	1-410-397-21	FERRITE	1.1UH	JR503	1-216-295-91	SHORT	0
FB615	1-410-397-21	FERRITE	1.1UH	JR600	1-216-295-91	SHORT	0
						<COIL>	
		<IC>					
IC001	8-752-906-21	IC CXP86449-623S (except KV-PF21N70/PF21DK7)		L002	1-414-856-11	INDUCTOR	10UH
IC001	8-752-905-24	IC CXP86449-618S (KV-PF21N70 only)		L003	1-414-180-11	INDUCTOR	3.3UH
IC001	8-752-906-20	IC CXP86449-622S (KV-PF21DK7 only)		L005	1-414-233-22	INDUCTOR CHIP	0UH
IC002	8-759-371-21	IC MM1319AFBE		L101	1-414-856-11	INDUCTOR	10UH
IC003	8-759-527-71	IC M24C08-BN6		L102	1-414-856-11	INDUCTOR	10UH
				L103	1-414-856-11	INDUCTOR	10UH
				L104	1-414-856-11	INDUCTOR	10UH

The components identified by shading
and mark $\triangle$ are critical for safety.
Replace only with part number specified.

KV-PF21N70/PF51P40/PF21P70/PF21Q40

RM-915

RM-952

RM-952

RM-952

KV-PF21Q70/PF21M70/PF21DK7

RM-952

RM-952

RM-952

A

REF. NO.	PART NO.	DESCRIPTION	REMARK
L105	1-414-856-11	INDUCTOR 10UH	
L204	1-414-856-11	INDUCTOR 10UH	
L301	1-414-189-31	INDUCTOR 100UH	
L302	1-414-185-41	INDUCTOR 22UH	
L501	1-412-525-31	INDUCTOR 10UH	
L502	1-422-613-11	COIL, AIR CORE	
L503	1-412-525-31	INDUCTOR 10UH	
L504	1-412-525-31	INDUCTOR 10UH	
L505	1-412-525-31	INDUCTOR 10UH	
L506	1-412-525-31	INDUCTOR 10UH	
L507	1-459-111-00	INDUCTOR 10MMH	
L508	1-412-525-31	INDUCTOR 10UH	
L509	1-459-390-00	INDUCTOR 390UH	
L510	1-416-972-11	COIL, HORIZONTAL LINEARITY	
L512	1-412-549-31	INDUCTOR 1MMH	
L513	1-412-549-31	INDUCTOR 1MMH	
L515	1-459-104-00	COIL, WITH CORE	
L518	1-414-187-11	INDUCTOR 47UH	
L601	1-412-527-11	INDUCTOR 15UH	
L901	1-408-603-31	INDUCTOR 10UH	
L905	1-414-856-11	INDUCTOR 10UH	
<PHOTO COUPLER>			
PH600 $\triangle$	8-749-010-64	PHOTO COUPLER PC123F2	
<IC LINK>			
PS200	1-532-675-21	LINK, IC 1.5A/150V	
<TRANSISTOR>			
Q002	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q003	8-729-424-08	TRANSISTOR UN2111	
Q004	8-729-421-22	TRANSISTOR UN2211	
Q101	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q201	8-729-424-67	TRANSISTOR UN2216	
Q203	8-729-421-19	TRANSISTOR UN2213	
Q204	8-729-216-22	TRANSISTOR 2SA1162-G	
Q205	8-729-421-19	TRANSISTOR UN2213 (except KV-PF21N70)	
Q206	8-729-421-19	TRANSISTOR UN2213	
Q207	8-729-421-19	TRANSISTOR UN2213	
Q301	8-729-216-22	TRANSISTOR 2SA1162-G	
Q302	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q303	8-729-216-22	TRANSISTOR 2SA1162-G	
Q305	8-729-216-22	TRANSISTOR 2SA1162-G	
Q306	8-729-216-22	TRANSISTOR 2SA1162-G	
Q307	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q308	8-729-216-22	TRANSISTOR 2SA1162-G	
Q312	8-729-216-22	TRANSISTOR 2SA1162-G	
Q313	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q315	8-729-421-19	TRANSISTOR UN2213	
Q401	8-729-424-67	TRANSISTOR UN2216	
Q404	8-729-216-22	TRANSISTOR 2SA1162-G	
Q503	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q505	8-729-931-45	TRANSISTOR IRF614	
Q506	8-729-140-96	TRANSISTOR 2SD774-34	

REF. NO.	PART NO.	DESCRIPTION	REMARK
Q507	8-729-216-22	TRANSISTOR 2SA1162-G	
Q509	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q511	8-729-048-07	TRANSISTOR 2SD2578-CA	
Q601	8-729-023-22	TRANSISTOR 2SD2114K	
Q602	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q603	8-729-424-08	TRANSISTOR UN2111	
Q604	8-729-200-17	TRANSISTOR 2SA1091-O	
Q605	8-729-044-30	TRANSISTOR 2SK2845-LB102	
Q606	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q607	8-729-922-37	TRANSISTOR 2SD2144S-UVW	
Q608	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q901	8-729-421-19	TRANSISTOR UN2213	
Q902	8-729-421-19	TRANSISTOR UN2213	
<RESISTOR>			
R001	1-414-233-22	INDUCTOR CHIP 0UH	
R002	1-216-025-91	RES,CHIP 100	5% 1/10W
R003	1-216-295-91	SHORT 0	
R004	1-216-025-91	RES,CHIP 100	5% 1/10W
R005	1-216-025-91	RES,CHIP 100	5% 1/10W
R007	1-216-295-91	SHORT 0	
R008	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R010	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R011	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R012	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R013	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R014	1-216-025-91	RES,CHIP 100	5% 1/10W
R015	1-216-025-91	RES,CHIP 100	5% 1/10W
R017	1-216-049-91	RES,CHIP 1K	5% 1/10W
R018	1-216-033-00	RES,CHIP 220	5% 1/10W
R019	1-216-073-00	RES,CHIP 10K	5% 1/10W
R021	1-216-073-00	RES,CHIP 10K	5% 1/10W
R022	1-216-033-00	RES,CHIP 220	5% 1/10W
R024	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R025	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R026	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R027	1-216-073-00	RES,CHIP 10K	5% 1/10W
R029	1-216-049-91	RES,CHIP 1K	5% 1/10W
R031	1-216-049-91	RES,CHIP 1K	5% 1/10W
R035	1-216-025-91	RES,CHIP 100	5% 1/10W
R036	1-216-025-91	RES,CHIP 100	5% 1/10W
R037	1-216-025-91	RES,CHIP 100	5% 1/10W
R040	1-216-025-91	RES,CHIP 100	5% 1/10W
R041	1-216-025-91	RES,CHIP 100	5% 1/10W
R042	1-216-295-91	SHORT 0	
R043	1-216-049-91	RES,CHIP 1K	5% 1/10W
R044	1-216-025-91	RES,CHIP 100	5% 1/10W
R045	1-414-233-22	INDUCTOR CHIP 0UH	
R046	1-216-049-91	RES,CHIP 1K	5% 1/10W
R047	1-414-233-22	INDUCTOR CHIP 0UH	
R048	1-216-073-00	RES,CHIP 10K	5% 1/10W
R050	1-216-073-00	RES,CHIP 10K	5% 1/10W
R053	1-216-049-91	RES,CHIP 1K	5% 1/10W
R055	1-216-073-00	RES,CHIP 10K	5% 1/10W
R056	1-216-073-00	RES,CHIP 10K	5% 1/10W
R061	1-216-033-00	RES,CHIP 220	5% 1/10W
R062	1-216-041-00	RES,CHIP 470	5% 1/10W

KV-PF21N70/PF51P40/PF21P70/PF21Q40

RM-915

RM-952

RM-952

RM-952

KV-PF21Q70/PF21M70/PF21DK7

RM-952

RM-952

RM-952

A

REF. NO.	PART NO.	DESCRIPTION			REMARK
R063	1-216-037-00	RES,CHIP	330	5%	1/10W
R064	1-216-037-00	RES,CHIP	330	5%	1/10W
R065	1-216-037-00	RES,CHIP	330	5%	1/10W
R066	1-216-049-91	RES,CHIP	1K	5%	1/10W
R067	1-216-049-91	RES,CHIP	1K	5%	1/10W
R105	1-216-295-91	SHORT	0		
R109	1-216-041-00	RES,CHIP	470	5%	1/10W
R111	1-216-025-91	RES,CHIP	100	5%	1/10W
R112	1-216-025-91	RES,CHIP	100	5%	1/10W
R113	1-216-047-91	RES,CHIP	820	5%	1/10W
R202	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R203	1-216-077-91	RES,CHIP	15K	5%	1/10W
R204	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R208	1-216-073-00	RES,CHIP	10K	5%	1/10W
		(except KV-PF21P40)			
R208	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
		(KV-PF21P40 only)			
R210	1-164-004-11	CERAMIC CHIP	0.1MF	10%	25V
R211	1-216-043-91	RES,CHIP	560	5%	1/10W
R212	1-216-033-00	RES,CHIP	220	5%	1/10W
R213	1-216-073-00	RES,CHIP	10K	5%	1/10W
R214	1-216-073-00	RES,CHIP	10K	5%	1/10W
R215	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R216	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R217	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R218	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R219	1-216-025-91	RES,CHIP	100	5%	1/10W
R220	1-216-025-91	RES,CHIP	100	5%	1/10W
R221	1-216-295-91	SHORT	0		
R225	1-216-033-00	RES,CHIP	220	5%	1/10W
R226	1-216-033-00	RES,CHIP	220	5%	1/10W
R227	1-216-033-00	RES,CHIP	220	5%	1/10W
R229	1-216-073-00	RES,CHIP	10K	5%	1/10W
R230	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R231	1-216-295-91	SHORT	0		
R234	1-249-389-11	CARBON	4.7	5%	1/4W
R235	1-216-069-00	RES,CHIP	6.8K	5%	1/10W
R236	1-216-069-00	RES,CHIP	6.8K	5%	1/10W
R237	1-216-308-00	RES,CHIP	4.7	5%	1/10W
R301	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
		(except KV-PF21N70/PF21P40)			
R301	1-216-073-00	RES,CHIP	10K	5%	1/10W
		(KV-PF21N70/PF21P40)			
R302	1-216-295-91	SHORT	0		
R303	1-216-049-91	RES,CHIP	1K	5%	1/10W
R304	1-216-073-00	RES,CHIP	10K	5%	1/10W
R305	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R306	1-216-073-00	RES,CHIP	10K	5%	1/10W
R308	1-216-025-91	RES,CHIP	100	5%	1/10W
R309	1-216-025-91	RES,CHIP	100	5%	1/10W
R310	1-216-025-91	RES,CHIP	100	5%	1/10W
R311	1-216-017-91	RES,CHIP	47	5%	1/10W
R312	1-216-041-00	RES,CHIP	470	5%	1/10W
R313	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R314	1-216-045-00	RES,CHIP	680	5%	1/10W
R316	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R317	1-216-077-91	RES,CHIP	15K	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R318	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R319	1-216-025-91	RES,CHIP	100	5%	1/10W
R320	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R321	1-216-073-00	RES,CHIP	10K	5%	1/10W
R322	1-216-033-00	RES,CHIP	220	5%	1/10W
R331	1-216-295-91	SHORT	0		
R332	1-216-033-00	RES,CHIP	220	5%	1/10W
R333	1-216-073-00	RES,CHIP	10K	5%	1/10W
R334	1-216-129-00	RES,CHIP	2.2M	5%	1/10W
R335	1-216-045-00	RES,CHIP	680	5%	1/10W
R338	1-216-033-00	RES,CHIP	220	5%	1/10W
R340	1-216-025-91	RES,CHIP	100	5%	1/10W
R345	1-216-081-00	RES,CHIP	22K	5%	1/10W
R348	1-208-806-11	RES,CHIP	10K	0.50%	1/10W
R349	1-216-073-00	RES,CHIP	10K	5%	1/10W
R350	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R351	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R354	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R355	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R356	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R357	1-216-079-00	RES,CHIP	18K	5%	1/10W
R358	1-216-049-91	RES,CHIP	1K	5%	1/10W
R359	1-216-033-00	RES,CHIP	220	5%	1/10W
R360	1-216-033-00	RES,CHIP	220	5%	1/10W
R361	1-216-073-00	RES,CHIP	10K	5%	1/10W
R362	1-216-075-00	RES,CHIP	12K	5%	1/10W
R363	1-216-079-00	RES,CHIP	18K	5%	1/10W
R364	1-216-295-91	SHORT	0		
R365	1-216-033-00	RES,CHIP	220	5%	1/10W
R366	1-216-073-00	RES,CHIP	10K	5%	1/10W
R367	1-216-073-00	RES,CHIP	10K	5%	1/10W
R370	1-216-033-00	RES,CHIP	220	5%	1/10W
R376	1-216-081-00	RES,CHIP	22K	5%	1/10W
R377	1-216-121-91	RES,CHIP	1M	5%	1/10W
R378	1-216-031-00	RES,CHIP	180	5%	1/10W
R404	1-216-073-00	RES,CHIP	10K	5%	1/10W
R405	1-216-049-91	RES,CHIP	1K	5%	1/10W
R406	1-216-073-00	RES,CHIP	10K	5%	1/10W
R408	1-216-049-91	RES,CHIP	1K	5%	1/10W
R411	1-216-113-00	RES,CHIP	470K	5%	1/10W
R412	1-216-041-00	RES,CHIP	470	5%	1/10W
R413	1-216-021-00	RES,CHIP	68	5%	1/10W
R414	1-216-113-00	RES,CHIP	470K	5%	1/10W
R417	1-216-077-91	RES,CHIP	15K	5%	1/10W
R418	1-216-113-00	RES,CHIP	470K	5%	1/10W
R419	1-216-022-00	RES,CHIP	75	5%	1/10W
R426	1-216-033-00	RES,CHIP	220	5%	1/10W
R505	1-216-099-00	RES,CHIP	120K	5%	1/10W
R506	1-216-085-00	RES,CHIP	33K	5%	1/10W
R507	1-249-389-11	CARBON	4.7	5%	1/4W F
R508	1-215-910-00	METAL OXIDE	68	5%	3W F
R509	1-215-911-11	METAL OXIDE	100	5%	3W F
R510	1-215-885-00	METAL OXIDE	68	5%	2W F
R511	1-215-911-11	METAL OXIDE	100	5%	3W F
R516	1-216-081-00	RES,CHIP	22K	5%	1/10W
R518	1-247-807-31	CARBON	100	5%	1/4W
R520	1-215-445-00	METAL	10K	1%	1/4W

A

REF. NO.	PART NO.	DESCRIPTION	REMARK		REF. NO.	PART NO.	DESCRIPTION	REMARK	
R522	1-208-806-11	RES,CHIP	10K	0.50%	1/10W	R604	1-216-097-91	RES,CHIP	100K 5% 1/10W
R523	1-249-411-11	CARBON	330	5%	1/4W	R607	1-249-425-11	CARBON	4.7K 5% 1/4W
R525	1-208-830-11	RES,CHIP	100K	0.50%	1/10W	R608	1-240-205-91	CARBON	22M 5% 1/2W
R526	1-208-798-11	RES,CHIP	4.7K	0.50%	1/10W	R609	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R527	1-216-001-00	RES,CHIP	10	5%	1/10W	R610	1-216-073-00	RES,CHIP	10K 5% 1/10W
R528	1-208-814-91	RES,CHIP	22K	0.50%	1/10W	R611	1-216-089-91	RES,CHIP	47K 5% 1/10W
R529	1-208-766-11	RES,CHIP	220	0.50%	1/10W	R612	1-216-045-00	RES,CHIP	680 5% 1/10W
R531	1-247-843-11	CARBON	3.3K	5%	1/4W	R614	1-216-041-00	RES,CHIP	470 5% 1/10W
R533	1-249-417-11	CARBON	1K	5%	1/4W	R615	1-216-350-11	METAL OXIDE	1.2 5% 1W F
R534	1-216-361-00	METAL OXIDE	0.22	5%	2W F	R616	1-260-302-51	CARBON	6.8 5% 1/2W F
R535	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	R617	1-247-791-91	CARBON	22 5% 1/4W
R536	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	R619	1-260-128-11	CARBON	270K 5% 1/2W
R537	1-208-814-91	RES,CHIP	22K	0.50%	1/10W	R620	1-215-915-11	METAL OXIDE	470 5% 3W F
R540	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R622	1-215-908-00	METAL OXIDE	33 5% 3W F
R541	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R623	1-216-095-00	RES,CHIP	82K 5% 1/10W
R542	1-216-295-91	SHORT	0			R624	1-216-089-91	RES,CHIP	47K 5% 1/10W
R543	1-249-426-11	CARBON	5.6K	5%	1/4W F	R626	1-216-049-91	RES,CHIP	1K 5% 1/10W
R544	1-216-457-00	METAL OXIDE	1.2K	5%	2W F	R627	1-240-251-11	CMT,MELF	6.8 5% 10W
R545	1-216-077-91	RES,CHIP	15K	5%	1/10W	R629	1-247-747-11	CARBON	470 5% 1/2W F
R546	1-216-077-91	RES,CHIP	15K	5%	1/10W	R630	1-249-429-11	CARBON	10K 5% 1/4W F
R547	1-216-085-00	RES,CHIP	33K	5%	1/10W	R631	1-216-089-91	RES,CHIP	47K 5% 1/10W
R549	1-215-451-00	METAL	18K	1%	1/4W	R632	1-202-933-61	FUSIBLE	0.1 10% 1/2W F
R550	1-216-097-91	RES,CHIP	100K	5%	1/10W	R634	1-218-265-11	METAL	8.2M 5% 1W
R551	1-249-421-11	CARBON	2.2K	5%	1/4W	R635	1-216-492-11	METAL OXIDE	82K 5% 3W F
R552	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R636	1-215-924-00	METAL OXIDE	15K 5% 3W F
R553	1-215-457-00	METAL	33K	1%	1/4W	R637	1-216-492-11	METAL OXIDE	82K 5% 3W F
R554	1-215-457-00	METAL	33K	1%	1/4W	R639	1-216-363-00	METAL OXIDE	0.33 5% 2W F
R556	1-215-437-00	METAL	4.7K	1%	1/4W	R640	1-249-415-11	CARBON	680 5% 1/4W
R558	1-249-421-11	CARBON	2.2K	5%	1/4W	R641	1-216-362-11	METAL OXIDE	0.27 5% 2W F
R559	1-249-429-11	CARBON	10K	5%	1/4W	R642	1-249-419-11	CARBON	1.5K 5% 1/4W
R560	1-216-073-00	RES,CHIP	10K	5%	1/10W	R643	1-247-843-11	CARBON	3.3K 5% 1/4W
R562	1-249-401-11	CARBON	47	5%	1/4W	R644	1-249-419-11	CARBON	1.5K 5% 1/4W
R565	1-216-073-00	RES,CHIP	10K	5%	1/10W	R646	1-215-924-00	METAL OXIDE	15K 5% 3W F
R567	1-216-105-91	RES,CHIP	220K	5%	1/10W	R647	1-249-401-11	CARBON	47 5% 1/4W
R568	1-249-383-11	CARBON	1.5	5%	1/4W F	R648	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R570	1-216-069-00	RES,CHIP	6.8K	5%	1/10W	R649	1-249-417-11	CARBON	1K 5% 1/4W
R571	1-215-437-00	METAL	4.7K	1%	1/4W	R650	1-215-882-00	METAL OXIDE	22 5% 2W F
R573	1-216-089-91	RES,CHIP	47K	5%	1/10W	R652	1-215-900-11	METAL OXIDE	22K 5% 2W F
R577	1-215-913-11	METAL OXIDE	220	5%	3W F	R653	1-215-873-00	METAL OXIDE	4.7K 5% 1W F
R578	1-216-369-00	METAL OXIDE	1	5%	2W F	R657	1-260-127-11	CARBON	220K 5% 1/2W
R579	1-216-097-91	RES,CHIP	100K	5%	1/10W	R659	1-216-049-91	RES,CHIP	1K 5% 1/10W
R580	1-208-830-11	RES,CHIP	100K	0.50%	1/10W	R660	1-216-073-00	RES,CHIP	10K 5% 1/10W
R581	1-208-798-11	RES,CHIP	4.7K	0.50%	1/10W	R661	1-215-873-00	METAL OXIDE	4.7K 5% 1W F
R585	1-249-391-11	CARBON	6.8	5%	1/4W F	R901	1-249-411-11	CARBON	330 5% 1/4W
R588	1-215-888-00	METAL OXIDE	220	5%	2W F	R903	1-216-022-00	RES,CHIP	75 5% 1/10W
R589	1-215-888-00	METAL OXIDE	220	5%	2W F	R904	1-216-033-00	RES,CHIP	220 5% 1/10W
R590	1-215-465-00	METAL	68K	1%	1/4W	R905	1-216-113-00	RES,CHIP	470K 5% 1/10W
R591	1-260-288-11	CARBON	0.47	5%	1/2W F	R906	1-216-077-91	RES,CHIP	15K 5% 1/10W
R593	1-260-288-11	CARBON	0.47	5%	1/2W F	R909	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R594	1-260-288-11	CARBON	0.47	5%	1/2W F	R910	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R596	1-216-485-11	METAL OXIDE	5.6K	5%	3W F	R911	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R597	1-247-750-11	CARBON	680	5%	1/2W F	R912	1-216-041-00	RES,CHIP	470 5% 1/10W
R598	1-249-438-11	CARBON	56K	5%	1/4W	R913	1-216-049-91	RES,CHIP	1K 5% 1/10W
R599	1-249-389-11	CARBON	4.7	5%	1/4W	R914	1-216-055-00	RES,CHIP	1.8K 5% 1/10W
R600	1-249-438-11	CARBON	56K	5%	1/4W	R915	1-216-061-00	RES,CHIP	3.3K 5% 1/10W
R601	1-249-418-11	CARBON	1.2K	5%	1/4W F	R916	1-216-017-91	RES,CHIP	47 5% 1/10W
R602	1-249-389-11	CARBON	4.7	5%	1/4W F	R917	1-216-041-00	RES,CHIP	470 5% 1/10W
R603	1-215-485-00	METAL	470K	1%	1/4W	R918	1-216-041-00	RES,CHIP	470 5% 1/10W

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952



The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK
<RELAY>			
	RY601 Δ 1-755-266-11	RELAY	
<SWITCH>			
S502	1-572-707-11	SWITCH, LEVER	
S600	Δ 1-571-433-21	SWITCH, PUSH (AC POWER)	
S901	1-692-431-21	SWITCH, TACTILE	
S902	1-692-431-21	SWITCH, TACTILE	
S903	1-692-431-21	SWITCH, TACTILE	
S904	1-692-431-21	SWITCH, TACTILE	
S905	1-692-431-21	SWITCH, TACTILE	
S906	1-692-431-21	SWITCH, TACTILE	
S907	1-692-431-21	SWITCH, TACTILE	
<TRANSFORMER>			
T501	1-437-195-11	TRANSFORMER, HORIZONTAL DRIVE	
T503	Δ 1-453-293-11	TRANSFORMER ASSY, FLYBACK (NX-1748//M3A4)	
T601	1-424-682-11	TRANSFORMER, LINE FILTER	
T603	Δ 1-433-512-31	TRANSFORMER, CONVERTER (SRT)	
T604	Δ 1-431-852-11	TRANSFORMER, CONVERTER (SRT)	
<THERMISTOR>			
THP600	1-810-961-11	THERMISTOR, POSITIVE	
<TUNER>			
TU101	8-598-447-00	TUNER, FSS BTF-LG411 (except KV-PF21N70/PF21M70)	
TU101	8-598-430-00	TUNER, FSS BTF-FA401 (KV-PF21N70 only)	
TU101	8-598-449-10	TUNER, FSS BTF-LG433 (KV-PF21M70 only)	
<CRYSTAL>			
X001	1-579-125-11	VIBRATOR, CERAMIC	
X301	1-781-134-21	VIBRATOR, CRYSTAL	
X302	1-781-132-21	VIBRATOR, CRYSTAL (except KV-PF21Q40/PF21Q70/PF21DK7)	
***** * *****			
* A-1331-884-A C3 BOARD MOUNTED *****			
	7-682-948-01	SCREW +PSW 3X8	
<CAPACITOR>			
C701	1-162-114-00	CERAMIC	0.0047MF 2KV
C702	1-102-074-00	CERAMIC	0.001MF 50V
C703	1-107-651-11	ELECT	4.7MF 20% 250V
C704	1-130-202-00	FILM	0.022MF 5% 400V
C706	1-104-664-11	ELECT	47MF 20% 16V
C708	1-102-114-00	CERAMIC	470PF 10% 50V
C709	1-102-114-00	CERAMIC	470PF 10% 50V

REF. NO.	PART NO.	DESCRIPTION	REMARK
C710	1-102-114-00	CERAMIC	470PF 10% 50V
C712	1-102-116-00	CERAMIC	680PF 10% 50V
C713	1-102-116-00	CERAMIC	680PF 10% 50V
C714	1-102-116-00	CERAMIC	680PF 10% 50V
C716	1-126-933-11	ELECT	100MF 20% 16V
C717	1-101-880-00	CERAMIC	47PF 5% 50V
C736	1-102-114-00	CERAMIC	470PF 10% 50V
C737	1-102-114-00	CERAMIC	470PF 10% 50V
C746	1-102-114-00	CERAMIC	470PF 10% 50V
<CONNECTOR>			
CN701	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P	
CN702	1-695-915-11	TAB (CONTACT)	
CN703 *	1-564-509-11	PLUG, CONNECTOR 6P	
CN704	1-695-915-11	TAB (CONTACT)	
<DIODE>			
D701	8-719-911-19	DIODE 1SS119-25	
D702	8-719-911-19	DIODE 1SS119-25	
D703	8-719-911-19	DIODE 1SS119-25	
D707	8-719-911-19	DIODE 1SS119-25	
D708	8-719-911-19	DIODE 1SS119-25	
D709	8-719-911-19	DIODE 1SS119-25	
D710	8-719-911-19	DIODE 1SS119-25	
D711	8-719-911-19	DIODE 1SS119-25	
D712	8-719-911-19	DIODE 1SS119-25	
D713	8-719-911-19	DIODE 1SS119-25	
D714	8-719-911-19	DIODE 1SS119-25	
D715	8-719-911-19	DIODE 1SS119-25	
D716	8-719-911-19	DIODE 1SS119-25	
D717	8-719-121-26	DIODE RD9.1ESL2	
<JACK>			
J701	Δ 1-540-071-22	SOCKET, CRT	
<COIL>			
L701	1-410-667-31	INDUCTOR	22UH
L710	1-408-613-31	INDUCTOR	68UH
L711	1-408-613-31	INDUCTOR	68UH
L712	1-408-613-31	INDUCTOR	68UH
<TRANSISTOR>			
Q704	8-729-326-11	TRANSISTOR 2SC2611	
Q705	8-729-326-11	TRANSISTOR 2SC2611	
Q706	8-729-326-11	TRANSISTOR 2SC2611	
Q707	8-729-200-17	TRANSISTOR 2SA1091-O	
Q708	8-729-200-17	TRANSISTOR 2SA1091-O	
Q709	8-729-200-17	TRANSISTOR 2SA1091-O	
Q710	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q711	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q712	8-729-119-78	TRANSISTOR 2SC2785-HFE	

The components identified by shading
and mark $\triangle$ are critical for safety.
Replace only with part number specified.

KV-PF21N70/PF51P40/PF21P70/PF21Q40

RM-915

RM-952

RM-952


RM-952

KV-PF21Q70/PF21M70/PF21DK7

RM-952

RM-952

RM-952



REF. NO.	PART NO.	DESCRIPTION	REMARK			
<RESISTOR>						
R703	1-249-496-11	CARBON	100K	5%	1/2W	
R705	1-216-380-11	METAL OXIDE	8.2	5%	2W	F
R706	1-215-417-00	METAL	680	1%	1/4W	
R707	1-215-413-00	METAL	470	1%	1/4W	
R708	1-216-379-11	METAL OXIDE	6.8	5%	2W	F
R710	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F
R711	1-247-752-11	CARBON	1K	5%	1/2W	
R712	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F
R713	1-247-752-11	CARBON	1K	5%	1/2W	
R714	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F
R715	1-247-752-11	CARBON	1K	5%	1/2W	
R719	1-215-480-00	METAL	300K	1%	1/4W	
R720	1-249-923-11	CARBON	1K	5%	1/4W	F
R721	1-215-489-00	METAL	680K	1%	1/4W	
R722	1-249-923-11	CARBON	1K	5%	1/4W	F
R723	1-215-479-00	METAL	270K	1%	1/4W	
R724	1-249-923-11	CARBON	1K	5%	1/4W	F
R725	1-249-421-11	CARBON	2.2K	5%	1/4W	
R726	1-249-421-11	CARBON	2.2K	5%	1/4W	
R727	1-249-421-11	CARBON	2.2K	5%	1/4W	
R728	1-249-407-11	CARBON	150	5%	1/4W	
R729	1-249-407-11	CARBON	150	5%	1/4W	
R730	1-249-407-11	CARBON	150	5%	1/4W	
R731	1-249-407-11	CARBON	150	5%	1/4W	
R732	1-249-407-11	CARBON	150	5%	1/4W	
R733	1-249-406-11	CARBON	120	5%	1/4W	
R734	1-247-739-11	CARBON	100	5%	1/2W	
R738	1-247-807-31	CARBON	100	5%	1/4W	
R739	1-247-807-31	CARBON	100	5%	1/4W	
R740	1-247-807-31	CARBON	100	5%	1/4W	
R755	1-249-418-11	CARBON	1.2K	5%	1/4W	
R756	1-249-418-11	CARBON	1.2K	5%	1/4W	
R757	1-249-418-11	CARBON	1.2K	5%	1/4W	
<VARIABLE RESISTOR>						
RV702	1-241-656-21	RES, ADJ, METAL FILM 110M				

* A-1241-355-A		MOUNTED PWB, F	*****			
1-533-223-11		CLIP, FUSE				
* 4-374-846-01		COVER, CAPACITOR, CAP TYPE				
<CAPACITOR>						
C654	 1-117-703-11	CERAMIC	0.0047MF	99%	250V	
C4602	 1-104-708-11	FILM	0.47MF	20%	250V	

REF. NO.	PART NO.	DESCRIPTION	REMARK			
<CONNECTOR>						
CN4601 *	1-580-843-11	PIN, CONNECTOR (POWER)				
CN4602 *	1-580-843-11	PIN, CONNECTOR (POWER)				
CN4603	1-695-915-11	TAB (CONTACT)				
<FUSE>						
F4601	△ 1-532-237-00	FUSE, TIME-LAG (BET) 3.15A/250V				
<RESISTOR>						
R4601	△ 1-202-719-00	SOLID	1M	10%	1/2W	
<TRANSFORMER>						
T4601	1-424-682-11	TRANSFORMER, LINE FILTER				
T4602	1-424-682-11	TRANSFORMER, LINE FILTER				
<VARISTOR>						
VDR461	1-801-073-31	VARISTOR TNR14V471K660				

MISCELLANEOUS						

X-4036-748-3		BEZNET ASSY				
1-416-946-11		COIL, DEMAGNETIC (except KV-PF21N70)				
1-416-946-31		COIL, DEMAGNETIC (KV-PF21N70 only)				
1-417-151-21		MATCHING TRANSFORMER, ANTENNA				
1-452-094-00		CIRCULAR DISC MAGNET B				
1-452-032-00		MAGNET,DISC				
1-501-372-81		ANTENNA, TELESCOPIC				
1-505-740-11		SPEAKER (5X9CM)				
1-574-062-11		CORD, POWER (WITH CONNECTOR) 2.5A/250V (except KV-PF21N70)				
1-575-023-11		CORD, POWER (WITH CONNECTOR) 2.5A/250V (KV-PF21N70 only)				
8-451-505-11		DEFLECTION TOKE (Y21RSA-S)				
△ 8-738-809-05		PICTURE TUBE (A51LPT70X)(except KV-PF21Q40/PF51P40)				
△ 8-738-812-05		PICTURE TUBE (A51LPT70X)(KV-PF21Q40/PF51P40)				

KV-PF21N70/PF51P40/PF21P70/PF21Q40
RM-915 RM-952 RM-952 RM-952
KV-PF21Q70/PF21M70/PF21DK7
RM-952 RM-952 RM-952

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
ACCESSORIES AND PACKING MATERIALS							

	1-417-151-21	MATCHING TRANSFORMER, ANTENNA					
	1-501-372-81	ANTENNA, TELESCOPIC					
	3-701-910-00	SCREW, SPECIAL (DIA. 3.8X20)					
	3-867-184-12	MANUAL, INSTRUCTION					
		(except KV-PF21N70/PF51P40/PF21DK70					
	3-867-184-51	MANUAL, INSTRUCTION (KV-PF21N70)					
	3-867-637-11	MANUAL, INSTRUCTION (KV-PF51P40)					
	3-867-184-61	MANUAL, INSTRUCTION (KV-PF21DK7)					
	4-392-003-11	BAND, HOLD					
	4-392-004-11	CLIP					
*	4-070-297-01	CUSHION(UPPER)(ASSY)					
*	4-070-298-01	CUSHION(LOWER)(ASSY)					
*	4-070-299-01	INDIVIDUAL CARTON					
*	4-395-957-01	BAG, PROTECTION					

REMOTE COMMANDER							

	1-418-163-11	REMOTE COMMANDER (RM-952)					
	9-939-697-01	BATTERY COVER, REMOTE COMMANDER					