

Service Service Service

VR710/02/07/16/39/58


VR765/02/07/16/39/58

VR810/02/07/16/39

VR910/02/07/16/39/58



VR710, VR765



VR810, VR910

Service Manual

Evolution: AA

For technical data reference is made to the Service Manual of APOLLO 20 4822 726 15538. The present Manual states only the differences.

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

Survey of types:

VR710/VR765: Longplay, FM Audio, Tape manager
 VR810: Longplay, FM Audio, Tape manager, Jog/Shuttle
 VR910: Longplay, FM Audio, Tape manager, Jog/Shuttle

Survey of versions:

/02 PAL B/G German Stereo
 /07 PAL I, NICAM
 /16 PAL B/G, NICAM & German Stereo
 /39 PAL B/G & SECAM L, NICAM & German Stereo
 /58 PAL B/G & SECAM BG/DK, NICAM & German Stereo

Survey of remote controls:

VR710/VR765:	english:	RT118/101	8622 661 18101
	french (/39):	RT118/104	8622 661 18104
VR810 :	english:	RT119/101	8622 661 19101
	french (/39):	RT119/104	8622 661 19104
VR910 :	english:	RT517/101	8622 665 17101
	french (/39):	RT517/104	8622 665 17104

Survey of tape decks:

VR710/VR765:	WDQT-S4/2	4 Video+ 2 FM-Audio Heads
VR810, VR910:	WDQT-S4/2S	4 Video+ 2 FM-Audio Heads
		Swing search



PHILIPS

Table of contents

	Page		Page
Chapter 1		Chapter 4	
TECHNICAL DATA AND FEATURES		TAPE DECK	
Front page	1-1	<i>Deck parts replacement</i>	
Table of contents	1-2	Auxiliary tools for deck adjustment	4-1
Survey of sets and features	1-3	Deck layout diagrams	4-2
Survey of sets and PCBs, Technical specifications	1-4	Lift	4-2
Safety instructions	1-5/6	Head disc	4-3
Direction for use	1-7	A/C Head	4-4
		Threading motor	4-4
		Capstan motor	4-4
		Pressure roller	4-4
		Roller unit right	4-4
		Roller unit left	4-5
Chapter 3		<i>Adjustments</i>	
PRINTED BOARDS		Tape path	4-5
Adjustment procedures	3-1	„Roller unit left; roller unit right“	4-5
List of abbreviations	3-2	A/C Head	4-5
Wiring diagram	3-3	Horizontal distance	4-6
Block diagram Video	3-4/5	Brake band	4-6
Block diagram Audio	3-6/7	Tape tension adjustment	4-6
Block diagram Digital	3-8/9	Friction clutch control	4-6
Block diagram power part	3-10/11	Reverse brake control	4-6
<i>Power supply ASM</i>		Top view, Underside view	4-7
PCB drawing ASM	3-12	<i>Exploded view</i>	
Circuit diagram ASM	3-13	Cleaning and lubrication	4-8/9
<i>Mother Board</i>		Parts list	4-10
PCB drawing Mother Board	3-14/17		
Circuit diagram (PS)	3-18		
Circuit diagram Front End (FV)	3-20		
Circuit diagram Stereo Decoder (FM_STEREO_TDA)	3-22		
Circuit diagram Stereo Decoder (FM_STEREO_MSP)	3-23		
Audio FM (AF) circuit diagram	3-24		
Circuit diagram Erase Oscillator (ER)	3-25		
Audio linear-AL circuit diagram	3-26		
Video Signal Processing (VS) circuit diagram	3-29		
Head Amplifier (HA) circuit diagram	3-30		
SECAM Processing (VS_SEC) circuit diagram	3-33		
Chroma Noise Reduction (CNR) circuit diagram	3-34		
In/Out (IO) circuit diagram	3-35		
Central Control (AIO1) circuit diagram	3-36		
Deck Electronics (DE) circuit diagram	3-39		
Central Control (AIO2) circuit diagram	3-40		
On Screen Display (VPO) circuit diagram	3-41		
Circuit diagram FOME, VPS, PE	3-42		
<i>Display Control ADCP18</i>			
PCB drawing ADCP18	3-44		
Circuit diagram ADCP18 (DC)	3-45		
<i>Connector PCB ACP18</i>			
PCB drawing ACP18	3-46		
Circuit diagram ACP18	3-47		
		Chapter 5	
		PARTS LIST	
		Exploded view of cabinet parts	5-2
		Cabinet parts	5-3
		Power supply	5-4
		Mother Board	5-5/11
		Display Control ADCP18	5-12
		Connector PCB ACP18	5-13

Features

[illegible]

PCBs & Tape Decks

	POWER SUPPLY	MOTHER BOARD	DISPLAY CONTROL				TAPE DECK	
	ASM1	AMB	ADCP18	ADCP18.1	ACP18	ACP18.1	WDQT-S4/2	WDQT-S4/2S
VR710; VR765 /02	•	•	•		•		•	
VR710; VR765 /07	•	•	•		•		•	
VR710; VR765 /16	•	•	•		•		•	
VR710; VR765 /39	•	•	•		•		•	
VR710; VR765 /58	•	•	•		•		•	
VR810/02	•	•		•	•			•
VR810/07	•	•		•	•			•
VR810/16	•	•		•	•			•
VR810/39	•	•		•	•			•
VR910/02	•	•		•		•		•
VR910/07	•	•		•		•		•
VR910/16	•	•		•		•		•
VR910/39	•	•		•		•		•
VR910/58	•	•		•		•		•

(GB)

Technical Data

Mains voltage
Mains frequency
Power consumption:
 with Low Power Standby
Ambient temperature
Relative humidity
Weight
Fast forward/rewind time
Position of use
Video resolution
Audio

(D)

Technische
Daten

Netzspannung
Netzfrequenz
Leistungsaufnahme:
 Standby mit geringem Verbrauch
Raumtemperatur
Relative Luftfeuchtigkeit
Gewicht
Vor-/Rückspulzeit
Betriebslage
Video-Auflösung
Audio

(F)

Caractéristiques

Tension secteur 220 – 240 V
Fréquence 47 – 63 Hz
Puissance absorbée: 16 W during operation
 avec la fonction veille faible consommation < 4 W
Température ambiante +10°C to +35°C
Humidité relative 20 – 80 %
Poids 4.3 kg
Temps (re-)bobinage typ. 95s (E180 cass.)
Position d'emploi horizontally, max. 15°
Résolution vidéo ≥ 240 lines VHS
Audio SP: 80Hz – 10kHz (±8dB)
Audio LP: 80Hz – 5kHz (±8dB)
FM Audio: 20Hz – 20kHz (±3dB)

(NL)

Technische
Gegevens

Netspanning
Netfrequentie
Opgenomen vermogen:
 met Low Power Standby
Omgevingstemperatuur
Relatieve vochtigheid
Gewicht
Vooruit/terugspoeltijd
Gebruikspositie
Oplossend vermogen
Audio

(E)

Datos Tecnicos

Tensión de red
Frecuencia de red
Consumo de potencia:
 con standby de bajo consumo
Temperatura ambiente
Humedad relativa
Peso
tiempo de (re-)bobinado
Posición de uso
Resolución video
Audio

(I)

Dati Tecnici

Tensione di alimentazione 220 – 240 V
Frequenza di rete 47 – 63 Hz
Potenza assorbita: 16 W during operation
 in attesa a basso consumo < 4 W
Temperatura ambiente +10°C to +35°C
Umidità relativa 20 – 80 %
Peso 4.3 kg
Tempo di (ri-)avvolgimento typ. 95s (E180 cass.)
Posizione di funzionamento horizontally, max. 15°
Risoluzione video ≥ 240 lines VHS
Audio SP: 80Hz – 10kHz (±8dB)
Audio LP: 80Hz – 5kHz (±8dB)
FM Audio: 20Hz – 20kHz (±3dB)

Safety instructions

- Safety regulations demand that the set be restored to its original condition and that components identical with the original types be used.

Safety components are marked by the symbol 

- All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair may reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools on the same potential.
- A set to be repaired should always be connected to the mains via a suitable isolating transformer.
- Never replace any modules or any other parts while the set is switched on.
- Use plastic instead of metal alignment tools. This in order to preclude short-circuit or to prevent a specific circuit from being rendered unstable.

Remarks

- The direct voltages and oscillograms ought to be measured relative to the set mass.
EXCEPTION
At the power supply, the DC voltages and the oscillograms at the primary side are measured to LIVE GND.
- The direct voltages and oscillograms mentioned in the diagrams ought to be measured with a colour bar signal and the picture carrier at 503.25 MHz (C25).
- The oscillograms and direct voltages have been measured in RECORD or PLAY mode.
- The semiconductors, which are mentioned in the circuit diagram and in the parts lists, are fully exchangeable per position with the semiconductors in the set, irrespective of the type designation of these semiconductors.

Sicherheitshinweise

- Die Sicherheitsvorschriften erfordern es, daß sich das Gerät nach der Reparatur in seinem originalen Zustand befindet und daß die zur Reparatur benutzten Ersatzteile mit den Originalersatzteilen identisch sind.

Sicherheits-Bauteile sind mit der Markierung  versehen

- Alle IC's und Halbleiter sind empfindlich gegen elektrostatische Entladungen (ESD). Unvorschriftsmässige Behandlung von Halbleitern im Reparaturfall kann zur Zerstörung dieser Bauteile oder zu einer drastischen Reduzierung der Lebensdauer führen. Sorgen Sie dafür, daß Sie sich im Reparaturfall über ein Armband mit Widerstand auf dem gleichen Potential, wie die Masse des Gerätes befinden. Alle Bauteile, Werkzeuge und Hilfsmittel sind auf das gleiche Potential zu legen.
- Ein zu reparierendes Gerät ist immer über einen Trenntransformator an die Netzspannung anzuschließen.
- Bei eingeschaltetem Gerät dürfen keine Module oder sonstige Einzelteile ausgetauscht werden.
- Zum Abgleich sind ausschließlich Kunststoffwerkzeuge zu benutzen (keine Metallwerkzeuge verwenden). Dadurch wird vermieden, daß ein Kurzschluß entstehen kann oder eine Schaltung instabil wird.

Anmerkungen

- Die Gleichspannung und Oszillogramme sind gegen Gerätemasse zu messen.
AUSNAHME
Beim Netzteil sind die Gleichspannungen und Oszillogramme auf der Primärseite gegen Live GND gemessen.
- Die Gleichspannungen und Oszillogramme angeführt in den Schaltbildern sollen unter folgenden Bedingungen gemessen werden: Farbbalkensignal, Bildträger auf 503.25 MHz (C25)
- Die Oszillogramme und Gleichspannungen sind in RECORD oder PLAY gemessen. Die in den Stücklisten aufgeführten Bauteile sind positionsweise voll auswechselbar gegen die Bauteile in dem Gerät, ungeachtet der etwaigen Typenbezeichnungen.

Avertissements

- Les normes de sécurité exigent qu'après réparation l'appareil soit remis dans son état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées.

Les composants de sécurité sont marqués 

- Tout les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD). Leur longévité pourrait être considérablement écourté par le fait qu'aucune précaution n'est prise à leur manipulation. Lors de réparations s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfiler le bracelet serti d'une résistance de sécurité. Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.
- Toujours alimenter un appareil à réparer à travers un transfo d'isolement.
- Ne jamais remplacer les modules ni d'autres composants quand l'appareil est sous tension.
- Pour l'ajustage, utiliser des outils en plastique au lieu d'instruments métalliques. Ceci afin d'éviter les court-circuits et exclure l'instabilité dans certains circuits.

Observations

- La mesure des tensions continues et des oscillogrammes doit se faire par rapport à la terre de l'appareil.
EXCEPTION
Sur l'unité d'alimentation la tension continue et l'oscillogramme sont mesurés sur le côté primaire en Live GND.
- La mesure des tensions continues et des oscillogrammes figurant sur le schéma doit se faire dans un signal de barre couleur porteuse image sur 503.25 MHz (C25).
- Les oscillogrammes et tension sont mesurées en mode RECORD ou PLAY.
- Les semi-conducteurs indiqués dans le schéma de principe et à la liste des composants, sont interchangeables par repère sur ce châssis avec les semi-conducteurs de l'appareil quelle que soit la désignation de type donnée sur ces semi-conducteurs.

Veiligheidsinstructies

- Veiligheidsbepalingen vereisen, dat het apparaat in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, indientiek aan de oorspronkelijke, worden toegepast.

De veiligheidsonderdelen zijn aangeduid met het symbool 

- Alle IC's en vele andere halfgeleiders zijn gevoelig voor elektrostatische ontladingen (ESD). Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen. Zorg ervoor, dat U tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat. Houd componenten en hulpmiddelen ook op hetzelfde potentiaal.
- Sluit een apparaat dat gerepareerd wordt altijd via een scheidingstransformator aan op de netspanning.
- Verwissel nooit modules of andere onderdelen terwijl het apparaat is ingeschakeld.
- Gebruik voor het afregelen plastic i.p.v. metalen gereedschap. Dit om mogelijke kortsluiting te voorkomen of een bepaalde schakeling instabiel te maken.

Opmerkingen

- De gelijkspanningen en oscillogrammen dienen gemeten te worden ten opzichte van de apparaat aarde.
- De gelijkspanningen en oscillogrammen vermeld in de schema's dienen gemeten te worden met een kleurbalkensignaal beeldtraagloopp op 503.25 MHz (C25).
- De oscillogrammen en gelijkspanningen zijn in RECORD of PLAY mode gemeten.
- De halfgeleiders, die in het princieschema en in de stuklijsten, zijn vermeld, zijn per positie volledig uitwisselbaar met de halfgeleiders in het apparaat, ongeacht de typeaanduiding op deze halfgeleiders.

Avvertimenti

- Le prescrizioni di sicurezza richiedono che l'apparecchio sia ricondotto alle condizioni originali e che siano usati ricambi originali.

Componenti di sicurezza sono marcati con 

- Tutti gli IC e semiconduttori sono sensibili a scariche elettrostatiche (ESD). Noncuranze durante la riparazione di semiconduttori possono danneggiarli o condurre ad una riduzione drastica della durata. Durante la riparazione assicurarsi di essere collegati allo stesso potenziale attraverso un bracciale di protezione contro scariche elettrostatiche. Inoltre tenere anche tutti i componenti e gli attrezzi a questo potenziale.
- Apparecchi da riparare bisogna collegarli sempre via un trasformatore isolante (separatore) alla tensione normale.
- Non scambiare moduli o altri componenti quando l'apparecchio è in funzione.
- Per l'accordo usare soltanto attrezzi di plastica (non usare attrezzi metallici). Così si evitano cortocircuiti e collegamenti instabili.

Osservazioni

- Misurare le tensioni continue e gli oscillogrammi riferendosi alla massa dell'apparecchio.
ECCEZIONE
Le tensioni continue e gli oscillogrammi dall'alimentatore sono misurati sulla parte primaria contro GND-Live.
- Le tensioni continue e gli oscillogrammi indicati negli schemi di collegamento devono essere misurati secondo le condizioni seguenti: segnale barre colore, portante dell'immagine su: 503.25 MHz (C25).
- Gli oscillogrammi e le tensioni continue sono misurati in RECORD o PLAYBACK.
- I componenti indicati nelle liste sono intercambiabili con quelli nell'apparecchio nonostante l'eventuale denominazione di modelli.

Avisos

- Las instrucciones de seguridad exigen que después de la reparación el aparato se encuentre en el estado original y que las piezas de repuesto, utilizadas para la reparación, sean idénticas a las originales.

Los componentes de seguridad estan marcados con 

- Todos los IC y semiconductores son sensibles a descargas electrostáticas (ESD). Un tratamiento no conforme a las instrucciones de semiconductores en caso de reparación, podría llevar a la destrucción de estos componentes, o a una reducción drástica de la duración. Tenga cuidado de que, en caso de reparación, estar al mismo potencial que la masa del aparato, por una pulsera con resistencia. Ponga todos los componentes, herramientas y recursos al mismo potencial.
- Para reparar un aparato hay que conectarlo siempre a la alimentación a través de un transformador de aislamiento.
- Cuando un aparato está en marcha no pueden ser cambiados módulos u otras piezas de repuesto.
- Para los ajustes hay que utilizar exclusivamente herramientas de plástico (nunca herramientas metálicas). Así se evitan cortocircuitos y circuitos inestables.

Notas

- Hay que medir las tensiones continuas y los oscilogramas contra la masa del aparato.
UITZONDERING:
Bij het netgedeelte zijn de gelijkspanningen en oscillogrammen aan de primaire kant tegen Live GND gemeten.
- Las tensiones continuas y los oscilogramas mencionados en los esquemas tienen que ser medidos de manera siguiente: señal barra de color portadora de imagen en 503.25MHz (C25)
- Los oscilogramas y las tensiones continuas son medidas en „RECORD“ y „PLAYBACK“
- Los componentes mencionados en las listas se los puede cambiar por los componentes en el aparato, a pesar de eventuales designaciones de tipos.

Table of contents


3	Initial installation	Setting channel, date and time for the first time	10
		Searching for a TV channel manually	10
		Allocating decoder	11
		Using a satellite receiver	11
		Searching for TV channels automatically	12
		Sorting and clearing of TV channels manually	12
		Sorting TV channels automatically	13
		Changing the time and date	13
		General information	14
		Navigation in the main menu	14
		Adding a cassette to the Tape Manager	14
		Editing recording title	15
4	Settings	Searching for recording title	15
		Displaying contents of cassette	16
		Searching for blank space on tape	16
		Removing cassette from Tape Manager	16
		Copying Tape Manager memory	17
		Playing cassettes	17
5	Operating instructions	Playing back NTSC cassettes	17
		Displaying tape position	18
		Display / reset tape position	18
		Searching for tape position with picture (picture search)	18
		Searching for tape position without picture (forward wind and rewind)	18
		Searching automatically for tape position (index search)	19
6	Tape Manager (TM)	Finding a blank position on tape automatically	19
		Still picture / slow motion	19
		Skipping commercials	19
		Selecting picture setting (Smart Picture)	20
		Optimizing tracking	20
7	Playback	Optimizing still picture	20
		Cleaning video heads	21
		Starting and stopping of recording manually	21
		Starting recording manually and stopping automatically	22
		Lining up manual recordings	22
		Selecting the recording speed	22
8	Removing picture interference	Activate / deactivate direct recording	23
		Making a direct recording	23
		Recording automatically from a satellite receiver	24
		Programming timer with VIDEO Plus+	24
		Problem solving (VIDEO Plus-Programming)	25
		Programming timer without VIDEO Plus+	26
9	Manual recording	Problem solving (Timer programming)	27
		"Turbo Timer"-Recording	27
		Problem solving (Turbo Timer programming)	28
		Delete / check / change programmed recordings	28
		Using the NexTVView Link	28
10	Programmed recordings	Adjusting automatic switch-off	29
		Adjusting the child lock	29
		Replaying cassette continuously	29
		Changing the TV system	30
		Adjusting the OSD information	30
		Audio recording	30
11	Other functions	Dubbing (Audio Dubbing)	31
		Selecting the sound channel	32
		Selecting sound setting (Smart Sound)	32
		Manual mute	32
		Energy-saving mode	32
		Preparing a synchronised re-recording (Synchro Edit)	33
		Making a synchronised re-recording (Synchro Edit)	33
		Adjusting Preroll time	34
		Inserting recordings (Video Insert)	34
		Adapting remote control	35
		Demonstration mode	36
		Adjusting the key illumination	36
		Using the TV remote control	36
		Optimizing the modulator	37
		Switching the modulator on / off	37

Remote control

You will find explanations for the controls and the displays on your video recorder on the second to last page of these operating instructions.



TIP



TAPE MANAGER SMART ☐ SURROUND/SMART MONITOR

STANDBY/ON

SELECT

- Activate / deactivate Tape Manager
- Select picture adjustment
- Select sound setting
- Change between TV reception and video recorder reception
- Switch set on / off
- Interrupt function
- Interrupt programmed recording
- Select function

0-9

TURBO TIMER TIMER

CLEAR (CL) MENU OK

↑ / ▸

↓ / ■

← / ◀

→ / ▶

- Enter data
- Select programme number
- Programme Turbo Timer recordings
- Programme recordings
- Check / change recordings
- Delete recordings
- Delete TV channel / entry
- Switch main menu on / off
- Store
- Confirm
- Play back recorded cassette
- Select next menu point
- Select next programme number
- Stop tape
- Select previous menu point
- Select previous programme number
- Select entry field
- In STOP or STANDBY mode: Rewind
- In playback mode: Fast reverse
- Select entry field
- In STOP or STANDBY mode: Wind forward
- In playback mode: Fast forward

TV functions

+ - TV / TV / TV / AV + TV -

- Increase / reduce TV volume
- Switch TV on / off
- Switch TV sound on / off
- Change programme number "E" to scart socket AVI EXT
- Select next / previous programme number

INDEX

COUNTER STILL / JOG ON


RECORD/OTR

- With ◀◀ or ▶▶: Searching for index marking
- Display picture position
- Activate / deactivate Jog and Shuttle on the remote control
- Stop tape and show still picture
- Starting recording manually


Accessories

- | | |
|--------------------------|----------------------|
| ✓ Operating instructions | ✓ Aerial cable |
| ✓ Quick Start Guide | ✓ Mains cable |
| ✓ Remote control | ✓ Scart cable |
| ✓ Batteries | ✓ Coaxial cable (2x) |

Video recorder / display



- 1 **STANDBY/ON**
 - Switch set on/off
 - Interrupt function
 - Interrupt programmed recording
- 2 **AUDIO/VIDEO IN**
 - Connecting the Camcorder, video recorder, sound source (Programme number "FLX" or "E3")
- 3 **MANUAL**
 - Manual mute
- 4 **PROGRAMME - / +**
 - Select previous/next programme number/menu point
- 5 **RECORD**
 - Record
- 6 **STOP/EJECT**
 - During playback: Stop tape
 - In stop or standby mode: Eject tape
- 7 **PLAY**
 - Playback recorded cassette
- 8
 - In stop or standby mode: Rewind tape
 - During playback: Reverse picture search
- In stop or standby mode: Forward wind tape
 - During playback: Forward picture search
- 9 **STILL**
 - Still picture / slow motion




3

Initial installation

Setting channel, date and time for the first time


If your TV set supports the Easylink function and you have already corrected and/or confirmed the settings for year, month, date and time, you can skip this section. Your video recorder has already stored all the necessary details. Please continue by reading the sub-section "Searching for a TV channel manually".



- 1 Using the **OK** button activate the automatic initial installation


"Aim" correctly
Always point the remote control at the video recorder and not at the TV set.

- 2 The set seeks out and stores all available TV channels as well as time and date. This procedure may take several minutes.



PROBLEM
X Despite a continued search the video recorder finds no TV channels ("00 TV CHANNELS FOUND")
✓ Please be patient! The video recorder will search through the entire frequency range in order to identify the maximum possible number of available TV channels. TV channels transmitted in your country may use a higher frequency band. As soon as this range is reached, the video recorder will find all available channels.

- 3 The initial setting of channel, date and time is completed



TIP
The Teletext clock resets automatically
If a TV channel which has Teletext is stored as programme number P01, the video recorder automatically takes in the date and time from the text function. The change from summer to winter time and vice versa should also occur automatically.

Searching for a TV channel manually

In exceptional cases, it may happen that on initial installation the set does not find all the available TV channels. In this case, the missing TV channels must be searched for and stored manually. If your set supports the Easylink function, you can start the automatic transfer of channel data by means of the following steps.

- 1 Switch on the TV set and - if necessary - select the programme number set for video recorder operation

- 2 Press the **MENU** button on the remote control. The on-screen menu appears

What is an on-screen menu?
The on-screen menu takes the mystery out of using your new video recorder. All settings and recording steps can be done easily via the on-screen menu by following the corresponding instructions on the screen.



PARDON?

- 3 Use **↓** or **↑** to select the option "INSTALLATION" and confirm with **→**

- 4 Use **↓** or **↑** to select the option "MANUAL SEARCH" and confirm with **→**

- 5 Use **↓** or **↑** to select the option "CHANNEL/FREQ.," and use **→** or **←** (or **0-9**) to select the type of display desired.

What is hidden behind the settings?
"FREQ.": The frequency display
"CH": The channel display
"S-CH": Entering a special channel




TIP



What is a channel, or a special channel?
TV channels are transmitted on precisely-defined frequency ranges. These ranges are also referred to as "channels". Each channel has its own TV station allocated to it. Most cable and satellite TV providers supply tables of channel allocations. Special channels (hyper-band channels) are transmitted on special frequencies.



PARDON?

- 6 If you already know the frequency or the channel of the TV station you are searching for, use **↓** or **↑** to select the option "ENTRY/SEARCH" and enter the frequency or the channel with the number buttons **0-9**





2 Press the **MENU** button. The on-screen menu appears



What is an on-screen menu?

The on-screen menu takes the mystery out of using your new video recorder. All settings and recording steps can be done easily via the on-screen menu by following the corresponding instructions on the screen.


7

Use **↓** or **↑** to select the option "PROGRAMME NUMBER" and use **→** or **←** (or 0-9) to select the programme position where you wish to store the TV station you have found

PROBLEM

✗ I don't know the channels for my TV stations

✓ No problem. Hold down the button **→** to start the automatic channel search. A changing channel number will appear on screen. Continue the automatic channel search until you have found the desired TV station



PROBLEM

✗ I cannot find the TV channels from my satellite receiver


✓ These do not have to be stored as actual TV channels. On your video recorder, select programme number "E2". Individual TV channels must be selected on the actual satellite receiver itself

8

Store the TV channel you have found with the button **OK**. The screen will show the message "STORED"

9

Finish manual searching of TV channels by pressing the **MENU** button or return to step 6 to allocate additional TV channels



Allocating decoder

If your TV set supports the Easylink function you must allocate the decoder directly to the TV set. If necessary, you should refer to the instructions for your TV set for assistance. If your TV set does not support the Easylink function you must allocate the decoder to the TV set in the following manner.



1

Use **↓** and **↑** or the number keys **0-9** to select the TV channel, which will in future be automatically decoded by your decoder

PARDON?

What is a decoder?

Like a deciphering machine, a decoder (available in TV and video stores) deciphers the TV channels for which additional charges must be paid. Without the appropriate decoder, you will receive these TV channels distorted.



3

Use **↓** or **↑** to select the option "INSTALLATION" and confirm with button **→**

4

Use **↓** or **↑** to select the option "MANUAL SEARCH" and confirm with button **→**

5

Use **↓** or **↑** to select the option "DECODER" and use **→** or **←** to select the setting "ON" (Decoder activated) or "OFF" (Decoder deactivated)

6

Confirm with **OK** and leave the on-screen menu with the **MENU** button. The screen will briefly show the message "STORED"



Check decoder allocation at a glance

There is no need to call up the on-screen menu to check to which TV channel on the video recorder a decoder is allocated. Simply use **↓** and **↑** to select a TV channel. If "DEC" appears in the display, a decoder is allocated to this channel.






Using a satellite receiver

Those TV channels which are received via a satellite receiver connected (to the scart socket AV2 EXT2) can be viewed on the video recorder on programme number "E2". Press the number button **0** on the remote control and then the button **↓** to select this programme number. The TV channels of the satellite receiver are selected not on the video recorder itself, but directly on the satellite receiver.

4 Settings

Searching for TV channels automatically

On initial installation, the video recorder performs an automatic channel search. If the channel assignments of your cable or satellite TV provider change or if you are reinstalling the video recorder, e.g. after moving house, you can start this procedure again. The video recorder finds all the available TV channels and stores the new settings. If your set supports the Easylink function, you can start the automatic transfer of channel data by means of the following steps.



- 1 Switch on the TV set and - if necessary - select the programme number set for video recorder operation
- 2 Press the **MENU** button on the remote control. The on-screen menu appears
- 3 Use **↓** or **↑** to select the option "INSTALLATION" and confirm with **→**
- 4 Use **↓** or **↑** to select the option "AUTOINSTALL" (automatic channel search) and confirm with **→**



TIP
Sequence of TV channels
TV channels are stored in the following sequence:
BBC1, BBC2, ITV, CH 4, CH 5, others.






- 5 The set seeks out and stores all available TV channels. This procedure may take several minutes
- 6 End the automatic channel search with the **MENU** button



PROBLEM
✗ The video recorder is not finding all the TV channels
✓ In exceptional cases, it may happen that the set does not find all the available TV channels. In this case, the missing TV channels must be searched for and stored manually. You can look up how to do this in the chapter "Initial installation" ("Searching for a TV channel manually").

Sorting and clearing of TV channels manually



After you have performed the automatic channel search you may not agree with the sequence in which the individual TV channels have been allocated to the programme positions of the video recorder. You can use this function to individually sort the TV channels found or to delete unwanted TV channels or those with poor reception. If your TV set supports the Easylink function, you will not need to rearrange the TV channels later. The sequence corresponds to the channel allocation of your TV set.



- 1 Switch on the TV set and - if necessary - select the programme number set for video recorder operation
- 2 Press the **MENU** button on the remote control. The on-screen menu appears
- 3 Use **↓** or **↑** to select the option "INSTALLATION" and confirm with **→**
- 4 Use **↓** or **↑** to select the option "TV CHANNEL ALLOCATION" and confirm with **→**
- 5 Use the buttons **↓** or **↑** to select the TV channel which is to be allocated to a programme position and confirm with **→**
- 6 **Delete:** Delete the TV channel which has been set with **CLEAR (CL)**
Sorting: Allocate the selected TV channels with the buttons **↓** or **↑** to the desired programme position and confirm with **←**
- 7 Repeat the steps 5 and 6 to allocate additional TV channels or to delete additional unwanted TV channels
- 8 Use **OK** to store and finish the manual sorting/clearing of TV channels with the **MENU** button (the screen will show the message "STORED")

Sorting TV channels automatically (Follow TV)

After you have performed the automatic channel search you may not agree with the sequence in which the individual TV channels have been allocated to the programme positions of the video recorder. With this function, the video recorder arranges the stored TV channels in the same sequence as on the TV set. If your TV set supports the Easylink function, you will not need to rearrange the TV channels later. The sequence corresponds to the channel allocation of your TV set.



How does "Follow TV" function?

The video recorder compares the TV channels stored on the TV set at programme position 01 with its own programme position memory. If it finds a match, it also allocates the corresponding TV channel to programme position 01.



PARDON?

- 1 Switch on the TV set and - if necessary - select the programme number set for video recorder operation
- 2 Press the **MENU** button on the remote control. The on-screen menu appears
- 3 Use **↓** or **↑** to select the option "INSTALLATION" and confirm with **→**
- 4 Use **↓** or **↑** to select the option "FOLLOW TV" and confirm with **→**
- 5 Press **OK**. The display will show "TV 01".
- 6 On the TV set select the corresponding programme number ("TV 01") and confirm with **OK** on the remote control of the video recorder

- 7 The video recorder stores the TV channel on the programme number "01". The display will show "TV 02". Repeat step 6 until all available TV channels are allocated



X The screen will show "TV 01".
Unfortunately your TV set does not support this function. Please read "Sorting / deleting channels manually".

PROBLEM

- 8 Finish with the **MENU** button

1

2

3

4

5

6

7

8

1

2

3

4

5

6

7

8

Changing the time and date

If the display shows an incorrect time or "00:00", the time and date must be set manually.

- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "INSTALLATION" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "TIME/DATE" and confirm with **→**








TIP

Enter the values correctly

Numbers less than 10 must be entered with an additional "0". For "9" thus "09" should be entered.

- 4 Use **↓** or **↑** to select the option "TIME" and - if the displayed setting is incorrect - enter the current time with the number buttons **0-9** or with **→** or **←**
- 5 Use **↓** or **↑** to select the option "YEAR" and - if the displayed setting is incorrect - enter the current year with the number buttons **0-9** or with **→** or **←**
- 6 Use **↓** or **↑** to select the option "MONTH" and - if the displayed setting is incorrect - enter the current month with the number buttons **0-9** or with **→** or **←**
- 7 Use **↓** or **↑** to select the option "DATE" and - if the displayed setting is incorrect - enter the current date with the number buttons **0-9** or with **→** or **←**
- 8 Check the settings displayed for year, month, date and time and store them by pressing **OK**. The display will show "STORED".
- 9 Leave the on-screen menu with the **MENU** button



5

Operating instructions

General information

Switching on

If the video recorder is in standby mode, it can be switched on either by pressing the Standby button **⏻** or by pressing one of the number buttons 0-9 or by inserting a cassette.

Automatic switch-off

If the video recorder is not used for several minutes, it switches itself off automatically. This function can be deactivated (e.g. if you want to use the video recorder as a TV receiver). You can find out more about this in the chapter "Other functions" ("Adjusting automatic switch off").

Energy consumption

The video recorder should always be connected to the mains so as not to affect programmed recordings and use of the TV set. Power consumption (in energy saving mode) is less than 4W.

Saving energy

In standby mode, the display of the video recorder shows the current time. This display can be deactivated manually, in order to reduce power consumption to a minimum in standby mode. You can find the necessary steps in the section "Other functions" ("Energy-saving mode").

Emergency exit

The video recorder and the remote control have the option of an "Emergency exit". You can use the Standby button **⏻** to interrupt any step during use. But even without an "emergency brake", your new video recorder is safe: there is no risk whatsoever of damaging the set by performing user steps incorrectly.


In the event of a power cut

Channel data are stored for around 1 year, time and timer data remain in the memory of the video recorder for around 7 hours.

Navigation in the main menu

You can check and / or change many functions and settings of your video recorder via the main menu. The individual functions are selected as follows via the on-screen menu of the video recorder

- Call up: **MENU**
- Select: **↑ and ↓ or →**
- Confirm: **OK**
- Enter: **0-9, or → and ←**
- Interrupt: **STANDBY/ON ⏻**
- Abandon: **MENU**



GENERAL INFORMATION / NAVIGATION

ENGLISH

6

Tape Manager (TM)

Adding a cassette to the Tape Manager

What is a Tape Manager (TM)?

This databank, which is integrated in your video recorder, makes a note of all recordings performed with this set. This means that by simply pressing a button, you can not only access an overview of your entire video collection, you will also know which film is on which cassette or how many minutes of this cassette have not yet been recorded on. And: At the touch of a button, the video recorder automatically winds backward or forwards to the start of a recording or to a blank part of the tape.

PARDON?

1 Switch on the TV set and - if necessary - select the programme number set for video recorder operation

2 Insert a blank cassette which is ready for recording

Never use cassettes which have already been recorded on.

Warning: Only blank cassettes or those already included in the Tape Manager can be managed by the Tape Manager. Recordings made by other video recorders (without the Tape Manager function) will not be recognised by the Tape Manager.

TIP

3 The inserted cassette will be searched for existing Tape Manager titles

4 The screen will show the message "THIS CASSETTE IS EMPTY."

5 Press OK to allocate this cassette to the Tape Manager.



I can see a cassette number and an overview of the recordings on it.

- ✓ You have inserted a cassette which has already been included in the Tape Manager and contains a recording. If there is still enough blank playing time on it, you can use this cassette for the current recording.
- ✗ I cannot see any information about the content of the inserted cassette
 - ✓ Then it is a cassette which has been recorded by a different video recorder. This cassette cannot be included in the memory of the Tape Manager.


PROBLEM

ENGLISH

TAPE MANAGER



TAPE MANAGER



- 6 The cassette will be assigned a number. Please write this number on the cassette accordingly. The Tape Manager may ask you, when searching for blank parts of a tape or for existing recordings, to insert the cassette with this number
- 7 The cassette is ejected. The video recorder will immediately recognise that this cassette is included in the Tape Manager. In future, after insertion, the number and cassette content will automatically be displayed on the screen
- 8 Finish with the button **TAPE MANAGER**



TIP

Tape Manager can manage up to 150 cassettes
Up to 150 cassettes or up to 210 recording titles can be managed in the memory of the Tape Manager.

Edit recording title

What is a recording title?

Each cassette entered in the Tape Manager has a "List of contents" that displays all the recordings on it. It shows the recording title and the duration of the corresponding recording. Some TV stations transmit the title of a programme. In this case, the title will be included automatically (e.g. "rocky"). If the title is not transmitted, only the date and time of the recording will appear in the list of contents. The title of the recording can only be changed after the completed recording has been entered. To do this, it is not necessary to insert the corresponding cassette.



PARDON?

- 1 On the remote control, press the button **TAPE MANAGER**

- 2 Use **↓** or **↑** to select the option "EDIT A TITLE" and confirm with **→**



- 3 The list of contents of a cassette included in the Tape Manager will be shown on the screen

Display correct list of contents




If there is a cassette in the video recorder, which is included in the Tape Manager, the list of contents of this cassette will be displayed automatically.



TIP



EDIT RECORDING TITLE



- 4 Select - if necessary - using **→** or **←** the number of the cassette whose list of contents is to be revised
- 5 Use **↓** or **↑** to select the recording title which you want to revise, and confirm with **→**
- 6 Use **→** or **←** to select the letters / digits to be altered and change them with the buttons **↓** or **↑**
- 7 Store, once all changes have been made, using the button **OK**
- 8 Go back to step 5, to revise additional recording titles, or finish with the button **TAPE MANAGER**

Searching for recording title

- 1 On the remote control, press the button **TAPE MANAGER**

- 2 Use **↓** or **↑** to select the option "FIND A TITLE" and confirm with **→**

- 3 A list of all recording titles included in the Tape Manager will be displayed

- 4 Use **↓** or **↑** to select the recording title which you want to play back, and confirm with **OK**

- 5 The video recorder winds to the start of the recording selected and starts playback automatically



PROBLEM

X I can see the message "INSERT CASSETTE NUMBER XXXX"

✓ The recording title selected is on the Tape Manager cassette with the number stated ("XXXX"). Please insert the corresponding cassette. The video recorder winds to the start of the selected recording and automatically starts playback.



- 6 If you want to end a search after the beginning of the selected recording, press the button **TAPE MANAGER**

ENGLISH

SEARCHING FOR RECORDING TITLE

Displaying contents of cassette

- 1 On the remote control, press the button **TAPE MANAGER**
- 2 Use **↓** or **↑** to select the option "BROWSE CASSETTES" and confirm with **→**
- 3 The list of contents of a cassette included in the Tape Manager will be shown on the screen



X I can see the text "THIS CASSETTE" and "TH-MEMORY"


✓ You have inserted a cassette which is not included in the Tape Manager. Use **↓** or **↑** to select "THIS CASSETTE". Search the inserted cassette. Continue with step **5** and confirm with **→**.

"TH-MEMORY"

Search all cassettes included in Tape Manager. Continue with step **6** and confirm with **→**.



PROBLEM

- 4 If necessary, you can use **→** or **←** to page through the catalogue of cassettes included in the Tape Manager
 - 5 Delete: Use **↓** or **↑** to select the corresponding recording title "EMPTY" and confirm with **OK**
- Finish: Press **TAPE MANAGER**



Searching for blank space on tape





- 1 On the remote control, press the button **TAPE MANAGER**
- 2 Use **↓** or **↑** to select the option "BROWSE CASSETTES" and confirm with **→**
- 3 The list of contents of a cassette included in the Tape Manager will be shown on the screen



X I can see the text "THIS CASSETTE" and "TH-MEMORY"

✓ You have inserted a cassette which is not included in the Tape Manager. Use **↓** or **↑** to select "THIS CASSETTE" or "TH-MEMORY" and confirm with **→**

PROBLEM



- 4 If necessary, use **→** or **←** to select the number of the cassette which has enough remaining playing time ("EMPTY")
- 5 Use **↓** or **↑** to select the option "EMPTY" and confirm with **OK**
- 6 The video recorder winds to the start of the blank space on the tape and stops the tape

X I can see the message "INSERT CASSETTE NUMBER XXX"

✓ The blank space selected on the tape is in the Tape Manager cassette with the number stated ("XXX"). Please insert the corresponding cassette. The video recorder winds to the start of the blank space on the tape and stops the tape.

PROBLEM

Removing cassette from Tape Manager

Cassettes included in the Tape Manager can be removed from the memory. To do this, the corresponding cassette does not have to be in the video recorder.

- 1 On the remote control, press the button **TAPE MANAGER**
- 2 Use **↓** or **↑** to select the option "REMOVE A CASSETTE NR." and confirm with **→**
- 3 The list of contents of a cassette included in the Tape Manager will be shown on the screen
- 4 If necessary, use **→** or **←** to select the cassette number to be removed from the memory of the Tape Manager and confirm with **OK**
- 5 The screen will show "CASSETTE NUMBER XXX WILL BE REMOVED FROM THE MEMORY". Confirm with **OK** or interrupt with the button **TAPE MANAGER**

TIP


Cassette content will not be deleted!
 The cassette will only be removed from the memory of the Tape Manager. The content will remain unaltered!

Finish with the button **TAPE MANAGER**

7 Playback

Copying Tape Manager memory

If you no longer wish to use a video recorder (henceforth referred to as VCR A), but would still like to use your Tape Manager archive, you can transfer the content of the memory to a second video recorder (henceforth referred to as VCR B). Requirements: 1. VCR B must also be equipped with a Tape Manager System. 2. The memory of the Tape Manager of VCR B must be empty.




- 1 Make sure there are no cassettes in either of the two video recorders and switch VCR A and VCR B off using the Standby button

- 2 Take a scart cable and connect the scart socket AVI EXT1 on the back of VCR A with the scart socket AVI EXT1 on the back of VCR B

- 3 On the front of VCR A, press simultaneously the Record button and the button PROGRAMME -

- 4 On the front of VCR B simultaneously press the Playback button and the button PROGRAMME +

- 5 The data in the Tape Manager will be copied from VCR A to VCR B. This may take several minutes. As soon as the copying procedure has been completed, the display will show "12/11"





X	"12/11" appears in the display of VCR B		PROBLEM
✓	Cassettes had already been included in the Tape Manager of VCR B. It is not possible to perform the copying procedure. Press the Standby button to finish this function		
X	"12/11" appears in the display of VCR B		PROBLEM
✓	There are no cassettes included in the Tape Manager of VCR A. Press the Standby button to finish this function		
X	"ERR" appears in the display of VCR B		PROBLEM
✓	The copying procedure cannot be performed. Perform steps 1 to 5 again		

- 6 Both video recorders switch off automatically. The data in the Tape Manager have been successfully transferred.

Playing cassettes

- 1 Insert a VHS cassette in the cassette opening on the front of the video recorder. The tape will be caught and automatically placed in the correct position. The display will show "001"




What does VHS mean?

The "Video Home System" (VHS) has become the world-wide standard for recording and playback of amateur video cassettes. The popular standard has since been refined. Super-VHS (S-VHS) offers greater sharpness and less noise. Digital-VHS (D-VHS) now only works with digital picture and sound signals. Your video recorder can only record and play standard VHS cassettes.



PARDON?

- 2 Press the Playback button to play the tape



X Picture / sound quality is poor
✓ Please read the chapter "Removing picture interference".

✓ When playing many rental videos or older, poorer quality cassettes, it may not be possible to completely filter out picture and sound interference. There is nothing wrong with the video recorder.



PROBLEM

- 3 Press the Stop button on the remote control (or the Stop/Eject button on the front of the video recorder) to stop playback



- 4 Press the Stop/Eject button on the front of the video recorder to remove the tape



TIP

Automatic switch-off

Many functions (pause, still picture, search, ...) switch themselves off automatically after a short time in order to protect the cassette and to save energy.




Playing back NTSC cassettes

If you are using a PAL TV set which is capable of showing a frame frequency of 60 Hz, you can play cassettes which have been recorded on the NTSC standard (USA, Japan, etc.). During an NTSC playback, some special functions (e.g. still picture) are not possible. The display will show "60/12".

Displaying tape position

If the **COUNTER** button is pressed during playback and recording the current tape position will be briefly displayed on the screen. There are three different types of display available.

- 1 Start playback (Playback button ►) or recording (Record button ●)
- 2 By pressing the button **COUNTER** the current tape position will be displayed on the screen. Each further press of the button **COUNTER** activates the next type of display



What types of display are available to me?

- “COUNTER”: The display shows the number of minutes of tape already played after insertion of the cassette (hours/minutes/seconds)
- “TIME LEFT”: The display shows the remaining playing time to the end of the cassette (hours/minutes)
- “TIME USED”: The actual tape position (from the start of the tape to the present tape position) will be displayed.



PARDON?

As soon as the button **COUNTER** has not been pressed for a few seconds, the display of the tape position disappears again.

3

- ✗ The counter stops running when unrecorded places are found (“COUNTER” display type)
 - ✓ This is normal, and is necessary for technical reasons.
- ✗ The display shows a negative playing time
 - ✓ This may happen, for example, when you insert an incompletely-rewound cassette into the video recorder and rewind it to the start of the tape. Since the display is automatically reset to “00:00:00” when you insert a cassette, the actual start of the cassette for the set is less than zero - thus in the negative range. The tape position is displayed with a minus sign “-”.
- ✗ After inserting a cassette the video recorder shows no remaining playing time
 - ✓ The set needs a little time to calculate the remaining playing time. After a few seconds, the display should change from “-” to the corresponding value



PROBLEM

Display / reset tape position

Call up: **COUNTER**

Reset: **CLEAR (CL)** (only in the “COUNTER” display mode)

Automatic reset

Whenever a cassette is inserted the display is automatically reset to “00:00:00”.



TIP

Searching for tape position with picture (picture search)

- 1 During playback press ◀◀ (rewind) or ▶▶ (forward)
- 2 Interrupt the search wherever you like with the Playback button ▶

Reduced quality

During picture search the picture quality is affected. The sound is switched off.

Different search speeds

If you press ◀◀ or Press ▶▶ twice, the tape speed will increase. Interrupt the search with the Playback button ▶.



TIP

Searching for tape position without picture (forward wind and rewind)

- 1 Stop the tape with the Stop button ■
- 2 Press ◀◀ (rewind) or ▶▶ (forward)
- 3 Interrupt the search wherever you like with the Playback button ▶


Switching between rewind / forward wind and picture search (instant view)

When winding the tape backwards or forwards if you hold down ◀◀ (rewind) or ▶▶ (forward wind), the set will immediately switch without a break to picture search (with picture). When you release the rewind or forward wind button the rewind or forward wind process (without picture) will continue



FOR EXPERTS

Searching automatically for tape position (index search)



- 1 Insert a tape recorded on this video recorder or on another set with index marking


What is an index marking?

At the start of each new recording the video recorder automatically places a magnetic marking - similar to a bookmark - at the appropriate place on the tape. These positions can be found again quickly and easily later by pressing a button.



PARDON?

- 2 Press the Index button and then (next index marking) or (previous index marking)



- 3 The video recorder searches for the desired index marking and automatically switches to playback




PROBLEM

The tape has been stopped

The video recorder was unable to find an index marking on the tape inserted.

Finding a blank position on tape automatically



- 1 Press the Index button and then the Stop button

- 2 The video recorder searches for the next blank part - longer than one minute - of the tape and automatically switches to pause




PROBLEM

The cassette is ejected

The video recorder was unable to find any blank space on the tape inserted

Still picture / slow motion

- 1 To stop the picture, press the Still button during playback
- 2 Keep pressed down to play back the picture in slow motion or press several times in succession in order to move the picture forward frame by frame



Continue playback

Press the Play button to continue playback. Press the Stop button to finish playback




TIP

Skipping commercials

Do you get annoyed by the commercial breaks which are recorded along with your programmes? With the function "Commercial Skip" you can skip these quickly and easily.

- 1 During playback, press button

- 2 The video recorder winds the tape forward for about 2 minutes playing time and then switches to playback again. Repeat step 1 until the end of the commercial break has been reached



Interrupt "Commercial Skip"

During winding, press the button to switch back immediately to playback.




TIP

8

Removing picture interference

Selecting picture setting (Smart Picture)

Using the **SMART** ☐ button the picture settings can be displayed and altered. There are four different settings available.



- 1 Press once on the **SMART** ☐ button. The current picture setting will be displayed
- 2 Press several times on the **SMART** ☐ button to change the picture setting. Each time the button is pressed, the next picture setting will be displayed.

What types of picture setting are available to me?

"NATURAL":	Standard setting (for all types of films)
"DISTINCT":	Emphasises details (e.g. for sports programmes)
"SOFT":	Suppression of interference (when using rented cassettes)
"SHARP":	Increase in sharpness (e.g. for animated films)



PARDON?




- 3 As soon as the **SMART** ☐ button has not been pressed for a few seconds, the last selected picture setting will be accepted.

Play compact VHS cassettes

You can, of course, also use this video recorder to play back compact VHS cassettes. To do this, you will need the appropriate cassette adapter. Its dimensions match those of a normal VHS cassette. The adapter is recognised and treated by the set as a VHS cassette



FOR EXPERTS



Optimizing tracking

- 1 During playback press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "PLAY FUNCTIONS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "MANUAL TRACKING" and confirm with **OK**

What is tracking?

Tracking is the name given to the process of optimizing picture and sound playback. During this process the speed of the tape is adjusted in such a way that all kinds of interference are removed or (in the case of old VHS cassettes) minimised.



PARDON?

- 4 Hold down **→** or **←** until optimal playback quality has been achieved and confirm with **OK**. The screen will show "STORED".

- 5 Leave the on-screen menu with the **MENU** button





TIP

Tracking adjustment is retained

The adjustments made are stored until the cassette is removed. After that the standard tracking adjustment is restored.


Optimizing still picture

- 1 When still picture is activated, press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "PLAY FUNCTIONS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "VERTICAL STABILITY" and confirm with **OK**



Starting and stopping of recording manually

- 1 Switch on the TV set and - if necessary - select the programme number set for video recorder operation




- 2 Insert a cassette without erase protection

What is erase protection?

VHS cassettes can be protected from over-recording by breaking off a thin strip of plastic (arrow). This erase protection can be overridden by sticking one or more strips of adhesive tape tightly over the gap which has been created.

PARDON?

- 3 Use the buttons $\downarrow$ or $\uparrow$ to select the programme number, under which your video recorder has stored the desired TV channel



PROBLEM

X I can't find the TV channels from my satellite receiver

X I want to record from an additional device



✓ Signals from additional devices - such as a camcorder, other video recorder, PCs, etc. - are received via the scart socket of the video recorder. The programme numbers "E" and "E2" are allocated for these sources.

FOR EXPERTS

Selecting the recording speed


You have the option of two playback and recording speeds: Standard Play (SP) offers the usual first-class picture quality. By using Long Play (LP), you can (with somewhat reduced picture quality) for example record about 360 minutes of programmes on a 180 minute cassette. This chapter explains how to set the desired recording speed ("Selecting the recording speed").

- 4 Start recording by pressing the Record button $\bullet$ (remote control or on front of set). The display will show "●".



- 5 End the recording by pressing the Stop button $\blacksquare$

- 4 Hold down $\rightarrow$ or $\leftarrow$ until optimal playback quality has been achieved and confirm with OK. The screen will show "STORED"



PROBLEM

X I can't get optimal quality

✓ When using rental cassettes or older tapes, it may not be possible to get rid of all interference completely

- 5 Leave the on-screen menu with the MENU button

TIP




The setting is retained

The adjustments made are stored until the cassette is removed. Then the still picture standard setting is restored.

Cleaning video heads

If horizontal lines of interference appear during playback, the video heads need cleaning.


- 1 During playback press the MENU button on the remote control. The on-screen menu appears
- 2 Use $\downarrow$ or $\uparrow$ to select the option "PLAY FUNCTIONS" and confirm with $\rightarrow$
- 3 Use $\downarrow$ or $\uparrow$ to select the option "HEAD CLEANING"



Why is it necessary to clean the video heads?

When playing back video tapes, microscopic particles of the tape material build up a layer on the video head. If too much tape material collects, this can affect playback quality. By using the function "Clean video heads", this tape material can be gently removed from the surface of the video heads.

- 4 Press OK, to start the cleaning process. The screen will show "HEAD CLEANING IN PROGRESS"



- 5 Wait until the message disappears and leave the on-screen menu with MENU


CLEANING VIDEO HEADS

ENGLISH

ENGLISH

STARTING / STOPPING RECORDING MANUALLY

Starting recording manually / stopping automatically




- 1 Insert a cassette without erase protection

What is erase protection?

VHS cassettes can be protected from over-recording by breaking off a thin strip of plastic (arrow). This erase protection can be overridden by sticking one or more strips of adhesive tape tightly over the gap which has been created.



- 2 Use the buttons $\downarrow$ or $\uparrow$ to select the programme number, under which your video recorder has stored the desired TV channel



- ✗ I can't find the TV channels from my satellite receiver
- ✗ I want to record from an additional device
- ✓ Signals from additional devices - such as a camcorder, other video recorder, PCs, etc. - are received via the scart socket of the video recorder. The programme numbers "E" and "E2" are allocated for these sources.




Selecting the recording speed

You have the option of two playback and recording speeds: Standard Play (SP) offers the usual first-class picture quality. By using Long Play (LP), you can (with somewhat reduced picture quality) for example record about 360 minutes of programmes on a 180 minute cassette. This chapter explains how to set the desired recording speed ("Selecting the recording speed").



- 3 Press the Record button $\bullet$ several times. The time faded in corresponds to the duration of recording to be selected. Each time the Record button is pressed again this is increased in regular steps (30 minutes). Stop the adjustment when you have reached the desired duration. Recording will start.




Delete entry

The recording period displayed can be reset to "00:00:00" with the CL button.



Lining up manual recordings




When you add a further recording to a cassette, which already has a recording on it, a short blank (flicker) usually appears between the old and the new recording. This is how to avoid such an effect.



- 1 Look at the last minute of the old recording (playback)
- 2 Press the Stop button $\blacksquare$ at the point where you want the new recording to start (the display will show II)
- 3 Press the Record button $\bullet$ in the usual way, to start the new recording

Selecting the recording speed

- 1 Press the MENU button on the remote control. The on-screen menu appears
- 2 Use $\downarrow$ or $\uparrow$ to select the option "RECORDING FUNCTIONS" and confirm with $\rightarrow$
- 3 Use $\downarrow$ or $\uparrow$ to select the option "RECORD SETTINGS" and confirm with $\rightarrow$
- 4 Use $\downarrow$ or $\uparrow$ to select the option "RECORDING SPEED", and use $\rightarrow$ or $\leftarrow$ to select a recording speed




Standard Play / Long Play / Auto Long Play


Standard Play (SP) offers the usual, first-class picture quality. By using Long Play (LP), you can (with somewhat reduced picture quality) for example record about 360 minutes of programmes on a 180 minute cassette. With the Auto Long Play (AUTO) setting, the video recorder calculates, before starting the programmed recording, how much playing time remains on the cassette inserted. Depending on the calculated remaining playing time and the duration of the programmed recording, the recording will be made in Standard Play or Long Play.






- 5 Confirm with OK. The screen will show "STORED"
- 6 Stop selection of recording speed with MENU



Activate / deactivate direct recording



- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "RECORDING FUNCTIONS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "RECORD SETTINGS" and confirm with **→**
- 4 Use **↓** or **↑** to select the option "DIRECT RECORD"



What is a "direct recording"?

The "Direct Record" function means you can record in seconds when the video recorder is switched off. When the Record button is pressed, the video recorder automatically recognises which TV channel has been selected on the TV set and starts to record the corresponding programme.

Requirements: 1. The TV set and video recorder are connected with a scart cable. 2. The TV set supports the "Easylink" function. 3. The "Direct Record" function has been activated in the on-screen menu. 4. There is a cassette ready for recording in the machine!



PARDON!

- 5 Use **→** or **←** to select the setting "ON" to enable direct recordings, or "OFF" to deactivate this function.




PROBLEM

✗ I cannot select "ON" or "OFF"


✓ If the comment "N.A.C.T." appears in the "DIRECT RECORD" option, unfortunately your TV set does not support the "Easylink" function. This means that direct recordings are not possible.

- 6 Confirm the setting with **OK**. The screen will show "STORED"
- 7 Leave the on-screen menu with the **MENU** button



Making a direct recording

- 1 The "Direct Record" function must be activated in the on-screen menu (see previous page). No direct recordings can be made unless this function has been activated



What is a "direct recording"?

The "Direct Record" function means you can record in seconds when the video recorder is switched off. When the Record button is pressed, the video recorder automatically recognises which TV channel has been selected on the TV set and starts to record the corresponding programme.

Requirements: 1. The TV set and video recorder are connected with a scart cable. 2. The TV set supports the "Easylink" function. 3. The "Direct Record" function has been activated in the on-screen menu. 4. There is a cassette ready for recording in the machine!



PARDON!

- 2 Insert a cassette without erase protection



What is erase protection?

VHS cassettes can be protected from over-recording by breaking off a thin strip of plastic (arrow). This erase protection can be overridden by sticking one or more strips of adhesive tape tightly over the gap which has been created.



PARDON!

- 3 Switch off the video recorder with the Standby button **⏻**
- 4 On the TV set, select the channel for the programme you wish to record
- 5 Press the Record button **●** on the video recorder. The video recorder recognises the TV channel on the TV set and automatically records the correct programme
- 6 End the recording by pressing the Stop button **■**



10

Programmed recordings

Recording automatically from a satellite receiver






You can only use this function if you have a satellite receiver which can control other devices via a scart cable

What is a scart cable?

The scart or Euro-AV cable serves as the universal recording and playback connector for picture, sound, and control signals. With this type of connection, there is practically no loss of quality during the signal transfer. We recommend that you use a scart cable when using this video recorder.

PARDON?

- 1 Insert a cassette without erase protection
- 2 Make sure that the satellite receiver is connected to the scart socket AV1 EXT1 or AV2 EXT2 at the back of the video recorder
- 3 Press the MENU button on the remote control. The on-screen menu appears
- 4 Use ↓ or ↑ to select the option "RECORDING FUNCTIONS" and confirm with →
- 5 Use ↓ or ↑ to select the option "RECORD SETTINGS" and confirm with →
- 6 Use ↓ or ↑ to select the option "SAT RECORDING" and use → or ← to select the scart socket ("E1" or "E2"), to which the satellite receiver has been connected (see step 2). Confirm with OK. The screen will show "STORED"
- 7 Leave the on-screen menu with MENU
- 8 Programme the data on the satellite receiver for the desired recording. If necessary, you should refer to the instructions for your satellite receiver for assistance.
- 9 SWITCH OFF THE VIDEO RECORDER WITH THE STANDBY/ON BUTTON ⏻! IF YOU DON'T DO THIS, THE SET WILL NOT RECORD.
When automatic recording has been activated by a satellite receiver, "⏻" will light up in the display



RECORDING AUTOMATICALLY FROM A SATELLITE RECEIVER

ENGLISH

Programming timer with VIDEO Plus+

- 1 Press the TIMER button ⏰

What is a Timer?

The timer controls the programmed recordings of your video recorder. Requirements for a timer which works correctly: The clock in the video recorder must be correctly set or the reception of the TV signal must be as free from interference as possible (for example, if there is interference, the video recorder might not correctly recognise the VPS signal of a TV channel).

PARDON?

- 2 Use ↓ or ↑ to select the option "VIDEOPUS RECORDING" and confirm with →. The VIDEO Plus+ screen will appear.

What is VIDEO Plus+?

A programming system which replaces the often tiresome entry of date, starting time, finish time and programme number by the simple entry of a number up to nine digits long (which can be found in any TV programme listing).

PARDON?

- 3 Use the 0-9 keys to enter the PlusCode programming number of the TV programme selected. Incorrect entries can be deleted with the button CL

Daily / weekly recordings

If you like, you can use SELECT "MO-FR" for recordings, which are repeated daily (Mon-Fri) or "WEEKLY" for recordings, which are repeated each week on the same day.






FOR EXPERTS

- 4 Confirm with OK

✓ I get the error message "PROGRAMME NUMBER ← P-- →"

You have entered a correct PlusCode programming number, but automatic recognition of the correct TV channel has failed. Please enter the programme number under which your video recorder has stored the desired TV channel using the buttons 0-9 and confirm with OK.

PROBLEM



PROGRAMMING TIMER WITH VIDEO Plus+

ENGLISH

Problem solving (VIDEO Plus-Programming)

PROBLEM	SOLUTION
Error message: "PLUSCODE NUMBER ← P →"	A correct PlusCode programming number has been entered - but automatic recognition of the correct TV channel has failed. Please enter the programme number under which your video recorder has stored the desired TV channel using the buttons 0-9 and confirm with OK .
Error message: "PLUSCODE NUMBER WRONG"	The Pluscode programming number entered is incorrect. Please repeat the entry or finish with the button STANDBY/ON .
Error message: "WEEKEND PROGRAMMING NOT POSSIBLE"	The attribute "NO-FR" has been selected for a recording at the weekend. This is only possible for recordings from Monday to Friday. Please repeat the entry or finish with the button STANDBY/ON .
Error message: "SWITCH TO STANDBY - TIMER RECORDING"	A recording was programmed, but the video recorder was not switched into timer mode with the Standby button ⏻ . Press STANDBY/ON ⏻ in order to make the programmed recording. Warning: if you do not do this, the video recorder will not record.
Error message: "NO CASSETTE"	A recording was programmed, but there is no cassette in the machine. Insert a cassette without erase protection ready for recording.
Error message: "MEMORY FULL"	All the available memory locations in your video recorder for timer and VIDEO Plus programming are full. Delete a programmed recording (see chapter "Deleting a programmed recording").
"⏻" and/or "⏻" flash in the display of the video recorder	A recording was programmed, but there is no cassette in the machine. Insert a cassette without erase protection ready for recording. A recording was programmed, but the video recorder was not switched into timer mode with the Standby button ⏻ . Press STANDBY/ON ⏻ in order to make the programmed recording. Warning: if you do not do this, the video recorder will not record.
Cassette is ejected after programming	A cassette with erase protection was inserted. Please deactivate the erase protection or insert another cassette which is ready for recording.
Cassette is ejected during recording	The end of the tape was reached during a programmed recording. The recording could not be completed satisfactorily.
The set cannot be used during recording.	Once started, a recording can only be interrupted by pressing the STANDBY/ON button ⏻ . WARNING: This will not only stop the recording, but it will also delete the programmed recording from the memory of the video recorder.
Year/month/date/time screen appears	The time has not been set or not set correctly. After entering/confirming year, month, date and time you can continue programming.

ENGLISH

PROBLEM SOLVING (VIDEO PLUS-PROGRAMMING)



- 5 The data of previously entered VIDEO Plus recordings are displayed. If necessary select the entry fields with with **→** or **←** and enter date, programme number, start time or end time with **↑**, **↓** or **0-9**

TIMER
VIDEOPLUS PROGRAMMING

LP/AUTO-LP/SP
PRESS SELECT

TO STORE
PRESS OK

DATE PROG START PDC END
21 01 20:00 * 21:30 SP



FOR EXPERTS

Activate VPS/PDC

VPS (Video Programming Service) and PDC (Programme Delivery Control) signals are transmitted by TV channels at the start and end of transmissions and ensure that programmes will be completely recorded, even if they are rescheduled. In the entry field, "START" use **SELECT** to switch recognition of these signals on (*) or off ().

Selecting the recording speed

You have the option of two playback and recording speeds: Standard Play (SP) offers the usual first-class picture quality, and with Long Play (LP) you can for example (with somewhat reduced picture quality) record about 360 minutes on a 180-minute cassette. In Auto Long Play (AUTO), the video recorder recognizes how much remaining playing time is available and automatically selects SP or LP. In the entry field "END" use **SELECT** to enter the required setting.

- 6 Confirm with **OK**. The screen will show "STORED".

- 7 Insert a cassette without erase protection



PARDON?

What is erase protection?

VHS cassettes can be protected from over-recording by breaking off a thin strip of plastic (arrow). This erase protection can be overridden by sticking one or more strips of adhesive tape tightly over the gap which has been created.



- 8 SWITCH OFF THE VIDEO RECORDER WITH THE **STANDBY/ON** BUTTON **⏻**! IF YOU DON'T DO THIS, THE SET WILL NOT RECORD.

The display will show "⏻"



PROBLEM


YOU WILL FIND TIPS FOR SOLVING PROBLEMS TO DO WITH VIDEO PLUS RECORDING ON THE FOLLOWING PAGE.



ENGLISH


PROGRAMMING TIMER WITH VIDEO PLUS+

Programming timer without VIDEO Plus+



1 Press the button **TIMER**


2 Use or to select the option **"TIMER RECORDING"** and confirm with



3 The timer screen appears


TIP
Enter the values correctly
Numbers less than 10 must be entered with an additional "0". For "9", thus "09" should be entered.

4 Use or to select the entry field **"DATE"** and use or the number buttons **0-9** to enter the date of the desired recording




FOR EXPERTS
Daily / weekly recordings
If you like, you can use **SELECT "MO-FR"** for recordings, which are repeated daily (Monday-Friday) or **"WEEKLY"** for recordings, which are repeated each week on the same day.

5 Use or to select the entry field **"PROG."** and use or the number buttons **0-9** to enter the programme number under which the video recorder has stored the desired TV channel




6 Use or to select the entry field **"START"** and use or the number buttons **0-9** to enter the start time of the desired recording



7

Use or to select the entry field **"END."** and use or the number buttons **0-9** to enter the end time of the desired recording


FOR EXPERTS
Activate VPS/PDC
VPS (Video Programming Service) and PDC signals (Programme Delivery Control) are transmitted by TV channels at the start and end of transmissions and ensure that programmes will be completely recorded, even if they are rescheduled. In the entry field, **"START"**, use **SELECT** to switch recognition of these signals on (*) or off ().



8

Check that the date, programme number, start and finish time are shown correctly on the screen. Confirm with **OK**. The display will show **"STORED"**


FOR EXPERTS
Selecting the recording speed
You have the option of two playback and recording speeds: Standard Play (SP) offers the usual first-class picture quality, and with Long Play (LP) you can, for example (with somewhat reduced picture quality) record about 360 minutes on a 180-minute cassette. In Auto Long Play (AUTO), the video recorder recognizes how much remaining playing time is available and automatically selects SP or LP. In the entry field **"END"**, use **SELECT** to enter the required setting.



9

Insert a cassette without erase protection

PARDON?
What is erase protection?
VHS cassettes can be protected from over-recording by breaking off a thin strip of plastic (arrow). This erase protection can be overridden by sticking one or more strips of adhesive tape tightly over the gap which has been created.



10

SWITCH OFF THE VIDEO RECORDER WITH THE STANDBY/ON BUTTON! If you don't do this, the set will not record.

The display will show "00"

PROBLEM
YOU WILL FIND TIPS FOR SOLVING PROBLEMS TO DO WITH TIMER RECORDING ON THE FOLLOWING PAGE.

Problem solving (Timer programming)

PROBLEM

SOLUTION

Error message:
"NO CASSETTE"

A recording was programmed, but there is no cassette in the machine. Insert a cassette without erase protection ready for recording.

Error message:
"SWITCH TO STANDBY
TIMER RECORDING"

A recording was programmed, but the video recorder was not switched into timer mode with the Standby button. Press **STANDBY** in order to make the programmed recording. Warning: if you do not do this, the video recorder will not record.

"E" and/or "E2" flash
in the display of the
video recorder

A recording was programmed, but there is no cassette in the machine. Insert a cassette without erase protection ready for recording.
A recording was programmed, but the video recorder was not switched into timer mode with the Standby button. Press **STANDBY** in order to make the programmed recording. Warning: if you do not do this, the video recorder will not record.

Error message:
"MEMORY FULL"

All the available memory locations in your video recorder for timer and VIDEO Plus programming are full. Delete a programmed recording (see chapter "Delete / check / change programmed recordings").

Cassette is ejected
during recording

The end of the tape was reached during a programmed recording. The recording could not be completed satisfactorily.

Cassette is ejected
after programming

A cassette with erase protection was inserted. Please deactivate the erase protection or insert another cassette which is ready for recording.

The set cannot be
used during recording

Once started, a recording can only be interrupted by pressing the **STANDBY** button. **WARNING:** This will not only stop the recording, but it will also delete the programmed recording from the memory of the video recorder.

Year/month/date/time
screen appears

The time has not been set or not set correctly. After entering/confirming year, month, date and time you can continue programming.


Recording via external sources

If you want to watch or record transmissions from a satellite receiver, films from a video camera (or from other external devices), connect the device to the socket **EXT1 AV1** or **EXT2 AV2** and select the programme number on your video recorder "E" or "E2".

FOR EXPERTS


"Turbo Timer"-Recording

Using the "Turbo Timer", you can make a programmed recording within the next 24 hours quickly and simply, without having to switch on the TV set. All you need to do now is enter or confirm the desired programme number and start and finish time in the video recorder.





1

Press the **TURBO TIMER** button on the remote control.



2

The display shows the actual starting time, e.g.: "20:00". Change – if necessary – the displayed start time with **↓** or **↑** (or with **0-9**).





3

Confirm with **OK**


4

The display shows a suggestion for the end of the recording e.g.: "22:00" (Start time + 2 hours). Change – if necessary – the displayed finish time with **↓** or **↑** (or with **0-9**). Confirm with the **TURBO TIMER** button.



5

The display shows the programme number to which the video recorder is currently set, e.g.: "P01". Change – if necessary – the displayed programme number with **↓** or **↑** (or with **0-9**). Confirm with the **TURBO TIMER** button. In the display there will briefly appear "OK".





FOR EXPERTS

Activate VPS/PDC

VPS (Video Programming Service) and PDC (Programme Delivery Control) signals are transmitted by TV channels at the start and end of transmissions and ensure that programmes will be completely recorded, even if they are rescheduled. Use **SELECT** to switch recognition of these signals on (VPS/PDC appears in the display) or off.

Delete / check / change programmed recordings


- 1 Press **TIMER**  on the remote control twice
- 2 Use **↓** or **↑** to select the option "TIMER LIST" and confirm with **→**
- 3 In the display, use the button **↓** or **↑** to select the storage position you wish to check/change/delete



What is a memory location?
For technical reasons, your video recorder has access to a limited number of "drawers" in which you can store your programming requirements. "Drawers" occupied by programme recording details are only available for use again after the video recorder has successfully completed a programmed recording or if it has been manually deleted. Your video recorder can store up to six programmed recordings.



- 4 **Delete:** Press **CLEAR (CL)**, confirm with the button **OK** (the screen will show "TIMER CLEARED") and finish with **TIMER** 
- Check:** Press **→**, check the stored details and (once you have checked) end with **TIMER** 
- Change:** Press **→**, use **↓** or **↑** to select the entry fields to be altered and use **0-9** to enter the new value(s). Confirm with **OK** and switch off the video recorder with the Standby button .




Using the "NexTVView Link"

If your TV set supports the "NexTVView Link" function, there is another option for you to quickly and simply programme recordings: With these TV sets, you can call up the listings for the TV channels, mark the programmes you want to record and automatically transfer their details into the memory of the video recorder. Please look in the instructions for your TV set to find out whether and how you can benefit from this function.

DELETE / CHECK / CHANGE RECORDINGS / NEXTVIEW

- 6 Insert a cassette without erase protection




What is erase protection?

VHS cassettes can be protected from over-recording by breaking off a thin strip of plastic (arrow). This erase protection can be overridden by sticking one or more strips of adhesive tape tightly over the gap which has been created.



- 7 **SWITCH OFF THE VIDEO RECORDER WITH THE STANDBY/ON BUTTON  IF YOU DON'T DO THIS, THE SET WILL NOT RECORD.**

The display will show "



Problem solving (Turbo Timer programming)

PROBLEM

Error message: "COLLISION"

" and " will blink in the display

Error message: "FULL"

Cassette is ejected during recording

Cassette is ejected after programming

The set cannot be used during recording

Error message: "CLK"

SOLUTION

It is impossible to make another programmed recording at the same time as an earlier programmed recording. Please check the programmed recordings ("Delete / check / change programmed recordings").

A recording was programmed, but there is no cassette in the machine. Insert a cassette without erase protection ready for recording.

All the available memory locations in your video recorder for timer and VIDEO Plus programming are full. Delete a programmed recording (see chapter "Delete / check / change programmed recordings").

The end of the tape was reached during a programmed recording. The recording could not be completed satisfactorily.

A cassette with erase protection was inserted. Please deactivate the erase protection or insert another cassette which is ready for recording.

Once started, a recording can only be interrupted by pressing the **STANDBY/ON** button . **WARNING:** This will not only stop the recording, but it will also delete the programmed recording from the memory of the video recorder.

The time has not been set or not set correctly. A Turbo Timer recording is not possible. Please enter the correct time (Section "Changing the time and date").



PROBLEM SOLVING

ENGLISH

ENGLISH

Adjusting automatic switch-off

If the video recorder is not used for several minutes, it switches itself off automatically. If you want to use the video recorder as a TV receiver, you can deactivate the automatic switch-off as follows:




- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "SPECIAL SETTINGS", and confirm with **→**
- 3 Use **↓** or **↑** to select the option "AUTO STANDBY" and use **→** or **←** to select the setting "ON" (automatic switch-off) or "OFF" (no automatic switch-off). Confirm with **OK**
- 4 Complete the adjustment of automatic switch-off with the **MENU** button

Adjusting the child lock

You can prevent unauthorised use of your video recorder with this function. Once it is activated, the buttons on the front of the set are locked. Previously entered programmes will of course be recorded



- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "SPECIAL SETTINGS", and confirm with **→**
- 3 Use **↓** or **↑** to select the "CHILD LOCK" and use **→** or **←** to select the setting "ON" (Child lock on) or "OFF" (Child lock off). Confirm with **OK**



TIP
Put the remote control away in a safe place.

Once the child lock has been activated, "ON" lights up in the display. The video recorder can now only be used with the remote control. Buttons on the front of the set will not function. Put away the remote control somewhere out of the reach of children.





- 4 Finish with the **MENU** button



Replaying cassette continuously

This function can be used to play a tape over and over again. If the end of the cassette or of the recording has been reached, the video recorder automatically rewinds to the start of the tape and starts to play back again. This function is activated or deactivated as follows:



- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "SPECIAL SETTINGS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "REPEAT PLAY" and use **→** or **←** to select the setting "ON" (continuous playback on) or "OFF" (continuous playback off). Confirm with **OK**



- 4 Complete the adjustment of continuous playback with the **MENU** button
- 5 Insert a cassette
- 6 Press the **Play** button **▶** to start the playback or continuous playback (depending on the setting)

Changing the TV system

When playing back cassettes which have been recorded with signals from a different TV system there may be interference with the colour. To deactivate the automatic change to a different TV system, you must follow these steps.





TV systems
Other countries, other TV systems: In central Europe transmissions are broadcast in the PAL-System (Phase Alternation Line) Standard, while in France SECAM (Séquentiel à mémoire) is used. In some countries (USA and Japan), TV viewers receive their programmes as an NTSC signal (National Television System Committee). Many TV and video sets can process and show several transmission systems.



PARDON?

- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "SPECIAL SETTINGS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "TU SYSTEM", use **→** or **←** to select the desired TV system or "B/W" for black/white playback and confirm with **OK**



Reactivating automatic change-over
As soon as the cassette is ejected with the Stop/Eject button **■/▲** the set switches automatically back to the "HLL/IT" setting (automatic switching). To change the setting during playback, perform the steps **1-3** again and select "HLL/IT".




TIP

- 4 End the change-over to automatic TV system changing with the **MENU** button

Adjusting the OSD information

If this function is activated, the current operating details of the video recorder will be briefly displayed on the screen



What is an OSD?

The on-screen menu or OSD ("On Screen Display") takes the mystery out of using your new video recorder. Using the main menu (MENU button on your remote control), all settings and recording steps can be done easily via the on-screen menu by following the corresponding instructions on the screen.



PARDON?

- 1 During playback press the **MENU** button on the remote control. The on-screen menu appears
 - 2 Use **↓** or **↑** to select the option "SPECIAL SETTINGS" and confirm with **→**
 - 3 Use **↓** or **↑** to select the option "OSD MODE", use **→** or **←** to select the desired setting and confirm with **OK**
- What goes on behind the settings?**
AUTO: For each type of operation selected (playback, recording, etc.) the corresponding symbol appears briefly on the screen
ON: The OSD details will be shown
OFF: OSD information is not shown
- 5 Complete the adjustment of the OSD information with the **MENU** button




TIP

Audio recording

You can record audio signals (without picture) on VHS cassettes, if you connect the sound source with the start or audio sockets of the video recorder. Only use cassettes, that are not included in the Tape Manager. The chapter "Tape Manager (TM)" explains how to remove cassettes from the Tape Manager memory.

- 1 Connect the desired sound source to the video recorder and insert a cassette ready for recording

- 2 Use $\downarrow$ or $\uparrow$ to select the corresponding programme number




Which is the correct programme number?

Socket	Programme number
AV1 EXT1 (Rear)	E 1
AV2 EXT2 (Rear)	E 2
AUDIO (Front)	E 3
AUDIO IN (Rear)	FLX

PARDON?


- 3 Press the MENU button. The on-screen menu appears



- 4 Use $\downarrow$ or $\uparrow$ to select the option "RECORDING FUNCTIONS" and confirm with the button $\rightarrow$


- 5 Use $\downarrow$ or $\uparrow$ to select the option "AUDIO ONLY" and confirm with $\rightarrow$

- 6 Press the Record button $\bullet$ in the usual way to start the recording



- 7 Press the Stop button $\blacksquare$ to end the recording

- 8 Leave the on-screen menu with the MENU button



- 1 Connect the desired sound source to the video recorder and insert a cassette ready for recording

- 2 Use $\downarrow$ or $\uparrow$ to select the corresponding programme number

Dubbing (Audio Dubbing)

Of course, you can also dub existing video recordings with this video recorder. The mono track is recorded with a new sound signal. The original stereo signal is retained. To make dubbing audible during playback, you must select the "H1X" or "H1QD" sound channel setting. Only use cassettes, that are not included in the Tape Manager. The chapter "Tape Manager (TM)" explains how to remove cassettes from the Tape Manager memory.


- 3 Press the MENU button. The on-screen menu appears

- 4 Use $\downarrow$ or $\uparrow$ to select the option "RECORDING FUNCTIONS" and confirm with $\rightarrow$

- 5 Use $\downarrow$ or $\uparrow$ to select the option "AUDIO DUBBING" and confirm with $\rightarrow$

- 6 The video recorder switches to still picture

- 7 Wind to the space on the tape, where the dubbing should end, and with the button CLEAR (CL) set the counter to "00:00:00"



PROBLEM
 ✗ The tape stops automatically and the "RECORD FUNCTIONS" screen appears
 ✓ The end of the tape was reached during winding or playback. Go back to step 6, to start this procedure again.


- 8 Wind to the space on the tape, where the dubbing should begin, and press $\blacktriangleleft$. The video recorder switches to still picture

- 9 Press $\blacktriangleleft$ (still picture) several times until the desired point is reached and confirm with the Stop button $\blacksquare$

- 10 On the connected sound source start the playback of the sound signal and press simultaneously the Record button $\bullet$ on the remote control of the video recorder to start the recording.

- 11 The new sound signal is being recorded. As soon as the tape position previously marked with "00:00:00" is reached, the dubbing will stop automatically

- 12 Finish with the MENU button




Make dubbing audible

To make dubbing audible, you must select the "H1X" or "H1QD" sound channel setting (see "Selecting the sound channel").

Selecting the sound channel

During playback or while receiving a TV channel via the video recorder, one or more sound channels can be selected. This means, for example, if there are multilingual transmissions, you can select the language you want.



- 1 Press the **SELECT** button on the remote control. The current sound channel setting is displayed



TIP

What goes on behind the settings?

STEREO: Both left and right stereo sound tracks can be heard


LEFT: The left stereo sound track can be heard

RIGHT: The right stereo sound track can be heard

MONO: The mono sound track can be heard

MIXED: The mono sound track as well as the left and right stereo sound tracks can be heard

- 2 Press the **SELECT** button several times until the desired setting can be seen on the screen





TIP

Automatic switch-over to mono


If no stereo signal is recorded on a video cassette, the video recorder automatically switches over to the "MONO" sound channel setting

Make dubbing audible

When dubbing video recordings, the mono track is recorded with a new sound signal. The original stereo signal is retained. To make dubbing audible, you must select the "MIX" or "MONO" sound channel setting.

Selecting sound setting (Smart Sound)

Using the button **SURROUND/SMART** the picture settings can be displayed and altered. There are four different settings available.



- 1 Press once on the **SURROUND/SMART** button. The current sound setting will be displayed
- 2 Press several times on the **SURROUND/SMART** button to change the sound setting. Each time the button is pressed, the next sound setting will be displayed.



What types of sound settings are available to me?

"STANDARD": Neutral sound impression


"SURROUND": Wider sound impression

"MUSIC": Optimal setting for music playback

"SPEECH": Optimal setting for speech playback

PARDON?


- 3 As soon as the **SURROUND/SMART** button is released for a few seconds, the last selected picture setting will be accepted.



Manual mute

With the **MANUAL** button on the front of the video recorder you can regulate the signal level of the audio signals (scart sockets, audio sockets) received by the video recorder.



- 1 Press the **MANUAL** button on the front of the video recorder until the current setting (e.g. "MAN20") appears in the display
- 2 On the front of the video recorder use **PROGRAMME -** or **PROGRAMME +** to select the desired setting or press **MANUAL** again, to switch back to automatic mute ("AUTO")



Energy-saving mode

To reduce the power consumption of the video recorder you can switch the clock in the display of the video recorder on or off.

- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↑** or **↓** to select the option "SPECIAL SETTINGS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "CLOCK DISPLAY", use **→** or **←** "ON" (time display on in standby mode) or "OFF" (time display off in standby mode) and confirm with **OK**. The screen will show "STORED"
- 4 Finish with the **MENU** button



Preparing synchronised re-recording (Synchro Edit)

The "Synchro Edit" function allows you to re-record picture and sound signals from special Camcorders directly onto VHS cassettes.



How does "Synchro Edit" function?

With the help of a synchronizing impulse and a (variable) switch-on time (Preroll time) the beginning of playback and recording can be so precisely tuned that not a single second of the audio/video signal required for the re-recording is lost. Warning: To make proper use of this function, the linked Camcorder must have a compatible "Synchro Edit"!

- 1 Plug the Camcorder into the front socket on the video recorder






Which connections are necessary?

VR 910	Cable	Camcorder
Socket EDIT	Synchro Edit Cable	corresponding socket
Socket LAUDIO R	Coaxial cable*	corresponding socket
Socket VIDEO	Coaxial cable	corresponding socket

*...attached to the video recorder.
**...if necessary, you should refer to the instructions for your Camcorder for assistance.

- 2 Press the **MENU** button on the remote control. The on-screen menu appears
- 3 Use **↓** or **↑** to select the option "RECORDING FUNCTIONS" and confirm with **→**
- 4 Use **↓** or **↑** to select the option "CAMERA LINK". Switch the Camcorder to still picture and confirm with **→** on the remote control of the video recorder

- 5 The video recorder checks the connected Camcorder type. The screen will show "LINK DETECTED - CAMERA TO CONTROL VIDEO RECORDER" or "LINK DETECTED - VIDEO RECORDER TO CONTROL CAMERA"



PREPARING SYNCHRO EDIT




What goes on behind this message?




VIDEO RECORDER TO CONTROL CAMERA:
The video recorder controls the synchronized re-recording. Start and end is controlled by pressing the video recorder buttons.

CAMERA TO CONTROL VIDEO RECORDER:
The Camcorder controls the synchronized re-recording. Start and end is controlled by pressing the Camcorder buttons.

Making a synchronised re-recording (Synchro Edit)



- 1 Press the **MENU** button on the remote control. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "RECORDING FUNCTIONS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "SYNCHRO EDIT" and confirm with **→**
- 4 A still picture of the precise point on the tape in the video recorder will appear. If necessary find the point on the tape at which the synchronized re-recording is to begin and switch again to still picture with the **STILL / JOG ON** button
- 5 Press **SELECT**. The current picture from the linked Camcorder appears
- 6 Find the point on the tape where the synchronized re-recording is to begin and switch again to still picture



ENGLISH

ENGLISH

PERFORMING A SYNCHRO EDIT

- 7 Start or interrupt the synchronised re-recording in the following manner:





VIDEO RECORDER TO CONTROL CAMERA:

Start RECORD/OTR button
Interrupt ■ button

CAMERA TO CONTROL VIDEO RECORDER:

Start Corresponding (Play) button on the Camcorder
Interrupt Corresponding (Pause) button on the Camcorder

- 8 Press the MENU button on the remote control of the video recorder, to leave the Synchro Edit mode








PROBLEM

- ✗ The first few seconds of a synchronized re-recording are not recorded
- ✗ Before a synchronized re-recording a still picture appears for a few seconds
- ✓ The Preroll time is not correctly adjusted. Read the section "Adjusting Preroll time".

Adjusting Preroll time

What is Preroll time?
For a synchronized re-recording the playback and recording appliances must be started at the same time. However, different appliances react at different speeds. In such cases the Preroll function will allow a fixed space of time to be inserted, to ensure that one appliance starts earlier or later than the other. This avoids recordings starting too soon or too late.

- 1 Press the MENU button on the remote control. The on-screen menu appears
- 2 Use ↓ or ↑ to select the option "RECORDING FUNCTIONS" and confirm with →
- 3 Use ↓ or ↑ to select the option "RECORD SETTINGS" and confirm with →



- 4 Use ↓ or ↑ to select the option "PREROLL TIME" and change the settings with ← and → or with 0-9

How do I discover the correct preroll time?
Since you can make a synchronized re-recording with any "Synchro Edit" compatible appliance, there is no fixed preroll time that will operate for every combination of appliances. Experiment to find the correct setting. Preroll times can be adjusted between 1 and 5 seconds.

PARDON?

- 5 Confirm the amended Preroll time with OK
- 6 Complete the adjustment of the Preroll time with the MENU button

Inserting recordings (Video Insert)

What do I need this function for?
With "Video Insert" you can insert a new recording directly into an existing recording. The signal source for this may be an existing Camcorder or a second video recorder (connect to the audio/video socket on the front of the video recorder or the Scart socket at the back of the video recorder).

PARDON?

- 1 Insert a cassette for each recording, into which a new recording is to be inserted
- 2 Press the MENU button on the remote control. The on-screen menu appears
- 3 Use ↓ or ↑ to select the option "RECORDING FUNCTIONS" and confirm with →
- 4 Use ↓ or ↑ to select the option "VIDEO INSERT" and confirm with →

Adapting remote control

If you are using two video recorders which both react to the same remote control commands, you can use this function to change remote control and video recorder to other commands.

What are remote control codes?

Each time the button on your remote control is pressed an invisible infra-red signal is sent to the video recorder. Each button has been allocated a specific code which ensures that the video recorder will carry out the corresponding function. If two video recorders respond to the same codes, the remote control signal emitted will be recognised and performed by both. Therefore the possibility exists, to allocate different remote control commands (with other codes) to this video recorder. This means that the uninterrupted use of both video recorders is possible once more.

PARDON?

1 During playback press the **MENU** button on the remote control. The on-screen menu appears

2 Use $\downarrow$ or $\uparrow$ to select the option "SPECIAL SETTINGS" and confirm with $\rightarrow$

3 Use $\downarrow$ or $\uparrow$ to select the option "UCR 1 OR 2", use $\rightarrow$ or $\leftarrow$ to select "UCR 1" or "UCR 2" and confirm with **OK**. The video recorder has now been reset to the desired mode

What must I see?

If two video recorders respond to the same codes, they are either both set to "UCR 1" or "UCR 2". Please change the setting of only one video recorder! The factory setting of the video recorder is "UCR 1".

TIP





4 Now press, on the remote control, **simultaneously** on the buttons **SELECT** and the number button corresponding to the previously selected setting (thus "1" for "UCR 1" or "2" for "UCR 2")

5 Confirm with **OK**. The remote control has now been reset to the new commands

6 Finish with the **MENU** button

PROBLEM

X After the buttons are pressed "UCR 1" or "UCR 2" appears in the display of the video recorder
 ✓ Repeat step 2 to reset the remote control to the displayed settings



5 Use $\downarrow$ or $\uparrow$ to select the programme number, that is to be inserted for the new programme

Which programme numbers are available for selection?

Theoretically all, that have been allocated a TV channel by your video recorder are available. Most recordings are derived from external signal sources (Camcorder, video recorder etc....) To connect these there are three options:

- E1 Scart socket AV1 EXT1 (Rear)
- E2 Scart socket AV2 EXT2 (Rear)
- E3 Audio/Video socket (Front)

PARDON?

6 Find the point on the inserted cassette, where the synchronized re-recording is to end, and press **STILL/JOG ON**

7 Press **CLEAR (CL)**. The tape position will be reset to "00:00:00"

8 Find the point on the inserted cassette, where the synchronized re-recording is to begin, and press **STILL/JOG ON**





9 Press the Stop button $\blacksquare$. The video recorder switches to Pause

10 Start playback on the connected playback set

11 As soon as the point on the tape is reached where the recording is to be inserted press the **RECORD/OTR** $\bullet$ button on the video recorder



12 The video recorder starts recording and stops automatically at the tape position previously marked with "00:00:00"

13 Finish the "Video Insert" function with the **MENU** button



Demonstration mode

In this operating mode, the video recorder automatically gives a demonstration of its functions after switching off. Programmed recordings are obviously performed.





- 1 Press **MENU**. The on-screen menu appears
- 2 Use **↓** or **↑** to select the option "SPECIAL SETTINGS" and confirm with **→**
- 3 Use **↓** or **↑** to select the option "DEMO", use **→** or **←** to select "ON" or "OFF" and confirm with **OK**
- 4 Finish with the **MENU** button

Adjusting the key illumination


The front of the video recorder is fitted with illuminated keys that react to pressure. This function can be activated or deactivated as follows:

- 1 Make sure there is no cassette in the video recorder
- 2 Switch off the video recorder with the Standby button **⏻**
- 3 Press simultaneously on the front of the video recorder the buttons **PLAY** **▶** and **PROGRAMME** + until the display shows "OFF" (key illumination deactivated) or "ON" (key illumination activated)
- 4 The adjustment of the key illumination is complete



Using the TV remote control

With the enclosed multicode remote control you can control the main functions of your TV set. To do this, you must first enter the make of your TV set.



- 1 Find the make of your TV set from the list below and take note of the corresponding remote control code(s)
- 2 Hold down the button **↵** - and enter one of the listed codes with the number buttons **0-9**.
- 3 Now you can control your TV set remotely with the following buttons:
 + **↵** - (Increase / decrease TV volume)
TV / ⏻ Switch TV on / off
TV / ⌘ Switch TV volume on / off
TV / AV (Switch TV to programme number AV)
 + **TV** - (Next / previous TV programme number)

REMOTE CONTROL CODES

Brandt	21	Philips	01
Emerson	14	RCA	10
Ferguson	31	Saba	21
Finlux	33	Salora	30
Funai	35	Samsung	01, 18, 37, 38, 39
GoldStar	04	Sanyo	11
Graetz	30	Seleco	30
Grundig	24, 25	Sharp	16
Hitachi	12	Sony	09
ITT	30	Telefunken	21
JVC	05, 27, 28, 29	Thomson	21, 22, 23
Luxor	30	Toshiba	08
Magnavox	01, 02, 03	Zenit	06, 15
Mitsubishi	13, 26		
Mivar	32		
NEC	36		
Nokia	34		
Nordmende	21		
Panasonic	07, 17, 19, 20		

If the codes corresponding to your set do not succeed, please try entering one of the other remote control codes listed.

Suppressing interference





Optimizing the modulator

If the TV set and the video recorder are only connected with an aerial cable - rather than with an additional scart cable - it may happen that in certain reception locations the modulator frequency of the video recorder is occupied by a TV channel. As soon as the video recorder is switched on, the reception quality of the TV picture deteriorates. The following steps will show you how to overcome this problem.



TIP

What is a modulator?
The purpose of this electronic assembly inside your video recorder is to pass on the picture and sound information: read in from the video tape via an aerial cable like a TV signal to the TV set. The modulator frequency determines the frequency range in which these signals are transmitted.



- 1 Switch the video recorder on and make sure there is no cassette in the video recorder
- 2 Press simultaneously on the front of the video recorder the button **STOP/EJECT**  and the button **PLAY**  until the display shows the modulator frequency (e.g. "1583" or "1436")
- 3 The video recorder will now transmit a test image on this frequency
- 4 Use  or  to select the option "OPTIMIZE" and enter a new frequency with the number buttons 0-9




PROBLEM

Which modulator frequency should I enter?
You can also make the video recorder search automatically for an appropriate frequency. To do so, simply hold down the button . As soon as a free frequency has been found, it will be shown in the display.

- 5 Tune the programme number of your TV set allocated for video use to the new modulator frequency until you see the test image sharply and in colour

OPTIMIZING THE MODULATOR

ENGLISH



- 6 Confirm the new modulator frequency with **OK**. The screen will show "STORED"
- 7 Leave the on-screen menu with the **MENU** button







FOR EXPERTS

Switching off the modulator
If you have connected the video recorder to the TV set with a scart cable, you can switch off the modulator when there is interference with the picture or sound (see below).

Switching the modulator on / off

If picture and sound interference cannot be removed by optimising the modulator, the integral modulator can be switched off. Warning: this is only possible if you have connected the video recorder to the TV set with a scart cable. It is not possible to operate with the modulator switched off without a scart cable.



- 1 Switch the video recorder on and make sure there is no cassette in the video recorder
- 2 Press simultaneously on the front of the video recorder the button **STOP/EJECT**  and the button **PROGRAMME** until the display shows the modulator frequency (e.g. "1583" for 583 MHz)
- 3 The video recorder will now transmit a test image on this frequency
- 4 Use  or  to select the option "MODULATOR"
- 5 Use  or  to select the setting "ON" (Modulator on) or "OFF" (Modulator off)
- 6 Confirm with **OK**. In the display there will briefly appear "OK". The screen will show "STORED"
- 7 Leave the on-screen menu with the **MENU** button

ENGLISH

SWITCHING THE MODULATOR ON / OFF

ADJUSTMENT INSTRUCTIONS

1. Tape Manager

Set the tape manager number

This setting has to be done after replacement of the EEPROM.

- call up the service test program, select step 43
- the display shows T-:--:43
- using the remote control, type in the last three digits of the serial number, located on the type plate of the set
- press the ok button
- exit the service test program.

2. Video signal processing (VS-SEC)

Service tasks after replacement of ICs 7004, 7072:

Before commencing adjustment:

Call the service test program and enter Step 10 (Dummy mode). Remove the drive from the motherboard.


2.1 3.3 MHz adjustment [3089] (for SECAM)

Purpose: To adjust the mixing oscillator

Consequences of incorrect settings:

Cross patterns in coloured areas, coloured noise.

TP	ADJ.	MODE	INPUT
IC7072 pin 17	R3089	Dummy mode step 10 playback	1.2 MHz sinus 100mVpp, R3065 +5V on IC 7072 pin16; R3064
TAPE		MEAS. EQ.	SPEC.
		Oscilloscope	adjust to optimum sinus
		Video pattern generator	
		Sinus generator	



A: AC, 50mV/Div, 50ns/Div
IC 7072 Pin 17

2.2 SECAM chrominance record current adjustment [3088]:


Purpose: To set the optimum record SECAM chroma level.

Symptom, if incorrectly set:

If the record level is too high, beats may appear on the picture. If the level is too low, the colour may be degraded.

TP	ADJ.	MODE	INPUT
CSRV pos.9068	R3088	Dummy mode Record Preset E2	(VIDEO IN E2) Red Picture SECAM 75% Saturation
TAPE		MEAS. EQ.	SPEC.
		Oscilloscope Video Pattern Generator	A=240 ± 15 mV _{pp} ,

Notes: With varying frame amplitudes, the setting is made for the greatest amplitude.





A: AC, 50mV/Div, 20us/Div

List of Signal Abbreviations


2FSC	2x Colour subcarrier	HEST	Heater voltage control signal
10SC12	Scart 1/2 Pin 10	HP1	Head pulse video
8SC1	Scart 1 pin 8 input	HP2	Head pulse audio
8SC1H	Scart 1 pin 8 high level	HSC	Head Select Control (SP/LP)
8SC1M	Scart 1 pin 8 medium level	IMEO	Main erase oscillator on/off
8SC2	Scart 2 pin 8 input	INIT	Deck switch
9_14VM2	Capstan motor supply, switched	INT	Interrupt
A0-19	Address lines	IPOR	Inverse power on reset
AEH1/2	Audio erase head	IRAF	Inverse record FM-audio
AF1	Audio from frontend, left	IRAL	Inverse Record Audio Linear
AF2	Audio from frontend, right	IREV	Inverse Record Video
AFC	Automatic frequency control	ISTBY	Inverse stand by
AFE	Audio from frontend	ISWS	Crosstalk Reduction
AGC	Automatic gain control	IWIND	Control pulse amplification low
AH1/2/C	Audio heads	LH1/2/C	Long play heads
AIN1L	Audio input scart 1, left	MEH1/2	Main erase head
AIN1R	Audio input scart 1, right	MON	Loop through pin 16 scart 2/1
AIN2L	Audio input scart 2, left	MTA	Audio mute
AIN2R	Audio input scart 2, right	NC	Not connected
AINBL	Audio left from cinch connector	ODAT	Shift register bus data
AINBR	Audio right from cinch connector	OFP	OSD Frame pulse
AINFL	Audio left from Front connector	PBV	Playback Video
AINFR	Audio right from front connector	PG_FG	Head wheel position/-speed
AMCO	Audio mono to the modulator	PIN10_IN	Pin 10 scart 1/2 output
AMLPL	Audio mono playback	PIN10_OUT	Pin 10 scart 1/2 input
AMLR	Audio mono record	POR	Power on reset
AN1/2	Analog voltage from keyboard matrix	PSS	PAL/SECAM Switch
ANIL	NICAM Audio, left	RD	Output Enable RAM/ROM
ANIR	NICAM Audio, right	RECP	Record protection
AOUT1L	Audio output from scart 1, left	RxD	Receive Data
AOUT1R	Audio output from scart 1, right	SB1	Secam band 1
AOUT2L	Audio output from scart 2, left	SCL	IIC bus clock
AOUT2R	Audio output from scart 2, right	SDA	IIC bus data
APH	Audio playback head	SCL2	YCA IIC bus clock
ARH	Audio record head	SDA2	YCA IIC bus data
CAGC	Chroma Automatic gain control	SCL3	High Speed IIC bus clock
CAP	Capstan regulation voltage	SDA3	High Speed IIC bus data
CKDET	Colour killer detection	SFS	Sound filter switch
CNR	Chroma Noise Reduction	SH1/2/C	Standard play heads
CPRV	Chrominance PAL record	SRCLK	Shift Register Clock
CREV	Capstan reverse	SSIF	Second sound intermediate frequency
CROT	Colour rotation	STROBE	Strobe pulse for shiftregister
CS0	Chip Select 0	SWIN	Head switching pulse
CS1	Chip Select 1	SYNC	Control track pulse
CSCP	Colour phase switching for LP feature mode	TAE	Tape end detection
CSI	Colour system information	TAS	Tape start detection
CSP	Chrominance secam playback	THIO	Threading motor in/out
CSPO	Chroma to Noise Reduction	TMO	Loading motor on/off
CSRV	Chrominance secam record	TRIA_ALM	Tracking information audio / Audio level indication
CSW	9V/17V switching for capstan motor	TRIV	Tracking information video
CSYNC/1/2	Composite sync pulse	TxD	Transmit Data
CTL1/2	Control track signal	VBS	Video to signal electronics
D0-7	Data lines	VCCD1	Signal before Y-CCD
DC_RESET	Reset Display Control	VCCD2	Signal after Y-CCD
DRUM	Head wheel control	VFRONT	Video from front connector
EDIT1/2	Synchro-Edit control signal	VFV	Video from front end
ENVC	Envelope comparator signal	VIDOUT1	Video output scart 1
FFP	Feature frame pulse	VIDOUT2	Video output scart 2
FGD	Capstan tachometer pulse digital	VIDEOIN1	Video input scart 1
FM1	L+R	VIDEOIN2	Video input scart 2
FM2	2R	VISS	Control sync pulse inversion
FMAP	FM audio playback	VOL	headphone volume
FMAR	FM audio record	VOUT	Video from OSD part
FMPV	FM video playback	VSB	Video from signal electronics
FMRV	FM video record	W_R	Control track write/read
FOME	Follow Me (video signals equal)	WR	Write enable for RAM
FSC	Colour subcarrier	WTL	Wind tachometer left
FTA	Threading tachometer	WTL2	Wind tachometer left digital
FTAD	Threading tachometer digital	WTR	Wind tachometer right
HEHI	Heater for displaytube high	WTRD	Wind tachometer right digital
HELO	Heater for displaytube low		

Wiring Diagram







Block Diagram Video




A: DC, 500mV/Div, 10us/Div
IC 7705 Pin 8






A: DC, 500mV/Div, 10us/Div
Tumod Pin 1












FRONT END VIDEO (FV)

























Block Diagram Audio




Oscillograms Block Diagram Audio




Oscillograms Block Diagram Digital






Block Diagram Digital







Block Diagram Supply & I²C








Block Diagram Supply & I²C













ELECTRONICS & CONTROL PART (AIO1,AIO2,DE)









HOT CIRCUIT, BE CAREFUL AND USE AN ISOLATION TRANSFORMER WHEN SERVICING

DO NOT OPERATE WITHOUT CASE


CAUTION: LETHAL POTENTIALS AT PRIMARY




PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE
FS 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	3-42



Motherboard (MOBO)







Component Mapping Motherboard

0001	F1	2776	F1	3551	A3	6507	A2	9462	A8	9757	F2
0007	F4	2782	F2	3551	A4	6508	A2	9463	A8	9758	F2
0008	D7	2790	F3	3551	A5	6601	A5	9464	A7	9759	F2
0020	D3	2799	F3	3551	A2	7072	F1	9465	B8	9760	F1
0021	D6	2804	F3	3551	A2	7321	D10	9466	A7	9761	F1
0031	F8	2805	F3	3551	A2	7323	D10	9467	A7	9762	F1
0037	F8	2805	F3	3551	A2	7325	F10	9468	A7	9763	F2
0050	A4	2805	F3	3551	A2	7326	F10	9469	A7	9764	D2
1001	C5	2807	F3	3551	A2	7407	D8	9470	A7	9765	F4
1322	D10	2839	F3	3551	A1	7440	A8	9471	A7	9766	F4
1323	D10	2839	F3	3551	A1	7443	B7	9472	A6	9767	F4
1324	F10	2841	F3	3551	A1	7446	A7	9473	A8	9768	F4
1325	F10	2850	F3	3551	A2	7451	A10	9474	A8	9769	F4
1451	C10	2851	F3	3551	A2	7452	A9	9475	A8	9770	F4
1460	F8	2851	F3	3551	A2	7461	D3	9476	A8	9771	F4
1461	F4	2877	F3	3551	A4	7462	D3	9477	A8	9772	F4
1701	A1	3001	F3	3551	A4	7463	D3	9478	A8	9773	F4
1703	D1	3008	F3	3551	A4	7465	F4	9479	A8	9774	F4
1704	C1	3008	F3	3551	A4	7466	D7	9480	A8	9775	F4
1705	D2	3010	D5	3551	B5	7506	A1	9481	A8	9776	F4
1706	D2	3012	D4	3551	A5	7509	A9	9483	A7	9777	F4
1707	D2	3030	B7	3551	A5	7604	A5	9484	A8	9778	F4
1708	A1	3034	F6	3551	A5	7807	F6	9485	A8	9779	F4
1760	F1	3035	F7	3551	A5	7830	F9	9486	B7	9780	F4
1761	F1	3035	F7	3551	A5	9011	F1	9487	C7	9781	F4
1851	F6	3036	D6	3551	A5	9012	B3	9488	C7	9782	F4
1871	F9	3038	B7	3551	A5	9013	B4	9489	C7	9783	F4
1911	A4	3040	B7	3551	A5	9014	B4	9490	C7	9784	F4
1912	A4	3042	B7	3551	A6	9015	B4	9491	D7	9785	F4
1941	A8	3042	B7	3551	A6	9016	B4	9492	F10	9786	F4
1942	F10	3042	B7	3551	A6	9017	B4	9493	F10	9787	F4
1944	F10	3042	B7	3551	A6	9018	B5	9494	F10	9788	F4
1945	D5	3042	B7	3551	A6	9019	A5	9495	D1	9789	F4
1946	B8	3042	B7	3551	A6	9021	B5	9496	A1	9790	F4
1947	B8	3071	F4	3551	C2	9022	A4	9497	A3	9791	F4
1948	A7	3072	D4	3551	C1	9023	C4	9498	A3	9792	F4
1951	A2	3080	F3	3551	E2	9024	C4	9499	A3	9793	F4
1952	A2	3082	D4	3551	F1	9025	C4	9500	A2	9794	F4
1953	A1	3083	D3	3551	F1	9061	F3	9501	A2	9795	F4
1954	A4	3083	D3	3551	F1	9062	F3	9502	A2	9796	F4
1955	A4	3083	D3	3551	F1	9063	B4	9503	A2	9797	F4
1956	B2	3083	D3	3551	F1	9064	D3	9504	A2	9798	F4
1957	B2	3083	D3	3551	F1	9065	D3	9505	A2	9799	F4
1958	B2	3083	D3	3551	F1	9066	D3	9506	A2	9800	F4
1959	B2	3083	D3	3551	F1	9067	D3	9507	A2	9801	F4
1960	A6	3083	D3	3551	F1	9068	D3	9508	A2	9802	F4
1961	B2	3083	D3	3551	F1	9069	D3	9509	A2	9803	F4
1962	B2	3083	D3	3551	F1	9070	D3	9510	A2	9804	F4
1963	B2	3083	D3	3551	F1	9071	D3	9511	A2	9805	F4
1964	B2	3083	D3	3551	F1	9072	C5	9512	A2	9806	F4
1965	B2	3083	D3	3551	F1	9073	C5	9513	A2	9807	F4
1966	B2	3083	D3	3551	F1	9074	D5	9514	A2	9808	F4
1967	B2	3083	D3	3551	F1	9075	D5	9515	A2	9809	F4
1968	B2	3083	D3	3551	F1	9076	F6	9516	A2	9810	F4
1969	B2	3083	D3	3551	F1	9077	C6	9517	A2	9811	F4
1970	B2	3083	D3	3551	F1	9078	C6	9518	A2	9812	F4
1971	B2	3083	D3	3551	F1	9079	C6	9519	A2	9813	F4
1972	B2	3083	D3	3551	F1	9080	C6	9520	A2	9814	F4
1973	B2	3083	D3	3551	F1	9081	C6	9521	A2	9815	F4
1974	B2	3083	D3	3551	F1	9082	C6	9522	A2	9816	F4
1975	B2	3083	D3	3551	F1	9083	C6	9523	A2	9817	F4
1976	B2	3083	D3	3551	F1	9084	C6	9524	A2	9818	F4
1977	B2	3083	D3	3551	F1	9085	C6	9525	A2	9819	F4
1978	B2	3083	D3	3551	F1	9086	C6	9526	A2	9820	F4
1979	B2	3083	D3	3551	F1	9087	C6	9527	A2	9821	F4
1980	B2	3083	D3	3551	F1	9088	C6	9528	A2	9822	F4
1981	B2	3083	D3	3551	F1	9089	C6	9529	A2	9823	F4
1982	B2	3083	D3	3551	F1	9090	C6	9530	A2	9824	F4
1983	B2	3083	D3	3551	F1	9091	C6	9531	A2	9825	F4
1984	B2	3083	D3	3551	F1	9092	C6	9532	A2	9826	F4
1985	B2	3083	D3	3551	F1	9093	C6	9533	A2	9827	F4
1986	B2	3083	D3	3551	F1	9094	C6	9534	A2	9828	F4
1987	B2	3083	D3	3551	F1	9095	C6	9535	A2	9829	F4
1988	B2	3083	D3	3551	F1	9096	C6	9536	A2	9830	F4
1989	B2	3083	D3	3551	F1	9097	C6	9537	A2	9831	F4
1990	B2	3083	D3	3551	F1	9098	C6	9538	A2	9832	F4
1991	B2	3083	D3	3551	F1	9099	C6	9539	A2	9833	F4
1992	B2	3083	D3	3551	F1	9100	C6	9540	A2	9834	F4
1993	B2	3083	D3	3551	F1	9101	C6	9541	A2	9835	F4
1994	B2	3083	D3	3551	F1	9102	C6	9542	A2	9836	F4
1995	B2	3083	D3	3551	F1	9103	C6	9543	A2	9837	F4
1996	B2	3083	D3	3551	F1	9104	C6	9544	A2	9838	F4
1997	B2	3083	D3	3551	F1	9105	C6	9545	A2	9839	F4
1998	B2	3083	D3	3551	F1	9106	C6	9546	A2	9840	F4
1999	B2	3083	D3	3551	F1	9107	C6	9547	A2	9841	F4
2000	B2	3083	D3	3551	F1	9108	C6	9548	A2	9842	F4
2001	B2	3083	D3	3551	F1	9109	C6	9549	A2	9843	F4
2002	B2	3083	D3	3551	F1	9110	C6	9550	A2	9844	F4
2003	B2	3083	D3	3551	F1	9111	C6	9551	A2	9845	F4
2004	B2	3083	D3	3551	F1	9112	C6	9552	A2	9846	F4
2005	B2	3083	D3	3551	F1	9113	C6	9553	A2	9847	F4
2006	B2	3083	D3	3551	F1	9114	C6	9554	A2	9848	F4
2007	B2	3083	D3	3551	F1	9115	C6	9555	A2	9849	F4
2008	B2	3083	D3	3551	F1	9116	C6	9556	A2	9850	F4
2009	B2	3083	D3	3551	F1	9117	C6	9557	A2	9851	F4
2010	B2	3083	D3	3551	F1	9118	C6	9558	A2	9852	F4
2011	B2	3083	D3	3551	F1	9119	C6	9559	A2	9853	F4
2012	B2	3083	D3	3551	F1	9120	C6	9560	A2	9854	F4
2013	B2	3083	D3	3551	F1	9121	C6	9561	A2	9855	F4
2014	B2	3083	D3	3551	F1	9122	C6	9562	A2	9856	F4
2015	B2	3083	D3	3551	F1	9123	C6	9563	A2	9857	F4
2016	B2	3083	D3	3551	F1	9124	C6	9564	A2	9858	F4
2017	B2	3083	D3	3551	F1	9125	C6	9565	A2	9859	F4
2018	B2	3083	D3	3551	F1	9126	C6	9566	A2	9860	F4
2019	B2	3083	D3	3551	F1	9127	C6	9567	A2	9861	F4
2020	B2	3083	D3	3551	F1	9128	C6	9568	A2	9862	F4
2021	B2	3083	D3	3551	F1	9129	C6	9569	A2	9863	F4
2022	B2	3083	D3	3551	F1	9130	C6	9570	A2	9864	F4
2023	B2	3083	D3	3551	F1	9131	C6	9571	A2	9865	F4
2024	B2	3083	D3	3551	F1	9132	C6	9572	A2	9866	F4
2025	B2	3083	D3	3551	F1	9133	C6	9573	A2	9867	F4
2026	B2	3083	D3	3551	F1	9134	C6	9574	A2	9868	F4
2027	B2	3083	D3	3551	F1	9135	C6	9575	A2	9869	F4
2028	B2	3083	D3	3551	F1	9136	C6	9576	A2	9870	F4
2029	B2	3083	D3	3551	F1	9137	C6	9577	A2	9871	F4
2030	B2	3083	D3	3551	F1	9138	C6	9578	A2	9872	F4
2031	B2	3083	D3	3551	F1	9139	C6	9579	A2	9873	F4
2032	B2	3083	D3	3551	F1	9140	C6	9580	A2	9874	F4
2033	B2	3083	D3	3551	F1	9141	C6	9581	A2	9875	F4
2034	B2	3083	D3	3551	F1	9142	C6	9582	A2	9876	F4
2035	B2	3083	D3	3551	F1	9143	C6	9583	A2	9877	F4
2036	B2	3083	D3	3551	F1	9144	C6	9584	A2	9878	F4
2037	B2	3083	D3	3551	F1	9145	C6	9585	A2	9879	F4
2038	B2	3083	D3	3551	F1	9146	C6	9586	A2	9880	F4
2039	B2	3083	D3	3551	F1	9147	C6	9587	A2	9881	F4
2040	B2	3083	D3	3551	F1	9148	C6	9588	A2	9882	F4
2041	B2	3083	D3	3551	F1	9149	C6	9589	A2	9883	F4
2042	B2	3083	D3	3551	F1	9150	C6	9590	A2	9884	F4
2043	B2	3083	D3	3551	F1	9151	C6	9591	A2	9885	F4
2044											


Motherboard (MOBO)





Supply Part (PS)

1323 C8	2321 C7	2325 D2	3322 A4	3327 D4	3331 A4	3336 B5	7321 C6	7325 D3	7329 B5	C806 E2	F2104 E
1324 E8	2322 D7	2326 E2	3323 B5	3328 E4	3332 A3	3337 D7	7322 B4	7326 E3	7330 C6	F2101 A1	F2105 A
1325 D8	2323 D9	2328 D9	3325 D7	3329 E3	3334 A6	5322 E6	7323 D6	7327 A3	C804 E1	F2102 A1	F2107 E




Interconnections


Manual Page

PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	


F2110 B1 F2117 C1 F9326 B2 F9333 E9 F9338 C8 F9342 D8 I325 B4 I329 D4 I333 D2 I337 B5
 F2111 A1 F2118 C1 F9330 E7 F9334 E8 F9339 C9 F9343 C7 I326 B4 I330 D3 I334 A3 I338 B6
 F2114 B1 F2119 C1 F9331 E7 F9335 E9 F9340 D9 I323 A5 I327 D5 I331 E3 I335 A4 I339 D7



Oscillograms Supply Part







A: DC, 500mV/Div, 5us/Div
Connector 1944 Pin 13




A: DC, 5 V/Div, 5us/Div
Connector 1944 Pin 5

Frontend (FV)

1701 E1	2701 B10	2707 C9	2713 E7	2719 G12	2725 H3	3700 H9	3706 B9	3712 C15	3718 G6	3724 H3	3730 A7	3777 H5	5701 D13	5707 G1
1703 G7	2702 C11	2708 C9	2714 E6	2720 G1	2726 H3	3701 B7	3707 C9	3713 D13	3719 G7	3725 H9	3731 H11	4701 D6	5702 B10	5708 H4
1704 E8	2703 C3	2709 C10	2715 F9	2721 G2	2727 H2	3702 B11	3708 C11	3714 D6	3720 G9	3726 H3	3732 H11	4702 G8	5703 C3	5701 A10
1705 D13	2704 C8	2710 C14	2716 G4	2722 G2	2728 I1	3703 B11	3709 C4	3715 D13	3721 G6	3727 H6	3733 D15	4703 F10	5704 E6	5702 G7
1706 F10	2705 C12	2711 D13	2717 G4	2723 G3	2729 E5	3704 B3	3710 C12	3716 E14	3722 G5	3728 H6	3734 D15	4704 H9	5705 D5	5701-A F13
1707 G10	2706 C12	2712 G6	2718 G11	2724 G9	2730 E5	3705 B7	3711 C13	3717 F11	3723 G5	3729 F11	3776 H5	4705 G6	5706 B12	5701-B C13






Variant List Frontend

	PAL BG	PAL BG	PAL I Fullband	PAL, SEC BG/DK	PAL, SEC BG/I/DK, L/L'
	/02	/13, /16	/07	/58	/39
Pos.	FM QSS	FM, NICAM QSS	FM, NICAM QSS	NICAM QSS	FM, AM, NICAM QSS
1708	TP916L MKII	TP916L MKII	-	-	TP926L MKII
1701	TCBZ4-001A/B	TCBZ4-001A/B	TCBZ4-001A/B	TCBZ4-001A/B	TCBZ4-003A/B
1703	K9656M	K9656M	K9656M	K9656M	K9656M
1704	G3956M	G3956M	K3953M	G3956M	K3953M
1705	TPS 5,5	TPS 5,5	TPS 6,0	TPS 5,5	TPS 5,5
1706	-	-	-	-	-
1707	-	-	-	-	-
2707	-	-	-	-	100n
2712	1n	1n	1n	1n	1n
2713	-	-	-	-	120p
2714	-	-	-	-	220p
2718	-	-	-	-	-
2719	-	-	-	-	-
2722	470p	470p	470p	470p	-
3701	-	-	-	-	39K
3710	-	-	-	220E	220E
3711	-	-	-	3k3	3k3
3714	-	-	-	-	100E
3715	330E	330E	330E	330E	270E
3716	-	-	-	2k2	2k2
3717	-	-	-	-	-
3718	-	-	-	-	2k2
3719	-	-	-	-	6k8
3720	-	-	-	-	-
3721	-	-	-	-	4k7
3725	-	-	-	-	-
3726	1k	1k	1k	1k	-
3727	-	-	-	-	5k6
3728	-	-	-	-	5k6
3729	5k6	5k6	5k6	5k6	5k6
3730	-	-	-	-	100K
4701	0E	0E	0E	0E	-
4702	-	-	-	-	-
4703	-	-	-	-	-
4704	0E	0E	0E	0E	0E
4705	0E	0E	0E	0E	-
4706	0E	0E	0E	0E	-
5701	15uH	15uH	15uH	15uH	15uH
5704	-	-	-	-	41645
6702	-	-	-	-	BA792
7701	-	-	-	HEF4053	HEF4053
7702	-	-	-	-	PDTC124EU
7705	TDA 9817 T	TDA 9817 T	TDA 9817 T	TDA 9817 T	TDA 9818 T
7706	-	-	-	-	BC847BW
9701	0E	0E	0E	-	-
9702	0E	0E	0E	0E	0E


FUNKTION
TUMOD PHILIPS
TUMOD ALPS MK3
QSS Sound OFW
QSS Video OFW
Video-TRAP
1. Sound-Filter
2. Sound-Filter
VIF AGC TDA 9818T only
QSS Sound OFW Kopplung
40,4 Falle
40,4 Falle
Deemphasis MONO
FM PLL Demodulator
Siebung Audio Modul. IN
SEC Band 1 Adj.
Video Trap Bypass
Video-Amplitude Multistdt.
40,4 Falle
Video Trap Vorwiderstand
Video Trap Abschluß
Deemphasis MONO
Sound OFW Umsch.
Sound OFW Umsch.
EFC Vorwiderstand
Sound OFW Umsch.
2. EFC Vorwiderstand
Audio IN Modulator
Sound OFW Umsch.
Sound OFW Umsch.
Mute FM Demodulator
SEC Band 1 Adj.
40,4 Falle Bypass
Intercarrier switch
4053 Bypass
SIF zu MSP/TDA
QSS OFW BG/DK/I Select.
Meßpunktverbindung
Video Trap Spule
40,4 Falle
Sound OFW Umsch.
EFC / TRAP switch
AFC L'
AV Demodulator
Sound OFW Umsch.
4053 Bypass
SIF zu MSP/TDA




PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	




1760 D5
2760 E3
2763 E4
2770 D4
2772 A3
2773 A3
2775 A6
2778 A5
2779 E6
2780 E6
2781 A5
2782 C7
2783 E5
2784 C3
2785 D4
2786 D8
2789 A6
3762 E3
3766 E6
3768 A3
3769 E6
3770 C2
3771 E5
3778 B8
3779 B8
4760 C7
4761 D7
7760 B3
9011 C8
I770 C8
I771 E5
I778 C2
I791 E4
I792 E3
I796 B8




Stereo Decoder (FM-STEREO-MSP)




PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	













- | | |
|---------|---------|
| 1761 F6 | 1789 B7 |
| 2758 E8 | 1790 B5 |
| 2759 E9 | 1793 A2 |
| 2761 A6 | 1794 E8 |
| 2762 A6 | 1795 D8 |
| 2764 A6 | |
| 2765 D8 | |
| 2766 A6 | |
| 2767 B8 | |
| 2768 B8 | |
| 2769 B7 | |
| 2771 B2 | |
| 2774 C2 | |
| 2776 D7 | |
| 2787 F5 | |
| 2788 F6 | |
| 2790 F5 | |
| 2791 F5 | |
| 2792 C2 | |
| 2793 D2 | |
| 2794 D2 | |
| 2795 C7 | |
| 2796 C8 | |
| 2797 E8 | |
| 2798 E7 | |
| 2799 A6 | |
| 3760 A6 | |
| 3763 A7 | |
| 3764 A8 | |
| 3765 B2 | |
| 3767 B2 | |
| 3772 D8 | |
| 3773 E8 | |
| 3774 A1 | |
| 3775 A1 | |
| 4759 A5 | |
| 4762 F3 | |
| 4763 F3 | |
| 4764 F4 | |
| 4765 F4 | |
| 4770 D9 | |
| 4771 E9 | |
| 5760 A8 | |
| 5761 F5 | |
| 5762 F5 | |
| 6761 A7 | |
| 7761 B3 | |
| 7762 A2 | |
| C760 A2 | |
| F760 E3 | |
| F761 F5 | |
| I760 B2 | |
| I761 B2 | |
| I762 B2 | |
| I763 C2 | |
| I764 C2 | |
| I765 D2 | |
| I766 D2 | |
| I767 E3 | |
| I768 E3 | |
| I769 E3 | |
| I772 E4 | |
| I773 E4 | |
| I774 E5 | |
| I775 E5 | |
| I776 E6 | |
| I777 E6 | |
| I779 E6 | |
| I780 E7 | |
| I781 D7 | |
| I782 D7 | |
| I783 D7 | |
| I784 C7 | |
| I785 B7 | |
| I786 B7 | |
| I787 A6 | |
| I788 A6 | |





Oscillograms FM Audio, Erase Oscillator




Interconnections


Manual Page


PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	3-42

Main Erase Oscillator (ER)





1964 B4	2643 B2	2646 C3	3642 A2	3645 B2	3648 C2	7642 B1	F6402 B4	I642 B1	I645 C2	I648 C2
2641 A1	2644 B4	3640 A2	3643 A1	3646 B1	5641 C3	7643 C2	F9641 B2	I643 A2	I646 B3	I649 C2
2642 B3	2645 C3	3641 A2	3644 B1	3647 C2	7641 A2	F6401 B4	I641 B1	I644 A2	I647 B3	








Oscillograms Audio Linear




Interconnections		Manual		Page											
PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE							
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	3-42							


Oscillograms Video Signal Processing




Interconnections				Manual Page						
PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42		
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41			



1001 B4	7008 I2
2000 A2	7009 I8
2001 A6	7010 I5
2002 A5	7011 I6
2003 A9	7014 G2
2004 B4	7015 H2
2005 B5	7016 H2
2006 B5	F9001 B5
2007 A13	F9002 B6
2008 A13	F9003 B7
2009 B7	F9004 D9
2010 B4	F9005 D9
2011 B6	F9006 F7
2012 B4	F9007 G7
2013 B5	F9008 F7
2014 B2	F9009 I2
2015 B6	F9070 C11
2016 C1	F9072 H4
2017 C9	F9073 G5
2018 C9	F9074 B7
2019 D12	I201 C2
2020 D11	I202 D2
2021 E9	I203 E2
2022 E9	I204 E1
2023 F9	I205 F2
2024 F9	I206 F3
2025 G9	I207 G1
2026 F2	I208 G2
2027 F7	I209 G3
2028 B8	I210 G3
2029 G8	I211 I1
2030 G3	I212 G3
2031 G8	I213 I2
2032 G3	I214 G5
2033 G4	I215 A1
2034 G5	I216 F7
2035 G4	I217 A4
2036 G6	I218 H3
2037 G6	I220 I4
2038 G6	I221 H5
2039 H13	I222 H5
2040 H7	I223 I5
2041 H6	I224 I6
2042 H8	I225 I6
2043 H6	I226 I7
2044 I2	I227 H7
2045 I1	I228 I8
2047 I13	I229 H7
2048 I7	I241 G6
2049 I7	I242 G6
2050 I8	I249 H8
2052 I4	I250 F8
2053 D11	I253 E9
2054 G3	I254 E10
2055 G2	I255 D9
2056 G3	I256 D9
2057 H3	I257 C9
2060 A4	I258 C11
2093 A2	I259 D12
2094 A1	I260 D13
2095 C9	I261 A12
3001 A4	I262 A13
3002 B4	I265 A11
3003 B1	I270 A6
3004 A4	I271 B6
3005 B5	I272 B6
3006 B3	I275 B4
3007 B7	I278 B4
3008 C1	I279 B4
3009 D13	I281 B3
3010 E1	I282 B3
3011 D12	I283 A2
3012 E13	I284 A2
3013 C9	I285 H1
3014 D2	
3017 F6	
3018 G4	
3019 G6	
3020 G6	
3021 A1	
3022 B1	
3023 G4	
3024 G6	
3025 F6	
3026 G7	
3027 G7	
3028 H7	
3030 H5	
3031 H6	
3032 H8	
3034 B3	
3035 A1	
3037 I3	
3038 I2	
3040 I6	
3041 I5	
3042 I6	
3046 I8	
3047 G1	
4001 A7	
5001 D11	
5002 G6	
5003 H12	
5004 H7	
5005 H5	
5006 H7	
5008 I2	
5009 I4	
5010 A2	
7001 A4	
7002 A1	
7003 B12	
7004 D12	
7005 B2	
7006 G7	
7007 G8	




Head Amplifier (HA)




Interconnections

Manual Page

PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	



Oscillograms Head Amplifier







Interconnections


Manual Page


PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	3-42

Oscillograms SECAM L Chroma Processing




Interconnections		Manual Page							
PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42	
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41		





2071 A4 F086 E5
 2072 A4 F087 E5
 2073 A3 F088 F4
 2074 B2 F089 F4
 2075 A6 F090 F4
 2076 A4 F091 E3
 2077 B5 F092 E2
 2078 F9 1069 F8
 2079 B7 1070 E7
 2080 E7 1071 A4
 2081 E4 1072 A2
 2082 E5 1073 B4
 2083 E1 1074 A5
 2084 F6 1075 B6
 2085 F6 1076 B7
 2086 F7 1077 B7
 2087 F4 1078 D8
 2088 F3 1079 E7
 2089 F3 1080 F3
 2090 F3 1081 F7
 2091 E9 1082 F6
 2092 B6 1083 F5
 2096 A9 1084 F5
 2097 B8 1085 F5
 2098 D7 1086 F5
 3061 F6 1087 A6
 3062 F8 1088 F6
 3063 F4 1089 E1
 3064 F6 1090 B8
 3065 F8 1091 F9
 3066 C8 1092 C7
 3067 C9 1094 E9
 3068 D8
 3069 B8
 3070 B8
 3071 A6
 3072 A2
 3073 A5
 3074 A2
 3075 A5
 3076 A5
 3077 C7
 3078 B5
 3079 B7
 3080 E7
 3081 E8
 3082 E5
 3083 F5
 3084 F2
 3085 F4
 3086 F3
 3087 F4
 3088 F5
 3089 F5
 5071 A5
 5072 A3
 5073 B7
 5074 E7
 5075 F4
 7071 A6
 7072 B2
 7073 B8
 7074 E8
 7075 F5
 F072 B2
 F073 B4
 F074 B5
 F075 B5
 F076 A6
 F077 E2
 F078 A8
 F079 A8
 F080 B6
 F081 B9
 F082 E8
 F084 F7
 F085 E6


Chroma Noise Reduction (CNR)




Interconnections

Manual Page


PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	




2800 E8	I801 A1
2801 A2	I802 F8
2802 B3	I803 A2
2803 B5	I804 B2
2804 B2	I805 B1
2805 B4	I807 C2
2806 B3	I808 C2
2807 B4	I809 C2
2808 B4	I810 D3
2809 C4	I811 A4
2810 C4	I813 A4
2811 C7	I814 A5
2812 D2	I815 B5
2813 D7	I816 A5
2814 D8	I817 B7
2815 D7	I818 B6
2816 D5	I819 C5
2817 D8	I820 C8
2818 E9	I821 D6
2819 F9	I823 D7
2820 E9	I824 D7
2821 F5	I825 D8
2822 F6	I827 E8
2823 F6	I828 E8
2824 F6	I829 F9
2825 F7	I830 F9
2826 F8	I832 C4
2827 F8	I833 F7
2828 B6	I834 F6
2829 C6	I835 E6
3801 A2	I836 E6
3802 A3	I837 D6
3803 A4	I838 C6
3804 B7	I839 C7
3805 A4	
3806 A4	
3807 A4	
3808 B1	
3809 A2	
3810 B4	
3811 B4	
3812 B7	
3813 C8	
3814 B2	
3815 C2	
3816 C1	
3817 C2	
3818 E9	
3819 B6	
3820 C6	
3821 C5	
3822 D6	
3823 F6	
5801 E4	
5802 F8	
5803 D5	
5804 E5	
5805 F7	
5806 F8	
5807 E9	
7801 A1	
7802 B8	
7803-A B5	
7803-B C5	
7803-C B7	
7803-D C7	
7804 B1	
7805 D4	
7807 D6	
C820 E1	
F9801 F8	
F9802 E8	
F9808 A2	
F9809 B2	
F9810 D7	






















6503 B8	6513 A1	7508 F9	C501 G11	C509 G12	F5106 A8	F5202 A13	F5220 A11	F5604 G9	I104 G6	I112 G2	I120 F10	I128 E3	I144 H1
6504 B10	6514 B1	7509 A2	C502 G12	F4101 A3	F5108 A8	F5203 A13	F52041 B4	F5606 H9	I105 G7	I113 A2	I121 G3	I129 E2	I145 H2
6505 B6	6515 A3	7510 G1	C503 G11	F4102 A3	F5110 B7	F5206 A12	F5402 B4	F5607 H9	I106 G8	I114 E7	I122 B3	I138 E3	I146 F4
6508 B10	6516 A3	7511 F2	C504 G12	F4103 A3	F5114 A7	F5208 A12	F5403 B5	F9501 B6	I107 G8	I115 B4	I123 C3	I139 F1	I147 H3
6507 D13	7502 C7	7512-A E1	C505 G12	F5101 A10	F5116 A8	F5210 A11	F5404 B5	F9502 D7	I108 F8	I116 E9	I124 D3	I140 G2	I148 D5
6508 D8	7504 D9	7512-B E3	C506 G12	F5102 A9	F5119 A7	F5214 A11	F5405 B5	I101 C7	I109 G7	I117 F9	I125 E12	I141 G3	I149 E5
6509 B8	7505 F9	9500 D1	C507 G12	F5103 A9	F5120 A6	F5216 A12	F5601 G9	I102 A1	I110 G7	I118 E9	I126 D1	I142 G3	I150 E5
6510 C12	7506 E6	C500 G12	C508 G12	F5104 A9	F5201 A14	F5219 A11	F5603 G9	I103 E7	I111 D9	I119 B3	I127 E2	I143 G3	I152 D4





Oscillograms Central / Deck Control



Longplay

















Standard Play

Interconnections

Manual Page


PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	3-42

Oscillograms Deck Electronics



PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	


Deck Electronics (DE)




OSCILLOGRAMS

... V MEASURED IN PLAYBACK MODE

... V MEASURED IN RECORD MODE




0001 F9	9301 A8
0007 F5	F4601 D9
0008 B4	F4602 E9
1946 D9	F4603 E9
1947 A3	F4604 E9
1948 D5	F4605 E9
2461 F8	F4606 E9
2462 E9	F4607 E9
2463 F6	F4701 A3
2471 A6	F4703 B3
2472 A2	F4801 D5
2473 A5	F4802 D5
2474 B5	F4803 D5
2475 B6	F4804 D5
2476 B6	F4805 D5
2477 B2	F4806 D5
2478 C2	F9470 A1
2479 C5	F9471 A1
2480 C6	F9472 A2
2482 C9	F9473 A2
2483 D1	F9481 E1
2484 E4	I566 E1
2485 E4	I567 F1
2486 E4	I568 E3
2487 E3	I569 C1
2489 E1	I570 B1
2490 D8	I571 A1
2491 E1	I572 B2
2492 E4	I573 C1
2493 E3	I574 A5
2494 F1	I575 A6
2495 F3	I576 E6
2496 F3	I577 F5
2497 F1	I578 B6
3363 E5	I579 B6
3364 E5	I580 C6
3365 E8	I581 B5
3370 E1	I582 B4
3371 A1	I583 C4
3372 A1	I584 A8
3373 A5	I585 B8
3374 A6	I586 B8
3375 A9	I587 B9
3376 A5	I588 C9
3377 A2	I589 C8
3378 B5	I590 C9
3379 B1	I591 D8
3380 B4	I592 E3
3381 B5	I593 E4
3382 B1	I594 E4
3383 B5	I595 F1
3384 B8	I596 F3
3385 B1	I597 F3
3386 B5	I598 E3
3387 B2	
3388 C8	
3389 C9	
3390 C3	
3391 C8	
3392 C8	
3393 C8	
3394 C9	
3395 D4	
3396 D4	
3397 D4	
3398 D8	
3399 E1	
4498 E6	
5471 D1	
7440-A A2	
7440-B B2	
7441 A9	
7442 A5	
7443 C7	
7446 F2	
7464 C4	
7465 F5	
7466 B4	




Interconnections Manual Page


PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE 3-42
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	




OSD Part (VPO)




PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	3-42






Follow me part (FOME, VPS, PE)




1871 E1	1040 D4
2099 C8	1881 B5
2830 A6	1882 B4
2831 B4	1884 B3
2832 A2	1885 B3
2833 C2	1887 A2
2834 A2	1888 A2
2835 C2	1889 A1
2836 A1	1890 C4
2837 B1	1891 F8
2872 C4	1892 B1










Display Control ADCP18 (DC)




PS 3-18	FM-STEREO-TDA 3-22	AF 3-24	AL 3-26	HA 3-30	CNR 3-34	AIO1 3-36	DE 3-39	VPS; FOME; PE
FV 3-20	FM-STEREO-MSP 3-23	ER 3-25	VS 3-29	VS-SEC 3-33	IO 3-35	AIO2 3-40	VPO 3-41	3-42



Connector PCB ACP18



[illegible]

4. DRIVE ASSEMBLY

This tape deck has three motors; one providing precision drive for the scanner unit; the second providing direct drive for the capstan and belt drive for the reel tables; the third motor drives the lift and tape threading/dethreading operations.

Special features are:

Quick start
Short winding time
Automatic cleaning of video heads by cleaning roller

To obtain a high repair standard we have developed a range of service kit's. These kit's covers the spare parts which are engaged together.

The tape deck's sensors are located on the motherboard underneath the tape deck, and included in its circuitry, lay out and parts list.

4.1 Deck parts replacement

The procedure for the removal and refitting of the following parts is described; only the scanner, the capstan motor and the A/C head are fixed by screws.

All the other deck assembly parts are held only by snap hooks.

For the replacement of parts on the underside of the tape deck, remove the tape deck from the motherboard.

Manual extraction of cassette:

If, after the Eject button has been pressed, the drive does not unthread and eject the cassette, the dethreading/eject operation can also be carried out manually by turning the wheel at the rear of the threading motor.





fig. 1


IMPORTANT:

After each repair has been carried out in the drive assembly, the first operation after repairing must be to bring the cassette compartment into „eject“ position by hand.

Auxiliary tools for deck adjustment:




Tool for removing the head disc 4822 395 90977




Tentelometer 4822 395 90584



Tool for tapetension adjustment 4822 395 50188



Handle 4822 256 90493



Torquemeter:

600 gf-cm 4822 395 90232
90 gf-cm 4822395 80196



Post adjustment screwdriver 4822 395 50275

Testcassette 4822 397 30103


Nylon gloves 5322 395 94022

4.1.1 Deck lay out diagram


Deck in position „threaded out“.

The following diagrams indicate the relative position of the gearwheels and levers when the deck is in the threaded out (cassette-compartment down) position.

Top view



Underside view



4.1.2 The Lift

Refitting the lift compartment:

Ensure the lift compartment is down and gear A is rotated one click stop anticlockwise from the down position.


The removal and refitting of the lift can be carried out in all deck positions with the exception of „eject“ (ensure that gears 103/105 are free and if present the cassette loader gear 2 pos.105 is positioned to the rear).

To remove the lift:

Free the holding bracket (Fig. 2) by rotating it up and back from the upper end.

Unscrew the 4 screws on the underside of the deck.

Carefully remove the lift vertically, noting the position of the record protect operating lever.




4.1.3 Head disc replacement

Removal :

Nylon gloves should be worn when handling the head disc.


Turn the head disc until the long hole of the rotor appears in the bigger hole of the scanner motor

Insert the reference pin C (included with each service head disc) through the bigger hole of the lid of the scanner motor until the pin snaps in the long hole of the rotor. (Fig. 3)



Important:

Choose Installation/Removal of the upper/lower clamping element by turning and attaching the reference element to the tool. (Fig. 4)






fig. 5

Position the tool on the upper clamping element, loosen the clamping element by turning the lever 90 degrees and remove it from the head disc. (Fig. 5)

Prepare the tool for the lower clamping element. Position the tool on the head disc and make sure that all 3 pins are snapped in the lower clamping element. Loosen the clamping element by turning the lever 90 degrees and remove the head disc plus the tool from the scanner spindle. (Fig. 6)




fig. 6

Installation:

Before carrying out the installation of the new head disc make sure that the scanner motor spindle is clean and undamaged. (The spindle has to be free of grease and must not be touched with bare hands)
Insert the 2 Mylar foils (included with each head disc) in the head disc. (Fig. 7)




fig. 7

Position the tool (reference: lower clamping element) on the new head disc (with protective cover) and loosen the lower clamping element.

Position the head disc so that pin D of the protective cover engages in the hole of the stator (the arrow on the protective cover must point towards the scanner print). (Fig. 8)




fig. 8

Reach the exact position through pressing the tool down with a force of 1 N. and fix the lower clamping element by turning the lever towards „close“.

Remove the tool.

Change the tool to „upper clamping element“ and position the clamping element exactly. (Fig. 9)




fig. 9

Tighten the clamping element through turning the lever towards „open“.
Position the tool planely on the head disc and fix the clamping element. (Fig. 5 „close“)
Remove the protecting cap from the head disc, withdraw the two foils and

Mylar
remove the
reference pins.

After replacing the head disc, carry out the following adjustments and checks :

Head switching pulse (gap position, chapter 3)
Write current adjustments (chapter 3)

Check tape path alignment (see paragraph 4.2.1.)

4.1.4 A/C Head (Combi head) (Pos. 36)

Remove the fixing spring (A) (fig. 10)

Remove the fixing screw and replace the A/C head.

Use a new fixing spring (included with new A/C head) for reassembly.

After the A/C head has been replaced, all adjustments described in paragraph 4.2.1.2 and paragraph 4.2.2 have to be carried out.




fig. 10

4.1.5 Threading motor (Pos. 38)

Remove the belt and disconnect the connector plug.

Remove the threading motor from the motor supports (Fig. 11).

During reassembly ensure that the threading motor is correctly located in the front and rear supports.




fig. 11

4.1.6 Capstan motor (Pos. 127)

Remove the tape deck.

Remove the belt (pos. 126) on the underside;

Remove the three capstan motor fixing screws (Fig. 12) and withdraw the capstan motor downward from the drive assy.

The reassembly is carried out in reverse order. Make sure that the capstan is free of grease.




fig. 12

4.1.7 Pressure roller (Pos. 37)

Remove the tape deck

Unhook and remove the pressure roller tension spring.

Release the pressure roller guide (pos. 41) from the guide in the threading motor holder by pressing the top of the motor guide rearwards and rotating the pressure roller guide assembly clockwise by approximately a quarter of a turn (Fig. 13). The pressure roller and guide can now be lifted clear.





fig. 13



Ensure that no grease from the pressure roller guide gets to the capstan or pressure roller.

The reassembly is carried out in reverse order.

4.1.8 Roller unit right (Pos. 26)

Remove the tape deck.

Compress the two snap hooks by means of a pair of tweezers and remove the roller assy from the roller unit right (Fig. 14).

Unhinge the loading arm right from the holding plate and push the latter towards the front of the deck to remove from the guide (right).

NOTE: During reassembly ensure the link from 25 is engaged in the hole of the holder plate 26.




fig. 14

After replacing the roller unit (right), the tape path has to be checked, and adjusted if necessary (paragraph 4.2.1).

4.1.9 Roller unit left (Pos.23)

Set the drive assy to „Eject“ position.

Unhook the tension arm spring (pos. 11), to avoid the tension arm spring being pre-loaded.

At the bottom side of the drive assy remove the tension lever (pos.112).

Compress the two snap hooks by means of a pair of tweezers (Fig. 9) and remove the roller assy (A) from the plate (B).

Unhinge the loading arm (left) from the holding plate and remove the latter downward from the drive assy through the recess in the chassis (Fig. 15).

The reassembly is carried out in reverse order.

NOTE : During reassembly

1. Place the carriage holding plate in the assembly with the half-round cutout nearest the rear of the deck.
2. When the loading arm is refitted ensure the pin on the underside of 23 is through the link of 24B.

After replacing the roller unit (left) the tape path has to be checked (paragraph 4.2.1.), and adjusted if necessary.




fig. 15

4.2 Adjustments

Adjustments must not be made in the service position.

4.2.1 Tape path




fig. 17

4.2.1.1 Roller left unit/roller unit right

Preparation:

Connect one input of a dual trace oscilloscope to observe the tape sync pulse CTL. The other input (DC coupled) to observe the tracking information TRIV.

Trigger the oscilloscope externally on the head pulse HP1 ("SWIN").

Playback the black and white section of the alignment test tape.

Set the deck in the condition where the video heads are running along the upper edge of the tracks only by:

1. Call the service test program (chapter 2.1)
2. Activate manual tracking (service test program step 03) and watch the tape sync pulse move to the left in relation to the TRIV signal.
3. Note the extreme left hand position reached by the sync pulse, repeat as necessary.
4. Stop the movement of the pulse when the TRIV signal reduces to 1/2 to 2/3 maximum amplitude by pressing the normal play button. A noisy picture (disturbances) is visible on the TV set and the CTL pulse should be to the left of the display.

The recorder will hold this position until the service test program step 03 is left.

This condition works only if X-distance is adjusted.





fig. 18



Adjustment:

Adjust the left and right roller units to make the tracking signal TRIV straight and flat as possible (Fig. 18).

4.2.1.2 A/C Combi head

Tilt angle adjustment

Set the drive to feature mode (e.g. +7)

Adjustment :




fig.19

By means of the tilt angle adjusting screw move the tape until the lower edge just touches the tape guide A1 (see Fig. 19) the tape must not be distorted at the lower edge (by pressing onto guide).

Adjustment of the azimuth angle and the head height

Connect an oscilloscope to the linear Audio output.
Play the section of the test cassette with the audio signal 400 Hz.
Adjust for maximum output voltage by means of the height adjustment screw
Play the section of the test cassette with the audio signal 8 kHz.
Adjust to maximum output voltage by means of the azimuth adjustment screw (Fig. 19).
If necessary, repeat this procedure
Check the tilt angle adjustment

If the tape path was completely out of adjustment or if several components in the tape path have been replaced, it is possible, that the adjustments described in paragraph 4.2.1.1 and paragraph 4.2.1.2 have to be repeated several times.

4.2.2 Adjustment of the horizontal distance (x-distance)

Before this adjustment is carried out, insert the test cassette (start from Eject position). Call the service test program (tracking value will take up its nominal position) and press the „play“ button. Playback the black/white part of the test cassette.)

Display the TRIV signal on an oscilloscope (DC-coupled) and adjust for maximum voltage by means of the excentric screw (Fig.19).

4.2.3 Brake band and tape tension

Due to further development it is no longer necessary to make these adjustments after replacement of the brake band.
If the brake band or tape tension are completely misadjusted, set them to a center position; set the drive to „play“ and adjust the brake band until the edge of the elbow of the tape tension arm is aligned with the left inner edge of the left guide (fig. 20).

4.2.4 Friction clutch control check

Set the drive to „Play“ position.
Place the torquemeter on the right reel.
Turn the capstan motor to move the right reel clockwise.
Keep turning, until the indication at the torquemeter no longer changes (Fig. 21)
The torque has to be 10,5 mNm $\pm$ 25% (105gFcm $\pm$ 25%)

4.2.5 Reverse brake control

Set the drive to „Reverse“ position.
Place a torquemeter on the right reel and turn the latter counterclockwise, until the reel just starts to flip.
The value indicated at the torquemeter has to be 7mNm $\pm$ 3mNm (70 gFcm $\pm$ 30gFcm) (Fig. 21).

fig. 20






fig. 21




Lift assy

pos.150




In order to make the replacement of the deck parts easier, the snap hooks are marked with an arrow.

TOP VIEW




UNDERSIDE VIEW




4.3 Exploded view

Top view



Underside view



4.4 MECHANICAL PARTS LIST

Pos.	Description	K I T S							Code number 4822
		B	I	L	P	Q	S	T	
1	Rec. protection lever (with spring)								402 10202
2	Chassis mounting spring (2x)								492 71022
5	Main brake left				P				
6	Main brake spring (2x)				P				
9	Damping roller *)								528 70782
10	Main brake right				P				
11	Tension arm spring								492 33317
12	Tension crank								403 70551
13	Slip ring							U	
14	Tension band				P				
15	Tension arm								403 70547
16	Erase head								249 10522
17	Swivelling gear							U	
18	Brake gear (2x)							U	
19	Swivelling plate							U	
20	Reel table (S)							U	
20a	Reel table (T)							U	
21	Headamplifier holder							T	
22	Bracket							T	
23	Roller unit left								528 70771
24	Loading arm left	B							
25	Loading arm right	B							
26	Roller unit right								528 70772
27	Loading gear	B							
30	Reverse clip					Q			
31	Reverse lever					Q			
32	Intermediate lever					Q			
34	Scanner assy. 4/2 (Head disc and motor)								4822 218 12032
35	Cleaning roller								528 70773
36	A/C Head (with clip and screws)								249 10468
37	Pressure roller (with spring)								528 70774
38	Threading motor								361 10809
39	Threading belt								358 20421
40	Motor holder							T	
41	Pressure roller guide						S		
42	Reverse brake				P				
44	Slider gear	B					S		
45	Cam wheel						S		
46	Cam shaft						S		
47	Pulley shaft								528 81462
48	Worm shaft						S		
49	Chassis mounting clip							T	
50	WD-holder							T	

Pos.	Description	K I T S							Code number 4822
		B	I	L	P	Q	S	T	
101	Cassette loader trigger			L					
102	Clip			L					
103	Cassette loader gear1			L					
104	Cassette loader spring			L					
105	Cassette loader gear2			L					
106	Spindle								535 93277
111	Cam wheel reverse	B							
112	Tension lever							T	
113	Cam wheel tension	B							
114	Clutch lever (with spring)								403 70549
115	Clutch								528 20736
116	Changing gear	I							
117	Double gear	I							
118	Light prism							T	
119	Init flap and holder							T	
120	Cam wheel lever							T	
121	S-VHS lever							T	
122	Prism right							T	
123	Prism left							T	
125	Main slider							T	
126	Driving belt								358 31166
127	Capstan motor (with screws)								361 10805
129	Reverse kicker with transmission gears *)								522 20451
128	Gear pulley	I							
150	Lift								443 64112
KIT	B								310 31955
KIT	I								310 31963
KIT	L								310 32116
KIT	P								310 32191
KIT	Q								310 10658
KIT	S								310 10661
KIT	T								310 10662
KIT	U						3103		109 09190

*) optional

Um eine hohen Reparaturstandard zu gewährleisten sind mit Ausnahme von Kit T immer alle im Kit enthaltenen Teile zu tauschen.

In order to guarantee a high repairstandard all spare parts included in a kit have to be replaced with the exception of kit T.


Per una riparazione garantita occorre sostituire tutti i pezzi contenuti nei kit, fatta eccezione per il kit T.

Para obtener un estándar de reparaciones elevado, es necesario cambiar todas las partes contenidas en el kit, la única excepción es para el kit T.

A fin d'obtenir un standard de réparations élevé, toutes les pièces de rechange incluses dans un kit sont à remplacer, exception faite du kit T.

Om een hoge reparatiekwaliteit te waarborgen moeten, met uitzondering van kit T, altijd alle zich in een kit bevindende onderdelen worden vervangen.

Exploded View of the Set & Mechanical Parts



Set Parts List

Position	Code Number	Description
1	3103 138 90890	FRAME ASSY
7	3103 100 42400	SCREW P3,5X16
8	4822 502 14431	SCREENING SCREW
11	4822 256 10504	TD-HOLDER
20	3103 138 89930	CONTROL PANEL ASSY VR710/02/16/58
20	3103 138 90750	CONTROL PANEL ASSY VR710/07
20	3103 138 90770	CONTROL PANEL ASSY VR710/39
20	3103 138 91070	CONTROL PANEL ASSY VR765/02/16/58
20	3103 138 91080	CONTROL PANEL ASSY VR765/07
20	3103 138 91100	CONTROL PANEL ASSY VR765/39
20	3103 138 89940	CONTROL PANEL ASSY VR810/02/16
20	3103 138 90780	CONTROL PANEL ASSY VR810/07
20	3103 138 90800	CONTROL PANEL ASSY VR810/39
20	3103 138 90810	CONTROL PANEL ASSY VR910/02/16/58
20	3103 138 90820	CONTROL PANEL ASSY VR910/07
20	3103 138 90840	CONTROL PANEL ASSY VR910/39
20/6	3103 178 29410	LIFT FLAP ASSY VR710-VR810
20/6	3103 178 29770	LIFT FLAP ASSY VR765-VR910
20/7	4822 492 70896	LEG SPRING LIFT FLAP
20/11	2511 076 50010	SCREW 3X8
20/12	3103 138 90140	KEY-PCB VR710/02/07/16/58
20/12	3103 138 91200	KEY-PCB VR710/39
20/12	3103 138 90150	KEY-PCB VR810/02/07/16/39
20/12	3103 138 91180	KEY-PCB VR765/02/07/16/58
20/12	3103 138 91380	KEY-PCB VR765/39
20/12	3103 138 91190	KEY-PCB VR910/02/07/16/39/58
20/17	3103 104 25620	SIDE CAP RIGHT VR710-VR810
20/17	3103 178 31360	SIDE CAP RIGHT VR765-VR910
20/18	3103 104 25610	SIDE CAP LEFT VR710-VR810
20/18	3103 178 31370	SIDE CAP LEFT VR765-VR910
22	3103 141 23350	COVER LAQUERED VR710-VR810
22	3103 141 23410	COVER LAQUERED VR765-VR910
23	4822 502 14109	PLASTITE SCREW 3,5X10
30, 31	4822 256 10198	DISTANCE HOLDER DECK
36	2511 076 50013	SCREW BK3X10
39	3103 104 25670	JOG KNOB VR810
39	3103 178 29840	JOG KNOB VR910
40	3103 104 25680	SHUTTLE RING VR810
40	3103 178 29830	SHUTTLE RING VR910
41	3103 178 29130	AV-COVER VR710-VR810/02/07/16/58
41	3103 178 29590	AV-COVER VR710-VR810/39
41	3103 178 29730	AV-COVER VR765-VR910/02/07/16/58
41	3103 178 30220	AV-COVER VR765-VR910/39
42	3103 178 29460	FOOT ASSY
42/2	4822 462 41806	FOOT RUBBER INLAY
43	2511 076 50013	SCREW BK3X10
50	4822 492 11687	SPRING
60, 61, 62	4822 256 10359	DISTANCE HOLDER MOBO

Power Supply ASM

MISCELLANEOUS

1115	242202514547	CONNECTOR 17P F 1.25 FFC 0.3
1150	▲ 311225024750	MAINS BUSH
1151	▲ 310313886490	FUSE T1.25A
1152	▲ 242254943073	SURGE PROTECT
1153	▲ 242208610514	FUSE T100mA

CAPACITORS

2150	▲ 222233629146	220 nF 275V
2151	202030890136	100 nF 400V
2152	222215190014	47 µF 400V
2153	▲ 202055490127	2.2 nF 250V
2154	202002191332	47 µF 50V
2155	222236545473	47 nF 250V
2156	202055890442	47 pF 2kV
2157	202055890442	47 pF 2kV
2158	202055295376	4.7 nF 50V
2159	202055291156	1 nF 50V
2160	202030890117	100 nF 50V
2161	202232600028	689 pF 100V
2162	202030890117	100 nF 50V
2163	319802534790	47 µF 25V
2164	319802531010	100 µF 25V
2165	202002191408	470 µF25V
2166	202002191408	470 µF25V
2167	202002191408	470 µF25V
2168	222237065682	6.8 nF 400V
2170	202002191332	47 µF 50V
2172	202055295376	4.7 nF 50V
2173	202002191386	2200 µF 16V
2174	202002490502	1000 µF 6.3V
2175	202030890117	100 nF 50V

RESISTORS

3150	212255000124	VDR DC 1MA/470V MAX 775V
3151	▲ 232224213335	3.3 M
3152	212010390018	220 R
3153	▲ 232224213335	3.3 M
3154	▲ 232224213335	3.3 M
3155	▲ 232220533109	10 R
3156	232219463123	12 k
3157	▲ 232220733102	1 k FUSE NFR25H
3158	▲ 232220533479	47 R NFR25
3159	319801106890	68 R
3160	319801104710	470 R 0.17W
3161	319801101820	1.8 k 0.17W
3162	319801108230	82 k
3163	319801108220	8.2 k 0.17W
3164	319801102220	2.2 k 0.17W
3165	319801104720	4.7 k 0.17W
3166	319801102230	22 k 0.17W
3167	232215623902	3.9 k 1%
3168	319801101530	15 k 0.17W
3169	232215621003	10 k 1%
3170	319801104710	470 R 0.17W
3171	232215621008	1.0 R 1%
3172	319801101090	10 R 0.17W
3175	319801102210	220 R 0.17W
3176	319801101020	1 k 0.17W
3177	319801101030	10 k 0.17W
3178	232215625602	5.6 k 1%
3179	212036890118	470 R TRIMMER
3180	232215624702	4.7 k 1%
3181	319801101090	10 R 0.17W
3182	319801101090	10 R 0.17W
3183	319801101510	150 R 0.17W
3184	319801101030	10 k 0.17W
3185	319801106810	680 R 0.17W
3186	319801101020	1 k 0.17W
3187	319801104710	470 R 0.17W
3188	319801102240	220 k 0.17W
3189	319801104730	47 k 0.17W
3190	319801101020	1 k 0.17W
3191	▲ 230620403479	47 R FUSE NFR25
3192	319801103920	3.9 k 0.17W

3193	319801106830	68 k
3194	319801104720	4.7 k 0.17W
3195	▲ 232220533478	4.7 R FUSE NFR25
3196	319801106810	680 R 0.17W
3197	319801101050	1 M 0.17W
3198	319801102240	220 k 0.17W
3199	232215623309	33 R 1%

COILS

5150	▲ 311243820170	LINE FILTER CHOKE (TDK)
5151	▲ 310312830460	TRANSF TDK SRW32ES
5153	242254943921	BEAD 150MHZ 1K B
5154	319801821090	10 µH
5155	242253596691	COIL 0MUH33 PM20
5156	242253594642	22 µH

DIODES

6151	933838660673	1N4006GP
6152	933838660673	1N4006GP
6153	933838660673	1N4006GP
6154	933838660673	1N4006GP
6155	933548710673	1N4003GP A (GI) A
6156	933548710673	1N4003GP A (GI) A
6157	933723420133	BYD33J
6158	933548710673	1N4003GP A (GI) A
6159	933548710673	1N4003GP A (GI) A
6160	933838660673	1N4006GP
6161	933624760133	BAT85
6162	932203213673	MTZJ5.6B A (RHM0)
6163	932203213673	MTZJ5.6B A (RHM0)
6164	932208187683	BYW98-200 RL
6165	932208187683	BYW98-200 RL
6166	932212672673	BYV27-200 A (TEGO)
6167	933723400133	BYD33D
6168	319801033390	BZX79-F33
6169	933723400133	BYD33D
6170	932212818682	SB340L-7010-PKG1
6172	319801010010	1N4148
6173	319801010010	1N4148
6174	319801010010	1N4148

TRANSISTORS & IC's

7150	932207704687	FET POW STP3NA60 FI
7151	932205310682	MC44603P
7152	▲ 932208848682	OPTO COUPL K1150PG (TEG)
7153	932208367676	TL431CZ-AP
7154	319802043430	BC327-25
7155	319802043430	BC327-25
7156	319802040030	BC547B
7157	319802040030	BC547B
7158	932210646687	FET POW STD17N06-1(ST00)L
7159	319802040030	BC547B
7160	933535470126	MPSA43
7161	319802043430	BC327-25

REPAIR KITS

4822 310 11237	POWER SUPPLY REPAIR KIT
----------------	-------------------------

Motherboard

MISCELLANEOUS

0007	310310761690	TACHO HOLDER
0008	310310761840	TACHO HOLDER
0020	310310761680	MOBO SENSORHOLDER DECK
0021	310310761680	MOBO SENSORHOLDER DECK
0022	310310761680	MOBO SENSORHOLDER DECK
1001	242254301125	CRYSTAL 4.43MHz
1322	▲ 242208610776	FUSE 0.5A
1323	▲ 242208610779	FUSE 1.0A
1324	▲ 242208610776	FUSE 0.5A
1325	▲ 242208610779	FUSE 1.0A
1451	242254300922	RESXTL 20MHZ 20P AT-49 A
1460	310310790110	SWITCH ASSY
1461	310310790110	SWITCH ASSY
1701	242254290063	TUMOD V+U PLL IEC BGIDK B
1703	242254944341	OFWK9656M
1704	242254942068	OFWG3956M
1704	932204272682	OFWK3953M
1705	242254941595	FILTER BS 5.5MHz
1705	242254940808	CER.FILTER TPS6.0MB-TF21F
1708	311229712190	TP926L MK2 (BOOSTER)

when changing TUMOD order also spring 4822 492 11687

1760	242254301119	CRYSTAL 4MHz
1761	242254300781	CRYSTAL 18.432MHz
1871	242254300779	QUARTZ 13MHZ875 20P HC49U
1911	310310720440	CONNECTOR 9P
1942	242202514527	CON BM V17P F1.25 FFC 0.3
1944	242202514524	CON V 14P F1.25 FFC 0.3
1946	310310720720	CAPSTAN-MOBO-SOCKET JST
1947	242202514512	CONNECTOR 3 PIN
1948	242202514515	CONNECTOR 6 PIN
1951	310310024010	SCART SOCKET 7133
1952	310310024210	SCART SOCKET 7135
1954	310310023300	CINCH 4FOLD
1956	242202514516	CONNECTOR 7 PIN
1957	242203411514	CONNECTOR 1 PIN
1960	242202514516	CONNECTOR 7 PIN
1964	242202509405	CONNECTOR 2 PIN
1991	242202514512	CONNECTOR 3 PIN

CAPACITORS

2000	319802321040	100 nF 25V
2001	319801701030	10 nF 50V
2002	319801701030	10 nF 50V
2003	319801701030	10 nF 50V
2004	319801721050	1 µF 16V
2005	319801721050	1 µF 16V
2006	319801701030	10 nF 50V
2007	319801701030	10 nF 50V
2008	319802321040	100 nF 25V
2009	319801701030	10 nF 50V
2011	319802322240	220 nF 25V
2012	319802304730	47 nF 25V
2013	319801702230	22 nF 50V
2014	319802321040	100 nF 25V
2015	319802951080	1 µF 50V
2016	319801701040	100 nF 16V
2017	319801721050	1 µF 16V
2018	319802931090	10 µF 25V
2019	319802931090	10 µF 25V
2020	319801701030	10 nF 50V
2021	319802931090	10 µF 25V
2022	319802321040	100 nF 25V
2023	319802321040	100 nF 25V
2024	319802922290	22 µF 16V
2025	319801701030	10 nF 50V
2026	319801701030	10 nF 50V
2027	319802954780	4.7 µF 50V
2028	319801701030	10 nF 50V
2029	319801721050	1 µF 16V
2030	319802951080	1 µF 50V
2032	319801701030	10 nF 50V
2033	319801701030	10 nF 50V
2034	319802321040	100 nF 25V
2035	319802922290	22 µF 16V
2036	202255205335	220 pF 50V

2037	319801602290	22 pF 50V
2038	202255205337	390 pF 50V
2039	319802902210	220 µF 6.3V
2040	319801608290	82 pF 50V
2041	319802321040	100 nF 25V
2042	319801602290	22 pF 50V
2043	319801603990	39 pF 50V
2044	319802321040	100 nF 25V
2045	319801701030	10 nF 50V
2046	319801604790	47 pF 50V
2047	319802921010	100 µF 16V
2049	319801602790	27 pF 50V
2050	319801701030	10 nF 50V
2052	319801602210	220 pF 50V
2053	319802924790	47 µF 16V
2054	319802954780	4.7 µF 50V
2055	319802924790	47 µF 16V
2056	319802954780	4.7 µF 50V
2057	319801724730	47 nF 50V
2060	319802321040	100 nF 25V
2071	319801701030	10 nF 50V
2072	319801601510	150 pF 50V
2073	319802921010	100 µF 16V
2074	202255205335	220 pF 50V
2075	319801701030	10 nF 50V
2076	319802321040	100 nF 25V
2077	319801701040	100 nF 16V
2078	319801701030	10 nF 50V
2079	319801608290	82 pF 50V
2080	319801601010	100 pF 50V
2082	319801701030	10 nF 50V
2083	319801701030	10 nF 50V
2084	319802931090	10 µF 25V
2085	202055295343	470 nF 16V
2086	319801701030	10 nF 50V
2087	319801606810	680 pF 50V
2088	319801721050	1 µF 16V
2089	319801702230	22 nF 50V
2090	319801602210	220 pF 50V
2091	319801701030	10 nF 50V
2092	319801601010	100 pF 50V
2093	319801604790	47 pF 50V
2094	319802321040	100 nF 25V
2095	319801721050	1 µF 16V
2096	319801701040	100 nF 16V
2097	319801601090	10 pF 50V
2098	319801701030	10 nF 50V
2099	202055295338	100 nF
2101	319801601010	100 pF 50V
2104	319801602290	22 pF 50V
2105	202055295677	220 nF
2106	319802924790	47 µF 16V
2107	319801701030	10 nF 50V
2108	319801702230	22 nF 50V
2110	319801701030	10 nF 50V
2111	319801701030	10 nF 50V
2112	319801701030	10 nF 50V
2113	319801701030	10 nF 50V
2114	319801701030	10 nF 50V
2115	319801701030	10 nF 50V
2116	319801701030	10 nF 50V
2117	319801701030	10 nF 50V
2118	319801701030	10 nF 50V
2122	202055295677	220 nF
2123	319801701030	10 nF 50V
2124	319801701030	10 nF 50V
2125	319802924790	47 µF 16V
2126	319801602290	22 pF 50V
2321	319802321040	100 nF 25V
2322	319802321040	100 nF 25V
2323	319802532210	220 µF 25V
2324	319802532210	220 µF 25V
2325	319801403340	330 nF 50V
2326	319802532210	220 µF 25V
2328	319802921010	100 µF 16V
2400	319802921010	100 µF 16V
2401	319802321040	100 nF 25V
2402	319801601010	100 pF 50V
2403	319801601010	100 pF 50V
2404	319801702220	2.2 nF 50V
2405	319801602210	220 pF 50V

Motherboard

2406	319802921010	100	μF	16V
2408	319801721050	1	μF	16V
2411	319801702220	2.2	nF	50V
2412	319801701030	10	nF	50V
2451	319802321040	100	nF	25V
2452	319802922290	22	μF	16V
2453	319801721050	1	μF	16V
2454	319802321040	100	nF	25V
2455	319802321040	100	nF	25V
2456	319801602790	27	pF	50V
2457	319801603390	33	pF	50V
2458	319801701030	10	nF	50V
2459	319801602790	27	pF	50V
2461	319801704720	4.7	nF	50V
2462	319802531010	100	μF	25V
2463	319801701030	10	nF	50V
2471	319802924790	47	μF	16V
2472	319802921010	100	μF	16V
2473	319801704720	4.7	nF	50V
2474	319801702220	2.2	nF	50V
2475	319802924790	47	μF	16V
2476	319801703330	33	nF	50V
2477	319802321040	100	nF	25V
2478	319801701030	10	nF	50V
2479	319801701030	10	nF	50V
2480	319802921010	100	μF	16V
2482	319802321040	100	nF	25V
2483	319801702230	22	nF	50V
2484	202001292784	1	μF	50V
2485	202001292784	1	μF	50V
2486	202001292784	1	μF	50V
2487	319802321040	100	nF	25V
2489	319802532210	220	μF	25V
2490	319802321040	100	nF	25V
2491	319801601010	100	pF	50V
2492	319801702230	22	nF	50V
2493	319801701030	10	nF	50V
2494	319802321040	100	nF	25V
2495	319801724730	47	nF	50V
2496	319801702230	22	nF	50V
2497	319801701030	10	nF	50V
2501	212255100008	VDR	MAX	21V
2502	212255100008	VDR	MAX	21V
2503	212255100008	VDR	MAX	21V
2504	212255100008	VDR	MAX	21V
2505	212255100008	VDR	MAX	21V
2506	212255100008	VDR	MAX	21V
2507	212255100008	VDR	MAX	21V
2508	212255100008	VDR	MAX	21V
2509	212255100008	VDR	MAX	21V
2510	212255100008	VDR	MAX	21V
2511	212255100008	VDR	MAX	21V
2512	212255100008	VDR	MAX	21V
2513	319802921010	100	μF	16V
2514	319802924790	47	μF	16V
2515	319802321040	100	nF	25V
2516	319802321040	100	nF	25V
2517	319802321040	100	nF	25V
2518	319802321040	100	nF	25V
2519	319802321040	100	nF	25V
2520	319802321040	100	nF	25V
2521	319802321040	100	nF	25V
2522	319802321040	100	nF	25V
2523	319802924790	47	μF	16V
2526	319801721050	1	μF	16V
2527	319802924790	47	μF	16V
2528	319801721050	1	μF	16V
2529	319802924790	47	μF	16V
2530	319801721050	1	μF	16V
2532	319801601090	10	pF	50V
2533	319801721050	1	μF	16V
2534	319801601090	10	pF	50V
2535	319802931090	10	μF	25V
2536	319802931090	10	μF	25V
2537	319801604710	470	pF	50V
2538	319801604710	470	pF	50V
2539	319801701030	10	nF	50V
2540	319801701030	10	nF	50V
2541	319801601010	100	pF	50V
2542	319801606890	68	pF	50V
2543	319801701020	1	nF	50V

2544	319801701020	1	nF	50V
2545	319801701040	100	nF	16V
2546	319801601010	100	pF	50V
2547	319801601010	100	pF	50V
2601	319802321040	100	nF	25V
2602	319802922290	22	μF	16V
2603	319802924790	47	μF	16V
2604	319801721050	1	μF	16V
2605	319801701030	10	nF	50V
2606	319802321040	100	nF	25V
2607	319802924790	47	μF	16V
2608	319802321040	100	nF	25V
2609	319802924790	47	μF	16V
2610	319801701530	15	nF	50V
2611	202255205244	39	nF	50V
2612	319801702220	2.2	nF	50V
2613	319802931090	10	μF	25V
2614	319802321040	100	nF	25V
2615	319802924790	47	μF	16V
2616	319802952280	2.2	μF	50V
2617	319801721050	1	μF	16V
2618	319801701030	10	nF	50V
2619	319801701020	1	nF	50V
2620	319801603310	330	pF	50V
2621	319801701020	1	nF	50V
2622	202255205341	820	pF	50V
2623	319802931090	10	μF	25V
2624	319802304730	47	nF	25V
2625	202030090606	12	nF	50V
2626	319802922290	22	μF	16V
2641	319802924790	47	μF	16V
2642	319801701020	1	nF	50V
2643	319802924790	47	μF	16V
2644	202030090611	27	nF	50V
2645	319801703330	33	nF	50V
2646	202030090573	10	nF	50V
2651	319802921010	100	μF	16V
2652	319801701030	10	nF	50V
2653	319801701040	100	nF	16V
2654	319801702230	22	nF	50V
2655	319802952280	2.2	μF	50V
2656	319801601010	100	pF	50V
2657	223891015649	100	nF	25V
2658	319801703320	3.3	nF	50V
2659	319802924790	47	μF	16V
2660	319802931090	10	μF	25V
2661	223891015649	100	nF	25V
2662	319801701030	10	nF	50V
2663	319801703320	3.3	nF	50V
2664	319802924790	47	μF	16V
2665	319802931090	10	μF	25V
2666	319801701020	1	nF	50V
2668	202055295677	220	nF	
2669	202055295677	220	nF	
2671	319802951080	1	μF	50V
2672	319802951080	1	μF	50V
2674	202055295677	220	nF	
2675	202055295677	220	nF	
2677	202055295677	220	nF	
2678	202055295677	220	nF	
2679	319802951080	1	μF	50V
2680	319802931090	10	μF	25V
2681	319802951080	1	μF	50V
2683	319802931090	10	μF	25V
2684	319801721050	1	μF	16V
2685	319802931090	10	μF	25V
2686	202055295677	220	nF	
2687	319802321040	100	nF	25V
2701	202002191355	2.2	μF	50V
2702	319802321040	100	nF	25V
2703	319802552290	22	μF	50V
2704	319801604710	470	pF	50V
2705	319801701030	10	nF	50V
2706	319802931090	10	μF	25V
2707	319802321040	100	nF	25V
2708	319802322240	220	nF	25V
2709	202055294914	8.2	pF	50V
2710	319802321040	100	nF	25V
2712	319801701020	1	nF	50V
2713	319801601210	120	pF	50V
2714	319801602210	220	pF	50V

Motherboard

2715	319802952280	2.2	μF	50V
2720	319802921010	100	μF	16V
2721	319802321040	100	nF	25V
2722	319801604710	470	pF	50V
2723	319802321040	100	nF	25V
2724	319801701030	10	nF	50V
2725	202055295499	100	nF	50V
2726	319802952280	2.2	μF	50V
2727	319801701040	100	nF	16V
2728	319801601010	100	pF	50V
2729	319801605690	56	pF	50V
2730	319801605690	56	pF	50V
2758	319801704720	4.7	nF	50V
2759	319801704720	4.7	nF	50V
2760	319801703320	3.3	nF	50V
2761	319801701040	100	nF	16V
2762	319802571090	10	μF	100V
2763	319801606810	680	pF	50V
2764	319801701030	10	nF	50V
2765	319801701040	100	nF	16V
2766	319802931090	10	μF	25V
2767	319801701030	10	nF	50V
2768	319802571090	10	μF	100V
2769	319802571090	10	μF	100V
2770	319801724740	470	nF	16V
2771	319801604790	47	pF	50V
2772	319801606810	680	pF	50V
2773	319801703320	3.3	nF	50V
2775	319801701030	10	nF	50V
2776	319802954780	4.7	μF	50V
2778	319801724740	470	nF	16V
2779	319801724740	470	nF	16V
2780	319801704720	4.7	nF	50V
2781	319801724740	470	nF	16V
2782	319802924790	47	μF	16V
2783	319801701040	100	nF	16V
2784	319801604790	47	pF	50V
2785	319801724740	470	nF	16V
2786	319801724740	470	nF	16V
2787	319801603380	3.3	pF	50V
2788	319801603380	3.3	pF	50V
2789	319801701030	10	nF	50V
2790	319802571090	10	μF	100V
2791	319801701030	10	nF	50V
2792	319801604790	47	pF	50V
2793	319801721050	1	μF	16V
2794	319801721050	1	μF	16V
2795	319801601020	1	nF	50V
2796	319801601020	1	nF	50V
2797	319801601020	1	nF	50V
2798	319801601020	1	nF	50V
2799	319802924790	47	μF	16V
2800	319801602290	22	pF	50V
2801	319801601090	10	pF	50V
2802	319802321040	100	nF	25V
2803	319802321040	100	nF	25V
2804	319802924790	47	μF	16V
2805	319801721050	1	μF	16V
2806	319801601090	10	pF	50V
2807	319801606810	680	pF	50V
2808	319801721050	1	μF	16V
2809	319801721050	1	μF	16V
2810	319801721050	1	μF	16V
2811	319801701030	10	nF	50V
2812	319802924790	47	μF	16V
2813	319802321040	100	nF	25V
2814	319801701030	10	nF	50V
2815	319801701030	10	nF	50V
2816	319801701030	10	nF	50V
2817	319802321040	100	nF	25V
2818	319801701030	10	nF	50V
2819	319801701030	10	nF	50V
2820	319801704720	4.7	nF	50V
2821	319801701030	10	nF	50V
2822	319802954780	4.7	μF	50V
2823	319802924790	47	μF	16V
2824	319801721050	1	μF	16V
2825	319801701030	10	nF	50V
2826	319801701030	10	nF	50V
2827	319802931090	10	μF	25V
2828	319801601020	1	nF	50V

2829	319801601020	1	nF	50V
2830	319802321040	100	nF	25V
2831	319802931090	10	μF	25V
2832	319801702220	2.2	nF	50V
2833	319801702220	2.2	nF	50V
2834	319801601810	180	pF	50V
2835	319801601810	180	pF	50V
2836	319801721050	1	μF	16V
2837	319801721050	1	μF	16V
2839	319802902210	220	μF	6.3V
2840	319801724740	470	nF	16V
2850	202030890117	100	nF	50V
2851	319802904790	47	μF	6.3V
2852	319802321040	100	nF	25V
2853	319802321040	100	nF	25V
2855	319801701040	100	nF	16V
2856	319802304730	47	nF	25V
2857	319801601210	120	pF	50V
2860	319801701020	1	nF	50V
2863	202055295677	220	nF	
2864	319801608280	8.2	pF	50V
2865	319801602290	22	pF	50V
2866	202055295338	100	nF	
2867	319801602290	22	pF	50V
2872	319802321040	100	nF	25V
2873	319802321040	100	nF	25V
2874	319802321040	100	nF	25V
2875	319801602290	22	pF	50V
2876	319801602290	22	pF	50V
2877	319802924790	47	μF	16V
2878	319802321040	100	nF	25V

RESISTORS

3001	319801102220	2.2	k	0.17W
3002	319802151820	1.8	k	0.1W
3003	319802151020	1	k	0.1W
3004	319802158220	8.2	k	0.1W
3005	319802151020	1	k	0.1W
3006	319801105620	5.6	k	0.17W
3009	319802151010	100	R	0.1W
3010	319801104730	47	k	0.17W
3011	319801101020	1	k	0.17W
3012	319801103930	39	k	0.17W
3013	319802151050	1	M	0.1W
3015	319802155610	560	R	0.1W
3016	319802151030	10	k	0.1W
3017	212010892619	2.2	k	1%
3019	212010892614	680	R	1%
3020	212010893465	1.3	k	1%
3021	319802152240	220	k	0.1W
3022	319802151540	150	k	0.1W
3023	319802152210	220	R	0.1W
3024	319802151030	10	k	0.1W
3025	319802152710	270	R	0.1W
3026	212010892624	4.7	k	1%
3027	319802154710	470	R	0.1W
3029	319802154710	470	R	0.1W
3030	319801106810	680	R	0.17W
3031	319802151020	1	k	0.1W
3032	319802152220	2.2	k	0.1W
3033	319802151510	150	R	0.1W
3034	319801102220	2.2	k	0.17W
3035	319801101010	100	R	0.17W
3036	319801103310	330	R	0.17W
3037	319802152220	2.2	k	0.1W
3041	319801106810	680	R	0.17W
3042	319801104710	470	R	0.17W
3046	319802152220	2.2	k	0.1W
3047	319801104730	47	k	0.17W
3048	319801101040	100	k	0.17W
3061	319802151230	12	k	0.1W
3062	319802151520	1.5	k	0.1W
3063	319802158220	8.2	k	0.1W
3065	319801103920	3.9	k	0.17W
3066	319802154720	4.7	k	0.1W
3067	319801101020	1	k	0.17W
3068	319802153330	33	k	0.1W
3069	319802152720	2.7	k	0.1W
3070	319802151020	1	k	0.1W

Motherboard

3072	319801101520	1.5 k	0.17W	3388	319802154720	4.7 k	0.1W
3073	319802158220	8.2 k	0.1W	3390	319802154710	470 R	0.1W
3074	212010892514	15 k	1%	3391	319802152250	2.2 M	0.1W
3075	319802151040	100 k	0.1W	3392	319802151040	100 k	0.1W
3076	319802151030	10 k	0.1W	3393	319802151040	100 k	0.1W
3077	319802153920	3.9 k	0.1W	3394	319802154730	47 k	0.1W
3078	319802151830	18 k	0.1W	3397	319802151010	100 R	0.1W
3079	319802156810	680 R	0.1W	3398	319802154720	4.7 k	0.1W
3081	319802152220	2.2 k	0.1W	3403	319802151010	100 R	0.1W
3082	319801104720	4.7 k	0.17W	3404	319802152730	27 K	0.1W
3083	319801101020	1 k	0.17W	3405	319802156820	6.8 k	0.1W
3084	319802152230	22 k	0.1W	3406	319802190020	CHIP JUMPER	
3085	319802152730	27 K	0.1W	3407	319802151010	100 R	0.1W
3086	319802152720	2.7 k	0.1W	3409	319802152220	2.2 k	0.1W
3087	319802151030	10 k	0.1W	3410	319802152220	2.2 k	0.1W
3088	212036890124	22 k	POT	3413	319801101010	100 R	0.17W
3089	212036890119	1 k	POT	3415	319802152220	2.2 k	0.1W
3090	319801101030	10 k	0.17W	3416	319802155630	56 k	0.1W
3091	319802154720	4.7 k	0.1W	3417	319801102220	2.2 k	0.17W
3092	319802154720	4.7 k	0.1W	3419	319802152220	2.2 k	0.1W
3093	319802151030	10 k	0.1W	3422	319802154730	47 k	0.1W
3094	319802151030	10 k	0.1W	3423	319802154720	4.7 k	0.1W
3095	319801101010	100 R	0.17W	3425	319802153330	33 k	0.1W
3101	319802154720	4.7 k	0.1W	3426	▲ 232220533109	10 R	
3102	319802155610	560 R	0.1W	3427	319802152210	220 R	0.1W
3103	319802155610	560 R	0.1W	3428	319801101020	1 k	0.17W
3104	319802151120	1.1 k		3429	319802151030	10 k	0.1W
3105	319802154720	4.7 k	0.1W	3430	319802151020	1 k	0.1W
3106	319802151530	15 k	0.1W	3432	319801101030	10 k	0.17W
3107	319802153310	330 R	0.1W	3433	319801104720	4.7 k	0.17W
3108	319802154720	4.7 k	0.1W	3435	319802154720	4.7 k	0.1W
3109	319802154710	470 R	0.1W	3436	319801101010	100 R	0.17W
3110	319802153310	330 R	0.1W	3438	319802154730	47 k	0.1W
3111	319802152240	220 k	0.1W	3440	319802151030	10 k	0.1W
3112	319802151030	10 k	0.1W	3444	319801103310	330 R	0.17W
3113	319802153310	330 R	0.1W	3446	319801101030	10 k	0.17W
3114	212010892631	27 k	1%	3447	319801101010	100 R	0.17W
3115	212010892672	5.6 R		3449	319802151030	10 k	0.1W
3116	319802151230	12 k	0.1W	3450	319802151030	10 k	0.1W
3118	212036890123	10 k	POT	3451	319802151030	10 k	0.1W
3119	319802152220	2.2 k	0.1W	3452	319802151020	1 k	0.1W
3120	319802151020	1 k	0.1W	3454	319802158210	820 R	0.1W
3321	319801102240	220 k	0.17W	3455	319802151030	10 k	0.1W
3322	319801104790	47 R	0.17W	3457	319802154710	470 R	0.1W
3323	319802151030	10 k	0.1W	3458	319802151020	1 k	0.1W
3325	319802152240	220 k	0.1W	3459	319802154730	47 k	0.1W
3327	319801102210	220 R	0.17W	3460	319802154720	4.7 k	0.1W
3328	319801101020	1 k	0.17W	3461	319802158220	8.2 k	0.1W
3330	319801104720	4.7 k	0.17W	3462	319802152230	22 k	0.1W
3331	319801101040	100 k	0.17W	3463	319802152230	22 k	0.1W
3332	319802151030	10 k	0.1W	3464	319802154730	47 k	0.1W
3334	319802151030	10 k	0.1W	3465	319801101020	1 k	0.17W
3335	319802154720	4.7 k	0.1W	3466	319801101040	100 k	0.17W
3336	319801101030	10 k	0.17W	3467	319801102220	2.2 k	0.17W
3337	319802151040	100 k	0.1W	3472	319802151230	12 k	0.1W
3340	319801101020	1 k	0.17W	3473	319801101230	12 k	0.17W
3341	319802151010	100 R	0.1W	3474	319802154720	4.7 k	0.1W
3344	319801101010	100 R	0.17W	3475	319802154720	4.7 k	0.1W
3352	319801101020	1 k	0.17W	3476	319802154730	47 k	0.1W
3354	319802154730	47 k	0.1W	3477	319802154730	47 k	0.1W
3357	319801104730	47 k	0.17W	3478	319802151030	10 k	0.1W
3358	319801101020	1 k	0.17W	3479	319801102220	2.2 k	0.17W
3363	319801103910	390 R	0.17W	3480	319801101020	1 k	0.17W
3364	319801103330	33 k	0.17W	3483	319801101030	10 k	0.17W
3365	319802151030	10 k	0.1W	3488	319802151020	1 k	0.1W
3371	▲ 232220533228	2.2 R	NFR25	3490	319802152230	22 k	0.1W
3372	319802152230	22 k	0.1W	3492	319801104730	47 k	0.17W
3373	319802154710	470 R	0.1W	3493	319801104720	4.7 k	0.17W
3374	319802152210	220 R	0.1W	3495	319801102220	2.2 k	0.17W
3375	319802151030	10 k	0.1W	3496	319802152210	220 R	0.1W
3376	319802154720	4.7 k	0.1W	3497	319802151030	10 k	0.1W
3377	319801101080	1 R	0.17W	3498	319802151030	10 k	0.1W
3378	319802154730	47 k	0.1W	3499	319802154720	4.7 k	0.1W
3379	319802153920	3.9 k	0.1W	3503	319801102210	220 R	0.17W
3380	319801102710	270 R	0.17W	3504	319802157590	75 R	0.1W
3381	319801105620	5.6 k	0.17W	3505	319802157590	75 R	0.1W
3382	319802151030	10 k	0.1W	3507	319802152210	220 R	0.1W
3383	319801101030	10 k	0.17W	3509	319802152210	220 R	0.1W
3385	319802152230	22 k	0.1W	3511	319802157590	75 R	0.1W
3386	319801103330	33 k	0.17W	3513	319802152210	220 R	0.1W
3387	319802158230	82 k	0.1W	3514	319802152210	220 R	0.1W

▲... Safety component, use only this type

Motherboard

3515	319802152210	220 R	0.1W	3656	319802155620	5.6 k	0.1W
3516	319802152210	220 R	0.1W	3657	319802156830	68 k	0.1W
3518	319802157590	75 R	0.1W	3658	319802155620	5.6 k	0.1W
3519	319801104720	4.7 k	0.17W	3659	319802151040	100 k	0.1W
3520	319802151030	10 k	0.1W	3660	319802151040	100 k	0.1W
3521	319802156820	6.8 k	0.1W	3663	319802154750	4.7 M	0.1W
3522	319802155630	56 k	0.1W	3664	319801101020	1 k	0.17W
3523	319801103910	390 R	0.17W	3700	319802154710	470 R	0.1W
3524	319801108210	820 R	0.17W	3701	319802153930	39 k	0.1W
3525	319801103330	33 k	0.17W	3702	319801101040	100 k	0.17W
3528	319801101230	12 k	0.17W	3703	319802151830	18 k	0.1W
3529	319801101010	100 R	0.17W	3704	319802153330	33 k	0.1W
3533	319802152240	220 k	0.1W	3705	319801106810	680 R	0.17W
3535	319802152240	220 k	0.1W	3706	319802153310	330 R	0.1W
3536	319801102240	220 k	0.17W	3707	212036890124	22 k	POT
3538	319802152220	2.2 k	0.1W	3708	319802151830	18 k	0.1W
3543	319802151830	18 k	0.1W	3709	319802151540	150 k	0.1W
3544	319802154720	4.7 k	0.1W	3710	319802152210	220 R	0.1W
3545	319802152240	220 k	0.1W	3711	319802153320	3.3 k	0.1W
3546	319802151830	18 k	0.1W	3712	319802151020	1 k	0.1W
3547	319802154720	4.7 k	0.1W	3714	319802151010	100 R	0.1W
3548	319802152240	220 k	0.1W	3715	319802153310	330 R	0.1W
3549	319802152230	22 k	0.1W	3715	319802152710	270 R	0.1W
3550	319802151040	100 k	0.1W	3716	319802153320	3.3 k	0.1W
3551	319802153940	390 k	0.1W	3718	319802152220	2.2 k	0.1W
3552	319802151040	100 k	0.1W	3719	319802156820	6.8 k	0.1W
3553	319802153940	390 k	0.1W	3721	319802154720	4.7 k	0.1W
3554	319802151040	100 k	0.1W	3722	319802151010	100 R	0.1W
3555	319802151040	100 k	0.1W	3723	319802151010	100 R	0.1W
3556	319802151510	150 R	0.1W	3724	319802152230	22 k	0.1W
3557	319802151510	150 R	0.1W	3726	319802151020	1 k	0.1W
3558	319802151010	100 R	0.1W	3727	319802155620	5.6 k	0.1W
3559	319802151010	100 R	0.1W	3728	319802155620	5.6 k	0.1W
3560	319802151010	100 R	0.1W	3729	319802155620	5.6 k	0.1W
3561	319802151010	100 R	0.1W	3730	212036890126	100 k	POT
3562	319801101510	150 R	0.17W	3731	319801104710	470 R	0.17W
3601	319801104730	47 k	0.17W	3732	319802151010	100 R	0.1W
3602	319802152250	2.2 M	0.1W	3733	319802152720	2.7 k	0.1W
3603	319802158220	8.2 k	0.1W	3734	319802153310	330 R	0.1W
3604	319801101010	100 R	0.17W	3762	319802155620	5.6 k	0.1W
3606	319802151030	10 k	0.1W	3763	319802190020	CHIP JUMPER	
3607	319802151230	12 k	0.1W	3764	319801104720	4.7 k	0.17W
3608	319802151830	18 k	0.1W	3765	319801101010	100 R	0.17W
3609	319802152230	22 k	0.1W	3768	319802155620	5.6 k	0.1W
3610	319802153320	3.3 k	0.1W	3770	319802151020	1 k	0.1W
3611	319801103390	33 R	0.17W	3771	212010891686	7.5 k	
3612	319802156820	6.8 k	0.1W	3772	319802151020	1 k	0.1W
3613	319802151530	15 k	0.1W	3773	319802151020	1 k	0.1W
3614	319801104720	4.7 k	0.17W	3774	319802151020	1 k	0.1W
3615	319802153910	390 R	0.1W	3775	319802152720	2.7 k	0.1W
3616	319802156810	680 R	0.1W	3776	319802151010	100 R	0.1W
3617	319802151030	10 k	0.1W	3777	319802151010	100 R	0.1W
3618	319802154750	4.7 M	0.1W	3778	319802154710	470 R	0.1W
3619	319802152240	220 k	0.1W	3779	319802154710	470 R	0.1W
3620	319801102220	2.2 k	0.17W	3801	319802152720	2.7 k	0.1W
3621	319802158220	8.2 k	0.1W	3802	319802152720	2.7 k	0.1W
3622	319801102230	22 k	0.17W	3803	319802151040	100 k	0.1W
3623	319802151230	12 k	0.1W	3804	319801101030	10 k	0.17W
3624	319802154730	47 k	0.1W	3805	319801101040	100 k	0.17W
3625	319802152220	2.2 k	0.1W	3806	319801104790	47 R	0.17W
3626	212036890126	100 k	POT	3807	319801101040	100 k	0.17W
3627	212010891729	390 k	0.1W	3808	319801102720	2.7 k	0.17W
3628	319802154730	47 k	0.1W	3809	319802151520	1.5 k	0.1W
3629	319802152220	2.2 k	0.1W	3810	319802151820	1.8 k	0.1W
3630	319802156810	680 R	0.1W	3811	319801101040	100 k	0.17W
3631	319801104790	47 R	0.17W	3812	319801108220	8.2 k	0.17W
3632	319802151090	10 R	0.1W	3813	319801102230	22 k	0.17W
3633	212010892664	1.5 R		3815	319802153310	330 R	0.1W
3641	319802151830	18 k	0.1W	3817	212036890121	2.2 k	trim.
3642	319801103310	330 R	0.17W	3818	319801108210	820 R	0.17W
3643	319802153920	3.9 k	0.1W	3819	319802151830	18 k	0.1W
3644	319802152240	220 k	0.1W	3820	319802151830	18 k	0.1W
3645	319802153330	33 k	0.1W	3821	319801102230	22 k	0.17W
3646	319802156830	68 k	0.1W	3822	319802152230	22 k	0.1W
3647	319802151090	10 R	0.1W	3823	319802154740	470 k	0.1W
3648	212010892664	1.5 R		3830	319802154720	4.7 k	0.1W
3651	319801101030	10 k	0.17W	3831	319802151040	100 k	0.1W
3652	212010892633	39 k	1%	3832	319802152230	22 k	0.1W
3653	319802151010	100 R	0.1W	3833	319802151530	15 k	0.1W
3654	319801101010	100 R	0.17W	3834	319802154720	4.7 k	0.1W
3655	319802156830	68 k	0.1W	3835	319802154720	4.7 k	0.1W

Motherboard

3836	319802154720	4.7 k	0.1W
3837	319802152220	2.2 k	0.1W
3838	319802152220	2.2 k	0.1W
3839	319802151060	10 M	
3840	319802151060	10 M	
3841	319802153330	33 k	0.1W
3842	319802153330	33 k	0.1W
3843	319802153330	33 k	0.1W
3844	319802153330	33 k	0.1W
3845	319802153330	33 k	0.1W
3846	319802153330	33 k	0.1W
3851	319802156830	68 k	0.1W
3852	319802153320	3.3 k	0.1W
3853	319802153320	3.3 k	0.1W
3856	212010891725	270 k	0.1W
3857	319801101010	100 R	0.17W
3867	319802151010	100 R	0.1W
3868	319802152220	2.2 k	0.1W
3870	319802158210	820 R	0.1W
3871	319802154730	47 k	0.1W
3872	319802154730	47 k	0.1W
3873	319802154730	47 k	0.1W
3876	319802151030	10 k	0.1W
3880	319801101080	1 R	0.17W
3881	319802158210	820 R	0.1W
3882	319801108210	820 R	0.17W

RESISTORS

4100	319802190020	CHIP JUMPER
4101	319802190020	CHIP JUMPER
4102	319802190020	CHIP JUMPER
4103	319802190020	CHIP JUMPER
4104	319802190020	CHIP JUMPER
4105	319802190020	CHIP JUMPER
4106	319802190020	CHIP JUMPER
4107	319802190020	CHIP JUMPER
4108	319802190020	CHIP JUMPER
4110	319802190020	CHIP JUMPER
4111	319802190020	CHIP JUMPER
4452	319802190020	CHIP JUMPER
4456	319802190020	CHIP JUMPER
4481	319802190020	CHIP JUMPER
4482	319802190020	CHIP JUMPER
4485	319802190020	CHIP JUMPER
4486	319802190020	CHIP JUMPER
4487	319802190020	CHIP JUMPER
4488	319802190020	CHIP JUMPER
4489	319802190020	CHIP JUMPER
4490	319802190020	CHIP JUMPER
4491	319802190020	CHIP JUMPER
4492	319802190020	CHIP JUMPER
4493	319802190020	CHIP JUMPER
4494	319802190020	CHIP JUMPER
4496	319802190020	CHIP JUMPER
4498	319802190020	CHIP JUMPER
4499	319802190020	CHIP JUMPER
4502	319802190020	CHIP JUMPER
4503	319802190020	CHIP JUMPER
4651	319802190020	CHIP JUMPER
4652	319802190020	CHIP JUMPER
4701	319802190020	CHIP JUMPER
4704	319802190020	CHIP JUMPER
4705	319802190020	CHIP JUMPER
4706	319802190020	CHIP JUMPER
4711	319802190020	CHIP JUMPER
4712	319802190020	CHIP JUMPER
4713	319802190020	CHIP JUMPER
4722	319802190020	CHIP JUMPER
4724	319802190020	CHIP JUMPER
4759	319802190020	CHIP JUMPER
4761	319802190020	CHIP JUMPER
4762	319802190020	CHIP JUMPER
4763	319802190020	CHIP JUMPER
4764	319802190020	CHIP JUMPER
4765	319802190020	CHIP JUMPER
4852	319802190020	CHIP JUMPER
4911	319802190020	CHIP JUMPER
4912	319802190020	CHIP JUMPER
4914	319802190020	CHIP JUMPER
4916	319802190020	CHIP JUMPER

COILS

5001	319801821090	10 μ H
5002	242253594339	150 μ H
5004	242253594335	56 μ H
5005	242253594334	47 μ H
5006	242253594327	15 μ H
5008	242253594325	10 μ H
5009	242253594338	100 μ H
5010	242253594323	6.8 μ H 5%
5071	242253594692	6.8 μ H 5%
5072	242253597877	10 μ H
5073	242253594335	56 μ H
5074	242253594329	22 μ H
5075	242253594699	27 μ H 5%
5076	319801890090	COIL
5100	242253594272	22 μ H 5%
5101	242253597333	100 μ H 10%
5322	242253597333	100 μ H 10%
5323	242253597342	22 μ H 10%
5453	242253594325	10 μ H
5454	242253595097	BOB 2,4MU FBA04HA900BB TY
5455	242254941993	IND FXD100MHZ600R BLM21KB
5456	242254941993	IND FXD100MHZ600R BLM21KB
5457	242254941993	IND FXD100MHZ600R BLM21KB
5471	242253594118	INDFXD SPT0203A0U33 PM10A
5501	242253594323	6.8 μ H 5%
5601	242253596863	10 μ H 5%
5602	310313824910	COIL ASSY
5603	242254941993	IND FXD100MHZ600R BLM21KB
5641	310313824910	COIL ASSY
5701	242253594327	15 μ H
5702	242254941645	IND VAR 0,256UH +6-10%
5703	242254941993	IND FXD100MHZ600R BLM21KB
5704	242254941645	IND VAR 0,256UH +6-10%
5706	242253594323	6.8 μ H 5%
5708	242253594325	10 μ H
5760	319801821090	10 μ H
5761	319801821010	COIL
5762	319801821090	10 μ H
5803	242254941993	IND FXD100MHZ600R BLM21KB
5804	242254941993	IND FXD100MHZ600R BLM21KB
5805	242254941993	IND FXD100MHZ600R BLM21KB
5806	242254941993	IND FXD100MHZ600R BLM21KB
5807	242254941993	IND FXD100MHZ600R BLM21KB
5853	242253594325	10 μ H
5854	242253594327	15 μ H
5856	242253594323	6.8 μ H 5%
5871	242253594325	10 μ H
5872	242254941993	IND FXD100MHZ600R BLM21KB

DIODES

6401	933624760133	BAT85
6460	310313887290	OPTO ASSY TCZT8299-PAER
6503	932203796673	MTZJ6.8C
6507	932203216673	MTZJ12C
6601	933712670673	BZX55-B7V5 A
6702	934025520115	BA792
6761	319801010010	1N4148

TRANSISTORS & IC's

7001	319801042030	BC847B
7002	319801042030	BC847B
7003	932210079685	LC89980M
7004	319801042150	BC857B
7005	932211964671	LA71527M (TSAJ) Y
7006	319801042030	BC847B
7007	319801044020	PDTA124ET
7008	319801042030	BC847B
7009	319801042030	BC847B
7010	933092111215	BFS20
7011	933092111215	BFS20
7014	319801042030	BC847B
7015	319801042150	BC857B
7016	319801042030	BC847B
7071	319801042150	BC857B

Motherboard

7072	932214759682	LA7339A	
7073	319801042030	BC847B	
7074	319801042030	BC847B	
7075	319801042030	BC847B	
7091	933406660653	HEF4094BT	
7092	319801044120	PDTC124ET	
7101	319801042030	BC847B	
7102	319801042030	BC847B	
7103	932211188668	STV5744ADT	
7104	932203746668	STV5712TR	
7105	319801044020	PDTA124ET	
7106	319801044020	PDTA124ET	
7107	319801044120	PDTC124ET	
7321	932214226687	FET POW STD16NE06-1	L
7322	933946350215	FET SIG BSS138	
7323	932214226687	FET POW STD16NE06-1	L
7324	319801042030	BC847B	
7325	319802043530	BC337-25	
7326	319802043430	BC327-25	
7327	319801042150	BC857B	
7328	319801042030	BC847B	
7329	319801042030	BC847B	
7401	932211746668	M24128-MN6 (ST00) R	
7404	319801042030	BC847B	
7406	310316530010	TMP93C071F 120PIN	
7407	319802043530	BC337-25	
7408	319801042150	BC857B	
7412	319801044020	PDTA124ET	
7413	319801042030	BC847B	
7414	319801042030	BC847B	
7415	319801042030	BC847B	
7440	933979290682	L2722	
7441	319801044020	PDTA124ET	
7442	319801042030	BC847B	
7443	935034880112	SAA1310/N2	
7446	935211440112	TDA5241	
7451	310317855360	EPROM ASSY ACOP8-Ux	
7452	932212786682	CY62256LL-70PC(CYPR) L	
7461	310313887290	OPTO ASSY TCZT8299-PAER	
7462	310313887290	OPTO ASSY TCZT8299-PAER	
7464	932209789682	OPT CP TCRT5000L	
7465	932209789682	OPT CP TCRT5000L	
7466	932209791682	OPT CP TCST1030L	
7502	933628640215	CHIP BC817/40	
7504	319801042030	BC847B	
7505	319801044120	PDTC124ET	
7506	932212428682	STV6401	
7508	319801044120	PDTC124ET	
7510	319801044120	PDTC124ET	
7511	933372950653	HEF4052BT	
7512	932209259668	TL072 (ST00) R	
7603	933589730215	BC856B	
7604	319802043430	BC327-25	
7605	933589560215	BC846B	
7606	933589560215	BC846B	
7607	319801042030	BC847B	
7608	933628640215	CHIP BC817/40	
7641	319801042150	BC857B	
7642	319801042030	BC847B	
7643	933628640215	CHIP BC817/40	
7651	935262251557	TDA9616H/N2 Y	
7701	933372960653	HEF4053BT	
7702	319801044120	PDTC124ET	
7703	319801042030	BC847B	
7704	319801042150	BC857B	
7705	935260611118	TDA9818T/V1 R	
7705	935262113118	TDA9817T/V1 R	
7706	319801042030	BC847B	
7707	319801042030	BC847B	
7760	935264081557	TDA9873HZ for German Stereo	
7761	932214797668	MSP3415D-QG-B3	
7761	932215069671	MSP3451G-QG-A1(MIAS) for Smart Sound only	
7762	319801042030	BC847B	
7801	933092111215	BFS20	
7802	319801042150	BC857B	
7803	932214339668	TS339CD (ST00)R	
7804	933092111215	BFS20	
7805	319801044020	PDTA124ET	
7807	932211821682	TA1225N (TOSJ) L	
7830	933984900682	LM339N ST	

7831	319801042030	BC847B
7832	319801042030	BC847B
7851	932213621668	SDA5652-2X
7854	319801042150	BC857B
7855	319801042030	BC847B
7856	319801042150	BC857B
7871	932213702668	STV5348D SO28

RESISTORS

9051	319802190020	CHIP JUMPER
9512	319802190020	CHIP JUMPER
9525	319802190020	CHIP JUMPER
9701	319802190020	CHIP JUMPER

Display Control ADCP18

MISCELLANEOUS

1234	242212915676	SWI JOG-SHUT EVQWM7-001
1261	242254098328	CER RES 8MHZ EFOEC8004T4A
1262	242254300056	CRYSTAL 32.768kHz
1281	242212802921	SWITACT 1P 50MA 12V EVQPV
1282	242212802921	SWITACT 1P 50MA 12V EVQPV
1295	242212802921	SWITACT 1P 50MA 12V EVQPV
1920	242202514524	CONNECTOR 14P F1.25 FFC 0.3
1922	242202514515	CONNECTOR 6 PIN
1923	242202514535	CONNECTOR 6P F 1.25 FFC 0.3

CAPACITORS

2200	202002590011	SUPCAP SD 5V5 220M P80M20
2201	202001293647	ELCAP MS7 6V3 S 220U PM20
2202	319802321040	100 nF 25V
2203	319801701030	10 nF 50V
2221	319801701020	1 nF 50V
2225	319802922290	22 µF 16V
2230	319801701030	10 nF 50V
2231	319801724730	47 nF 50V
2250	202055295499	100 nF 50V
2262	319801601590	15 pF 50V
2263	319801601590	15 pF 50V

RESISTORS

3210	319801101010	100 R	0.17W
3211	319801101010	100 R	0.17W
3212	319802154720	4.7 k	0.1W
3213	319802152730	27 K	0.1W
3214	319802152730	27 K	0.1W
3215	319802154710	470 R	0.1W
3216	319802152730	27 K	0.1W
3217	319802152730	27 K	0.1W
3218	319802152730	27 K	0.1W
3219	319802152730	27 K	0.1W
3220	319801102210	220 R	0.17W
3221	319801101030	10 k	0.17W
3222	319802151020	1 k	0.1W
3223	319802151530	15 k	0.1W
3224	319802152220	2.2 k	0.1W
3226	319802152210	220 R	0.1W
3227	319802151030	10 k	0.1W
3228	319802151030	10 k	0.1W
3230	319802152220	2.2 k	0.1W
3231	319802152210	220 R	0.1W
3232	319802152210	220 R	0.1W
3233	319802152210	220 R	0.1W
3234	319802152210	220 R	0.1W
3235	319802151030	10 k	0.1W
3236	319802152210	220 R	0.1W
3237	319802154720	4.7 k	0.1W
3238	319802152710	270 R	0.1W
3240	319802151030	10 k	0.1W
3241	319802151030	10 k	0.1W
3246	319802151040	100 k	0.1W
3247	319802151040	100 k	0.1W
3250	319802151830	18 k	0.1W
3251	319801101010	100 R	0.17W
3252	319801101010	100 R	0.17W
3257	319801104780	4.7 R	0.17W
3258	319801104780	4.7 R	0.17W
3259	319801104780	4.7 R	0.17W
3269	319802151030	10 k	0.1W
3279	319802151030	10 k	0.1W
3280	319802151030	10 k	0.1W
3281	319802151820	1.8 k	0.1W
3282	319802154720	4.7 k	0.1W
3289	319802151030	10 k	0.1W
3295	319802153930	39 k	0.1W
3299	319802151030	10 k	0.1W
3900	319802190020	CHIP JUMPER	
3901	319802190020	CHIP JUMPER	
3902	319802190020	CHIP JUMPER	
3906	319802190020	CHIP JUMPER	
3907	319802190020	CHIP JUMPER	

3908	319802190020	CHIP JUMPER
3909	319802190020	CHIP JUMPER
3910	319802190020	CHIP JUMPER
3911	319802190020	CHIP JUMPER
3912	319802190020	CHIP JUMPER
3921	319802190020	CHIP JUMPER
3925	319802190020	CHIP JUMPER
3927	319802190020	CHIP JUMPER
3931	319802190020	CHIP JUMPER

COILS

5200	242253597333	100 µH 10%
5201	242253594323	6.8 µH 5%

DIODES

6200	933624760133	BAT85
6250	319801021090	BZX79-C10

TRANSISTORS & IC's

7200	310316513100	TMP87CH70F AD0P1-1U
7202	310316500250	VACUUM FLUORESC. DISPLAY
7220	932211213687	IR REC TSOP1736(TEGO) L
7231	319801044120	PDTC124ET
7232	319801044120	PDTC124ET
7234	319801042150	BC857B
7235	319801042150	BC857B
7236	319801044020	PDTA124ET
7240	319801042150	BC857B
7241	319801042150	BC857B

Connector PCB ACP18, CABLES

MISCELLANEOUS

0010	310310416590	LED-SOCKET
1551	242212802921	SWITACT 1P 50MA 12V EVQPV
1929	242202514515	CONNECTOR 6 PIN
1980	242202514532	CONNECTOR 3 PIN
1981	310314027000	CABL TREE A 1POL BUPI-1957
1982	242202514536	CONNECTOR 7P F 1.25 FFC 0.3
1985	310310024260	CINCH SOCKET 3 FOLD
1989	242202604436	CON HSJ1452

CAPACITORS

2551	319801604710	470 pF	50V
2552	319801721050	1 μF	16V
2553	319801701040	100 nF	16V
2554	319801604710	470 pF	50V
2555	319801721050	1 μF	16V
2556	319801701040	100 nF	16V

RESISTORS

3551	212255100008	VDR	MAX 21V
3552	319802151050	1 M	0.1W
3553	319802156840	680 k	0.1W
3554	319802154740	470 k	0.1W
3555	319802154720	4.7 k	0.1W
3556	212255100008	VDR	MAX 21V
3557	319802151050	1 M	0.1W
3558	319802156840	680 k	0.1W
3559	319802154740	470 k	0.1W
3560	319802154720	4.7 k	0.1W
3561	319802157590	75 R	0.1W
3562	319801101510	150 R	0.17W
3564	319802151030	10 k	0.1W
3900	319802190020	CHIP JUMPER	
4507	319802190020	CHIP JUMPER	

COILS

5551	242253594339	150 μH
5552	319801811010	100 μH
5553	242253594339	150 μH

DIODES

6551	319801021290	BZX79-C12
6552	319801021290	BZX79-C12
6553	319801026880	BZX79-C6V8
6554	319801026880	BZX79-C6V8
6555	934025530115	BAS216
6556	934025530115	BAS216
6557	319801026880	BZX79-C6V8
6558	319801026880	BZX79-C6V8
6570	933845770682	LED RED TLHR4205

TRANSISTORS

7551	319801042040	BC847C
7552	319801042040	BC847C

CABLES

	4822 320 50377	ANTENNA cable
	4822 321 63002	SCART cable
▲	4822 321 10249	SBC1201 MAINS CABLE
▲	4822 321 10886	MAINS CABLE UK
	4822 320 50377	CONNECT. CABLE PAL
	4822 321 63002	SCART CABLE(PROJ.50)
	4822 321 62401	AUDIO-CABLE
8001	4822 320 11889	FFC TD1-1961
8003	4822 320 12453	FFC 3POL TD3-1947
8004	4822 320 12454	FFC 6POL TD4-1948
8011	4822 320 12455	FFC 7POL 1982-1956
8012	4822 320 12453	FFC 3POL TD3-1947
8013	4822 320 12461	FFC 1961-1102
8014	4822 320 12456	FFC 3POL 1929-1922
8018	4822 320 12458	FFC 17POL 1915-1942
8020	4822 320 12459	FFC 14POL 1944-1920
8024	3103 140 27540	FFC 6POL 1923-keyPCB

REPAIR KITS

4822 310 11237	POWER SUPPLY REPAIR KIT
----------------	-------------------------