


**SERVICE
MANUAL**



MODEL

FCM-800

VIDEO CAMERA RECORDER



CONTENTS

MAIN SECTION

SPECIFICATIONS	1 – 1
CAUTION OF LITHIUM BATTERIES REPLACEMENT	2 – 1
INSTRUCTIONS FOR HANDLING SEMICONDUCTORS	3 – 1
REPLACEMENT PROCEDURES FOR LEADLESS(CHIP) COMPONENTS	4 – 1
HOW TO REMOVE/INSTALL THE FLAT PACK IC	5 – 1
IMPORTANT SAFETY PRECAUTIONS	6 – 1
DISASSEMBLY INSTRUCTIONS(CABINET)	7 – 1
BLOCK DIAGRAM	
MAIN BLOCK DIAGRAM	8 – 1
CCD BLOCK DIAGRAM	8 – 2
PROCESS BLOCK DIAGRAM	8 – 3
DRIVER BLOCK DIAGRAM	8 – 4
SERVO/SYSTEM CONTROL BLOCK DIAGRAM	8 – 5
ALIGNMENT INSTRUCTIONS	
WIRING FOR ALIGNMENT	9 – 1
TEST BOARD SCHEMATIC DIAGRAM	9 – 2
TEST EQUIPMENT AND TOOLS	9 – 3
ELECTRICAL ADJUSTMENT INSTRUCTIONS(CAMERA)	9 – 4
ELECTRICAL ADJUSTMENT INSTRUCTIONS(VIDEO)	9 – 28
ELECTRICAL ADJUSTMENT INSTRUCTIONS(EVF)	9 – 51
TROUBLESHOOTING GUIDE	10 – 1
P.C.BOARD TOP/BOTTOM VIEW AND ALIGNMENT POINT	
MAIN PCB(TOP VIEW)	11 – 1
MAIN PCB(BOTTOM VIEW)	11 – 2
SERVO/SYSTEM CONTROL PCB(TOP VIEW)	11 – 3
SERVO/SYSTEM CONTROL PCB(BOTTOM VIEW)	11 – 4
CCD PCB(TOP/BOTTOM VIEW)	11 – 5
PROCESS PCB(TOP/BOTTOM VIEW)	11 – 6
DRIVER PCB(TOP VIEW)	11 – 7
DRIVER PCB(BOTTOM VIEW)	11 – 8
REAR CONTROL PCB(TOP/BOTTOM VIEW)	11 – 9
TOP CONTROL PCB(TOP/BOTTOM VIEW)	11 – 9
CAMERA CONTROL PCB(TOP/BOTTOM VIEW)	11 – 10
POWER PCB(TOP/BOTTOM VIEW)	11 – 10
EVF PCB(TOP/BOTTOM VIEW)	11 – 11
WIRING DIAGRAM	12 – 1
REPLACEMENT PARTS LIST/EXPLODED VIEW	
EXPLODED VIEW(CAMERA)	13 – 1
EXPLODED VIEW(CABINET)	13 – 2
MECHANICAL PARTS LIST	13 – 3
ELECTRICAL PARTS LIST	13 – 4

SCHEMATIC DIAGRAM

STANDARD NOTES	14 – 1
MAIN SCHEMATIC DIAGRAM	14 – 2
SERVO/SYSTEM CONTROL SCHEMATIC DIAGRAM	14 – 3
CCD SCHEMATIC DIAGRAM	14 – 4
PROCESS SCHEMATIC DIAGRAM	14 – 5
CONTROL/POWER SCHEMATIC DIAGRAM	14 – 6
DRIVER SCHEMATIC DIAGRAM	14 – 7
EVF SCHEMATIC DIAGRAM	14 – 8
SYSTEM CONTROL TIMING CHARTS	15 – 1
LEAD IDENTIFICATIONS	16 – 1
CHIP IDENTIFICATIONS	17 – 1
IC PIN FUNCTION DESCRIPTION	
SYSTEM CONTROL	18 – 1
EXPANDER	18 – 3
CHARACTER	18 – 4

DECK MECHANISM SECTION

DISASSEMBLY INSTRUCTIONS(DECK)	– 1 –
SERVICE FIXTURES AND TOOLS	– 8 –
STANDARD MAINTENANCE	– 9 –
MECHANICAL ADJUSTMENT INSTRUCTIONS	– 13 –
EXPLODED VIEW(DECK)	– 19 –
PARTS LIST(DECK)	– 24 –

AC CHARGER SECTION

BLOCK DIAGRAM(CHARGER)	– 1 –
ELECTRICAL ADJUSTMENT INSTRUCTIONS(CHARGER)	– 2 –
P.C.BOARD TOP/BOTTOM VIEW AND ALIGNMENT POINT	– 3 –
EXPLODED VIEW(CHARGER)	– 4 –
SCHEMATIC DIAGRAM(CHARGER)	– 5 –
PARTS LIST(CHARGER)	– 6 –

MAIN SECTION

GENERAL SPECIFICATION

A) SYSTEM

1) RECORDING STANDARD	PAL 625 lines 50 fields/sec
2) FORMAT	8MM Standard
3) RECORDING SYSTEM	2 Heads Helical Scanning for Video 1 Head for Flying Erase FM Hi-Fi (MONO for Audio)
4) TAPE SPEED	SP : 20.051mm/sec LP : 10.025mm/sec
5) RECORDING TIME	SP : 90 minutes (with P5-90) LP : 180 minutes (with P5-90)
6) TAPE WIDTH	width 8mm
7) MAXIMUM BATTERY RECORDING TIME	about 50 minutes (Brand new battery, continuous recording)
8) IMAGE SENSOR	1/3 inch CCD (charged coupled device)
9) NUMBERS of PIXELS for CCD	290 k pixels
10) LENS	F/1.6 f=6.7mm 8:1 power zoom (Nominal f=6.7mm~53.6mm) / by HAND Lens with auto iris control Macro position with zoom lever lock Filter diameter 46mm (Adapter ring is required.)
11) FOCUS	Auto Focus with IR/by HAND
12) VIEWFINDER	Electronic viewfinder with 0.6 inch BLACK/WHITE CRT
13) MINIMUM REQUIRED ILLUMINATION	5 Lux (at F/1.6)
14) BACK LIGHT	Back light position with push
15) DATE/TIME	Recording possible
16) REC REVIEW SYSTEM	
17) EDIT SEARCH SYSTEM	
18) TAPE COUNTER	Electronic tape counter
19) DEW SENSOR	
20) ASSEMBLE RECORDING	Noiseless assemble recording with short rewind
21) BATTERY	DC 6V 1.2A/H Ni-Cd Rechargeable battery
22) POWER SOURCE	Battery, AC Adapter
23) POWER CONSUMPTION	7.5W (under recording with DC 6V)
24) DIMENSION	105(W) × 125(H) × 239(D)mm 289(D)mm (EVF Included)
25) WEIGHT	980g(with out battery)
26) BATTERY WEIGHT	180g


B) JACK

1) A/V JACK (8 pin)	Video output / GND Audio output / GND DC 5V for RF Conv./ GND
2) DC JACK (φ 4.0)	DC power input /GND

C) SWITCH & CONTROL

POWER + CAMERA/VTR	P.OFF ⇄ CAMERA ON ⇄ VTR ON	Push SW
EJECT	Cassete Holder up	Push SW
PLAY/REC REVIEW	VTR POSITION	CAMERA POSITION
FF CUE/EDIT SEARCH	PLAY mode	REC REVIEW +mode
	FF mode	EDIT SEARCH -mode
	(CUE mode)	
REW REV/EDIT SEARCH	REW mode	EDIT SEARCH mode
	(REW mode)	
STILL	Still mode	Date ON/OFF and Preset
STOP	Stop mode	Title ON/OFF and Preset
RESET	Counter 0:00:00 Reset	Push SW
MEMORY	Stop at counter 0:00:00	Push SW
BACK LIGHT	Normal iris /Back light	Push SW
FOCUS	Auto / Manual	Slide SW
POWER ZOOMING	Wide/Tele	Seasaw SW
START/STOP	Recording START / STOP	Push SW
SET	Set Key for DATE/TIME and TITLE	Push SW
ADJUST	Adjust Key for DATE/TIME and TITLE	Push SW
FADE	Fade ON/OFF	Push SW
SP/LP	Select the Recording Tape Speed	Slide SW
REMOVE BATTERY		Push SW
DEOPTER ADJUSTMENT	Diopter adjustment (-7 ~ -1 dioptry)	Rotary SW
MACRO	Mounted on zoom lever	Push SW
HIGH SPEED SHUTTER	Normal/1/1000 sec	Slide SW

D) DISPLAY / WARNING



E) SAFETY SYSTEM

TAPE CUT	each mode ⇒ STAND BY mode
DEW	each mode ⇒ STAND BY mode
DRUM MOTOR LOCK	each mode ⇒ STAND BY mode (Expect FF/REW mode)
TAPE END	each mode ⇒ STOP mode
BATTERY DOWN	under DC5.7V each mode ⇒ STOP
REC SAFETY	If CAMERA mode is selected when REC safety position is selected display of "CASSETTE" will be on.
AUTOMATIC PAUSE	PAUSE mode remains on more than 5 min ⇒ STOP mode
/STILL RELEASE	STILL mode remains on more than 5 min ⇒ PLAY mode

F) SPECIFICATION

1) LENS SECTION	
FOCALLENGTH	f=6.7mm ~ 53.6mm (Nominal)
ZOOM RATIO	8:1 (Nominal)
F.NUMBER	1:1.6
FILTER DIAMETER	M46mm
2) CAMERA SECTION	
VIDEO OUTPUT	1.0 ± 0.1Vp-p
HORIZONTAL RESOLUTION	more than 300 line
VIDEO S/N RATIO	more than 45dB
MINIMUM REQUIRED ILLUMINATION	5 lux
ILLUMINATION RANGE	5 ~ 100,000 lux
AUTO WHITE	2,500 K ~ 7,000 K
BALANCE RANGE	
BACK LIGHT	50% level up
3) MECHANIZUM SECTION	
TAPE SPEED	20.051mm / sec(SP)
FF/REW TIME	within 6.5min at DC6.0V (P5-90)
LOADING/UNLOADING TIME	within 5sec at DC6.0V
WOW and FLUTTER	within 0.1% <CCIR/WTD> at SP mode R/P
JITTER LOW	within 0.15% at SP mode PB
CUE / REV SPEED	3 times (SP)
4) VCR SECTION	
VIDEO OUTPUT	1.0V ± 0.2Vp-p (75 Ω unbalanced)
VIDEO S/N RATIO	more than 43dB (SP)
RESOLUTION	more than 220 lines (SP)
AUDIO OUTPUT	-10dBs (10k Ω load)
AUDIO S/N RATIO	more than 40dB (RMS) (SP)
AUDIO FREQ, RESPONSE	200 ~ 12,000Hz(SP)
5) Others	
Operation tempreture	0 °C ~ +40 °C
Strage tempreture	-20 °C ~ +60 °C

ACCESSORIES

- 1) INSTRUCTION MANUAL
- 2) 8MM CASSETTE
- 3) BATTERY PACK
- 4) AC ADAPTER and BATTERY CHARGER
- 5) DC CABLE
- 6) AV CABLE with 8PINS PLUG
- 7) CARRING STARP
- 8) BATTERY for BACK up (CLOCK)

OPTION

- 1) RF CONV. UNIT WITH 8 pin PLUG
- 2) CABLE FOR RF CONV

CAUTION OF LITHIUM BATTERIES REPLACEMENT

ADVARSEL !

Lithiumbatteri - Eksplosionsfare ved fejlagtig handtering.
Udskiftning må kun ske med batteri
af samme fabrikat og type.
Levér det brugte batteri tilbage til leverand øren.

ADVARSEL

Lithiumbatteri - Eksplosjonsfare.
Ved utskifting benyttes kun batteri som
anbefalt av apparatfabrikanten.
Brukt batteri returneres apparatleverand øren.

VARNING

Explosionsfara vid felaktigt batteribyte.
Anvand samma batterityp eller en ekvivalent
typ som rekommenderas av apparattillverkaren.
Kassera anvant batteri enligt fabrikantens
instruktion.

VAROITUS

Paristo voi rajahtaa, jos se on virheellisesti asennettu.
Vaihda paristo ainoastaan laitevalmistajan suosittelemaan
tyyppiin. Havita kaytetty paristo valmistajan ohjeiden
mukaisesti.

CAUTION

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type recommended
by the equipment manufacturer. Discard used batteries acco-
rding to manufacturer's instructions.

INSTRUCTIONS FOR HANDLING SEMICONDUCTORS

Electrostatic breakdown of the semiconductors may occur due to a potential difference caused by electrostatic charge during unpacking or repair work.

Ground for Human Body


Be sure to wear a grounding band (1 Mohm) that is properly grounded to remove any static electricity that may be charged on the body.

Ground for Work bench


Be sure to place a conductive sheet or copper plate with proper grounding (1 Mohm) on the work bench or other surface, where the semiconductors are to be placed.

Because the static electricity charge on the clothing will not escape through the body grounding band, be careful to avoid contact of semiconductors with clothing.

INCORRECT



CORRECT



REPLACEMENT PROCEDURES FOR LEADLESS (CHIP) COMPONENTS

The following procedures are recommended for the replacement of the leadless components used in this unit.

1. Preparation for replacement

- a. Soldering Iron
Use a pencil-type soldering iron (less than 30 watts).
- b. Solder
Eutectic solder (Tin 63%, Lead 37%) is recommended.
- c. Soldering time
Do not apply heat for more than 4 seconds.
- d. Preheating
Leadless capacitor must be preheated before installation.
(130°C-150°C, for about two minutes.)

Note:


- a. Leadless components must not be reused after removal.
- b. Excessive mechanical stress and rubbing for the component electrode must be avoided.

2. Removing the leadless component

Grasp the leadless component body with tweezers and alternately apply heat to both electrodes. When the solder on both electrodes has melted, remove leadless component with a twisting motion.


Note:

- a. Do not attempt to lift the component off the board until the component is completely disconnected from the board by the twisting action.
- b. Take care not to break the copper foil on printed board.




3. Installing the leadless component

- a. Presolder the contact points of the circuit board.



- b. Press the part downward with tweezers and solder both electrodes as shown below.




Note:

Do not glue the replacement leadless component to the circuit board.

HOW TO REMOVE / INSTALL THE FLAT PACK IC


1. Removal
(With Hot - Air Flat Pack - IC Desoldering Machine)
- (1) Prepare the HOT - AIR FLAT PACK - IC DESOLDERING MACHINE, then apply hot air to Flat Pack - IC (about 5~6 seconds).



- (2) Remove the Flat Pack- IC with tweezers while applying the hot air.


Caution:

1 Do not supply the hot air to the chip parts around the Flat Pack - IC for over 6 seconds as damage may occur to the chip parts. Put Masking Tape around the Flat Pack - IC to protect other parts from damage.




- 2 The Flat Pack - IC on the P.C.B. is affixed with glue, so be careful not to break or damage the foil of each pin or solder lands under the IC when removing it.


- With Soldering Iron:**
- (1) Using De-solder braid, remove the solder from all pins of the Flat Pack - IC. When you use solder flux which is applied to all pins of the Flat Pack - IC, you can remove it easily.



- (2) Lift each lead of the Flat Pack-IC upward one by one using a sharp pin or wire to which solder will not adhere (iron wire). When heating the pins, use a fine tip soldering iron or a hot air blower.



- With Iron Wire:**
- (1) Using De-soldering braid, remove the solder from all pins of the Flat Pack - IC. When you use solder flux which is applied to all pins of the Flat Pack - IC, you can remove it easily.
- (2) Affix the wire to a workbench or solid mounting point, as shown in Fig. S-1-5.
- (3) Pull up wire as the solder melts so as to lift the IC leads from the P.C.B. contact pads, while heating the pins using a fine tip soldering iron or hot air blower.





Note:

When using a soldering iron, care must be taken to ensure that the Flat Pack - IC is not being held by glue or when it is removed from the P.C.B., it may be damaged if force is used.

2. Installation
- (1) Using a De-solder braid, remove the solder from the foil of each pin of the Flat Pack - IC on the P.C.B. so you can install a replacement Flat Pack - IC more easily.
- (2) The "●" mark on the Flat Pack - IC indicates pin 1. (See Fig. S-1-6) Make sure this mark matches the 1 on the P.C.B. when positioning for installa-

tion. Then pre - solder the four corners of the Flat Pack- IC (See Fig.S-1-7).



- (3) Solder all pins of the Flat Pack - IC. Make sure that none of the pins have solder bridges.

IMPORTANT SAFETY PRECAUTIONS

Prior to shipment from the factory, our products are strictly inspected to conform to the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

PRECAUTIONS DURING SERVICING

- 1.Locations requiring special caution are denoted by labels and inscribed on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.

2.Parts identified by the $\triangle$ symbol are critical for safety. Replace only with specified part numbers.

3.Use specified internal wiring. Note especially :

1) Wires covered with PVC tubing

2) Double insulated wires

3) High voltage leads
- 4.Use specified insulating materials for hazardous live parts. Note especially :

1) Insulation Tape

2) PVC tubing

3) Spacers

4) Insulation sheets for transistors

5.Observe that wires do not contact heat producing parts (heat sinks, oxide metal film resistors, fusible resistors, etc.)


6.Check that replaced wires do not contact sharp edged or pointed parts.

7.Also check areas surrounding repaired locations.

DISASSEMBLY INSTRUCTIONS (CABINET)

1. DISASSEMBLY FLOW CHART





This flow chart indicates the disassembly steps of the cabinet parts, VCP Unit and the P.C.Boards in order. Bend, route and dress the cables as they were originally.



STEP/LOC NO.	PART	REMOVAL		
		Fig. No	REMOVE/* UNLOCK/RELEASE/UNPLUG/UNCLAMP/UNSOLDER	Note
[1]	Side Case (R)	Fig. 1	2(S - 1)	-
[2]	Top Panel	Fig. 2	3(S - 3) * 2(L - 2)	1
[3]	Rear Panel	Fig. 2	3(S - 2) * 2(L - 1)	2
[4]	Lens Hood	Fig. 3	-----	3
[5]	Front Panel	Fig. 3	* 2(L - 3), (S - 17)	-
[6]	Right Side Cabinet	Fig. 4	* 2(L - 4) 2(S - 4) 2(S - 5) Connector (CN31)	-
[7]	Left Side Cabinet	Fig. 5	* Connectors (CN03, CN01, CN02)	-
[8]	Top Control PCB	Fig. 5	2(S - 6) * Connectors (CL19)	-
[9]	Rear Contorl PCB	Fig. 5	2(S - 7) * Connectors (CL18)	-
[10]	Sub Mechanism Chassis	Fig. 5	3(S - 8)	-
[11]	Bracket Mechanism Chassis	Fig. 5	4(S - 9)	-
[12]	Camera Unit	Fig. 5	(S - 10)	4
[13]	Video Main PCB	Fig. 6	* Connectors (CL06, CL07, CL08, CL09, CL10)	-
[14]	Process PCB	Fig. 6	* Connectors (CN30, CN29)	-
[15]	Servo/System Control PCB	Fig. 7	2(S - 11) * Connectors (CN13, CN15, CN16, CN17)	-
[16]	Driver PCB	Fig. 8	2(S - 12) * Connectors (CN23, CN24, CN26 ,CN22)	-
[17]	Mic Unit	Fig. 9	* (L - 5) Connector (CN03)	-
[18]	EVF Unit	Fig. 9	2(S - 13) Connector (CN02)	-
[19]	Bottom Lid	Fig. 5	2(S - 14)	-
[20]	Power PCB	Fig. 10	6(S - 15)	-
[21]	Camera Control PCB	Fig. 11	3(S - 16)	-

Reference <Notes> in Table

1. Remove 3 Screws(S - 3), then pull up the Top Panel in the direction of the arrow. Then release 2 Locking Tabs(L - 2).
2. Remove 3 Screws(S - 2), then pull up the Rear Panel in the direction of the arrow, then release 2 Locking Tabs(L - 1).
3. When removing the Lens, turn the Lens Hood counterclockwise.
4. When reinstall the Camera Unit, CCD PCB and Process PCB onto the Left Side Cabinet, confirm that CCD PCB and Process PCB is installed onto the Groove of Bottom Lid.






Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 9




Fig. 10




Fig. 11

CAMERA ELECTRICAL ADJUSTMENT

Note:
All adjustment procedures must be proceeded in order of numbering.

1. DC / DC Conv. Voltage Adjustment 5V

Test Point	Adj. Point	Mode	Input
TP51 (5V) TP04 (GND)	VR51 (5V)	---	---
Tape	M. EQ.	Spec.	
---	DC VOLTMETER	5.0V ±0.05V	
Connections of M. EQ.			
CCD PCB TP51 5V TP04 GND + — DC VOLTMETER			

- Reference notes:**
1. Connect equipments as shown in the above table.
 2. Adjust VR51 for reading 5.0V ±0.05V on the DC voltmeter.

2. DC / DC Conv. Voltage Adjustment 9V

Test Point	Adj. Point	Mode	Input
TP53 (9V) TP04 (GND)	VR53 (9V)	---	---
Tape	M. EQ.	Spec.	
---	DC VOLTMETER	9.0V ±0.1V	
Connections of M. EQ.			
CCD PCB TP53 9V TP04 GND + - DC VOLTMETER			

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Adjust VR53 for reading 9.0V ±0.1V on the DC voltmeter.

3. Frequency Adjustment

Test Point	Adj. Point	Mode	Input
TP01 (CLK) TP04 (GND)	TC01	---	---
Tape	M. EQ.	Spec.	
---	OSCILLOSCOPE FREQUENCY COUNTER	9.656250MHz ±20Hz	
Connections of M. EQ.			
CCD PCB TP01 CLK TP04 GND OSCILLOSCOPE CH1 OUT FREQUENCY COUNTER IN			

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Adjust TC01 for reading 9.656250MHz ±20Hz on the frequency counter.

4. PLL ERR Voltage Adjustment

Test Point	Adj. Point	Mode	Input
TP108 (ERR) TP111(GND)	TC101	---	---
Tape	M. EQ.	Spec.	
---	DC VOLTMETER	2.5V ±0.1V	
Connections of M. EQ.			
CCD PCB TP108 ERR TP111 GND + — DC VOLTMETER			

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Adjust TC101 for reading 2.5V ±0.1V on the DC Voltmeter.


5. Focus Pre-adjustment

Test Point	Adj. Point	Mode	Input
CAM OUT	ZOOM RING	---	GRAY SCALE CHART
Tape	M. EQ.	Spec.	
---	VIEWER	BEST FOCUS	
Connections of M. EQ.			
VIEWER 34 cm CAMERA GREEN BUTTON			

Reference notes:


- 1. Set equipments as shown in the above table.
- 2. Set the Viewer 34 cm distance in front of the camera.
- 3. Set the gray scale chart in Standard pattern frame of the Viewer.
Depressing the green button, turn the zoom ring toward the Macro position to get the best focus.

6. Blooming Pre-adjustment




- Reference notes:
- 1. Connect equipments as shown in the above table.
 - 2. Set the Viewer 34 cm distance in front of the camera.
 - 3. Set the gray scale chart in standard pattern frame of the Viewer.
 - 4. Adjust VR03 for reading maximum CCD OUT level on the oscilloscope.

7. Iris Normal Level Adjustment



- Reference notes:
- 1. Connect equipments as shown in the above table.
 - 2. Set the Viewer 34 cm distance in front of the camera.
 - 3. Set the gray scale chart in standard pattern frame of the Viewer.
 - 4. Adjust VR01 for reading 450 mVp-p ±15mV on the oscilloscope.


8. Iris High Level Adjustment



Reference note:

1. Connect equipments as shown in the above table.
2. Set the viewer 34 cm distance in front of the camera.
3. Set the gray scale chart in standard pattern frame of the Viewer.
4. Turn on the B-L SW (Black Light Switch).
5. Adjust VR02 for reading 550 mVp-p ±15mV on the oscilloscope.
6. Turn off the B-L SW after the adjustment.


9. PRE AMP. Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Set the Viewer 34 cm distance in front of the camera.
3. Set the gray scale chart in standard pattern frame of the Viewer.
4. Adjust VR04 for reading 250mVp-p ±10mV on the oscilloscope.


10. Low Clip Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Set the Lens Cap on the camera.
3. Adjust VR102 to get the minimum level of "A". ("A" = $4mV_{p-p}$)
4. Remove the Lens Cap after the adjustment.


11. Y. 1H Level Adjustment



Reference notes:


1. Connect equipments as shown in the above table.
2. Set the viewer 34 cm distance in front of the camera.
3. Set the gray scale chart in standard frame of the Viewer.
4. Adjust VR140 to obtain the same level on both channel of the oscilloscope.

12. Burst Level Adjustment




- Reference notes:
- 1. Connect equipments as shown in the above table.
 - 2. Set the Viewer 34 cm distance in front of the camera.
 - 3. Set the gray scale chart in standard pattern frame of the Viewer.
 - 4. Adjust VR138 for reading 600mVp-p ±10mV on the oscilloscope.

13. Hue Adjustment



- Reference notes:
- 1. Connect equipments as shown in the above table.
 - 2. Set the Viewer 34 cm distance in front of the camera.
 - 3. Set the color bar chart in standard pattern frame of the Viewer.
 - 4. Adjust VR135 to overlap each outer point of 6 color Spots.


14. B-Y / R-Y OFF-SET Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Set the Viewer 34 cm distance in front of the camera.
3. Set the color bar chart in standard pattern frame of the Viewer.
4. Adjust VR132 and VR133 so that burst signal start form the center of the vector scope.


15. R-Y / B-Y Pedestal Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Set the Viewer 40 cm distance in front of the camera.
3. Set the color bar chart in standard pattern frame of the Viewer with black mask of the chart.
4. Adjust VR108 and VR106 for reading minimum level "A" on the oscilloscope, and confirm that the black spot (shown in figure) is shown on the center of the vector scope.
5. Confirm the FH2 / C-PED Adjustment is correct, and proceed the FH2 / C-PED Adjustment as required.

16. White Balance Pre-adjustment




Note:

VR1001, VR1002 : Test Board

Reference notes:

1. Connect equipments as shown in the above table.
2. Set the Viewer 40 cm distance in front of the camera.
3. Set the color bar chart in standard pattern frame of the Viewer with black mask of the chart.
4. Adjust VR1001 and VR1002 on Test Board for reading minimum level "B" on the oscilloscope, and confirm that the white spot (shown in figure) is shown on the center of the vector scope.

17. FH2 / C-PED Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Set the Lens Cap on the camera.
3. Adjust VR105 and VR104 to be shown the black spot is on the center of the vector scope.
4. Confirm the R-Y / B-Y Pedestal Adjustment, and proceed the R-Y / B-Y Pedestal Adjustment as required.
5. Remove the Lens Cap after the Adjustment.

18. Color 2H Gain Adjustment

Test Point	Adj. Point	Mode	Input
CAM OUT	VR129 (C-2H)	---	COLOR BAR CHART
Tape	M. EQ.	Spec.	
---	VECTOR SCOPE TV MONITOR VIEWER	SEE BELOW	

Connections of M. EQ.

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Set the Viewer 34 cm distance in front of the camera.
- 3. Set the color bar chart in standard pattern frame of the Viewer.
- 4. Adjust VR129 so that each 6 Color Spots are not shake.

19. White Balance Level B-Y / R-Y Adjustment

Test Point	Adj. Point	Mode	Input
TP113 (B-Y) TP114 (R-Y) TP111 (GND) TP109(CA-Y+C)	VR115 (W/B B-Y LEV.) VR114 (W/B R-Y LEV.)	---	COLOR BAR CHART
Tape	M. EQ.	Spec.	
---	OSCILLOSCOPE VIEWER	B-Y LEVEL: 150mV ±10mV R-Y LEVEL: 150mV ±10mV	

Connections of M. EQ.

Figure

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Set the Viewer 34 cm distance in front of the camera.
- 3. Set the color bar chart in standard pattern frame of the Viewer.
- 4. Adjust VR115 for reading 150mVp-p ±10mV on the oscilloscope.
- 5. Adjust VR114 for reading 150mVp-p ±10mV on the oscilloscope.

20. B-Y / R-Y Level Adjustment

Test Point	Adj. Point	Mode	Input
CAM OUT	VR109 (B-Y) VR110 (R-Y)	---	COLOR BAR CHART
Tape	M. EQ.	Spec.	
---	VECTOR SCOPE TV MONITOR VIEWER	SEE BELOW	

Connections of M. EQ.

Figure

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Set the Viewer 34 cm distance in front of the camera.
- 3. Set the color bar chart in standard pattern frame of the Viewer.
- 4. Adjust VR109 and VR110 to overlap each outer point of color Spots (especially RED and BLUE) on the adjustment spot.

21. Camera Y+C Level Adjustment

Test Point	Adj. Point	Mode	Input
TP109 (CA-Y+C) TP111 (GND)	VR120 (Y LEVEL)	---	GRAY SCALE CHART
Tape	M. EQ.	Spec.	
---	OSCILLOSCOPE VIEWER	2.0Vp-p ±0.05V	


Connections of M. EQ.

Figure

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Set the Viewer 34 cm distance in front of the camera.
- 3. Set the gray scale in standard pattern frame of the Viewer.
- 4. Adjust VR120 for reading 2.0Vp-p ±0.05V on the oscilloscope.


22. Auto White Balance Off Set Adjustment



Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Set the Viewer 34 cm distance in front of the camera.
- 3. Set the gray scale chart in standard pattern frame of the Viewer.
- 4. Set WHITE BAL SW (SW1009) to auto position.
- 5. Adjust VR117 and VR116 to obtain the white Spot to center of vector scope.
- 6. Set the Lens Cap on the camera and confirm the black spot is shown on the center. If not, redo above procedure.

23. Blooming Adjustment




Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Set the 40W fluorescent lamp 4m distance in front of the camera.
- 3. Turn on the black light switch (SW1005).
- 4. Turn the VR03 toward the clockwise direction slowly until lay of the fluorescent lamp is stopped.

Notice: Do not turn the VR03 more than the maximum position.
Do not enter the interference light directly into the camera frame.

- 5. Turn off the Black Light Switch (SW1005) after adjustment.

24. Flange Back Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Set the Simenf Star Chart 20 m distance in front of the camera.
3. Set Focus Switch (SW1007) to Manual.
4. Loosen the screw 1.
5. Turn the Zoom Ring maximum toward Tele, and adjust the focus by turning the focus ring.
6. Turn the Zoom Ring maximum toward Wide, and adjust the focus by turning the screw 2.
7. Reconfirm the step 5 and 6.
8. Tighten the screw 1.

VIDEO ELECTRICAL ADJUSTMENT

How to Set Up the EE Mode
(Signal input from Pattern Genrator and Audio Oscillator)

1. Connect the TV monitor to Video Out(JK531) and Audio Out(JK531) on Main PCB.
2. Connect the Pattern Generator to JK1004.
3. Connect the Audio Oscillator through the Attenuator to JK1006.
4. Connect connectors of Video Main PCB to the test board as following:


PCB	Connector's name	Connector on test board
Video Main PCB	CL-10	CL-10-A
Video Main PCB	CN-03	CN-3-A
Servo/Sys-con PCB	CL-19	CL-19-A
Servo/Sys-con PCB	CL-18	CL-18-A

5. Connect the EVF Unit Assembly to CN-2 (Main PCB).
6. Set switches as follows:

Switch No.	Switch's name	Select position
SW1001	CAMERA/VTR	VTR
SW1010	CAMERA/VTR	VTR
SW1004	CAMERA/TEST	TEST
SW1043	SOFT/DIGITAL	DIGITAL

7. Depress SW1020 for Power On.

DC/DC Converter Voltage Adjustment




Reference Notes:

1. Connect equipments as shown in the above table.
2. Adjust VR331 for reading 5.0V ±0.05V between TP331 and TP503 on the DC Voltmeter.


DC/DC Converter Frequency Adjustment

Test Point	Adj. Point	Mode	Input
TP332 (5V FREQ) TP503 (GND)	VR332 (5V FREQ)	E-E	---
Tape	M. EQ.	Spec.	
---	OSCILLOSCOPE FREQUENCY COUNTER	304.6875KHZ ± 2.0KHZ	

Connections of M. EQ.



Figure




Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Adjust VR332 for reading 304.6875KHz ± 2.0KHz on the frequency counter.


AGC Level Adjustment

Test Point	Adj. Point	Mode	Input
TP302 (AGC) TP503 (GND)	VR301 (AGC)	E-E	COLOR BAR W/IQ
Tape	M. EQ.	Spec.	
---	TEST BOARD PATTERN GENERATOR OSCILLOSCOPE	0.5Vp-p ± 0.02Vp-p	

Connections of M. EQ.




Figure



Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Inject the color bar with white 100% to Video In (JK1004).
- 3. Adjust VR301 so that AGC level becomes 0.5Vp-p ± 0.02V.


Emphasis Level Adjustment



Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Inject the color bar with 100% white to Video In (JK1004).
- 3. Adjust VR353 so that the emphasis level becomes 0.5Vp-p ±0.02V.


Y/C Sepa. Adjustment



Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Inject the color bar with 100% white to Video In (JK1004).
- 3. Adjust VR351 to get the minimum level of color "A" at TP 354.


W/D Clip



Reference notes:

1. Connect equipments as shown in the above table.
2. Inject the color bar with white 100% to Video In (JK1004).
3. Confirm the white clip level and dark clip level as shown in above.


Burst Flag Pulse Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Inject the color bar with white 100% to Video In (JK1004).
3. Set the trigger of oscilloscope to CH2 (+).
4. Adjust VR352 so that the center of color burst (TP502) aligns to the decline point of the burst flag pulse (TP356).


Luminance Carrir Set / Deviation Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Inject the color bar with white 100% to Video In (JK1004).
3. Adjust VR355 so that Sync Tip Frequency becomes 4.2MHz ±40KHz.
4. Adjust VR354 so that White Peak Frequency becomes 5.4MHz ±40KHz.

FM Audio Carrir Set /Deviation Adjustment



reference note:

1. Connect equipments as shown in the above table.
2. Inject the non-audio signal to Audio In (JK1006).
3. Adjust VR452 so that FM Audio Carrier Frequency becomes 1.5MHz ±20KHz.
4. Inject 1KHz Audio Signal (-65dBv) to Audio In (JK1006).
5. Adjust VR453 so that FM Audio Sigal becomes 120KHz ±20KHz.

How to Setup the Play Mode

- 1. Connect equipments same connection as E-E mode.
- 2. Set the SW1010 (CAMERA/VTR) to VTR.
- 3. Insert a playback tape.
- 4. Depress the SW1022 (PLAY) to playback.
- 5. Depress the SW1025 (STOP) to stop .
- 6. Set the SW1043 (SOFT/DIGITAL) to DIGITAL.

PB Switching Point Adjustmennt

Test Point	Adj. Point	Mode	Input
TP353 (V-OUT) TP503 (GND) TP355 (RF-SW)	VR526(SWP)	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6A	OSCILLOSCOPE	7.0H ±0.5H	

Connections of M. EQ.

MAIN P.C.B.

TP353(V-OUT)
TP503(GND)
TP355(RF SW)

Oscilloscope

CH1 CH2

Figure

CH1 (V-OUT)

CH2 (RF SW)

CH1 500mV/DIV

Reference note:

- 1. Connect equipments as shown in the above table.
- 2. Set the trigger of oscilloscope to CH2 (+) trigger.
- 3. Playback the test tape FM6A and adjust VR526 so that the front edge of V-sync (CH1) delays 7.0 ±0.5H from rising point of RF SW Pulse (CH2).

Capstan LP Adjustment

Test Point	Adj. Point	Mode	Input
TP527 (ATF ERR) TP503 (GND) TP355 (RF-SW)	VR529 (C-LP)	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6AL	OSCILLOSCOPE	SEE BELOW	

Connections of M. EQ.

MAIN P.C.B.

TP527(ATF ERR)
TP503(GND)

Oscilloscope

CH1 CH2

TP355(RF SW) MAIN P.C.B.

Figure

CH1 0.5V/DIV

CH2 5V/DIV

5mS/DIV


CH2 (RF SW)

CH1 (ATF ERR)

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Playback the test tape FM6AL.
- 3. Adjust VR529 for reading 2.4V DC level as shown in the above.


Capstan SP Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Playback the test tape FM6A.
3. Adjust VR528 for reading 2.4V DC level as shown in the above.


ATF Balance Adjustment



Reference notes:

1. Connect equipments as shown in the above table.
2. Playback the test tape FM6A.
3. Adjust VR525 so that the output level of PB-RF becomes maximum.
4. Confirm Capstan LP/SP adjustment and redo as required.



SP/LP Detector Adjustment

Test Point	Adj. Point	Mode	Input
TP526 (DOC-DC) TP525 (C-SP/LP) TP503 (GND)	VR527(C – SP/LP)	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6AL	DC VOLTMETER	SEE BELOW	
Connections of M. EQ.			
TP526(DOC-DC) TP525(C-SP/LP) TP503(GND)  DC Voltmeter			

Reference notes:

- 1. connect equipments as shown in the above table.
- 2. Playback the test tape FM6AL under CUE mode and read the DC voltage at TP526 (Vcue).
- 3. Playback the test tape FM6AL under REV mode and read the DC voltage at TP526 (Vrev).
- 4. Comparing Vcue with Vrev, check the lower voltage (Vlower), then adjust VR527 so that DC voltage at TP525 becomes 0.7V less than Vlower.

PB Level Adjustment

Test Point	Adj. Point	Mode	Input
TP352 (CCD1) TP503 (GND)	VR356 (CCD1)	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6A	OSCILLOSCOPE	0.5Vp-p ±0.02V	
Connections of M. EQ.			
MAIN P.C.B. TP352(CCD1) TP503(GND)  Oscilloscope			
Figure			
100mV/DIV 10uS/DIV 			

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Playback the test tape FM6A and adjust VR356 so that the playback level becomes 0.5Vp-p ±0.02V.

PB Level Confirmation

Test Point	Adj. Point	Mode	Input
TP353 (V-OUT) TP503 (GND)	---	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6A	OSCILLOSCOPE	1.0Vp-p ±0.05V	

Connections of M. EQ.

MAIN
P.C.B.

TP353(V-OUT)
TP503(GND)

Oscilloscope

Figure

0.2V/DIV
10uS/DIV

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Playback the test tape FM6A and confirm the playback level is 1.0Vp-p ±0.05V.

Chroma Emphasis Freq. Adjustment

Test Point	Adj. Point	Mode	Input
JK531 (AV JACK)	T352	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6A	VECTOR SCOPE TV MONITOR	MINIMUM	

Connections of M. EQ.

MAIN PCB
JK531
AV JACK

Vector Scope
EXIT

TV Monitor

Figure

Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Playback the test tape FM6A.
- 3. Adjust T352 so that the spot showing on center of the Vector Scope becomes minimum.

FSC Adjustment

Test Point	Adj. Point	Mode	Input
JK531 (AV JACK) TP351 (4.43M)	VR532 (FSC)	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6EL	VECTOR SCOPE TV MONITOR	SEE BELOW	

Connections of M. EQ.

Vector Scope

TV Monitor

MAIN PCB
JK531
AV JACK

TP351 4.43

EXIT

Figure

- Reference notes:
- 1. Connect equipments as shown in the above table.
 - 2. Playback the test tape FM6EL .
 - 3. Set trigger mode of the Vector Scope to EXIT and PAL.
 - 4. Adjust the Phase Volume on the Vector Scope.
 - 5. Depress the STILL key until the noisebar is shown on TV screen.
 - 6. Adjust VR532 to overlap each color spots in one on the Vector Scope.

APC Adjustment

Test Point	Adj. Point	Mode	Input
JK531 (AV JACK) TP351 (4.43M)	VR531 (APC)	PLAYBACK	TEST TAPE
Tape	M. EQ.	Spec.	
FM6EL	VECTOR SCOPE TV MONITOR	SEE BELOW	

Connections of M. EQ.

Vector Scope

TV Monitor

MAIN PCB
JK531
AV JACK

TP351 (4.43)

EXIT

Figure


- Reference Note:
- 1. Connect equipments as shown in the above table.
 - 2. Playback the test tape.
 - 3. Set the Vector Scope trigger mode to EXIT and PAL.
 - 4. Adjust the FHASE VOLUME on Vector Scope.
 - 5. Depress the STILL key until the noisebar is shown on TV screen.
 - 6. Adjust VR531 so that each color spot are overlap on the Vector scope.

How to Setup the Rec Mode (On put signal from Pattern Generator and Audio Oscillator)


- 1. Connect equipments same connection as E-E mode.
- 2. Set the SW1010 (CAMERA/VTR) to camera.
- 3. Insert a blank tape.
- 4. Select the recording tape speed by SW1037 (SP/LP).
- 5. Depress the SW1031 for recording.
- 6. Depress the SW1031 for stop recording.

Set the SW1043 (SOFT/DIGITAL) to digital.Rec Luminance Current Adjustment

Test Point	Adj. Point	Mode	Input
TP353(V-OUT) TP708(CH1F) TP710(GND) TP355(RF-SW)	VR501(REC Y)	REC/SP	RED RASTER
Tape	M.EQ.	Spec.	
BRANK TAPE	TEST BOARD PATTERN GENERATOR OSCILLOSCOPE	200mV ± 5mV	



Figure




Reference notes:

- 1. Connect equipments as shown in the above figure.
- 2. Inject the Red Raster to Video In (JK1004).
- 3. Adjust VR501 so that REC-Y current becomes 200mV ±5mV.


Rec. Chroma Current Adjustment

Test Point	Adj. Point	Mode	Input
TP708 (CH1 F) TP710 (GND) TP355 (RF-SW)	VR502 (REC C)	REC/SP	RED RASTER
Tape	M. EQ.	Spec.	
BRANK TAPE	TEST BOARD PATTERN GENERATOR OSCILLOSCOPE SPECTRUM ANALYZER	Y -11dB ± 1dB	

Connections of M. EQ.




Figure



Reference notes:

- 1. Connect equipments as shown in the above table.
 - 2. Set the Spectrum Analyzer as following range.
- | Freq. Span | RBW | Sweep Time |
|------------|--------|------------|
| 10MHz | 100KHz | 10m sec |
- 3. Input the Red Raster from Video In (JK1004).
 - 4. Adjust VR502 so that REC C current level becomes 11dB lower than Red Carrir level.

Rec. AFM Current Adjustment



Reference notes:

- 1. Connect equipments as shown in the above table.
- 2. Set the Spectrum Analyzer as following level.

Freq. Span	RBW	SCAN Time
2MHz	30KHz	0.1 sec

- 3. Inject Red Raster to Video In (JK1004).
- 4. Adjust VR451 so that REC AMF current lever becomes 12dB lower than the REC C current.

How to Set Up the Rec Mode (Input signal from preadjusted Camera)

- 1. Disconnect CN-10 from the Camera PCB.
- 2. Disconnect CL-10 from the Main PCB.
- 3. Do all connectors on CAMERA PCB to Main PCB.


Camera PCB	Main PCB
CN-10	CL-10

- 4. Set the switch position as follows:

Switch No.	Switch name	Select position
SW1001	TV/TP	TV
SW1004	CAMERA/TEST	CAMERA
SW1010	CAMERA/VTR	VTR
SW1009	WHITE BALANCE	AUTO
SW1043	SOFT/DIGITAL	DIGITAL
SW1007	FOCUS M/A	A
SW1008	1/1000 ON/OFF	OFF

- 5. Set the recording tape speed by SW1037 (SP/LP).
- 6. Depress the SW1031 for recording.
- 7. Depress the SW1031 again for stop the recording.

Battery Down Adjustment



Reference notes:

- 1. Connect equipments as shown in the above table.
(Connect the power supply directly to battery terminals.)
- 2. Turn VR333 fully clockwise.
- 3. Set the power supply output voltage to 5.60V +0.05/-0V.
- 4. Adjust VR333 slowly to counterclockwise direction until the unit turn off.


EVF ELECTRICAL ADJUSTMENT

Note:
All adjustment procedures must be proceeded in order of numbering.

1. Brightness adjustment

Test Point	Adj. Point	Mode	Input
EVF MONITOR	VR804	PLAYBACK	MONOSCOPE
Tape	M. EQ.	Spec.	
FM6M	---	SEE BELOW	

Figure




The diagram shows a circular target with a central bullseye and radial lines. A horizontal bar across the top is divided into seven segments labeled 0 through 6. Two arrows point to the segments labeled 0 and 1, indicating the areas to be adjusted for brightness.

- Reference notes:**
- 1. Playback the test tape.
 - 2. Adjust VR804 to obtain the black level of area 0 and 1 are same.

2. Centering Adjustment

Test Point	Adj. Point	Mode	Input
EVF MONITOR	RING A RING B	PLAYBACK	MONOSCOPE
Tape	M. EQ.	Spec.	
FM6M	---	SEE BELOW	

Figure




The figure contains two diagrams. The left diagram shows a circular target with a central bullseye and radial lines, similar to the one in the first section, with a horizontal bar at the top labeled 0 through 6. An arrow points to the center of the target. The right diagram is a cross-sectional view of the EVF monitor assembly, showing the internal components. Two arrows point to specific rings, labeled RING B and RING A, indicating the points of adjustment for centering.

- Reference notes:**
- 1. Playback the test tape.
 - 2. Adjust the Ring A and Ring B alternately so that the largest circle of the monoscope is shown on the center of EVF.
 - 3. Fix the Ring A and Ring B by Silicon Glue.

3. Vertical Size Adjustment

Test Point	Adj. Point	Mode	Input
EVF MONITOR	VR802	PLAYBACK	MONOSCOPE
Tape	M. EQ.	Spec.	
FM6M	---	SEE BELOW	

Figure




Reference notes:

- 1. Playback the test tape.
- 2. Adjust VR802 so that the largest circle of the monoscope becomes perfect circle.

4. Focus Adjustment

Test Point	Adj. Point	Mode	Input
EVF MONITOR	VR803	PLAYBACK	MONOSCOPE
Tape	M. EQ.	Spec.	
FM6M	---	SEE BELOW	



Figure





Reference notes:



- 1. Playback the test tape.
- 2. Adjust VR803 to get the best focus using the area showing by arrow.



TROUBLESHOOTING GUIDE











When the SYSTEM CONTROL IC has runaway SYSTEM CONTROL IC will not accept any mode.
AT this time disconnect the battery and back up battery to reset the SYSTEM CONTROL IC.



















EXPLODED VIEW(CABINET)



MECHANICAL PARTS LIST(For Europe Model)

Ref.No.	Description	PartNo.
MECHANICAL PARTS		
A301	CABINET ASS'Y, LEFT	DVM200755X
A0101	LENS HOOD	OVM300869
A0302	COVER, LITHIUM BATTERY	OVM300864
A0303	CAP, LENS	OVM300868
A0304	KNOB SLIDE, BAT. EJECT	OVM300870
A0305	LOCK LEVER, BAT.	OVM300871
A0306	SPRING PULL . BAT	OVM402690
A0307	BASE,EVF	OVM402691
A0308	PLATE,EVF	OVM402692
A0309	SPRING PLATE, EVF	OVM402693
A0310	COVER, AF	OVM402694
A0311	BRACKET, BAT. EJECT LEVER	OVM402845
A0312	MICROPHONE HXM1214-010010	DMECX00HDOC1
A0501	FRONT PANEL ASS'Y	OVM300885
A0701	REAR PANEL ASS'Y	OVM300887
A0801	EVF CABINET CASE	OVM200750
A0901	EVF BOTTOM CASE ASS'Y	OVM402704
A1001	EVF EYEPIECE ASS'Y	OVM300888
A1101	LID, BOTTOM	OVM200747
A1201	LENS UNIT 51YA	ULZU000JA001
B201	INSULATOR, POWER P PLATE	OVM403155
B202	SUB CHASSIS	OVM200748
B203	BRACKET MECHANICAL CHASSIS	OVM300875
B204	BRACKET, X'TAL, OPLF	OVM300858
B205	BRACKET CCD, HEATSINK	OVM402679
B206	CUSHION, OPLF	OVM402680
SCREWS		
L20101	M2X6, BIND HEAD	SBK32060
L20201	CAMERA, M2X5, PAN HEAD	MPKJ2050
L20202	CAMERA, M2X5, PAN HEAD	MPKJ2050
L20203	CAMERA, M2X5, PAN HEAD	MPKJ2050
L20205	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20302	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20303	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20304	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20305	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20306	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20307	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20308	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20309	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20401	TAPPING, CAMERA, M2X6, BAIND HEAD	GCMB2060
L20402	TAPPING, CAMERA, M2X6, BAIND HEAD	GCMB2060
L20501	CAMERA, M2X10, PAN HEAD	MPKJ2100
L20601	CAMERA, M1.6X3	MPKJG030
L20602	CAMERA, M1.6X3	MPKJG030
L20603	CAMERA, M1.6X3	MPKJG030
L20701	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20702	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20703	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20704	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20705	TAPPING, M2X5, PAN HEAD	MPKF2050
L20801	TAPPING, CAMERA, M1.6X4, PAN HEAD	MPKGG040

Ref.No.	Description	PartNo.
PACKING MATERIALS		
	STYROFOAM, UPPER	OVM200873
	STYROFOAM, LOWER	OVM200874
	GIFT BOX	OVM301026
	BAG, UNIT	OVM402901
	SERIAL NO. LABEL	7E00050
	LABEL, SERIAL NO.	7E51030
ACCESSORIES		0VSA04453
	AV CABLE	WPC0152TM001
	DC CABLE	WPC0202TM001
	BATTERY PACK 5KR1200AEFNI-1581	XB0N122SY002
	ACCESSORY BAG	Z305060
	ACCESSORY BAG	Z323370
	CASSETTE TAPE 8MM	OVMN00548
▲	OWNER'S MANUAL	OVMN00833
	SHOULDER BELT	OVM301116
	ACCESSORY BAG FOR CHARGER	Z312480
	LITHUM BATTER Y CR2025	5790121
BATTERY CHAGER UNIT		0VSA04455
CONSISTS OF THE FOLLOWING:		
L20801	SCREW, TAPPING, M2X6, BIND HEAD	GPKB9012
L20802	SCREW, TAPPING, M2X6, PAN HEAD	GPKB2060
L20901	SCREW, M2X4, BIND HEAD	SBM32040
L21001	SCREW, M3X8, BIND HEAD	SBM33080
L21002	SCREW, M3X8, BIND HEAD	SBM33080
B207	AC BARRIER	OVM200816
B208	SHIELD CASE, AC	OVM200817
A1301	TOP CASE, AC	OVM200814
A1401	BOTTOM CASE, AC	OVM200815
A1501	LED, WINDOW	OVM300962
	AC CHARGER PCB ASSY (SEE ELECTRI- CAL PARTS LIST)	0VSA04170

MECHANICAL PARTS LIST(For Northern Europe Model)

Ref.No.	Description	PartNo.
MECHANICAL PARTS		
A301	CABINET ASS'Y, LEFT	DVM200755X
A0101	LENS HOOD	OVM300869
A0302	COVER, LITHIUM BATTERY	OVM300864
A0303	CAP, LENS	OVM300868
A0304	KNOB SLIDE, BAT. EJECT	OVM300870
A0305	LOCK LEVER, BAT.	OVM300871
A0306	SPRING PULL . BAT	OVM402690
A0307	BASE,EVF	OVM402691
A0308	PLATE,EVF	OVM402692
A0309	SPRING PLATE, EVF	OVM402693
A0310	COVER, AF	OVM402694
A0311	BRACKET, BAT. EJECT LEVER	OVM402845
A0312	MICROPHONE HXM1214-010010	DMECX00HDOC1
A0501	FRONT PANEL ASS'Y	OVM300885
A0701	REAR PANEL ASS'Y	OVM300887
A0801	EVF CABINET CASE	OVM200750
A0901	EVF BOTTOM CASE ASS'Y	OVM402704
A1001	EVF EYEPIECE ASS'Y	OVM300888
A1101	LID, BOTTOM	OVM200747
A1201	LENS UNIT 51YA	ULZU000JA001
B201	INSULATOR, POWER P PLATE	OVM403155
B202	SUB CHASSIS	OVM200748
B203	BRACKET MECHANICAL CHASSIS	OVM300875
B204	BRACKET, X'TAL, OPLF	OVM300858
B205	BRACKET CCD, HEATSINK	OVM402679
B206	CUSHION, OPLF	OVM402680
SCREWS		
L20101	M2X6, BIND HEAD	SBK32060
L20201	CAMERA, M2X5, PAN HEAD	MPKJ2050
L20202	CAMERA, M2X5, PAN HEAD	MPKJ2050
L20203	CAMERA, M2X5, PAN HEAD	MPKJ2050
L20205	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20302	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20303	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20304	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20305	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20306	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20307	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20308	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20309	TAPPING, CAMERA, M2X5, PAN HEAD	MPKG2050
L20401	TAPPING, CAMERA, M2X6, BAIND HEAD	GCMB2060
L20402	TAPPING, CAMERA, M2X6, BAIND HEAD	GCMB2060
L20501	CAMERA, M2X10, PAN HEAD	MPKJ2100
L20601	CAMERA, M1.6X3	MPKJG030
L20602	CAMERA, M1.6X3	MPKJG030
L20603	CAMERA, M1.6X3	MPKJG030
L20701	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20702	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20703	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20704	TAPPING, CAMERA, M2X5, PAN HEAD	MPKF2050
L20705	TAPPING, M2X5, PAN HEAD	MPKF2050
L20801	TAPPING, CAMERA, M1.6X4, PAN HEAD	MPKGG040

Ref.No.	Description	PartNo.
PACKING MATERIALS		
	STYROFOAM, UPPER	OVM200873
	STYROFOAM, LOWER	OVM200874
	GIFT BOX	OVM301026
	BAG, UNIT	OVM402901
	SERIAL NO. LABEL	7E00050
	LABEL, SERIAL NO.	7E51030
ACCESSORIES		0VSA04453
	AV CABLE	WPC0152TM001
	DC CABLE	WPC0202TM001
	BATTERY PACK 5KR1200AEFNI-1581	XB0N122SY002
	ACCESSORY BAG	Z305060
	ACCESSORY BAG	Z323370
	CASSETTE TAPE 8MM	OVMN00548
▲	OWNER'S MANUAL	OVMN00835
	SHOULDER BELT	OVM301116
	ACCESSORY BAG FOR CHARGER	Z312480
	LITHUM BATTER Y CR2025	5790121
BATTERY CHAGER UNIT		0VSA04455
CONSISTS OF THE FOLLOWING:		
L20801	SCREW, TAPPING, M2X6, BIND HEAD	GPKB9012
L20802	SCREW, TAPPING, M2X6, PAN HEAD	GPKB2060
L20901	SCREW, M2X4, BIND HEAD	SBM32040
L21001	SCREW, M3X8, BIND HEAD	SBM33080
L21002	SCREW, M3X8, BIND HEAD	SBM33080
B207	AC BARRIER	OVM200816
B208	SHIELD CASE, AC	OVM200817
A1301	TOP CASE, AC	OVM200814
A1401	BOTTOM CASE, AC	OVM200815
A1501	LED, WINDOW	OVM300962
	AC CHARGER PCB ASSY (SEE ELECTRI- CAL PARTS LIST)	0VSA04170

ELECTRICAL PARTS LIST

PRODUCT SAFETY NOTE: Products marked with a  have special characteristics important to safety. Before replacing any of these components, read carefully the product safety notice of this service manual. Don't degrade the safety of the product through improper servicing.

NOTE: Tolerance of Capacitors and Resistors are noted with the following symbols.

C.....±0.25%	J.....±5%	Z.....+80/-20%
D.....±0.5%	K.....±10%	X.....+40/-20%
F.....±1%	M.....±20%	P.....+100%
G.....±2%	N.....±30%	

MCV PCB ASSEMBLY

Ref.No.	Description	PartNo.
	MCV PCB ASSEMBLY CONSISTS OF THE FOLLOWING:	0VSA03992
	CAPACITORS	
C301	ELECTROLYTIC 22µF/6.3V M H7	526R226V
C302	CHIP CERAMIC F Z 0.022µF/50V or CHIP CERAMIC F Z 0.022µF/25V or CHIP CERAMIC F Z 0.022µF/25V or CHIP CERAMIC F Z 0.022µF/50V	CHD1JZ80F223 CHD1EZ80F223 CHD1EZ80Z223 CHD1JZ80Z223
C303	CHIP CERAMIC SL J 27PF/50V	CHD1JJ8SL270
C304	CHIP CERAMIC B K 0.01µF/25V or CHIP CERAMIC B K 0.01µF/50V or CHIP CERAMIC B K 0.01µF/25V or CHIP CERAMIC B K 0.01µF/50V	CHD1EK80B103 CHD1JK80B103 CHD1EK80X103 CHD1JK80X103
C305	CHIP CERAMIC B K 0.01µF/25V or CHIP CERAMIC B K 0.01µF/50V or CHIP CERAMIC B K 0.01µF/25V or CHIP CERAMIC B K 0.01µF/50V	CHD1EK80B103 CHD1JK80B103 CHD1EK80X103 CHD1JK80X103
C306	ELECTROLYTIC 47µF/6.3V M H7	526R476V
C307	CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V or CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V	CHD1JZ80F103 CHD1EZ80F103 CHD1JZ80Z103 CHD1EZ80Z103
C308	ELECTROLYTIC 2.2µF/50V M H7	526W225V
C309	ELECTROLYTIC 0.47µF/50V M H7	526W474V
C310	CHIP CERAMIC SL J 22PF/50V	CHD1JJ8SL220
C311	ELECTROLYTIC 10µF/16V M H7	526T106V
C312	CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125	CA1C010KC001 CA1C010MR002 CA1C010TU003
C313	CHIP CERAMIC F Z 0.1µF/16V or CHIP CERAMIC F Z 0.1µF/25V or CHIP CERAMIC F Z 0.1µF/25V or CHIP CERAMIC F Z 0.1µF/16V	CHD1CZ80F104 CHD1EZ80F104 CHD1EZ80Z104 CHD1CZ80Z104
C314	ELECTROLYTIC 10µF/16V M H7	526T106V
C315	ELECTROLYTIC 2.2µF/50V M H7	526W225V
C316	ELECTROLYTIC 0.47µF/50V M H7	526W474V
C317	CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V or CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V	CHD1JZ80F103 CHD1EZ80F103 CHD1JZ80Z103 CHD1EZ80Z103
C318	ELECTROLYTIC 10µF/16V M H7	526T106V
C319	CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V or CHIP CERAMIC F Z 0.01µF/50V or	CHD1JZ80F103 CHD1EZ80F103 CHD1JZ80Z103

Ref.No.	Description	PartNo.
	CHIP CERAMIC F Z 0.01µF/25V	CHD1EZ80Z103
C320	ELECTROLYTIC 10µF/16V M H7	526T106V
C326	OS 33µF/10V M SA	CA1A336SY001
C327	OS 10µF/16V M SC	CA1C106SY002
C328	CHIP CERAMIC SL J 470PF/50V	CHD1JJ8SL471
C329	CHIP CERAMIC SL J 47PF/50V	CHD1JJ8SL470
C330	OS 33µF/10V M SA	CA1A336SY001
C331	ELECTROLYTIC 47µF/6.3V M H7	526R476V
C332	ELECTROLYTIC 47µF/6.3V M H7	526R476V
C333	ELECTROLYTIC 47µF/6.3V M H7	526R476V
C334	CHIP CERAMIC B K 2700PF/50V or CHIP CERAMIC B K 2700PF/50V or CHIP CERAMIC B K 2700PF/25V or CHIP CERAMIC B K 2700PF/25V	CHD1JK80B272 CHD1JK80X272 CHD1EK80B272 CHD1EK80X272
C335	CHIP CERAMIC CH J 470PF/50V	CHD1JJ8CH471
C336	ELECTROLYTIC 4.7µF/25V M	121U475V
C338	CHIP CERAMIC B K 1000PF/50V or CHIP CERAMIC B K 1000PF/25V or CHIP CERAMIC B K 1000PF/50V or CHIP CERAMIC B K 1000PF/25V	CHD1JK80B102 CHD1EK80B102 CHD1JK80X102 CHD1EK80X102
C345	CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125	CA1C010KC001 CA1C010MR002 CA1C010TU003
C346	CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125	CA1C010KC001 CA1C010MR002 CA1C010TU003
C347	CHIP CERAMIC B K 0.1µF/50V or CHIP CERAMIC B K 0.1µF/25V	12B3104C 12B2104C
C348	CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V or CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V	CHD1JZ80F103 CHD1EZ80F103 CHD1JZ80Z103 CHD1EZ80Z103
C349	ELECTROLYTIC 4.7µF/50V M H7	526W475V
C350	CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V or CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V	CHD1JZ80F103 CHD1EZ80F103 CHD1JZ80Z103 CHD1EZ80Z103
C351	CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125 or CHIP CERAMIC 1µF/16V F 2125	CA1C010KC001 CA1C010MR002 CA1C010TU003
C352	ELECTROLYTIC 100µF/6.3V M H7	526R107V
C353	CHIP CERAMIC F Z 0.01µF/50V or CHIP CERAMIC F Z 0.01µF/25V or CHIP CERAMIC F Z 0.01µF/50V or	CHD1JZ80F103 CHD1EZ80F103 CHD1JZ80Z103

Ref.No.	Description	PartNo.
C354	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C355	ELECTROLYTIC 10μF/16V M H7	526T106V
C356	ELECTROLYTIC 10μF/16V M H7	526T106V
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C357	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C358	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C359	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C360	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C361	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C362	ELECTROLYTIC 10μF/16V M H7	526T106V
C363	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C364	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C365	ELECTROLYTIC 10μF/16V M H7	526T106V
C366	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C367	ELECTROLYTIC 10μF/16V M H7	526T106V
C368	ELECTROLYTIC 10μF/16V M H7	526T106V
C369	ELECTROLYTIC 10μF/16V M H7	526T106V
C370	ELECTROLYTIC 10μF/16V M H7	526T106V
C371	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C372	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
	CHIP CERAMIC B K 1000PF/25V or	CHD1EK80B102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80X102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80X102
C373	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80Z223
C374	ELECTROLYTIC 10μF/16V M H7	526T106V
C375	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80Z223
C376	OS 47μF/6.3V M SA	CAOK476SY001
C377	CHIP CERAMIC SL J 270PF/50V	CHD1JJ8SL271
C378	CHIP CERAMIC SL J 56PF/50V	CHD1JJ8SL560
C379	ELECTROLYTIC 10μF/16V M H7	526T106V
C380	CHIP CERAMIC SL J 22PF/50V	CHD1JJ8SL220

Ref.No.	Description	PartNo.
C381	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80Z223
C382	ELECTROLYTIC 10μF/16V M	121T106V
C383	CHIP CERAMIC SL J 390PF/50V	CHD1JJ8SL391
C384	CHIP CERAMIC SL J 470PF/50V	CHD1JJ8SL471
C385	CHIP CERAMIC SL J 18PF/50V	CHD1JJ8SL180
C386	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C387	CHIP CERAMIC B K 0.1μF/50V or	12B3104C
	CHIP CERAMIC B K 0.1μF/25V	12B2104C
C388	CHIP CERAMIC SL J 470PF/50V	CHD1JJ8SL471
C389	CHIP CERAMIC SL J 180PF/50V	CHD1JJ8SL181
C390	CHIP CERAMIC SL J 22PF/50V	CHD1JJ8SL220
C391	CHIP CERAMIC SL J 100PF/50V	CHD1JJ8SL101
C392	CHIP CERAMIC SL J 12PF/50V	CHD1JJ8SL120
C393	ELECTROLYTIC 10μF/16V M H7	526T106V
C394	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/50V	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80Z223
C395	CHIP CERAMIC SL J 100PF/50V	CHD1JJ8SL101
C396	CHIP 1/16W J 0Ω	RCXGJR8Z0000
C398	CHIP CERAMIC CH J 22PF/50V or	CHD1JJ8CH220
	CHIP CERAMIC CG J 22PF/50V	CHD1JJ8CG220
C399	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C400	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C401	CHIP CERAMIC SL D 8PF/50V or	CHD1JD8SL8R0
	CHIP CERAMIC SL C 8PF/50V	CHD1JC8SL8R0
C402	CHIP CERAMIC SL J 100PF/50V	CHD1JJ8SL101
C403	ELECTROLYTIC 10μF/16V M	121T106V
C404	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C405	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C406	OS 47μF/6.3V M SA	CAOK476SY001
C407	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80Z223
C408	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C409	CHIP CERAMIC SL J 220PF/50V	CHD1JJ8SL221
C410	CHIP CERAMIC SL J 150PF/50V	CHD1JJ8SL151
C411	ELECTROLYTIC 10μF/10V M NP	524T106V
C412	ELECTROLYTIC 10μF/16V M H7	526T106V

Ref.No.	Description	PartNo.
C413	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80B223
	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80X223
	CHIP CERAMIC B K 0.022μF/16V	CHD1CK80X223
C415	ELECTROLYTIC 47μF/6.3V M H7	526R476V
C416	ELE CAP (NP) 0.22μF/50V(NP) H=7 or	CA1JR22NC001
	ELE CAP(NP) 0.22μF/50V(NP) H=7	CA1JR22EA001
C417	CHIP CERAMIC SL J 150PF/50V	CHD1JJ8SL151
C418	ELECTROLYTIC 0.47μF/50V M H7	526W474V
C419	ELECTROLYTIC 2.2μF/50V M H7	526W225V
C420	ELECTROLYTIC 10μF/16V M H7	526T106V
C421	ELECTROLYTIC 10μF/16V M H7	526T106V
C422	ELECTROLYTIC 1μF/50V M H7	526W105V
C423	CHIP CERAMIC B K 8200PF/50V or	CHD1JK80B822
	CHIP CERAMIC B K 8200PF/25V or	CHD1EK80B822
	CHIP CERAMIC B K 8200PF/50V or	CHD1JK80X822
	CHIP CERAMIC B K 8200PF/25V	CHD1EK80X822
C424	CHIP CERAMIC SL J 680PF/50V	1270681C
C425	CHIP CERAMIC B K 0.039μF/50V	12B3393C
C426	CHIP CERAMIC B K 4700PF/50V or	CHD1JK80B472
	CHIP CERAMIC B K 4700PF/50V or	CHD1JK80X472
	CHIP CERAMIC B K 4700PF/25V or	CHD1EK80X472
	CHIP CERAMIC B K 4700PF/25V	CHD1EK80B472
C427	CHIP CERAMIC CH C 5PF/50V or	CHD1JC8CH5R0
	CHIP CERAMIC CG C 5PF/50V	CHD1JC8CG5R0
C428	CHIP CERAMIC SL J 220PF/50V	CHD1JJ8SL221
C429	ELECTROLYTIC 2.2μF/50V M	121W225V
C430	CHIP CERAMIC SL J 100PF/50V	CHD1JJ8SL101
C431	ELECTROLYTIC 2.2μF/50V M	121W225V
C432	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80Z104
	CHIP CERAMIC F Z 0.1μF/25V	CHD1EZ80Z104
C433	CHIP CERAMIC SL J 470PF/50V	CHD1JJ8SL471
C434	ELECTROLYTIC 4.7μF/25V M	121U475V
C435	ELECTROLYTIC 47μF/6.3V M	121R476V
C436	ELECTROLYTIC 1μF/50V M	121W105V
C437	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80Z104
	CHIP CERAMIC F Z 0.1μF/25V	CHD1EZ80Z104
C438	CHIP CERAMIC CH C 5PF/50V or	CHD1JC8CH5R0
	CHIP CERAMIC CG C 5PF/50V	CHD1JC8CG5R0
C439	ELECTROLYTIC 3.3μF/50V M	121W335V
C440	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C441	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80F473
	CHIP CERAMIC F Z 0.047μF/50V or	CHD1JZ80F473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80F473
	CHIP CERAMIC F Z 0.047μF/25V	CHD1EZ80Z473
C442	ELECTROLYTIC 100μF/6.3V M	121R107V
C443	ELECTROLYTIC 47μF/6.3V M	121R476V
C444	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C445	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223

Ref.No.	Description	PartNo.
C446	CHIP CERAMIC F Z 0.022μF/50V	CHD1JZ80Z223
	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80B222
	CHIP CERAMIC B K 2200PF/25V or	CHD1EK80B222
	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80X222
	CHIP CERAMIC B K 2200PF/25V	CHD1EK80X222
C447	CHIP CERAMIC B K 3900PF/50V or	CHD1JK80B392
	CHIP CERAMIC B K 3900PF/25V or	CHD1EK80B392
	CHIP CERAMIC B K 3900PF/50V or	CHD1JK80X392
	CHIP CERAMIC B K 3900PF/25V	CHD1EK80X392
C448	CHIP CERAMIC SL J 220PF/50V	CHD1JJ8SL221
C449	CHIP CERAMIC B K 1500PF/50V or	CHD1JK80B152
	CHIP CERAMIC B K 1500PF/25V or	CHD1EK80B152
	CHIP CERAMIC B K 1500PF/50V or	CHD1JK80X152
	CHIP CERAMIC B K 1500PF/25V	CHD1EK80X152
C450	ELECTROLYTIC 0.47μF/50V M H7	526W474V
C451	CHIP CERAMIC SL J 220PF/50V	CHD1JJ8SL221
C452	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80B223
	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80X223
	CHIP CERAMIC B K 0.022μF/16V	CHD1CK80X223
C453	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C454	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C455	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C456	CHIP CERAMIC B K 6800PF/50V or	CHD1JK80B682
	CHIP CERAMIC B K 6800PF/25V or	CHD1EK80B682
	CHIP CERAMIC B K 6800PF/50V or	CHD1JK80X682
	CHIP CERAMIC B K 6800PF/25V	CHD1EK80X682
C457	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80B222
	CHIP CERAMIC B K 2200PF/25V or	CHD1EK80B222
	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80X222
	CHIP CERAMIC B K 2200PF/25V	CHD1EK80X222
C458	CHIP CERAMIC SL J 120PF/50V	CHD1JJ8SL121
C459	CHIP CERAMIC B K 3300PF/50V or	CHD1JK80B332
	CHIP CERAMIC B K 3300PF/25V or	CHD1EK80B332
	CHIP CERAMIC B K 3300PF/50V or	CHD1JK80X332
	CHIP CERAMIC B K 3300PF/25V	CHD1EK80X332
C460	ELECTROLYTIC 47μF/6.3V M	121R476V
C461	ELECTROLYTIC 47μF/6.3V M H7	526R476V
C463	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80B223
	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80X223
	CHIP CERAMIC B K 0.022μF/16V	CHD1CK80X223
C475	CHIP CERAMIC SL J 56PF/50V	CHD1JJ8SL560
C476	CHIP CERAMIC SL D 10PF/50V or	CHD1JD8SL100
	CHIP CERAMIC SL C 10PF/50V	CHD1JC8SL100
C477	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C478	CHIP CERAMIC SL J 56PF/50V	CHD1JJ8SL560
C479	CHIP CERAMIC SL J 82PF/50V	CHD1JJ8SL820
C480	CHIP CERAMIC SL J 180PF/50V	CHD1JJ8SL181
C481	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103

Ref.No.	Description	PartNo.
C482	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
	ELECTROLYTIC 22μF/6.3V M H7	526R226V
C483	CHIP CERAMIC SL J 56PF/50V	CHD1J8SL560
C484	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C485	CHIP CERAMIC SL J 82PF/50V	CHD1J8SL820
C486	CHIP CERAMIC B K 3300PF/50V or	CHD1JK80B332
	CHIP CERAMIC B K 3300PF/25V or	CHD1EK80B332
	CHIP CERAMIC B K 3300PF/50V or	CHD1JK80X332
	CHIP CERAMIC B K 3300PF/25V	CHD1EK80X332
C487	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C488	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C489	ELECTROLYTIC 22μF/6.3V M H7	526R226V
C490	CHIP CERAMIC B K 0.027μF/50V	12B3273C
C491	CHIP CERAMIC SL J 68PF/50V	CHD1J8SL680
C492	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80B222
	CHIP CERAMIC B K 2200PF/25V or	CHD1EK80B222
	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80X222
	CHIP CERAMIC B K 2200PF/25V	CHD1EK80X222
C493	CHIP CERAMIC SL J 33PF/50V	CHD1J8SL330
C494	CHIP CERAMIC SL J 150PF/50V	CHD1J8SL151
C495	CHIP CERAMIC SL J 47PF/50V	CHD1J8SL470
C496	CHIP CERAMIC SL J 470PF/50V	CHD1J8SL471
C497	CHIP CERAMIC SL J 39PF/50V	CHD1J8SL390
C498	CHIP CERAMIC SL J 270PF/50V	CHD1J8SL271
C499	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80B223
	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80X223
	CHIP CERAMIC B K 0.022μF/16V	CHD1CK80X223
	CHIP CERAMIC SL D 9PF/50V or	CHD1JD8SL9R0
C500	CHIP CERAMIC SL C 9PF/50V	CHD1JC8SL9R0
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
C502	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
C503	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
	CHIP CERAMIC SL D 10PF/50V or	CHD1JD8SL100
	CHIP CERAMIC SL C 10PF/50V	CHD1JC8SL100
	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80B223
C504	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80X223
	CHIP CERAMIC B K 0.022μF/16V	CHD1CK80X223
	CHIP CERAMIC SL J 15PF/50V	CHD1J8SL150
	CHIP CERAMIC SL J 33PF/50V	CHD1J8SL330
C505	ELECTROLYTIC 10μF/16V M H7	526T106V
C506	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
C531	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
C532	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103

Ref.No.	Description	PartNo.
C533	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C534	CHIP CERAMIC SL J 18PF/50V	CHD1J8SL180
C535	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C536	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V	CHD1JK80X103
C537	ELECTROLYTIC 4.7μF/50V M H7	526W475V
C538	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
	CHIP CERAMIC B K 1000PF/25V or	CHD1EK80B102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80X102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80X102
C539	ELECTROLYTIC 1μF/50V M H7	526W105V
C540	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C541	CHIP CERAMIC SL D 10PF/50V or	CHD1JD8SL100
	CHIP CERAMIC SL C 10PF/50V	CHD1JC8SL100
C542	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
	CHIP CERAMIC B K 1000PF/25V or	CHD1EK80B102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80X102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80X102
C544	CHIP CERAMIC SL J 330PF/50V	CHD1J8SL331
C545	ELECTROLYTIC 1μF/50V M H7	526W105V
C546	CHIP CERAMIC SL D 10PF/50V or	CHD1JD8SL100
	CHIP CERAMIC SL C 10PF/50V	CHD1JC8SL100
C547	CHIP CERAMIC SL J 100PF/50V	CHD1J8SL101
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
C549	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
	ELECTROLYTIC 220μF/6.3V M H7	526R227V
C550	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V	CHD1JZ80Z223
C551	ELECTROLYTIC 22μF/6.3V M H7	526R226V
C552	ELECTROLYTIC 220μF/6.3V M H7	526R227V
FILTERS		
CF301	LEEDLESS LC TRAP FILTER 5.2MHZ	FAE525CTE001
CF302	CERAMIC FILTER 5.17MHZ	FBB515LMR001
CONNECTORS		
CL-6	CONNECTOR(B TO B)12P REC 4-175638-2	JC38T12APH0C
CL-7	CONNECTOR(B TO B)18P REC 4-175638-8	JC38T18APH0C
CL-8	CONNECTOR(B TO B)18P REC 4-175638-8	JC38T18APH0C
CL-9	CONNECTOR(B TO B)12P REC 4-175638-2	JC38T12APH0C
CL-10	CONNECTOR(B TO B)16P POST1-175643-6	JC43A16APH0C
CN-1	CONNECTOR IL-Z-10PL-SMTY	JCILD10NBH0C
CN-2	CONNECTOR IL-Z-05PL-SMTY	JCILD05NBH0C
CN-3	CONNECTOR IL-Z-03PL-SMTY	JCILD03NBH0C
DIODES		
D331	ZENER DIODE RD4.7M(B2)	ARD4R7MT1B2*

Ref.No.	Description	PartNo.
D332	CHIP DIODE DA115	ADA115T106**
D351	SCHOTTKY DIODE 1SS283	A1SS283T1***
D352	CHIP DIODE MA159	AMA159TX****
D501	CHIP DIODE MA160	AMA160TX****
D531	CHIP DIODE DA115	ADA115T106**
D532	CHIP DIODE MA141WK	AMA141WKTX**
D538	ZENER DIODE RD10M(B)	ARD10MT1B***
D539	ZENER DIODE RD10M(B)	ARD10MT1B***
D542	ZENER DIODE RD10M(B)	ARD10MT1B***
D543	ZENER DIODE RD10M(B)	ARD10MT1B***
ICS		
IC301	IC UPD6145G-101-T1	14DV731
IC302	IC CXA1201Q	GCXA1201Q***
IC331	SWITCHING REGULATOR FA7612N-TE1	GFA7612NTE10
IC351	IC CXL1502M-T1	GCXL1502MT1*
IC352	IC CXA1200BQ	GCXA1200BQ**
IC451	IC(OPERATIONNAL AMPLIFIER) BA4558F	GBA4558FT1**
IC452	IC CX20037A	GCX20037A***
IC531	IC CXA1203M-T1	GCXA1203MT1*
IC532	IC/6DB AMP MM1031XM T1	GMM1031XMR**
COILS		
L301	INDUCTOR 100UH J or	1170982T
L302	LEAD INDUCTOR 100UH J	LLAXJBVFS101
	INDUCTOR 82UH J or	1170981T
	LEAD INDUCTOR 82UH J	LLAXJBVFS820
	POWER INDUCTOR RCH-875 22UH	LLBD00PSF005
L330	POWER INDUCTOR RCH-875 10UH	LLBD00PSF004
L332	POWER INDUCTOR RCR-875D 22UH	LLBD00PSF006
L333	COIL RCH-664 or	117D806
	INDUCTOR 56UH	117B960
	COIL RCH-664 or	117D806
	INDUCTOR 56UH	117B960
L334	COIL RCH-664 or	117D806
L335	INDUCTOR 56UH	117B960
	COIL RCH-664 or	117D806
	INDUCTOR 56UH	117B960
	INDUCTOR 100UH J or	1170982T
L336	INDUCTOR 100UH J or	1170982T
L337	LEAD INDUCTOR 100UH J	LLAXJBVFS101
	INDUCTOR 100UH J or	1170982T
	LEAD INDUCTOR 100UH J	LLAXJBVFS101
	INDUCTOR 100UH J or	1170982T
L338	INDUCTOR 100UH J or	1170982T
L351	LEAD INDUCTOR 100UH J	LLAXJBVFS101
	MAGNETIC SHIELD INDUCTOR 56UH K	LLARKETTE560
	MAGNETIC SHIELD INDUCTOR 33UH K	LLARKETTE330
	INDUCTOR 39UH J or	1170977T
L352	LEAD INDUCTOR 39UH J	LLAXJBVFS390
	INDUCTOR 100UH J or	1170982T
	LEAD INDUCTOR 100UH J	LLAXJBVFS101
	CHIP INDUCTOR 100UH J or	1170742
L353	CHIP INDUCTOR 100UH J 3225 or	LLACJE8FS101
	CHIP INDUCTOR 100UH J	1170756
	INDUCTOR 10UH J or	1170970T
	LEAD INDUCTOR 10UH J	LLAXJBVFS100
L451	CHIP INDUCTOR 220UH J or	1170794
	CHIP INDUCTOR 220UH J 3225 or	LLACJE8FS221
	CHIP INDUCTOR 220UH J	1170791
	CHIP INDUCTOR 8.2UH J	5170010
L501	CHIP INDUCTOR 82UH J or	1170741
L502	CHIP INDUCTOR 82UH J 3225 or	LLACJE8FS820
	CHIP INDUCTOR 82UH J	1170755
	CHIP INDUCTOR 120UH J or	1170743
	CHIP INDUCTOR 120UH J 3225 or	LLACJE8FS121

Ref.No.	Description	PartNo.
L504	CHIP INDUCTOR 120UH J	1170757
	CHIP INDUCTOR 220UH J or	1170794
	CHIP INDUCTOR 220UH J 3225 or	LLACJE8FS221
	CHIP INDUCTOR 220UH J	1170791
L505	INDUCTOR 100UH J or	1170982T
	LEAD INDUCTOR 100UH J	LLAXJBVFS101
L506	CHIP INDUCTOR 150UH J or	1170792
	CHIP INDUCTOR 150UH J 3225 or	LLACJE8FS151
	CHIP INDUCTOR 150UH J	1170789
	CHIP INDUCTOR 100UH J or	1170742
L507	CHIP INDUCTOR 100UH J 3225 or	LLACJE8FS101
	CHIP INDUCTOR 100UH J	1170756
L508	INDUCTOR 100UH J or	1170982T
	LEAD INDUCTOR 100UH J	LLAXJBVFS101
L509	INDUCTOR 4.7UH J	1170966T
L510	INDUCTOR 470UH J or	1170990T
	LEAD INDUCTOR 470UH J	LLAXJBVFS471
L511	INDUCTOR 330UH J or	1170988T
	LEAD INDUCTOR 330UH J	LLAXJBVFS331
L512	INDUCTOR 39UH J or	1170977T
	LEAD INDUCTOR 39UH J	LLAXJBVFS390
L513	INDUCTOR 330UH J or	1170988T
	LEAD INDUCTOR 330UH J	LLAXJBVFS331
L514	INDUCTOR 180UH J or	1170985T
	LEAD INDUCTOR 180UH J	LLAXJBVFS181
L515	INDUCTOR 33UH J or	1170976T
	LEAD INDUCTOR 33UH J	LLAXJBVFS330
L516	INDUCTOR 120UH J or	1170983T
	LEAD INDUCTOR 120UH J	LLAXJBVFS121
L518	INDUCTOR 10UH J or	1170970T
	LEAD INDUCTOR 10UH J	LLAXJBVFS100
L531	INDUCTOR 100UH J or	1170982T
	LEAD INDUCTOR 100UH J	LLAXJBVFS101
L532	INDUCTOR 100UH J or	1170982T
	LEAD INDUCTOR 100UH J	LLAXJBVFS101
TRANSISTORS		
Q301	CHIP 2SC4081(R) or	QSC4081T106R
Q302	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q303	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q304	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q305	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q331	CHIP SAH02-V1	QSAH02V10000
Q351	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q352	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
Q353	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q354	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S

Ref.No.	Description	PartNo.
Q357	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
Q358	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
Q359	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q360	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q361	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q362	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q363	CHIP 2SB1132(Q) or	QB1132T101Q*
	CHIP 2SB1132(R)	QB1132T101R*
Q451	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q452	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q453	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q454	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q455	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q456	CHIP FET 2SK1332(2) or	Q2SK1332TL*
	CHIP FET 2SK1332(3) or	Q2SK1332TL*
	CHIP FET 2SK1332(4)	Q2SK1332TL*
Q457	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q458	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q459	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q460	CHIP FET 2SK94(X1) or	Q2SK94T1X1**
	CHIP FET 2SK94(X2) or	Q2SK94T1X2**
	CHIP FET 2SK94(X3) or	Q2SK94T1X3**
	CHIP FET 2SK209(BL) or	QK209BLTE85L
	CHIP FET 2SK209(GR) or	QK209GRTE85L
	CHIP FET 2SK209(Y)	QSK209YTE85L
Q501	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q502	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
Q503	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q504	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q505	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q506	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q507	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q508	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q509	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
Q510	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S

Ref.No.	Description	PartNo.
Q511	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q512	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
Q513	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q514	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q531	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q532	CHIP 2SC4098(AP) or	QC4098T106AP
	CHIP 2SC4098(AQ)	QC4098T106AQ
QR301	CHIP RES. BUILT-IN DTC124EU	QTC124EUT106
QR302	CHIP RES. BUILT-IN DTC124EU	QTC124EUT106
QR303	CHIP RES. BUILT-IN DTC124EU	QTC124EUT106
QR304	CHIP DTC144EU	QTC144EUT106
QR331	CHIP DTA144EU	QTA144EUT106
QR332	CHIP DTC144EU	QTC144EUT106
QR351	CHIP DTC144EU	QTC144EUT106
QR352	CHIP DTC144EU	QTC144EUT106
QR353	CHIP DTC144EU	QTC144EUT106
QR451	CHIP DTC144EU	QTC144EUT106
QR501	CHIP DTC144EU	QTC144EUT106
QR502	CHIP DTA144EU	QTA144EUT106
QR531	CHIP DTA144EU	QTA144EUT106
QR532	CHIP DTA144EU	QTA144EUT106
QR533	CHIP DTC144EU	QTC144EUT106
QR534	CHIP DTC144EU	QTC144EUT106
QR535	CHIP IMH2	QIMH2T110***
RESISTORS		
R301	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R302	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R303	CHIP 1/16W J 4.3KΩ	RCXGJR8Z0432
R304	CHIP 1/16W J 2.4KΩ	RCXGJR8Z0242
R305	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R306	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R307	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R308	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R309	CHIP 1/16W J 3.6KΩ	RCXGJR8Z0362
R310	CHIP 1/16W J 270Ω	RCXGJR8Z0271
R311	CHIP 1/16W J 240Ω	RCXGJR8Z0241
R312	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R313	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R314	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R315	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R316	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R317	CHIP 1/10W J 47Ω	134F470C
R318	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R319	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R320	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R321	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R322	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R323	CHIP 1/16W F 100KΩ	RCXGFR8Z0104
R326	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R327	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R328	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R329	CHIP 1/10W J 560Ω	134F561C
R330	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R331	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R332	CHIP 1/16W J 1KΩ	RCXGJR8Z0102

Ref.No.	Description	PartNo.
R333	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R334	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R335	CHIP 1/16W J 16KΩ	RCXGJR8Z0163
R336	CHIP 1/16W J 180KΩ	RCXGJR8Z0184
R337	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R338	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R339	CHIP 1/16W J 220Ω	RCXGJR8Z0221
R345	CHIP 1/16W J 330Ω	RCXGJR8Z0331
R346	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R347	CHIP 1/16W J 150Ω	RCXGJR8Z0151
R348	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R349	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R350	CHIP 1/16W J 120Ω	RCXGJR8Z0121
R351	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R352	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R353	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R354	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R355	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R356	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R357	CHIP 1/16W J 15KΩ	RCXGJR8Z0153
R358	CHIP 1/16W J 680KΩ	RCXGJR8Z0684
R359	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R360	CHIP 1/16W G 3.3KΩ	RCXGGR8Z0332
R361	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R362	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R363	CHIP 1/16W J 120Ω	RCXGJR8Z0121
R364	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R365	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R366	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R367	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R368	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R369	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R370	CHIP 1/16W G 1KΩ	RCXGGR8Z0102
R371	CHIP 1/16W G 470Ω	RCXGGR8Z0471
R372	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R373	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R374	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R375	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R376	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R377	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R378	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R379	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R380	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R381	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R382	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R383	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R384	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R385	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R386	CHIP 1/16W J 820Ω	RCXGJR8Z0821
R387	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R388	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R389	CHIP 1/16W J 470KΩ	RCXGJR8Z0474
R390	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R391	CHIP 1/16W J 2.4KΩ	RCXGJR8Z0242
R392	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R393	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R394	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R395	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R396	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R397	CHIP 1/16W J 10KΩ	RCXGJR8Z0103

Ref.No.	Description	PartNo.
R398	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R399	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R400	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R401	CHIP 1/16W J 68Ω	RCXGJR8Z0680
R402	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R405	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R406	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R407	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R408	CHIP 1/16W J 820Ω	RCXGJR8Z0821
R409	CHIP 1/16W J 820Ω	RCXGJR8Z0821
R410	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R411	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R412	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R413	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R414	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R416	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R417	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R418	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R419	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R420	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R421	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R422	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R423	CHIP 1/16W J 220KΩ	RCXGJR8Z0224
R425	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R426	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R427	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R428	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R429	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R430	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R431	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R432	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R433	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R434	CHIP 1/16W J 12KΩ	RCXGJR8Z0123
R435	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R436	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R437	CHIP 1/16W J 270Ω	RCXGJR8Z0271
R438	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R439	CHIP 1/16W J 120Ω	RCXGJR8Z0121
R440	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R441	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R442	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R443	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R444	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R445	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R446	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R447	CHIP 1/16W F 820Ω	RCXGFR8Z0821
R448	CHIP 1/16W G 820Ω	RCXGGR8Z0821
R449	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R450	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R451	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R452	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R453	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R454	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R455	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R456	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R457	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R458	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R459	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R460	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R461	CHIP 1/16W J 15KΩ	RCXGJR8Z0153

Ref.No.	Description	PartNo.
R462	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R463	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R464	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R465	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R466	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R467	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R468	CHIP 1/16W J 15KΩ	RCXGJR8Z0153
R469	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R470	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R471	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R474	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R475	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R476	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R477	CHIP 1/16W J 220Ω	RCXGJR8Z0221
R478	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R479	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R481	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R482	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R483	CHIP 1/16W J 4.3KΩ	RCXGJR8Z0432
R484	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R485	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R486	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R487	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R488	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R489	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R490	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R491	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R492	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R493	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R494	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R495	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R496	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R497	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R498	CHIP 1/16W J 820Ω	RCXGJR8Z0821
R499	CHIP 1/16W J 330Ω	RCXGJR8Z0331
R500	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R501	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R502	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R503	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R504	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R505	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R506	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R507	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R508	CHIP 1/16W J 820Ω	RCXGJR8Z0821
R509	CHIP 1/16W J 68Ω	RCXGJR8Z0680
R510	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R511	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R512	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R513	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R514	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R515	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R516	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R517	CHIP 1/16W J 150Ω	RCXGJR8Z0151
R518	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R519	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R520	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R524	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R525	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R526	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R527	CHIP 1/16W J 22KΩ	RCXGJR8Z0223

Ref.No.	Description	PartNo.
R528	CHIP 1/16W J 24KΩ	RCXGJR8Z0243
R531	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R532	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R533	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R534	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R535	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R536	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R538	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R539	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R540	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R541	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R542	CHIP 1/16W F 100KΩ	RCXGFR8Z0104
R543	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R544	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R545	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R546	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R547	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R548	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R549	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R550	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R551	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R553	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R554	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R556	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R557	CHIP 1/10W J 75Ω	134F750C
R562	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R563	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R570	CHIP 1/16W J 150KΩ	RCXGJR8Z0154
FILTERS		
T351	CHIP FILTER 5.898MHZ TRAP or CHIP FILTER 2568-036	FAZ585CMM001 FAE585CSF001
T352	CHIP FILTER 4.43MHZ BPF or CHIP FILTER 2568-037	FAB445CMM001 FAB445CSF001
T451	CHIP FILTER 1.5MHZ BPF or CHIP FILTER 2570-022	FAB155CMM001 FAB155CSF002
T531	CHIP FILTER 4.43MHZ BPF(JOG) or CHIP FILTER 2570-041	FAB445CMM002 FAB445CSF003
VOLUMES		
VR301	CHIP P.O.T. 50KΩ B X	238N269C
VR331	CHIP P.O.T. 1KΩ B X	238N264C
VR332	CHIP P.O.T. 10KΩ B X	238N267C
VR333	CHIP P.O.T. 10KΩ B X	238N267C
VR351	CHIP P.O.T. 10KΩ B X	238N267C
VR352	CHIP P.O.T. 50KΩ B X	238N269C
VR353	CHIP P.O.T. 2KΩ B X	238N265C
VR354	CHIP P.O.T. 2KΩ B X	238N265C
VR355	CHIP P.O.T. 5KΩ B X	238N266C
VR356	CHIP P.O.T. 2KΩ B X	238N265C
VR451	CHIP P.O.T. 2KΩ B X	238N265C
VR452	CHIP P.O.T. 10KΩ B X	238N267C
VR453	CHIP P.O.T. 20KΩ B X	238N268C
VR501	CHIP P.O.T. 2KΩ B X	238N265C
VR502	CHIP P.O.T. 500Ω B X	238N263C
VR525	CHIP P.O.T. 10KΩ B X	238N267C
VR526	CHIP P.O.T. 500KΩ B X	238N272C
VR527	CHIP P.O.T. 10KΩ B X	238N267C
VR528	CHIP P.O.T. 200KΩ B X	238N271C
VR529	CHIP P.O.T. 10KΩ B X	238N267C
VR531	CHIP P.O.T. 10KΩ B X	238N267C
VR532	CHIP P.O.T. 5KΩ B X	238N266C

Ref.No.	Description	PartNo.
MISCELLANEOUS		
CP332	IC PROTECTOR ICP-F25	179F842
JK531	AV JACK CMS5008-0401	1700662
TP301	CHECKER CHIP 2.0-1.25	170A354C
TP302	CHECKER CHIP 2.0-1.25	170A354C
TP331	CHECKER CHIP 2.0-1.25	170A354C
TP332	CHECKER CHIP RCU00000C	XU0C000AL001
TP333	CHECKER CHIP 2.0-1.25	170A354C
TP351	CHECKER CHIP 2.0-1.25	170A354C
TP352	CHECKER CHIP 2.0-1.25	170A354C
TP353	CHECKER CHIP 2.0-1.25	170A354C
TP354	CHECKER CHIP 2.0-1.25	170A354C
TP355	CHECKER CHIP 2.0-1.25	170A354C
TP356	CHECKER CHIP 2.0-1.25	170A354C
TP357	CHECKER CHIP 2.0-1.25	170A354C
TP451	CHECKER CHIP 2.0-1.25	170A354C
TP501	CHECKER CHIP 2.0-1.25	170A354C
TP502	CHECKER CHIP 2.0-1.25	170A354C
TP503	CHECKER CHIP 2.0-1.25	170A354C
TP504	CHECKER CHIP 2.0-1.25	170A354C
TP505	CHECKER CHIP 2.0-1.25	170A354C
TP506	CHECKER CHIP 2.0-1.25	170A354C
TP525	CHECKER CHIP 2.0-1.25	170A354C
TP526	CHECKER CHIP 2.0-1.25	170A354C
TP527	CHECKER CHIP 2.0-1.25	170A354C
TP531	CHECKER CHIP 2.0-1.25	170A354C
X351	X'TAL 4.43MHZ	FXB445LDS001
△	P.C.B.	BC1580G02001

DRV PCB ASSEMBLY 0VSA04345
Consists of the following:

Ref.No.	Description	PartNo.
DRV-1 PCB ASSEMBLY		
FFC2	FFC WIRE 14P FFC 2:DRIVER 1	WX3914SZ3404
FFC3	FFC WIRE 12P FFC 3:DRIVER 2	WX3912SZ3404
FFC6	FFC WIRE 8P FFC 6:CAMERA CONT	WX3908SZ3410
△	P.C.B. C1580/DRIVER	BC1580G02009
DRV-1 PCB ASS'Y		
CONNECTORS		
CN-18	CONNECTOR(B TO B) 8P POST 6-175642-8	JC42A08APH0C
CN-19	CONNECTOR(B TO B)12P POST 7-175643-2	JC43A12APH0C
DIODES		
D901	LED(ORANGE)LT1S53A	ELT1S53A0000
D902	LED LT1E53A	ELT1E53A0000
D903	CHIP DIODE DAN202U	ADAN202UT106
D906	CHIP DIODE DAN202U	ADAN202UT106
D907	CHIP DIODE DA115	ADA115T106**
D908	CHIP DIODE DAN202U	ADAN202UT106
D909	CHIP DIODE DAN202U	ADAN202UT106
D913	CHIP DIODE DA115	ADA115T106**
R901	CHIP 1/10W J 330Ω	134F331C
R902	CHIP 1/10W J 330Ω	134F331C
SWITCHES		
SW901	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008

Ref.No.	Description	PartNo.
SW902	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW903	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW904	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW905	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW906	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW907	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW908	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW909	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW910	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW911	PUSH SWITCH EVQ-QHL 01W or PUSH SWITCH SKHUPA	SST0101MS006 SST0101AL008
SW913	SLIDE SWITCH ESD165206	SSS0102MS008
SW914	PUSH SWITCH SKHUPH	SST0101AL007
SW915	PUSH SWITCH SKHUPH	SST0101AL007
SW916	SLIDE SWITCH SSSS71	SSS0102AL007
SW917	SLIDE SWITCH SSSS71	SSS0102AL007

DRV-2 PCB ASS'Y

CAPACITORS		
C851	CHIP ELECTROLYTIC 33μF/16V M	122Z225
C852	CHIP ELECTROLYTIC 33μF/16V M	122Z225
C853	CHIP ELECTROLYTIC 33μF/16V M	122Z225
C854	CHIP CERAMIC B K 0.001μF/50V	12B3102C
C855	CHIP CERAMIC B K 0.01μF/50V	12B3103C
C856	TANTAL 100μF/10V M	1224107
C857	CHIP ELECTROLYTIC 100μF/10V M	122Z786C
C859	CHIP CERAMIC B K 0.0047μF/50V	12B3472C
C860	CHIP ELECTROLYTIC (NP) 10μF/10V M	122Z779C
C861	CHIP CERAMIC B K 0.1μF/25V or CHIP CERAMIC B K 0.1μF/50V	72B2104C 72B3104C
C862	CHIP CERAMIC F Z 1μF/16V	72F6105C
C863	CHIP CERAMIC B K 0.0039μF/50V	12B3392C
C864	CHIP ELECTROLYTIC 47μF/6.3V M	121R476C
C865	CHIP TANTAL 2.2μF/10V M or CHIP TANTAL 2.2μF/10V M	1224225C CA1A225KC003
C866	CHIP TANTAL 3.3μF/10V M or CHIP TANTAL 3.3μF/10V M	1224335C CA1A335KC003
C867	CHIP ELECTROLYTIC 220μF/6.3V	CA0K221NC001
C868	CHIP ELECTROLYTIC 22μF/6.3V M	121R226C
C869	CHIP ELECTROLYTIC 10μF/16V M	122Z223
C870	CHIP ELECTROLYTIC 10μF/16V M	122Z223
C871	CHIP ELECTROLYTIC 10μF/16V M	122Z223
C872	CHIP TANTAL 1μF/16V M or CHIP TANTAL 1μF/16V M	1225105C CA1C105KC003
C873	CHIP TANTAL 3.3μF/10V M or CHIP TANTAL 3.3μF/10V M	1224335C CA1A335KC003
C874	CHIP CERAMIC F Z 1μF/16V	72F6105C
C875	CHIP CERAMIC SL J 820PF/50V	1270821C
C876	CHIP CERAMIC B K 0.022μF/50V	12B3223C
C877	CHIP TANTAL 1μF/16V M or CHIP TANTAL 1μF/16V M	1225105C CA1C105KC003

Ref.No.	Description	PartNo.
C82	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80B102
	CHIP CERAMIC SL J 82PF/50V	CHD1JJ8SL820
	OS 6.8μF/16V OS	CA1C6R8SY001
C85	OS 6.8μF/16V OS	CA1C6R8SY001
C86	OS 6.8μF/16V OS	526T476V
C87	ELECTROLYTIC 47μF/16V M H7	CHD1JK80X152
C88	CHIP CERAMIC B K 1500PF/50V	CHD1JJ8SL151
C89	CHIP CERAMIC SL J 150PF/50V	CHD1JK80X332
C90	CHIP CERAMIC B K 3300PF/50V or	CHD1EK80X332
	CHIP CERAMIC B K 3300PF/25V or	CHD1JK80B332
	CHIP CERAMIC B K 3300PF/25V	CHD1EK80B332
C91	CHIP CERAMIC F Z 0.22μF/25V	12F2224C
C92	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80Z103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80F103
C93	CHIP CERAMIC SL J 220PF/50V	CHD1JJ8SL221
C94	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80X102
	CHIP CERAMIC B K 1000PF/25V or	CHD1EK80X102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80B102
C95	ELECTROLYTIC 33μF/25V M H7	526U336V
C96	ELECTROLYTIC 33μF/25V M H7	526U336V
C97	OS 6.8μF/16V OS	CA1C6R8SY001
C98	ELECTROLYTIC 47μF/16V M H7	526T476V
C99	ELECTROLYTIC 33μF/25V M H7	526U336V
C100	ELECTROLYTIC 33μF/25V M H7	526U336V
CONNECTORS		
CL-29	CONNECTOR, 14P 52022-1410	1700636
CL-30	CONNECTOR, 14P 52022-1410	1700636
CN-32	FPC CONNECTOR, 10P IL-402-10S-S1L-SA	JC42T10NBH0B
DIODES		
D01	CHIP DIODE MA141K	AMA141KTX***
D02	CHIP DIODE MA141K	AMA141KTX***
D04	CHIP DIODE MA141K	AMA141KTX***
D05	CHIP DIODE MA141K	AMA141KTX***
D08	CHIP DIODE MA141K	AMA141KTX***
D09	CHIP DIODE MA141K	AMA141KTX***
D51	CHIP DIODE MA141K	AMA141KTX***
D52	CHIP DIODE MA141K	AMA141KTX***
D53	SCHOTTKY DIODE SB007-03CP	ASB00703CPTB
D54	CHIP DIODE MA141K	AMA141KTX***
RESISTORS		
EF02	CHIP 1/10W J 0Ω	134F000C
EF03	CHIP 1/10W J 0Ω	134F000C
EF04	CHIP 1/10W J 0Ω	134F000C
ICS		
IC01	IC MM1036XFF(T1)	GMM1036XFFT1
IC02	IC UPC358G2(T1) or	GUPC358G2T1*
	IC BA10358F-T1 or	GBA10358FT1*
	IC NJM2904M(T1)	GNJM2904MT1*
IC03	IC LZ95D34	GLZ95D340000
IC05	IC AN2012S-(T1)	GAN2012ST100
IC06	IC MN3110SA-E2	GMN3110SAE20
IC51	IC UPC1100G-T1	14LV359
COILS		
L02	LEAD INDUCTOR 15UH K or	LLAXKBVFS150
	INDUCTOR 15UH J	1170972T

Ref.No.	Description	PartNo.
L03	LEAD INDUCTOR 15UH K or	LLAXKBVFS150
	INDUCTOR 15UH J	1170972T
L04	LEAD INDUCTOR 15UH K or	LLAXKBVFS150
	INDUCTOR 15UH J	1170972T
L05	LEAD INDUCTOR 15UH K or	LLAXKBVFS150
	INDUCTOR 15UH J	1170972T
L06	LEAD INDUCTOR 220UH K or	LLAXKBVFS221
	INDUCTOR 220UH J	1170986T
L07	LEAD INDUCTOR 15UH K or	LLAXKBVFS150
	INDUCTOR 15UH J	1170972T
L08	LEAD INDUCTOR 15UH K or	LLAXKBVFS150
	INDUCTOR 15UH J	1170972T
L11	CHIP INDUCTOR 15UH K or	1170718
	CHIP INDUCTOR 15UH K or	1170624
	CHIP INDUCTOR 15UH K or	117N599
	CHIP INDUCTOR 15UH K 3225 or	LLACKE8FS150
	CHIP INDUCTOR 15UH J	1170732
L12	CHIP INDUCTOR 15UH K or	1170718
	CHIP INDUCTOR 15UH K or	1170624
	CHIP INDUCTOR 15UH K or	117N599
	CHIP INDUCTOR 15UH K 3225 or	LLACKE8FS150
	CHIP INDUCTOR 15UH J	1170732
L13	LEAD INDUCTOR 100UH K or	LLAXKBVFS101
	INDUCTOR 100UH J	1170982T
L14	LEAD INDUCTOR 15UH K or	LLAXKBVFS150
	INDUCTOR 15UH J	1170972T
L15	LEAD INDUCTOR 33UH J or	LLAXJBVFS330
	INDUCTOR 33UH J	1170976T
L51	INDUCTOR 47UH or	117D583
	INDUCTOR 47UH	117B681
L52	MOLD POWER INDUCTOR 33UH M	LLBD00PSF008
L53	INDUCTOR 47UH or	117D583
	INDUCTOR 47UH	117B681
L54	LEAD INDUCTOR 270UH K or	LLAXKBVFS271
	INDUCTOR 270UH J	1170987T
L55	INDUCTOR 47UH or	117D583
	INDUCTOR 47UH	117B681
L56	LEAD INDUCTOR 270UH K or	LLAXKBVFS271
	INDUCTOR 270UH J	1170987T
TRANSISTORS		
Q01	CHIP FET 2SK621	Q2SK621TX***
Q02	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q03	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q15	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q51	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q52	CHIP 2SB1073Q-TX or	Q2SB1073QTX0
	CHIP 2SB1073P-TX or	Q2SB1073PTX0
	CHIP 2SB1386T101P or	QSB1386T101P
	CHIP 2SB1386T101Q	QSB1386T101Q
Q53	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
QD51	CHIP SAH02-V1	QSAH02V10000
RESISTORS		
R01	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R02	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R03	CHIP 1/16W J 39KΩ	RCXGJR8Z0393

Ref.No.	Description	PartNo.
R04	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R05	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R10	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R11	CHIP 1/16W J 390Ω	RCXGJR8Z0391
R12	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R13	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R14	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R16	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R17	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R24	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R25	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R26	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R28	CHIP 1/16W J 330Ω	RCXGJR8Z0331
R29	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R30	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R32	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R33	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R39	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R40	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R41	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R42	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R43	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R44	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R45	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R46	CHIP 1/16W J 4.7Ω	RCXGJR8Z04R7
R47	CHIP 1/16W J 4.7Ω	RCXGJR8Z04R7
R48	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R49	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R50	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R52	CHIP 1/16W J 4.7Ω	RCXGJR8Z04R7
R53	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R54	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R57	CHIP 1/16W J 4.7Ω	RCXGJR8Z04R7
R58	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R59	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R63	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R64	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R65	CHIP 1/16W J 2KΩ	RCXGJR8Z0202
R66	CHIP 1/16W J 43KΩ	RCXGJR8Z0433
R70	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R71	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R72	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R73	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R76	CHIP 1/16W G 22KΩ	RCXGJR8Z0223
R77	CHIP 1/16W G 6.2KΩ	RCXGJR8Z0622
R78	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R80	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R82	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R83	CHIP 1/8W J 680Ω	134H681C
R84	CHIP 1/8W J 680Ω	134H681C
R85	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R86	CHIP 1/16W J 7.5KΩ	RCXGJR8Z0752
R88	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R89	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R90	CHIP 1/16W J 82KΩ	RCXGJR8Z0823
R91	CHIP 1/16W G 20KΩ	RCXGJR8Z0203
R92	CHIP 1/16W G 3KΩ	RCXGJR8Z0302
R93	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R94	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R95	CHIP 1/10W J 39Ω	134F390C

Ref.No.	Description	PartNo.
R96	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R97	CHIP 1/8W J 470Ω	134H471C
R98	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R99	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R100	CHIP 1/16W J 0Ω	RCXGJR8Z0000
MISCELLANEOUS		
T51	DC-DC CONV TRANS 0313-084	LTA00ZPSF002
TC01	CHIP TRIMMER 30PF or	CVC3000T1004
	CHIP TRIMMER 30PF	1280175C
TP01	CHECKER CHIP RCU00000C	XU0C000AL001
TP02	CHECKER CHIP RCU00000C	XU0C000AL001
TP03	CHECKER CHIP RCU00000C	XU0C000AL001
TP04	CHECKER CHIP RCU00000C	XU0C000AL001
TP05	CHECKER CHIP RCU00000C	XU0C000AL001
TP51	CHECKER CHIP RCU00000C	XU0C000AL001
TP52	CHECKER CHIP RCU00000C	XU0C000AL001
TP53	CHECKER CHIP RCU00000C	XU0C000AL001
VR01	CHIP P.O.T. 2KΩ B X	238N265C
VR02	CHIP P.O.T. 2KΩ B X	238N265C
VR03	CHIP P.O.T. 10KΩ B X	238N267C
VR04	CHIP P.O.T. 50KΩ B X	238N269C
VR51	CHIP P.O.T. 2KΩ B X	238N265C
VR53	CHIP P.O.T. 500Ω B X	238N263C
X01	X'TAL 19MHZ	FXC196LCT001
CMV-B PCB ASSEMBLY		
CAPACITORS		
C101	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80F223
C103	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C107	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80Z473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80Z473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80F473
	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80F473
	CHIP CERAMIC F Z 0.047μF/50V	CHD1JZ80F473
C108	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80Z473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80Z473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80F473
	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80F473
	CHIP CERAMIC F Z 0.047μF/50V	CHD1JZ80F473
C109	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80F223
C110	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C111	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C112	OS 15μF/6.3V OS	CA0K150SY001
C115	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80Z473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80Z473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80F473
	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80F473

Ref.No.	Description	PartNo.
C229	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
C230	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
C231	CHIP CERAMIC F Z 0.01μF/50V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
C232	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
C233	ELECTROLYTIC 4.7μF/25V M	121U475V
C234	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C241	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1EZ80F223
C242	ELECTROLYTIC 47μF/6.3V M	121R476V
C243	ELECTROLYTIC 47μF/6.3V M	121R476V
C244	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80X103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
C246	CHIP CERAMIC B K 0.01μF/25V	CHD1EK80B103
	CHIP CERAMIC SL J 390PF/50V	CHD1JJ8SL391
C248	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
C249	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80F223
	ELECTROLYTIC 33μF/6.3V M	121R336V
C250	CHIP CERAMIC CG J 15PF/50V or	CHD1JJ8CG150
	CHIP CERAMIC CH J 15PF/50V	CHD1JJ8CH150
C252	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
C255	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
C256	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80F223
	ELECTROLYTIC 47μF/6.3V M	121R476V
CONNECTORS		
CN-10	CONNECTOR(B TO B)16P REC 4-175639-6	JC39T16APH0C
CN-29	B TO B CONNECTOR, 14P 53148-1420	1770430
CN-30	B TO B CONNECTOR, 14P 53148-1420	1770430
CN-31	FPC CONNECTOR, 8P IL-402R- 8S-S1L-SA	JC4RT08NBH0B
DIODES		
D101	CHIP DIODE MA141K	AMA141KTX***
D102	CHIP DIODE MA141K	AMA141KTX***
D103	CHIP DIODE MA141K	AMA141KTX***
D104	CHIP DIODE DA204U	ADA204UT106*
D105	CHIP DIODE MA141K	AMA141KTX***
D106	VARACTOR 1SV202	A1SV20217TRC

Ref.No.	Description	PartNo.
ICS		
IC201	IC AN2165FHP	GAN2165FHP00
IC202	IC(COMPARETER) BA10393F(T1)	GBA10393FT1*
IC203	IC TC4W66FTE12L	GC4W66FTE12L
IC204	IC BA10324FT1	GBA10324FT10
IC205	IC AN2365S-(T1)	GAN2365ST100
IC206	IC MN3820S-T1	14DN526
IC207	IC AN2457SB-(E1)	GAN2457SBE10
IC208	IC MSM6819MS-KR4	GSM6819MSKR4
IC209	IC MN73033XRA	GMN73033XRA0
COILS		
L103	CHIP INDUCTOR 15UH K or	1170718
	CHIP INDUCTOR 15UH K or	1170624
	CHIP INDUCTOR 15UH K or	117N599
L105	CHIP INDUCTOR 15UH K or	LLACKE8FS150
	CHIP INDUCTOR 15UH J	1170732
	CHIP INDUCTOR 33UH K or	1170722
L109	CHIP INDUCTOR 33UH K or	1170628
	CHIP INDUCTOR 33UH K or	117N603
	CHIP INDUCTOR 33UH K 3225 or	LLACKE8FS330
L111	CHIP INDUCTOR 100UH J or	1170736
	CHIP INDUCTOR 100UH K or	1170728
	CHIP INDUCTOR 100UH K or	1170633
L115	CHIP INDUCTOR 100UH K or	117N608
	CHIP INDUCTOR 100UH K 3225 or	LLACKE8FS101
	CHIP INDUCTOR 100UH J	1170742
L117	CHIP INDUCTOR 15UH K or	1170718
	CHIP INDUCTOR 15UH K or	1170624
	CHIP INDUCTOR 15UH K or	117N599
L119	CHIP INDUCTOR 15UH K or	LLACKE8FS150
	CHIP INDUCTOR 15UH K or	1170732
	CHIP INDUCTOR 15UH J	1170718
L121	CHIP INDUCTOR 15UH K or	1170624
	CHIP INDUCTOR 15UH K or	117N599
	CHIP INDUCTOR 15UH K 3225 or	LLACKE8FS150
L123	CHIP INDUCTOR 15UH J	1170732
	CHIP INDUCTOR 15UH K or	1170718
	CHIP INDUCTOR 15UH K or	1170624
L124	CHIP INDUCTOR 15UH K or	117N599
	CHIP INDUCTOR 15UH K 3225 or	LLACKE8FS150
	CHIP INDUCTOR 15UH J	1170732
L125	CHIP INDUCTOR 68UH J or	1170740
	CHIP INDUCTOR 68UH J or	1170754
	CHIP INDUCTOR 68UH J or	117N709

Ref.No.	Description	PartNo.
L127	CHIP INDUCTOR 15UH K or	1170624
	CHIP INDUCTOR 15UH K or	117N599
	CHIP INDUCTOR 15UH K 3225 or	LLACKE8FS150
L131	CHIP INDUCTOR 15UH J	1170732
	CHIP INDUCTOR 15UH K or	1170718
	CHIP INDUCTOR 15UH K or	1170624
FILTERS		
LC101	FILTER, TRAP NLT4532T-S4R8A	1813384
LC102	TLAP FILTER 9.6MHZ NLT4532-S9R7	FAE965CTE001
TRANSISTORS		
Q101	CHIP 2SC4081(R) or	QSC4081T106R
Q102	CHIP 2SC4081(S)	QSC4081T106S
Q103	CHIP 2SA1576(R) or	QSA1576T106R
Q107	CHIP 2SA1576(S)	QSA1576T106S
Q108	CHIP 2SA1576(R) or	QSA1576T106R
Q109	CHIP 2SA1576(S)	QSA1576T106S
Q114	CHIP 2SC4081(R) or	QSC4081T106R
Q115	CHIP 2SC4081(S)	QSC4081T106S
Q116	CHIP 2SC4081(R) or	QSC4081T106R
Q117	CHIP 2SC4081(S)	QSC4081T106S
Q118	CHIP 2SC4081(R) or	QSC4081T106R
Q120	CHIP 2SC4081(S)	QSC4081T106S
Q122	CHIP 2SC3929(R) or	Q2SC3929RTX*
Q123	CHIP 2SC3929(S) or	Q2SC3929STX*
Q124	CHIP 2SC3929(T)	Q2SC3929TTX*
Q126	CHIP 2SA1576(R) or	QSA1576T106R
Q131	CHIP 2SA1576(S)	QSA1576T106S
Q132	CHIP 2SA1576(R) or	QSA1576T106R
Q133	CHIP 2SA1576(S)	QSA1576T106S
Q134	CHIP 2SA1576(R) or	QSA1576T106R

Ref.No.	Description	PartNo.
Q139	CHIP 2SA1576(R) or	QSA1576T106R
Q140	CHIP 2SA1576(S)	QSA1576T106S
Q143	CHIP FET 2SK94(X1) or	Q2SK94T1X1**
	CHIP FET 2SK94(X2)	Q2SK94T1X2**
RESISTORS		
QR101	CHIP RES. BUILT-IN DTA124EU	QTA124EUT106
R102	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R103	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R104	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R105	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R106	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R107	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R108	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R110	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R111	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R112	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R113	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R114	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R115	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R116	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R117	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R118	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R119	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R120	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R121	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R122	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R123	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R124	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R125	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R126	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R131	CHIP 1/16W J 62KΩ	RCXGJR8Z0623
R134	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R137	CHIP 1/16W J 270KΩ	RCXGJR8Z0274
R138	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R139	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R140	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R143	CHIP 1/16W J 10Ω	RCXGJR8Z0100
R144	CHIP 1/16W J 12KΩ	RCXGJR8Z0123
R145	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R146	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R147	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R148	CHIP 1/16W J 15KΩ	RCXGJR8Z0153
R149	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R150	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R151	CHIP 1/16W J 150KΩ	RCXGJR8Z0154
R152	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R153	CHIP 1/16W J 12KΩ	RCXGJR8Z0123
R154	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R155	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R156	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R157	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R158	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R162	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R163	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R164	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R167	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R168	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R169	CHIP 1/16W J 1KΩ	RCXGJR8Z0102

Ref.No.	Description	PartNo.
R170	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R171	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R172	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R173	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R174	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R175	CHIP 1/16W J 30KΩ	RCXGJR8Z0303
R176	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R178	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R179	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R180	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R181	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R182	CHIP 1/16W J 120KΩ	RCXGJR8Z0124
R183	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R184	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R185	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R186	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R187	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R188	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R189	CHIP 1/16W J 120KΩ	RCXGJR8Z0124
R190	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R191	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R192	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R193	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R194	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R195	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R196	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R197	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R198	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R199	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R201	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R202	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R203	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R204	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R205	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R206	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R207	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R208	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R209	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R210	CHIP 1/16W J 510Ω	RCXGJR8Z0511
R211	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R212	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R213	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R215	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R216	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R217	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R218	CHIP 1/16W J 10Ω	RCXGJR8Z0100
R219	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R220	CHIP 1/16W J 24KΩ	RCXGJR8Z0243
R221	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R222	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R223	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R224	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R225	CHIP 1/16W J 330Ω	RCXGJR8Z0331
R226	CHIP 1/16W J 390Ω	RCXGJR8Z0391
R227	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R228	CHIP 1/16W J 680Ω	RCXGJR8Z0681
R229	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R230	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R232	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R233	CHIP 1/16W J 1KΩ	RCXGJR8Z0102

Ref.No.	Description	PartNo.
R234	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R235	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R236	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R237	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R238	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R241	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R242	CHIP 1/16W G 2.7KΩ	RCXGJR8Z0272
R243	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R244	CHIP 1/16W G 1.5KΩ	RCXGJR8Z0152
R245	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R246	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R247	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R248	CHIP 1/16W J 10Ω	RCXGJR8Z0100
R249	CHIP 1/16W G 5.6KΩ	RCXGJR8Z0562
R250	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R251	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R252	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R253	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R254	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R255	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R256	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R257	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R258	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R259	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R260	CHIP 1/16W J 560KΩ	RCXGJR8Z0564
R261	CHIP 1/16W J 680KΩ	RCXGJR8Z0684
R262	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R263	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R264	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R265	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R266	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R267	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R268	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R269	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R270	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R271	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R272	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R273	CHIP 1/16W J 24KΩ	RCXGJR8Z0243
R274	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R275	CHIP 1/16W J 20KΩ	RCXGJR8Z0203
R276	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R277	CHIP 1/16W J 20KΩ	RCXGJR8Z0203
R278	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R279	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R280	CHIP 1/16W J 30KΩ	RCXGJR8Z0303
R281	CHIP 1/16W J 330Ω	RCXGJR8Z0331
R282	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R283	CHIP 1/16W J 330Ω	RCXGJR8Z0331
R284	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R285	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R286	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R287	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R288	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R291	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R292	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R293	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R294	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R295	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R296	CHIP 1/16W J 5.6KΩ	RCXGJR8Z0562
R297	CHIP 1/16W J 10KΩ	RCXGJR8Z0103

Ref.No.	Description	PartNo.
R298	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R299	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
RR01	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
RR02	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
RR03	CHIP 1/16W G 22KΩ	RCXGJR8Z0223
RR04	CHIP 1/16W G 12KΩ	RCXGJR8Z0123
RR05	CHIP 1/16W G 24KΩ	RCXGJR8Z0243
RR06	CHIP 1/16W G 15KΩ	RCXGJR8Z0153
RR07	CHIP 1/16W G 560Ω	RCXGJR8Z0561
RR08	CHIP 1/16W G 36KΩ	RCXGJR8Z0363
RR09	CHIP 1/16W G 22KΩ	RCXGJR8Z0223
RR10	CHIP 1/16W J 15KΩ	RCXGJR8Z0153
RR11	CHIP 1/16W J 820Ω	RCXGJR8Z0821
RR12	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
RR13	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
FILTERS		
T101	L.P.F.(4.83MHZ) RXV-709N or L.P.F.(4.83MHZ) F-K4-RT/036083 or L.P.F.(4.83MHZ) S-061-851	FAL485CMG007 FAL485CMM006 FAL485CSF005
T102	L.P.F.(4.83MHZ) RXV-709N or L.P.F.(4.83MHZ) F-K4-RT/036083 or L.P.F.(4.83MHZ) S-061-851	FAL485CMG007 FAL485CMM006 FAL485CSF005
VOLUMES		
VR102	CHIP P.O.T. 10KΩ B X	238N267C
VR104	CHIP P.O.T. 10KΩ B X	238N267C
VR105	CHIP P.O.T. 20KΩ B X	238N268C
VR106	CHIP P.O.T. 10KΩ B X	238N267C
VR108	CHIP P.O.T. 10KΩ B X	238N267C
VR109	CHIP P.O.T. 5KΩ B X	238N266C
VR110	CHIP P.O.T. 5KΩ B X	238N266C
VR114	CHIP P.O.T. 2KΩ B X	238N265C
VR115	CHIP P.O.T. 2KΩ B X	238N265C
VR116	CHIP P.O.T. 2KΩ B X	238N265C
VR117	CHIP P.O.T. 2KΩ B X	238N265C
VR120	CHIP P.O.T. 500Ω B X	238N263C
VR129	CHIP P.O.T. 5KΩ B X	238N266C
VR132	CHIP P.O.T. 20KΩ B X	238N268C
VR133	CHIP P.O.T. 20KΩ B X	238N268C
VR135	CHIP P.O.T. 10KΩ B X	238N267C
VR138	CHIP P.O.T. 50KΩ B X	238N269C
VR140	CHIP P.O.T. 5KΩ B X	238N266C
MISCELLANEOUS		
TC101	CHIP TRIMMER 20PF or CHIP TRIMMER 20PF	CVC2000T1003 1280185C
TP102	CHECKER CHIP RCU00000C	XU0C000AL001
TP103	CHECKER CHIP RCU00000C	XU0C000AL001
TP104	CHECKER CHIP RCU00000C	XU0C000AL001
TP107	CHECKER CHIP RCU00000C	XU0C000AL001
TP108	CHECKER CHIP RCU00000C	XU0C000AL001
TP109	CHECKER CHIP RCU00000C	XU0C000AL001
TP111	CHECKER CHIP RCU00000C	XU0C000AL001
TP112	CHECKER CHIP RCU00000C	XU0C000AL001
TP113	CHECKER CHIP RCU00000C	XU0C000AL001
TP114	CHECKER CHIP RCU00000C	XU0C000AL001
TP115	CHECKER CHIP RCU00000C	XU0C000AL001
TP116	CHECKER CHIP RCU00000C	XU0C000AL001
TP117	CHECKER CHIP RCU00000C	XU0C000AL001
X101	X'TAL 17MHZ	FXC176LCT001

EVF PCB ASSEMBLY

Ref.No.	Description	PartNo.
EVF PCB ASSEMBLY CONSISTS OF THE FOLLOWING:		0VSA04005
CAPACITORS		
C801	CHIP CERAMIC F Z 0.33μF/16V	CA1C334RM001
C802	CHIP CERAMIC B K 0.0015μF/50V	12B3152C
C803	ELECTROLYTIC 100μF/6.3V M H5	121R107S
C804	CHIP CERAMIC F Z 0.022μF/25V	12F2223C
C805	CHIP CERAMIC F Z 0.33μF/16V	CA1C334RM001
C806	STACKED FILM 0.1μF/50V J	125U104S
C807	CHIP CERAMIC F Z 0.1μF/50V	12F3104C
C808	CHIP CERAMIC SL J 33PF/50V	1270330C
C809	ELECTROLYTIC 4.7μF/50V M H7	526W475S
C810	CHIP CERAMIC F Z 0.33μF/16V	CA1C334RM001
C811	ELECTROLYTIC 100μF/6.3V M	122Z638S
C812	ELECTROLYTIC 100μF/6.3V M	122Z638S
C813	ELECTROLYTIC 100μF/6.3V M	122Z638S
C814	MYLAR 3900PF/100V K or MYLAR 3900PF/100V K	CA2A392MS001 CA2A392MS002
C815	CERAMIC B K 1000PF/1KV	122Z739S
C817	CHIP CERAMIC F Z 0.047μF/25V	12F2473C
CONNECTORS		
CL-2	CONNECTOR ASS'Y 5P	WX1C1580-002
CN801	STRAIGHT PIN HEADER, 4P	1770488
D801	DIODE ERA91-02	AERA9102BPRB
IC		
IC801	EVF DEFLECTION IC BA7147F-T1	GBA7147FT100
COILS		
L801	INDUCTOR 56UH-J-5FT or INDUCTOR 56UH J	LLARJBSFS560 1170934
L803▲	RINEALITY COIL ELH-5L225N	LLBD00PMS002
L804▲	DEFLECTION YOKE ELY-06V572C	LLBY000MS001
TRANSISTORS		
Q801	CHIP 2SD1767(Q) or CHIP 2SD1767(R)	QSD1767T100Q QSD1767T100R
Q802	CHIP 2SA1037(R)	QSA1037T146R
Q803	CHIP 2SA1037(R)	QSA1037T146R
RESISTORS		
R801	CHIP 1/16W G 100KΩ	RCXGJR8Z0104
R802	CHIP 1/16W G 15KΩ	RCXGJR8Z0153
R803	CHIP 1/16W J 39KΩ	RCXGJR8Z0394
R804	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R805	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R806	CHIP 1/10W J 100Ω	134F101C
R807	CHIP 1/10W J 3.9Ω	134F399C
R808	CHIP 1/10W G 20KΩ	134G203C
R809	CHIP 1/10W J 3.3KΩ	134F332C
R810	CHIP 1/16W J 24KΩ	RCXGJR8Z0243
R811	CHIP 1/10W J 1MΩ	134F105C
R812	CHIP 1/10W J 2.2KΩ	134F222C
R813	CHIP 1/10W J 1.5MΩ	134F155C
R814	CHIP 1/10W J 1.5MΩ	134F155C
R815	CHIP 1/10W J 3.3MΩ	134F335C
R816	CHIP 1/10W J 12Ω	134F120C
R817	CHIP 1/10W J 470Ω	134F471C
R819	CHIP 1/10W J 30Ω	134F300C
R820	CHIP 1/10W J 560Ω	134F561C
R822	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R823	CHIP 1/10W J 0Ω	134F000C

Ref.No.	Description	PartNo.
MISCELLANEOUS		
T801▲	FLY-BACK TRANS ETf-08L11A	LTF11EPMS001
VR802	CHIP P.O.T. 220Ω B X	238N262C
VR803	POTENTIOMETEREVN49CA00B26	VZMB205MS001
VR804	POTENTIOMETEREVN49CA00B55	VZMB504MS001
▲	CRT M01KQM07WB or	TCRT190MS006
▲	CRT SOCKET CVT2906B040101 or	WX1C1560-001
	P.C.B. EVF(C1580EA)	BC1580F01004
	C1580EA	0VM300880
	C1580EA	0VM300881
	C1580EA	0VM402703

SCV PCB ASSEMBLY

Ref.No.	Description	PartNo.
	SCV PCB ASS'Y CONSISTS OF THE FOLLOWING:	OVSA03984
CAPACITORS		
C572	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C574	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C575	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C580	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C581	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C582	ELECTROLYTIC 47μF/16V M	121T476V
C583	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C584	ELECTROLYTIC 2.2μF/50V M NP	122Z201
C590	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C591	CHIP CERAMIC F Z 0.022μF/25V	12F2224C
C592	ELECTROLYTIC 10μF/10V H=5 NP	122Z766
C601	CHIP CERAMIC SL J 22PF/50V	CHD1JJ8SL220
C602	CHIP CERAMIC SL J 22PF/50V	CHD1JJ8SL220
C603	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C604	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C605	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80Z223
C606	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C607	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104

Ref.No.	Description	PartNo.
C608	CHIP CERAMIC CH J 27PF/50V or	CHD1JJ8CH270
	CHIP CERAMIC CG J 27PF/50V	CHD1JJ8CG270
C609	CHIP CERAMIC CH J 22PF/50V or	CHD1JJ8CH220
	CHIP CERAMIC CG J 22PF/50V	CHD1JJ8CG220
C671	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C672	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
	CHIP CERAMIC B K 1000PF/25V or	CHD1EK80B102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80X102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80X102
C673	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C674	ELECTROLYTIC 220μF/6.3V M H7	526R227V
C675	CHIP CERAMIC B K 0.047μF/50V or	12B3473C
	CHIP CERAMIC B K 0.047μF/25V	12B2473C
C676	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C677	CHIP CERAMIC B K 0.22μF/50V or	72B3224C
	CHIP CERAMIC B K 0.22μF/25V	72B2224C
C678	ELECTROLYTIC 10μF/10V H=5 NP	122Z766
C679	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C680	CHIP CERAMIC B K 0.1μF/50V or	12B3104C
	CHIP CERAMIC B K 0.1μF/25V	12B2104C
C681	CHIP CERAMIC CH J 68PF/50V or	CHD1JJ8CH680
	CHIP CERAMIC CG J 68PF/50V	CHD1JJ8CG680
C682	CHIP CERAMIC CH J 33PF/50V or	CHD1JJ8CH330
	CHIP CERAMIC CG J 33PF/50V	CHD1JJ8CG330
C683	CHIP CERAMIC CH J 68PF/50V or	CHD1JJ8CH680
	CHIP CERAMIC CG J 68PF/50V	CHD1JJ8CG680
C684	ELECTROLYTIC 220μF/6.3V M H7	526R227V
C685	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C686	MYLAR 0.0027μF/50V J	122Z784
C687	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C688	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C701	ELECTROLYTIC 10μF/16V M	121T106V
C702	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C703	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C704	CHIP TANTAL 4.7μF/6.3V M or	1223475C
	CHIP TANTAL 4.7μF/6.3V M	CA0K475KC003
C705	CHIP TANTAL 4.7μF/6.3V M or	1223475C
	CHIP TANTAL 4.7μF/6.3V M	CA0K475KC003

Ref.No.	Description	PartNo.
C706	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C707	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C708	CHIP CERAMIC SL J 470PF/50V	CHD1JJ8SL471
C709	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C710	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C711	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80B222
	CHIP CERAMIC B K 2200PF/25V or	CHD1EK80B222
	CHIP CERAMIC B K 2200PF/50V or	CHD1JK80X222
	CHIP CERAMIC B K 2200PF/25V	CHD1EK80X222
C712	CHIP CERAMIC SL J 220PF/50V	CHD1JJ8SL221
C713	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C714	CHIP CERAMIC B K 4700PF/50V or	CHD1JK80B472
	CHIP CERAMIC B K 4700PF/25V or	CHD1EK80B472
	CHIP CERAMIC B K 4700PF/50V or	CHD1JK80X472
	CHIP CERAMIC B K 4700PF/25V	CHD1EK80X472
C715	CHIP CERAMIC B K 3300PF/50V or	CHD1JK80B332
	CHIP CERAMIC B K 3300PF/25V or	CHD1EK80B332
	CHIP CERAMIC B K 3300PF/50V or	CHD1JK80X332
	CHIP CERAMIC B K 3300PF/25V	CHD1EK80X332
C716	CHIP CERAMIC SL J 330PF/50V	CHD1JJ8SL331
C717	CHIP CERAMIC F Z 0.047μF/50V or	CHD1JZ80F473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80F473
	CHIP CERAMIC F Z 0.047μF/16V or	CHD1CZ80F473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1EZ80Z473
	CHIP CERAMIC F Z 0.047μF/16V	CHD1CZ80Z473
C718	CHIP CERAMIC SL J 22PF/50V	CHD1JJ8SL220
C719	CHIP CERAMIC B K 1500PF/50V or	CHD1JK80B152
	CHIP CERAMIC B K 1500PF/25V or	CHD1EK80B152
	CHIP CERAMIC B K 1500PF/50V or	CHD1JK80X152
	CHIP CERAMIC B K 1500PF/25V	CHD1EK80X152
C720	CHIP CERAMIC SL J 56PF/50V	CHD1JJ8SL560
C721	CHIP CERAMIC SL J 0.001μF/50V	1270102C
C722	CHIP CERAMIC SL J 560PF/50V	CHD1JJ8SL561
C726	CHIP CERAMIC SL J 0.001μF/50V	1270102C
C727	CHIP CERAMIC SL J 0.001μF/50V	1270102C
C728	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80B223
	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80X223
	CHIP CERAMIC B K 0.022μF/16V	CHD1CK80X223
C729	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80B223
	CHIP CERAMIC B K 0.022μF/25V or	CHD1EK80X223
	CHIP CERAMIC B K 0.022μF/16V	CHD1CK80X223
C730	CERAMIC F Z 0.047μF/50V	12F3473
C731	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103

Ref.No.	Description	PartNo.
C732	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C733	ELECTROLYTIC 100μF/6.3V M	121R107V
C734	CHIP CERAMIC CH J 33PF/50V or	CHD1JJ8CH330
	CHIP CERAMIC CG J 33PF/50V	CHD1JJ8CG330
C735	CHIP CERAMIC CH J 33PF/50V or	CHD1JJ8CH330
	CHIP CERAMIC CG J 33PF/50V	CHD1JJ8CG330
C736	ELECTROLYTIC 2.2μF/50V M	121W225V
C737	CHIP CERAMIC F Z 0.033μF/50V or	CHD1JZ80F333
	CHIP CERAMIC F Z 0.033μF/25V or	CHD1EZ80F333
	CHIP CERAMIC F Z 0.033μF/16V or	CHD1CZ80F333
	CHIP CERAMIC F Z 0.033μF/50V	CHD1JZ80Z333
C738	ELECTROLYTIC 22μF/6.3V M	121R226V
C739	ELECTROLYTIC 22μF/6.3V M	121R226V
C740	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C741	ELECTROLYTIC 100μF/6.3V M	121R107V
C742	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80F223
	CHIP CERAMIC F Z 0.022μF/25V or	CHD1EZ80F223
	CHIP CERAMIC F Z 0.022μF/50V or	CHD1JZ80Z223
	CHIP CERAMIC F Z 0.022μF/25V	CHD1EZ80Z223
C743	CHIP CERAMIC B K 0.047μF/50V or	12B3473C
	CHIP CERAMIC B K 0.047μF/25V	12B2473C
C744	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C745	CHIP CERAMIC B K 0.047μF/50V or	12B3473C
	CHIP CERAMIC B K 0.047μF/25V	12B2473C
C750	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C752	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
C753	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/25V	CHD1EK80X103
C754	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C755	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C756	CHIP TANTAL 15μF/6.3V M or	1223156C
	CHIP TANTAL 15μF/6.3V M	CA0K156KC003
C757	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C758	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103

Ref.No.	Description	PartNo.
C759	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/25V	CHD1EK80X103
	CHIP CERAMIC B K 0.1μF/50V or	12B3104C
	CHIP CERAMIC B K 0.1μF/25V	12B2104C
C760	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010KC001
C761	CHIP CERAMIC 1μF/16V F 2125 or	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
	CHIP CERAMIC 1μF/16V F 2125	CA1C010MR002
	CHIP CERAMIC 1μF/16V F 2125	CA1C010TU003
C763	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/25V	CHD1EK80X103
C764	CHIP CERAMIC B K 0.1μF/50V or	12B3104C
	CHIP CERAMIC B K 0.1μF/25V	12B2104C
C765	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C766	CHIP CERAMIC B K 1500PF/50V or	CHD1JK80B152
	CHIP CERAMIC B K 1500PF/25V or	CHD1EK80B152
	CHIP CERAMIC B K 1500PF/50V or	CHD1JK80X152
	CHIP CERAMIC B K 1500PF/25V	CHD1EK80X152
C767	CHIP TANTAL 15μF/6.3V M or	1223156C
	CHIP TANTAL 15μF/6.3V M	CA0K156KC003
C768	CHIP CERAMIC F Z 0.047μF/50V or	CHD1JZ80F473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1CZ80F473
	CHIP CERAMIC F Z 0.047μF/16V or	CHD1EZ80Z473
	CHIP CERAMIC F Z 0.047μF/25V or	CHD1CZ80Z473
C769	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/25V	CHD1EK80X103
C770	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C771	CHIP CERAMIC B K 0.047μF/50V or	12B3473C
	CHIP CERAMIC B K 0.047μF/25V	12B2473C
C772	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C773	CHIP TANTAL 1μF/16V M or	1225105C
	CHIP TANTAL 1μF/16V M	CA1C105KC003
C774	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C775	CHIP CERAMIC B K 0.047μF/50V or	12B3473C
	CHIP CERAMIC B K 0.047μF/25V	12B2473C
C776	CHIP TANTAL 10μF/6.3V M or	1223106C
	CHIP TANTAL 10μF/6.3V M	CA0K106KC003
C777	CHIP CERAMIC F Z 0.1μF/16V or	CHD1CZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80F104
	CHIP CERAMIC F Z 0.1μF/25V or	CHD1EZ80Z104
	CHIP CERAMIC F Z 0.1μF/16V	CHD1CZ80Z104
C778	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103

Ref.No.	Description	PartNo.
C779	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
	CHIP CERAMIC B K 0.01μF/25V	CHD1EK80X103
	CHIP CERAMIC B K 0.047μF/50V or	12B3473C
C780	CHIP CERAMIC B K 0.047μF/25V	12B2473C
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80B103
	CHIP CERAMIC B K 0.01μF/25V or	CHD1EK80B103
	CHIP CERAMIC B K 0.01μF/50V or	CHD1JK80X103
C781	CHIP CERAMIC SL J 47PF/50V	CHD1J8SL470
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80F103
C782	CHIP CERAMIC F Z 0.01μF/25V or	CHD1EZ80F103
	CHIP CERAMIC F Z 0.01μF/50V or	CHD1JZ80Z103
	CHIP CERAMIC F Z 0.01μF/25V	CHD1EZ80Z103
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
C783	CHIP CERAMIC B K 1000PF/25V or	CHD1EK80B102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80X102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80X102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80B102
C784	CHIP CERAMIC B K 1000PF/25V or	CHD1EK80B102
	CHIP CERAMIC B K 1000PF/50V or	CHD1JK80X102
	CHIP CERAMIC B K 1000PF/25V	CHD1EK80X102
	CHIP CERAMIC SL J 100PF/50V	CHD1J8SL101
C785	CHIP CERAMIC SL J 100PF/50V	CHD1J8SL101
C786	CHIP CERAMIC SL J 150PF/50V	CHD1J8SL151
C787	CHIP CERAMIC SL J 150PF/50V	CHD1J8SL151
C788	CHIP CERAMIC SL J 100PF/50V	CHD1J8SL101
CONNECTORS		
CL-18	CONNECTOR(B TO B) 8P REC 3-175637-8	JC37T08APH0C
CL-19	CONNECTOR(B TO B) 12P REC 4-175639-2	JC39T12APH0C
CN-6	CONNECTOR(B TO B) 12P POST4-176833-2	JC33A12APH0C
CN-7	CONNECTOR(B TO B) 18P POST4-176833-8	JC33A18APH0C
CN-8	CONNECTOR(B TO B) 18P POST4-176833-8	JC33A18APH0C
CN-9	CONNECTOR(B TO B) 12P POST4-176833-2	JC33A12APH0C
CN-13	CONNECTOR IL-Z-06PL-SMTY	JCILD06NBH0C
CN-15	FPC CONNECTOR, 8P IL-402-8S-S1L-SA	JC42T08NBH0B
CN-16	FPC CONNECTOR, 14P IL-402-14S-S1L-SA	JC42T14NBH0B
CN-17	FPC CONNECTOR, 12P IL-402-12S-S1L-SA	JC42T12NBH0B
DIODES		
D574	CHIP DIODE DA115	ADA115T106**
D601	CHIP DIODE DA204U	ADA204UT106*
D603	CHIP DIODE DAN202U	ADAN202UT106
D701	CHIP DIODE DA115	ADA115T106**
ICS		
IC571	IC S-8420BF-T1	GS8420BFT100
IC574	IC TA7291F	GTA7291FER**
IC575	IC UPC358G2(T1) or	GUPC358G2T1*
	IC BA10358F-T1 or	GBA10358FT1*
	IC NJM2904M(T1)	GNJM2904MT1*
	IC BU4066BF(T1) or	GBU4066BFT1*
IC576	IC NJU4066BMT1	GNJU4066BMT1
	MICRO CONTROLLER 4BIT UPD75512GF	GC91000NE044
IC601	IC BU4094BFT1	GBU4094BFT1*
IC602	IC TC4024BF(TP1)	GTC4024BFTP1
IC603	IC BU74HC08FT1 or	GBU74HC08FT1
IC604	IC NJU74HC08MT1	GUJU74HC08MT1
	IC BU4052BF or	14DF547
	IC NJU4052BM (T1)	14D0573
	IC CX20035-T1	GCX20035T1**
IC606	IC CXA1204Q	GCXA1204Q***
IC701	IC CXA1204Q	GCXA1204Q***
IC702	IC UPC358G2(T1) or	GUPC358G2T1*

Ref.No.	Description	PartNo.
IC703	IC BA10358F-T1 or	GBA10358FT1*
	IC NJM2904M(T1)	GNJM2904MT1*
	HEAD AMP IC CXA1201R-T3	GCXA1202RT30
COILS		
L601	INDUCTOR 22UH J or	1170974T
L602	LEAD INDUCTOR 22UH J	LLAXJBVFS220
	INDUCTOR 33UH J or	1170976T
	LEAD INDUCTOR 33UH J	LLAXJBVFS330
	INDUCTOR 33UH J or	1170976T
L603	LEAD INDUCTOR 33UH J	LLAXJBVFS330
	INDUCTOR 33UH J or	1170988T
	LEAD INDUCTOR 33UH J	LLAXJBVFS331
	CHIP INDUCTOR 220UH K or	LLACKG0TE221
L701	LEEDLESS INDUCTOR 220UH J or	1170843
	CHIP INDUCTOR 220UH K	1170911
L703	CHIP INDUCTOR 10UH J or	1170810
	CHIP INDUCTOR 10UH K	1170861
L704	CHIP INDUCTOR 100UH J or	1170742
	CHIP INDUCTOR 100UH J or	1170756
	CHIP INDUCTOR 100UH J 3225	LLACJE8FS101
	CHIP INDUCTOR 150UH J or	1170792
L705	CHIP INDUCTOR 150UH J or	1170789
	CHIP INDUCTOR 150UH J 3225	LLACJE8FS151
L706	CHIP INDUCTOR 150UH J or	1170792
	CHIP INDUCTOR 150UH J or	1170789
	CHIP INDUCTOR 150UH J 3225	LLACJE8FS151
TRANSISTORS		
Q574	CHIP 2SC4081(R) or	QSC4081T106R
Q601	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q602	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q603	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q604	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q605	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q606	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q607	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q608	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q701	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q702	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SC4081(R) or	QSC4081T106R
Q703	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q704	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
Q705	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q706	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
Q707	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP 2SA1577(Q) or	QSA1577T106Q
	CHIP 2SA1577(R)	QSA1577T106R

Ref.No.	Description	PartNo.
Q752	CHIP 2SA1577(Q) or	QSA1577T106Q
Q753	CHIP 2SA1577(R)	QSA1577T106R
	CHIP 2SC4081(R) or	QSC4081T106R
	CHIP 2SC4081(S)	QSC4081T106S
	CHIP DTA144EU	QTA144EUT106
QR601	CHIP DTC144EU	QTC144EUT106
QR602	CHIP DTA114EU	QTA114EUT106
QR604	CHIP DTC114EU	QTC114EUT106
QR701	CHIP DTC144EU	QTC144EUT106
QR702	CHIP DTC144EU	QTC144EUT106
QR703	CHIP DTC144EU	QTC144EUT106
QR751	CHIP DTC144EU	QTC144EUT106
QR752	CHIP DTA144EU	QTA144EUT106
RESISTORS		
R571	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R572	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R573	CHIP 1/16W J 220KΩ	RCXGJR8Z0224
R574	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R577	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R578	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R580	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R581	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R583	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R584	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R586	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R587	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R591	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R592	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R593	CHIP 1/16W J 68KΩ	RCXGJR8Z0683
R594	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R595	CHIP 1/16W J 82KΩ	RCXGJR8Z0823
R596	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R601	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R602	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R603	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R604	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R605	CHIP 1/16W J 47KΩ	RCXGJR8Z0473</

Ref.No.	Description	PartNo.
R630	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R631	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R632	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R633	CHIP 1/16W J 220KΩ	RCXGJR8Z0224
R634	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R635	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R636	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R637	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R638	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R639	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R640	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R641	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R642	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R643	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R644	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R645	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R646	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R647	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R648	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R649	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R650	CHIP 1/16W J 330KΩ	RCXGJR8Z0334
R651	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R652	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R653	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R654	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R655	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R656	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R657	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R658	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R659	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R660	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R661	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R662	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R663	CHIP 1/16W J 15KΩ	RCXGJR8Z0153
R664	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R665	CHIP 1/16W J 220KΩ	RCXGJR8Z0224
R666	CHIP 1/16W J 100KΩ	RCXGJR8Z0104
R669	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R670	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R671	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R672	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R673	CHIP 1/16W J 0Ω	RCXGJR8Z0000
R674	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R675	CHIP 1/16W J 82KΩ	RCXGJR8Z0823
R676	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R677	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R678	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R679	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R680	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R681	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R682	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R683	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R684	CHIP 1/16W J 180KΩ	RCXGJR8Z0184
R685	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R686	CHIP 1/16W J 120KΩ	RCXGJR8Z0124
R687	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R688	CHIP 1/16W J 18KΩ	RCXGJR8Z0183
R689	CHIP 1/16W J 180KΩ	RCXGJR8Z0184
R690	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R691	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222

Ref.No.	Description	PartNo.
R692	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R693	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R694	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R695	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R696	CHIP 1/16W J 150KΩ	RCXGJR8Z0154
R697	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R701	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R702	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R703	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R704	CHIP 1/16W J 100Ω	RCXGJR8Z0101
R705	CHIP 1/16W J 150KΩ	RCXGJR8Z0154
R706	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R707	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R708	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R709	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R710	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R711	CHIP 1/16W J 1.8KΩ	RCXGJR8Z0182
R712	CHIP 1/16W J 2.7KΩ	RCXGJR8Z0272
R713	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R714	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R715	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R716	CHIP 1/16W J 150Ω	RCXGJR8Z0151
R717	CHIP 1/16W J 150Ω	RCXGJR8Z0151
R718	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R719	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R720	CHIP 1/16W J 33KΩ	RCXGJR8Z0333
R721	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R722	CHIP 1/16W J 560Ω	RCXGJR8Z0561
R723	CHIP 1/16W J 120Ω	RCXGJR8Z0121
R724	CHIP 1/16W J 180Ω	RCXGJR8Z0181
R725	CHIP 1/16W J 4.7KΩ	RCXGJR8Z0472
R726	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R727	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R729	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R730	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R731	CHIP 1/16W J 3.3KΩ	RCXGJR8Z0332
R732	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R733	CHIP 1/16W J 6.8KΩ	RCXGJR8Z0682
R734	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R735	CHIP 1/16W J 680KΩ	RCXGJR8Z0684
R736	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R737	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R738	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R739	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R740	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R741	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R742	CHIP 1/16W J 1.2KΩ	RCXGJR8Z0122
R743	CHIP 1/16W J 1MΩ	RCXGJR8Z0105
R744	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R745	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R746	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R747	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R748	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R751	CHIP 1/16W J 10KΩ	RCXGJR8Z0103
R752	CHIP 1/16W J 150KΩ	RCXGJR8Z0154
R753	CHIP 1/16W J 150KΩ	RCXGJR8Z0154
R754	CHIP 1/16W J 56KΩ	RCXGJR8Z0563
R755	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R756	CHIP 1/16W J 3.9KΩ	RCXGJR8Z0392
R757	CHIP 1/16W J 1KΩ	RCXGJR8Z0102

Ref.No.	Description	PartNo.
R758	CHIP 1/16W J 1KΩ	RCXGJR8Z0102
R759	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R760	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R761	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R762	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R763	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R764	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R765	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R766	CHIP 1/16W J 10Ω	RCXGJR8Z0100
R767	CHIP 1/16W J 10Ω	RCXGJR8Z0100
R768	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R769	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R770	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R771	CHIP 1/16W J 1.5KΩ	RCXGJR8Z0152
R772	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R773	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R774	CHIP 1/16W J 8.2KΩ	RCXGJR8Z0822
R775	CHIP 1/16W J 47KΩ	RCXGJR8Z0473
R776	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R777	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R778	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R779	CHIP 1/16W J 22KΩ	RCXGJR8Z0223
R780	CHIP 1/16W J 27KΩ	RCXGJR8Z0273
R781	CHIP 1/16W J 39KΩ	RCXGJR8Z0393
R782	CHIP 1/16W J 330Ω	RCXGJR8Z0331
R783	CHIP 1/16W J 22Ω	RCXGJR8Z0220
R784	CHIP 1/16W J 470Ω	RCXGJR8Z0471
R785	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R786	CHIP 1/16W J 2.2KΩ	RCXGJR8Z0222
R789	CHIP 1/10W J 0Ω	134F000C
R798	CHIP 1/16W J 0Ω	RCXGJR8Z0000
MISCELLANEOUS		
TP601	CHECKER CHIP RCU00000C	XU0C000AL001
TP708	CHECKER CHIP RCU00000C	XU0C000AL001
TP709	CHECKER CHIP RCU00000C	XU0C000AL001
TP710	CHECKER CHIP RCU00000C	XU0C000AL001
X601	X'TAL 32KHZ (10PPM)	1811351
X602	CERALOCK 4.19MHZ or CERAMIC RESONATOR KBR	1812885 1813682
X603	X'TAL KD8482FCB 4.433619 MHZ	FX0445SDS002
X701	X'TAL 5.859375MHZ or X'TAL 5.85938 MHZ	FXK585LDS002 FX0585LFS002
▲	P.C.B.	BC1580G02002

PSV PCB ASSEMBLY

Ref.No.	Description	PartNo.
	PSV PCB ASS'Y CONSISTS OF THE FOLLOWING:	0VSA04008
DIODES		
D849	DIODE 1SR35-100A	35100AT
D850	DIODE 1SS254	A1SS254T77**
D851	DIODE 1SS254	A1SS254T77**
D852	DIODE 1SS254	A1SS254T77**
MISCELLANEOUS		
F850▲	FUSE S506-3.15A-COLOR	1790486
JK850	DC JACK STJ-06	JYDJEE0SR001
SW848	PUSH SWITCH SKEGLC	SST0101AL009
SW849	PUSH SWITCH SKEGLC	SST0101AL009
SW850	PUSH SWITCH SKEGLA	SST0101AL004

Ref.No.	Description	PartNo.
W1	CONNECTOR ASS'Y 10P	WX1C1580-001
	TERMINAL	0VM402681
	TERMINAL	0VM402682
	TERMINAL; BAT	0VM402683
▲	P.C.B.	BC1580F01001
▲	FUSE HOLDER PFC5000-0202	XH01Z00SR001

CHASSIS ELECTRICAL PARTS

Ref.No.	Description	PartNo.
FFC 7	FFC WIRE 10P FFC 7:CAMERA AF	WX3910SZ4404
IC 04	IC LZ2323A9	GLZ2323A9000
	O.L.P.F. 0G-BF167 or	FCL999NDS002
	O.L.P.F. SV-511B	FCL999NKL001

SCHEMATIC DIAGRAM

STANDARD NOTES

SCHEMATIC DIAGRAMS

Warning


Many electrical and mechanical parts marked with $\triangle$ in this chassis have special characteristics. These characteristics often pass unnoticed and the protection afforded by them cannot necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts that have these special safety characteristics are identified in this manual and its supplements; electrical components having such features are identified by the mark shown below in the schematic diagram and the parts list. Before replacing any of these components, read the parts list in this manual carefully. The use of substitute replacement parts that do not have the same safety characteristics as specified in the parts list may create shock, fire, or other hazards.

Notes :


- ① Do not use the part number shown on these drawings for ordering. The correct part number is shown in the parts list, and may be slightly different or amended since these drawings were prepared.
- ② All resistance values are indicated in ohms ($K=10^3$, $M=10^6$).
- ③ Resistor wattages are 1/5W or 1/6W unless otherwise specified.
- ④ All capacitance values are indicated in μF ($P=10^{-6}\mu F$).
- ⑤ All voltages are DC voltages unless otherwise specified.
- ⑥ Voltage Indications for PB, STOP and REC mode on Schematic are as shown below.

Capacitor Temperature Markings

Mark	Capacity change rate	Standard temperature	Temperature Range
(B)	$\pm 10\%$	20°C	-25~+85°C
(F)	+30-80%	20°C	-25~+85°C
(SR)	$\pm 15\%$	20°C	-25~+85°C
(Z)	+30-80%	20°C	-10~+70°C



LEAD IDENTIFICATIONS



CHIP IDENTIFICATIONS

2SC4398		
2SC4397		
2SA1745		
2SA1678		
2SC4396		
DTA114EU		
DTC114EU		
DTC144TU		
FC106		
2SK303		
TC4S30F or SC14S70F		
2SA1213		
1SS283		

SAH-02		
SB007-03CP		
MA141K		
ISV202		
2SB1386		
2SB1073		
2SC3929		
2SK621		

2SD1767		
2SA1037		
UN5212		
UN5112		
2SA1622		
2SC4211		
2SA1676		
2SA1677		

2SC4081		
DA115		
DA204U		
DTA144EU		
DTC144EU		
2SC4098		
DAN202U		
DTC124EU		

MA159		
MA141WK		
2SK209		
DAP202U		
2SA1576		
2SA1577		
2SK1332		
MA720		

MA160		
2SK94		
DTA124EU		
DTA114YU		
RD*.M		
IMH2		

IC PIN FUNCTION DESCRIPTION

System Control(IC601)GC1000NE044

Pin No	IN/OUT	Signal Name	Function
1	IN	B-CHK	Battery Check
2	IN	AD-REF	Reference Voltage AD Conv. IN
3	—	VDD	VDD (+5V)
4	—	VDD	VDD (+5V)
5	OUT	REF	Reference Voltage
6	OUT	F-OUT	Fade out (PWM out)
7	OUT	VTR-ON	VTR Power on at "H"
8	OUT	EXP-OE	Port Expander Output at "H"
9	OUT	LM-FWD	Loading Motor Foward at "H"
10	OUT	LM-RVS	Loading Motor Reverse at "H"
11	OUT	LM-CTL	Loading Motor Power up at "H"
12	OUT	FE-ON	Flying Erase head on at "L"
13	OUT	REC	REC at "L"
14	OUT	C-BRK	Capstan Motor Brake at "H"
15	OUT	REV-H	Capstan Motor Reverse at "H"
16	OUT	C-ON	Capstan Motor on at "H"
17	IN	MD-3	Mode Switch Detector 3
18	IN	MD-2	Mode Switch Detector 2
19	IN	MD-1	Mode Switch Detector 1
20	IN	No USE	Always GND
21	IN	B-SELECT	Back up Battery at "L"
22	—	VDD	VDD (+5V)
23	IN	EJECT	EJECT at "L"
24	IN	POWER	Power ON/OFF at "L"
25	IN	DATA3	Key Scan Data 3
26	IN	DATA2	Key Scan Data 2
27	IN	DATA1	Key Scan Data 1
28	IN	DATA0	Key Scan Data 0
29	OUT	P-SAVE L	Power Save Mode at "L"
30	OUT	SCAN2	Key Scan Pulse 2
31	OUT	SCAN1	Key Scan Pulse 1
32	OUT	SCAN0	Key Scan Pulse 0
33	—	GND	GND
34	OUT	CAM LED	Camera LED on at "L"
35	OUT	VTR LED	VTR LED on at "L"
36	OUT	TALLYLED	Tally LED on at "L"
37	OUT	SRV-CS	Servo Chip Select at "L"
38	OUT	ATF TSA	ATF TSA Pulse
39	OUT	ATF SWP	ATF Switching Pulse
40	OUT	ATF SEL 1	ATF Select 1
41	OUT	ATF SEL 2	ATF Select 2
42	OUT	F SET-H	Fade Set at "H"

Character Generation IC (IC301) μ PD6145G

[illegible]

DECK MECHANISM SECTION DISASSEMBLY INSTRUCTIONS(DECK)

= Remark =

1. When removing the some components, work with care so as not break the plastic components.
2. Do not supply power to the unit during disassembly.
3. Place a cloth or some other soft material under the P.C.B. or Unit to prevent damage.
4. When reinstalling, ensure that the connectors are connected and electrical components have not been damaged.
5. The Cut Washer is not reusable. If removed, install a new one.

[1] CASSETTE HOLDER ASS'Y

(If not already removed the Driver P.C.B., remove the Driver P.C.B. refer to Disassembly instructions (SET) on page 1-4. Use step 1-12. Driver P.C.B. removal.)

- (1) Push the Eject Lever (A) to place the unit in Cassette Up condition.
- (2) Remove 4 Screws (B).
- (3) Then pull out the Cassette Holder ASS'Y.




Fig. 2-1

[2] CYLINDER ASS'Y/Cylinder Base

- (1) Remove 3 Screws (A), and take off the Cylinder Ass'y from Cylinder Base.
- (2) Remove 3 Screws (B), and take off the Cylinder Base.

= Remark =

1. When removing the Cylinder Ass'y, work with care so as not to damage the any components.
2. Use gloves and do not touch the drum surface with bare fingers.
3. If the Video Head is defective, replace the complete upper drum with the Head.




Fig. 2-2

[3] Power Logic Ass'y/Mode Switch/Stopper Loading/Logic Driver Ass'y/
Capstan Motor

1. Power Logic Ass'y

- (1) Remove 3 Screws (A) (H). At first remove the Lead wire with Motor.
Then turn the Mode Select Switch counterclockwise slightly.
Then take off the Power Logic Ass'y.

2. Mode Switch

- (1) Remove Cut Washer (B).
- (2) Remove the Gear Input.

3. Stopper Loading

- (1) Remove Cut Washer (C).
- (2) Remove Spring Stopper (D).

4. Logic Driver Ass'y

- (1) Remove Cut Washer (E).
- (2) Remove the Lever Guide Set.
- (3) Then remove the Logic Drive Ass'y

5. Capstan Motor

- (1) Remove 2 Screws (F)
- (2) Then remove Screw (G).
- (3) Then remove the Capstan Motor from Bottom Side.




Fig. 2-3

[4] Guide Rail Outer

1. Guide Rail Outer

- (1) Remove 3 Screws (A) and (B).
- (2) Release Locking Tab (C).




Fig. E2-4

[5] Cover Mechanism/Hand Brake Ass'y/Reel Base Ass'y/Slide Brake Operation /Lever LD Braket Joint/Brake Operation Lever Ass'y

1. Cover Mechanism

- (1) Remove 2 Screws (A).
- (2) Then take off the Cover Mechanism.

2. Hand Brake Ass'y

- (1) After removing the Cover Mechanism, unhook Spring (B).
- (2) Then take off the Hand Brake Ass'y.

3. Reel Base Ass'y

- (1) After removing the Hand Brake Ass'y, take off the Hand Brake Spring.

4. Slide Brake Operation

- (1) Remove Cut Washer (D).
- (2) Slide the Slide Brake Operation in the direction of arrow, then take off the Slide Brake Operation.

5. Lever LD Brake Joint/Brake Operation Lever Ass'y

- (1) Unhook Spring (C), then take off the Lever LD Brake Joint.
- (2) After removing the Lever LD Brake Joint, take off the Brake Lever Operation Lever Ass'y.




Fig. 2-5

[6] Braket Lever/Brake S and Brake T

- 1. Braket Lever
 - (1) Remove Screw(A) and unhook Spring(B).
 - (2) Then take off the Braket Lever.
- 2. Brake S and Brake T
 - (1) After removing the Braket Lever, take off the Brake T and Brake S.




Fig. 2-6

[7] Slide Direction Ass'y/Joint Slide Ass'y/Swing Arm Ass'y/Holder R,L Switch
Swing Arm Ass'y Lever UBT Lock/Gear

- 1. Slide Direction Ass'y
 - (1) Remove Cut Washer(A), then take off the Slide Direction Ass'y.
- 2. Joint Slide Ass'y
 - (1) Remove Cut Washer(B), then take off the Joint Slide Ass'y.
- 3. Swing Arm Ass'y
 - (1) After removing the Slide Direction Ass'y, remove Cut Washer(C).
 - (2) Then take off the Swing Arm Ass'y.
- 4. Holder R,L Switch
 - (1) Remove Screw(D), then take off the Holder R Switch.
 - (2) Remove Screw(E), then take off the Holder L Switch.
- 5. Gear
 - (1) Remove Cut Washer(G), then take off the Gear.




Fig. 2-7

SERVICE FIXTURES AND TOOLS


Followings are required for Deck Adjustment.

3-1. INSTRUMENT


- a) Color TV Monitor
- b) Oscilloscope

3-2. TOOL


- a) Driver : + No. 00 (marketing good)



- b) Driver : -2.5m/m




- c) Driver (Special)




3-3. TAPE AND TORQUE METER


- a) Alignment Tape : SP (FM6N)



- b) Torque Meter (SRK-8T-0102)



- c) Blank Tape (P-5-30 or marketing good)



STANDARD MAINTENANCE

4-1. Cleaning

4-1-1. Cleaning of Video Head (Fig. 1)

Head cleaning by using a chamois skin.

- 1) Remove the right side cabinet.
- 2) Put on a glove (thin type) to avoid touching the upper drum and lower drum with bare hand.
- 3) Put a few drops of alcohol on the chamois skin, and by slightly placing it against the head trip, allow the upper drum to turn the right and left.




Fig. 1

= Remark =

- a) The video head is of very hard material, but since it is very thin, avoid cleaning it vertically.
- b) Wait for the cleaned part to dry out before operating the unit.
- c) Do not reuse the stained chamois skin.

* When replacing the Upper Drum, replace it as a Unit because of its sensitivity.

4-2. Mode Select Switch Positioning (Fig. 2)

- 1) Setting Mode Select Switch on Deck, put 2 bosses on Mode Select Switch onto groove on Cam Power Logic as shown in Fig. 2.




Fig. 2

4-3. BT Adjustment (Fig. 3)

- 1) On REC Mode, adjust the Adjustment Screw so that the BT torque is $5.5 \pm 2\text{gcm}$.




Fig. 3

4-4. End LED (Infrared) Setting (Fig. 4)





Fig. 4

= Remark =

- a) Confirm wiring color.
- b) When soldering, component lead must be less than 1mm from P.C.board.
- c) LED must be set suitably to one's seat of Guide Rail (TG).
- d) Do not touch the sensor portion of Dew Sensor.

4-5. Cylinder Base Ass'y Setting (Fig. 5)



=Remark=

- 1) Set the Spring TG large side below.
- 2) Adjust Tape Guide T2 as shown above
- 3) Adjust torque value of Tape Guide T2 Ass'y to $200\text{g cm} \pm 20$.

4-6. Slide MG1 Ass'y Setting (Fig. 6)

- 1) Put Roller MG1 Guide, Roller MG1 Guide(2) onto Slide MG1 Ass'y, then fix it by Screws,
- 2) Adjust torque value to $150 \pm 20\text{g cm}$.






Fig. 6

4-7. Recognition SW, R Ass'y (Fig. 7)



= Remark =
Confirm wiring color.

4-8. Recognition Mode Switch (Fig. 8)




= Remark =
Take care of the order of
soldering with Lead wire.

MECHANICAL ADJUSTMENT INSTRUCTIONS


1. TAPE RUNNING ADJUSTMENT METHOD

1). TAPE RUNNING CONTROL

(SUPPLY SIDE)



(TAKEUP SIDE)



2). ENVELOPE ADJUSTMENT METHOD

ADJUSTMENT PREPARATION

- 1) Clean tape running side(Tape Guide, Drum, Capstan Post, Pinch Roller).
- 2) Connection to Oscilloscope.

1ch	: 1 CH	TP123
External Trigger	: RF - SW	TP07
GND	: GND	TP404
- 3) Play alignment tape for tracking. Confirm RF Waveform on both Take up Side and SupplySide flat (Refer to Fig. 1-1-a). In case that mormal waveform does no appear, adjust by the below method.
 - In case of RF Waveform on Take up side not to be flat. (Refer to Fig. 1-1-b)
 - 1. Adjust waveform according to Supply Side Adjustment.
 - In case of RF Waveform on Supply side not to be flat. (Fig. 1-1-c)
 - 2. Adjust waveform according to Take up Side Adjustment.
- 4) Perform temporary adjustment of ATF, Balance, Volume. About adjustment method, refer to the item of temporary adsutment of ATF BAL VOLUME Adjustment Method on Electrical Adsutment Method.




Fig. 1-1




Fig. 1-2 (TOP VIEW)

Supply Side Adjustment

- 1) Play alignment tape (FM6-N) for tracking, confirm the supply side waveform. In case that the waveform is not about flat (Fig. 1-3), adjust it according to below method.
- 2) Adjust the supply side waveform to be more than 75% by turning the No. 6 Guide every 90° clockwise. If turning clockwise cause the waveform to reduce, perform same adsutment by turning counterclockwise. (Fig. 1-3)
- 4) Slightly swell Supply side waveform by turning No. 6 Guide. (Fig. 1-5)




Fig. 1-3

- 3) Make the RF waveform envelope 2/3 by turning ATF Balance Volume (Refer to Fig. 1-4)




Fig. 1-4




Fig. 1-5

- 5) Make the waveform flat by turning No 5 Guide. (Fig. 1-6)




Fig. 1-6

Take up side Adjustment

- 1) Play alignment tape (FM6-N) for Tracking, then confirm the Take up Side waveform.
In case of not being flat, adjust the waveform according to below method. (Fig. 1-7)
- 2) Make the Take up side waveform more than 75% by turning No.9 Guide every 90°. (Fig. 1-7)




Fig. 1-7

- 3) Make the RF waveform envelope 2/3 by turning ATF Balance Volume (VR403). (Fig. 1-8)




Fig. 1-8

- 4) Slightly swell Take up Side Waveform by turning No. 9 Guide. (Fig. 1-9)




Fig. 1-9

- 5) Make the waveform flat by turning No. 8 Guide. (Fig. 1-10)




Fig. 1-10

- 6) Confirm the upper fringe portion of No. 8 Guide not to occur tape curling. If tape curling occur, back to 4), then adjust it again.
- 7) After adjustment, on PLAY Mode after completion of loading, after CUE/REV or on PLAY Mode after REW, confirm waveform to get up horizontally. In case of not getting, back to 4), then adjust it again. In this case, do not turn more than 15° once.

Checking after adjustment

1. Tracking Check

- 1) Play alignment tape (FM6-N) for tracking.
- 2) Make the RF waveform envelope 2/3 by turning ATF Balance Volume (VR403). (Fig. 1-11)




Fig. 1-11

- 3) Confirm that 75% of maximum envelope is minimum envelope of RF Waveform in this condition. (Fig. 1-12)




Fig. 1-12

- 4) In this case, confirm change quantity of RF waveform envelope to be as shown in Fig. 1-13.




Fig. 1-13

- 5) On REV Mode, confirm the waveform noise pitch is equal. In case of not equal, adjust the waveform according to the below method.
(Refer to Fig. 1-14)




Fig. 1-14

- 6) On REV Mode, In case of occurring the tape curling, on upper fringe or lower fringe on No. 8 Guide, No. 9 Guide, remove tape curling by turning No. 10 Guide every 45°. (Fig. 1-15)





Fig. 1-15

- 7) After completion of all running adjustment, perform the adjustment of ATF BAL VOL.
(Refer to Electrical Adjustment)

Supply Side Noise pitch stuffing

1) On PLAY Mode, confirm RF waveform to be flat.

[In case of not being flat]

Adjust the height of No. 6 Guide, according to the Supply Side Adjustment

[In case of being flat]

Adjust the height of No. 5 Guide, according to the Supply Side Adjustment




Fig. 1-16

Take up Side Noise Pitch Stuffing

1) On PLAY Mode, adjust the height of No. 8 Guide, No. 9 Guide according to the take up side adjustment.




Fig. 1-17

2) Confirm that tape curling does not occur on fringe portion on No. 8 Guide, No. 9 Guide. If occurring the tape curling, adjust the tape curling not to occur by turning No. 10 Guide. (Checking after Adjustment) Refer to 6.)

Getting Up Check

1) After completion of loading, on PLAY Mode, after CUE/REV, or on PLAY Mode After FF, confirm the RF waveform to get up horizontally. In case of not getting up horizontally, adjust waveform according to below Method.

<In case of occurring noise from supply side (lower portion on picture side after completion of loading, on PLAY Mode, on getting up>




Fig. 1-18

Turn No. 9 Guide 30° counterclockwise, again perform the getting up check,

<In case of occurring noise from take up side (lower portion on picture side after completion of loading, on PLAY Mode, on getting up>







Fig. 1-19

While performing getting up check, adjust No. 5 Guide by turning every 30°.





DECK MECHANICAL PARTS LIST

REF.NO.	DESCRIPTION	PART NO.
B-1	PCB	BC1800G01001
B-2	LED	EPLT462T3***
B-3	Spring MG1 Thrust	OVM401048
B-4	Capstan Motor	1640403
B-5	Spacer	OVM402215
B-6	Slide BT Set	OVM200343
B-7	Lever L, BT Lock	OVM300328
B-8	Chassis Ass'y	OVM100089
B-9	Rever BT Adjust	OVM300715
B-10	Guide Rail Inner	OVM100092
B-11	Cassette Holder Ass'y	OVM200328
B-12	Cam Power Logic	OVM200332
B-13	Bracket Spring	OVM300335
B-14	Holder RG Guide	OVM300393
B-15	Cover Mechanism	OVM200385
B-16	DL Gear Ass'y	OVM400970
B-17	Joint Slide Ass'y	OVM300302
B-18	Slide Brake Saucer	OVM300304
B-19	Lever Review Brake	OVM400972
B-20	Lower Loading Ring Ass'y	OVM300307
B-21	Upper Loading Ring Ass'y	OVM300309
B-22	Stopper Unloading	OVM300311
B-23	Swing Arm Ass'y	OVM300319
B-24	Spring Review Brake	OVM400973
B-25	Back Tention Lever Ass'y	OVM400983
B-26	Bracket Lever	OVM300331
B-27	Spring Back Tention	OVM400992
B-28	Holder R SW	OVM300337
B-29	Spring BT Release	OVM400993
B-30	Holder, L SW	OVM300364
B-31	Cylinder Drum Ass'y	OVM300587
B-32	Ring Guide	OVM401038
B-34	Gear Lower	OVM401039
B-35	Flange TG	OVM400895
B-36	Gear Upper	OVM401040
B-37	Gear Reduction	OVM401085
B-38	Holder Joint	OVM401131
B-39	T Operation Lever Ass'y	OVM401152
B-40	Bracket Gear Ass'y	OVM401166
B-41	Lever Preset	OVM400957
B-42	Pinch Lever Ass'y	OVM400963
B-43	Reel Operation Lever Ass'y	OVM401179
B-44	Brake T Sub	OVM401184
B-45	Spring T Sub Brake	OVM401296
B-46	Slide Direction Ass'y	OVM401361
B-47	Spring T Saucer	OVM401363
B-48	Spring Direction	OVM401364
B-49	Spring BT Lock	OVM401365
B-50	Band Brake Ass'y	OVM400988
B-51	Bracket LED	OVM401140
B-52	Guide Rail Outer	OVM100091
B-53	Logic Drive Lever Ass'y	OVM400996
B-54	Lever Joint	OVM401001
B-56	Gear Planetary	OVM401019
B-57	Gear Input	OVM401021
B-58	Guide Catcher	OVM200337
B-59	Ring Lower Drive	OVM401031
B-60	Moving Guide 2 Ass'y	OVM401052
B-61	Bracket; Slide N	OVM402874
B-62	Stopper Loading	OVM401041
B-63	Spring Stopper	OVM401042
B-64	Lever Guide Set	OVM401045

REF.NO.	DESCRIPTION	PART NO.
B-65	Order Screw MG2	OVM401055
B-66	Slide MG1 Ass'y	OVM300312
B-67	Roller MG1 Guide	OVM300417
B-68	Bracket PCB	OVM300412
B-69	Rug; Earth	OVM402102
B-70	Roller Impedance	OVM401059
B-71	Flange Impedance R	OVM401060
B-72	Reel Base Ass'y	OVM401061
B-73	Gear LD Drive	OVM300305
B-74	Gear Primary	OVM401086
B-75	Brake S	OVM401091
B-76	Brake T	OVM401092
B-78	Roller MG Guide (2)	OVM300657
B-80	Gear Output	OVM401017
B-81	Spring MG2	OVM401301
B-82	BT Lock Ass'y	OVM402328
B-83	Guide Saucer Link Ass'y	OVM401139
B-84	Cylinder Base Ass'y	OVM300292
B-85	Guide T1 Tape	OVM400894
B-86	Flange TG	OVM400895
B-87	Spring TG	OVM400896
B-88	Tape Guide T2 Ass'y	OVM400897
B-89	Switch Mode N	SSR0103HD001
B-90	Flange Nut	OVM400978
B-91	RG Lever Ass'y	OVM400979
B-92	Earth Brash Ass'y	OVM401292
B-93	Spring RG	OVM400982
B-95	Pinch Saucer Lever Ass'y	OVM401299
B-96	Guide T2 Tape	OVM401116
B-97	Brake LD	OVM401158
B-98	Brake Operation Lever-A	OVM401185
B-99	Lever LD Brake Joint	OVM401187
B-100	Spring Main Brake	OVM401366
B-101	Spring LD Brake	OVM401367
B-102	Connector Ass'y 6P	OVM400542
B-103	Washer Fixer	OVM401734
B-104	Cut Washer 0.8	OVM401745
B-105	Spring Logic Drive	OVM401869
B-106	Dew Sensor;H	PCZHUMZHH001
B-107	Screw Mode SW	OVM401323
B-108	Recognition SW	5622203
B-109	MG1 Lever Ass'y	OVM401049
B-110	Plug; R Recog SW	OVM400391
B-111	Holder; Tape End Sensor	OVM300855
B-112	Holder; Tape End Sensor	OVM300856
B-113	BS Power Logic Ass'y	OVM300659
L101	Screw, P-Tight Bind Head	M1.6 X6
L102	Screw, Small, Pan Head	M1.2 X3
L104	Screw, Small, Pan Hea	M1.6 X2.5
L105	Screw, Small, Pan Head	M1.6 X4
L106	Screw, Small, Pan Head	M1.6 X3
L107	Screw, Small, Pan Head	M1.6 X2
L108	Screw, Small, Pan Head	M1.6 X5
L109	Screw, Small, Pan Head	M1.6 X1.8
L110	Screw, S-Tight Bind Head	M1.6 X3

PARTS LIST(CHARGER)



0VSA04170
Consists of the following:

Ref.No.	Description	PartNo.
	AC CHARGER A PCB ASSEMBLY	not available
	AC CHARGER B PCB ASSEMBLY	not available
	P.C.B. AC CHARGER (C1580EA)	BC1580F01008
AC CHARGER A PCB ASSEMBLY		
CAPACITORS		
C951▲	METALLIZED FILM 0.22μF/250V M or	CA2E224MS002
▲	METALLIZED FILM 0.22μF/250V K	CTR2EK000224
C953	SAFTY 0.0022μF/400V	122Z649
C954	SAFTY 0.0022μF/400V	122Z649
C955	SAFTY 0.0022μF/400V	122Z649
C956	SAFTY 0.0022μF/400V	122Z649
C957	ELECTROLYTIC 47μF/400V M	122Z651
C958	MP 0.01μF/630V(K)	122Z650
C959	ELECTROLYTIC 100μF/35V M	126E107S
C960	ELECTROLYTIC 33μF/35V M	126E336S
C961	CHIP CERAMIC B K 0.022μF/50V	12B3223C
C964	CHIP CERAMIC F Z 0.22μF/25V	12F2224C
C966	ELECTROLYTIC 4.7μF/35V M	126E475S
C967	CHIP CERAMIC SL J 390PF/50V	1270391C
C968	CHIP CERAMIC B K 0.0033μF/50V	12B3332C
C976	CHIP CERAMIC B K 0.0022μF/50V	12B3222C
C977	ELECTROLYTIC 820μF/16V M	122Z652
C978	ELECTROLYTIC 470μF/16V M	626C477
C979	MYLAR 0.015μF/50V J	1254153S
C980	ELECTROLYTIC 1μF/50V M	126F105S
C981	ELECTROLYTIC 2.2μF/50V M	126F225S
C982	MYLAR 0.015μF/50V J	1254153S
DIODES		
D951	DIODE S1WB60	AS1WB60****
D952	DIODE AU01A	AAU01AV0****
D953	DIODE 1SS146	A1SS146T77**
D954	DIODE 1SS254	A1SS254T77**
D956	DIODE 1SS254	A1SS254T77**
D959	ZENER DIODE MTZ5.6A	AMTZ5R6AT77*
D960	ZENER DIODE MTZ22A	AMTZ22AT77**
D963	DIODE D5LCA20U	AD5LCA20U***
D964	DIODE 1SS254	A1SS254T77**
D965	DIODE 1SS254	A1SS254T77**
D966	ZENER DIODE MTZ5.1A	AMTZ5R1AT77*
D967	DIODE 1SS254	A1SS254T77**
D968	DIODE 1SS254	A1SS254T77**
ICS		
IC951	IC FA5311S-TE1	GFA5311STE10
IC952	IC BA10358F-T1	GBA10358FT1*
TRANSISTORS		
Q951	FET 2SK952	Q2SK952****
Q953	2SB1140(S) or	Q2SB1140S***
	2SB1140(T)	Q2SB1140T***
Q954	2SD1207(S) or	Q2SD1207S***
	2SD1207(T)	Q2SD1207T***
QR951	BUILT-IN DTC114ES	C114ESZ
QR952	BUILT-IN DTC114ES	C114ESZ
RESISTORS		
R562	CHIP 1/10W J 5.1KΩ	134F512C

Ref.No.	Description	PartNo.
R951	CARBON 1/2W J 330KΩ	1330968
R952	WOUNP 2W J 3.3Ω	RW023R3KA001
R953	CARBON 1/5W J 68KΩ	1324683T
R954	CARBON 1/5W J 68KΩ	1324683T
R955	CARBON 1/5W J 68KΩ	1324683T
R956▲	METAL 2W J 47KΩ or	1330963
▲	METAL 2W J 47KΩ	RN02473KA001
R957▲	METAL 1W J 0.47Ω or	1330965
▲	METAL 1W J 0.47Ω	RM01R47KA001
R958	CHIP 1/10W J 82Ω	134F820C
R960	CHIP 1/10W J 91Ω	134F910C
R964	CARBON 1/5W J 180Ω	1324181T
R965	CHIP 1/10W J 82Ω	134F820C
R969	CHIP 1/10W J 2.2KΩ	134F222C
R970	CHIP 1/10W J 100KΩ	134F104C
R971	CHIP 1/10W J 100Ω	134F101C
R972	CHIP 1/10W J 4.7KΩ	134F472C
R973	CHIP 1/10W J 4.7KΩ	134F472C
R974	CHIP 1/10W J 100KΩ	134F104C
R975	CHIP 1/10W G 9.1KΩ	134G912C
R976	CARBON 1/5W J 3.3KΩ	1324332T
R977	CARBON 1/5W G 7.5KΩ	1354752T
R978	CHIP 1/10W G 1KΩ	134G102C
R979	CARBON 1/5W J 4.7KΩ	1324472T
R980	CHIP 1/10W J 1KΩ	134F102C
R981	CARBON 1/5W J 12KΩ	1324123T
R982	CARBON 1/5W J 1KΩ	1324102T
R983	METAL 1W J 120Ω	RN01121KA001
R984	CARBON 1/5W J 1KΩ	1324102T
R985	CHIP 1/10W J 68Ω	134F680C
R986	CARBON 1/2W J 150Ω or	1330967
▲	METAL 1/2W J 150Ω	RNX2151KA001
R1000▲	METALLIZED FILM 1W J 0.1Ω or	1330966
▲	METAL 1W J 0.1Ω	RM010R1KA001
MISCELLANEOUS		
F951	FUSE T1.25A/250V	1790482
L951	LINE FILTER, 33MH ELF-18D290HN	1813569
L952	CHOKE COIL, 10UH RCH-895 100M	LLBD***SF001
PH951	PHOTO CUPPLAR TLP634(GB-LF2) or	GTLP634GBLF2
	PHOTO COUPLER PC-111	1813254
T951▲	SWITCHING TRANS TS7413-1	LTT24EPMS001
VR951	P.O.T. 1KOHM B	138J777
VR952	P.O.T. 5KOHM B	138J780
W9	JUMPER WIRE 5P	WX3005J63310
	AC CORD	WAE0182KD001
	SHEET	0VM402813
	SHEET; HEATSINK; B	0VM402939
	HOLDER, FUSE	1790424
AC CHARGER B PCB ASSEMBLY		
CAPACITORS		
C985	CHIP CERAMIC F Z 0.022μF/25V or	12F2223C
	CHIP CERAMIC F Z 0.022μF/50V	12F3223C
C986	ELECTROLYTIC 47μF/6.3V M H5	121R476S
C987	MYLAR 0.033μF/50V J	1254333S
C988	CHIP CERAMIC CH J 100PF/50V	12CH101C
C989	CHIP CERAMIC CH J 100PF/50V	12CH101C
C990	CHIP CERAMIC F Z 0.1μF/25V or	12F2104C
	CHIP CERAMIC F Z 0.1μF/50V	12F3104C
CF951	CERAMIC CSB1000J	YK105PMR001

Ref.No.	Description	PartNo.
DIODES		
D971	DIODE 1SS254	A1SS254T77**
D972	SCHOTTKY DIODE RK34	ARK340000000
D973	LED SLR-33VR3F	ESLR33VR3F00
D974	LED SLR-33VR3F	ESLR33VR3F00
ICS		
IC953	VOLTAGE REGULATOR IC AN78L05	AN78L05
IC954	IC(COMPATER) BA10393F(T1)	GBA10393FT1*
IC955	MICROCONTROLLER 4BIT /BU5156F-T1	GC91000RM015
TRANSISTORS		
Q956	CHIP 2SA1576(R) or	QSA1576T106R
	CHIP 2SA1576(S)	QSA1576T106S
QR953	CHIP RES. BUILT-IN DTA124EU or	QTA124EUT106
	CHIP RES. BUILT-IN UN5112(TX)	QUN5112TX000
QR954	CHIP RES. BUILT-IN DTC124EU or	QTC124EUT106
	CHIP RES. BUILT-IN UN5212(TX)	QUN5212TX000
RESISTORS		
R987	CHIP 1/10W J 0Ω	134F000C
R988	CHIP 1/10W J 10KΩ	134F103C
R989	CHIP 1/10W J 10KΩ	134F103C
R990	CHIP 1/10W J 6.8KΩ	134F682C
R991	CHIP 1/10W J 10KΩ	134F103C
R992	CHIP 1/10W J 1KΩ	134F102C
R993	CHIP 1/10W J 36KΩ	134F363C
R994	CHIP 1/10W J 12KΩ	134F123C
R995	CHIP 1/10W J 2.2KΩ	134F222C
R996	CHIP 1/10W J 10KΩ	134F103C
R997	CHIP 1/10W J 160KΩ	134F164C
R998	CARBON 1/5W J 1.8KΩ	1324182T
R999	CARBON 1/5W J 220Ω	1324221T
MISCELLANEOUS		
JK951	DC JACK STJ-06	JYDJEE0SR001
SW951	MICRO SWITCH MQS-53-5F	SSP0102KB002
	TERMINAL, AC	0VM402812

SCHEMATIC DIAGRAM(CHARGER)




AC 220V
ADAPTOR MODE ()
BATTERY CHARGE MODE

C1580EA
AC CHARGER


MAIN BLOCK DIAGRAM




CCD BLOCK DIAGRAM




PROCESS BLOCK DIAGRAM



DRIVER BLOCK DIAGRAM




EVF SCHEMATIC DIAGRAM




PB Mode ()
REC Mode

CI580EA

SYSTEM CONTROL TIMING CHARTS




SERVO/SYSTEM CONTROL BLOCK DIAGRAM




ALIGNMENT INSTRUCTIONS

WIRING FOR ALIGNMENT



AC CHARGER SECTION


BLOCK DIAGRAM(CHARGER)



ELECTRICAL ADJUSTMENT INSTRUCTIONS(CHARGER)

Note:
All adjustment procedures must be proceeded in order of numbering.


1. Adaptor Output Voltage Adjustment

Test Point	Adj. Point	Mode	Input
JK951	VR951	ADAPTOR	AC100~240V
Tape	M. EQ.	Spec.	
---	LOAD RESISTOR DC VOLT METER	7.4V ±0.1V	
Connections of M. EQ.			
			

Reference notes:

1. Connect equipments as shown in the above table.
2. Connect the AC Charger to power source (AC 100V ~ AC 240V), confirm power LED is turn on.
3. Adjust the VR951 so that output voltage of JK951 becomes 7.4V ±0.1V.


2. Charge Mode Output Voltage Adjustment

Test Point	Adj. Point	Mode	Input
BATTERY TERMINAL	VR952	CHARGE	AC100~240V
Tape	M. EQ.	Spec.	
---	LOAD RESISTOR DC VOLT METER	7.4V ±0.1V	
Connections of M. EQ.			
			

Reference notes:

1. Connect equipments as shown in the above table.
2. Connect the AC Charger to power source (AC 100V ~ 240V) and turn on the SW951.
3. Adjust VR952 so that output voltage of the battery becomes 7.4V ± 0.1V.

TEST BOARD SCHEMATIC DIAGRAM



ELECTRICAL ADJUSTMENT

TEST EQUIPMENT AND TOOLS

1. Oscilloscope:
 - Dual Trace 40MHz 5mV/Div
 - 10:1 Probe
 - 1:1 Probe
2. Frequency Counter
3. Vectorscope
4. TV Monitor
5. DC Voltmeter
6. AC Voltmeter (R. M. S.)
7. Spectrum Analyzer
8. DC Power Supply
9. Pattern Generator (Color Bar Signal with 100% White)
10. Attenuator
11. Audio Oscillator
12. Viewer:
 - DNP standard color viewer model-V
 - Available Area 250 X 190 mm
 - Lamp-Toshiba FL 10W (W-PL-B X 4)
 - 3200 degrees K
13. Deflection Chart:
 - Gray Scale Chart
 - Color Bar Chart
14. Simenf Star Chart
15. Focus Adjustment Driver : -2 m/m
16. Alignment Tape (FM6A, FM6AL, FM6N, FM6EL, FM6M)
17. Test Board
18. A/V Cable
19. Load Resistor

HOW TO SET UP THE CAMERA MODE

1. Connect the TV Monitor through the Vectorscope to CAM OUT Jack (JK1003) on the Test Board.
2. Set the Viewer in front of the Camera.
3. Connect the DC Power supply (DC 7V $\pm$ 0.1V) to DC Jack (JK1001) on the Test Board.
4. Connect the Camera connectors to the Test Board.

Camera


CN-10 ---> CN-10-A

CN-31 ---> CN-31-A


5. Set switch positions as follows:

Switch No.	Switch Name	Select Position
SW1010	CAM / VTR	CAM
SW1004	TEST / CAM	TEST
SW1005	B-L	OFF
SW1007	FOCUS	M
SW1008	1/1000	OFF
SW1009	WHITE BAL	IN DOOR
SW1001	TV / TP / VTR	TV


CONTROL/POWER SCHEMATIC DIAGRAM



DRIVER SCHEMATIC DIAGRAM




WIRING DIAGRAM




REPLACEMENT PARTS LIST/EXPLODED VIEW

EXPLODED VIEW(CAMERA)




P.C.BOARD TOP/BOTTOM VIEW AND ALIGNMENT POINT


AC CHARGER PCB(TOP VIEW)




AC CHARGER PCB(BOTTOM VIEW)




EXPLODED VIEW(CHARGER)




PROCESS PCB(TOP VIEW)




PROCESS PCB(BOTTOM VIEW)







CCD PCB(TOP VIEW)




CCD PCB(BOTTOM VIEW)




SERVO/SYSTEM CONTROL PCB(BOTTOM VIEW)




MAIN PCB(BOTTOM VIEW)







REAR CONTROL PCB(TOP VIEW)




TOP CONTROL PCB(TOP VIEW)




REAR CONTROL PCB(BOTTOM VIEW)




TOP CONTROL PCB(BOTTOM VIEW)




CAMERA CONTROL PCB(TOP VIEW)




CAMERA CONTROL PCB(BOTTOM VIEW)



POWER PCB(TOP VIEW)




POWER PCB(BOTTOM VIEW)



The diagram illustrates the component placement on a circuit board. Key components and their locations are as follows:

- IC801:** A large integrated circuit located in the upper left quadrant.
- VR802:** A variable resistor or potentiometer located at the top center.
- Q801, Q802, Q803:** Transistors located in the upper right, center, and lower center areas, respectively.
- J801 through J807:** Connectors located along the left and right edges of the board.
- R801 through R823:** Resistors distributed throughout the board, often in pairs or groups.
- C801 through C808:** Capacitors located in various positions, often near the ICs and transistors.

The board is populated with numerous other components, including resistors (R804, R805, R806, R807, R808, R809, R810, R811, R812, R813, R814, R815, R816, R817, R819, R820, R822) and capacitors (C804, C805, C807, C810, C817). The layout is symmetrical, with components mirrored across a central vertical axis.



POSITION OF MODE SWITCH MECHANISM





Table 1

IC574 (LOADING MOTOR DRIVER)

MODE	INPUT		OUTPUT	
	7pin	9pin	4pin	13pin
STOP	L	L	OPEN	OPEN
LOADING	H	L	H	L
UNLOADING	L	H	L	H
BRAKE	H	H	L	L

Table 2

PROCESS SCHEMATIC DIAGRAM




The schematic diagram illustrates the internal circuitry of a video camera, organized into several functional blocks:


- Power and Reference Section:** Includes a 5V reference (VR51), a 35KHz oscillator (TP52), and various decoupling capacitors (C75, C76, C77, C78, C79, C80, C81, C82, C83, C84, C85, C86, C87, C88, C89, C90, C91, C92, C93, C94, C95, C96, C97, C98, C99, C100).
- Signal Processing Section:** Features two operational amplifiers, IC51 (μPC1100G) and IC52 (2SC1386), along with a 35KHz oscillator (VR52) and a 35KHz oscillator (VR53).
- Control and Timing Section:** Includes a 35KHz oscillator (VR54), a 35KHz oscillator (VR55), and a 35KHz oscillator (VR56).
- Output and Display Section:** Contains a 35KHz oscillator (VR57), a 35KHz oscillator (VR58), and a 35KHz oscillator (VR59).
- Control Panel:** A panel with a 14-pin connector (CL-30) and a 14-pin connector (CL-30). The connector table is as follows:

Pin	Signal
1	SP2
2	I/1000 H
3	B-LIGHT
4	IRIS Y
5	NC
6	AF 5V
7	GND A
8	SP1
9	CFOB
10	ZOOM (T)
11	ZOOM (W)
12	ZOOM COM
13	SHUT-L
14	CDS OUT

The diagram also shows various other components such as resistors (R01, R02, R03, R04, R05, R06, R07, R08, R09, R10, R11, R12, R13, R14, R15, R16, R17, R18, R19, R20, R21, R22, R23, R24, R25, R26, R27, R28, R29, R30, R31, R32, R33, R34, R35, R36, R37, R38, R39, R40, R41, R42, R43, R44, R45, R46, R47, R48, R49, R50, R51, R52, R53, R54, R55, R56, R57, R58, R59, R60, R61, R62, R63, R64, R65, R66, R67, R68, R69, R70, R71, R72, R73, R74, R75, R76, R77, R78, R79, R80, R81, R82, R83, R84, R85, R86, R87, R88, R89, R90, R91, R92, R93, R94, R95, R96, R97, R98, R99, R100), capacitors (C01, C02, C03, C04, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C29, C30, C31, C32, C33, C34, C35, C36, C37, C38, C39, C40, C41, C42, C43, C44, C45, C46, C47, C48, C49, C50, C51, C52, C53, C54, C55, C56, C57, C58, C59, C60, C61, C62, C63, C64, C65, C66, C67, C68, C69, C70, C71, C72, C73, C74, C75, C76, C77, C78, C79, C80, C81, C82, C83, C84, C85, C86, C87, C88, C89, C90, C91, C92, C93, C94, C95, C96, C97, C98, C99, C100), and transistors (QD51, Q51, Q52, Q53, Q54, Q55, Q56, Q57, Q58, Q59, Q60, Q61, Q62, Q63, Q64, Q65, Q66, Q67, Q68, Q69, Q70, Q71, Q72, Q73, Q74, Q75, Q76, Q77, Q78, Q79, Q80, Q81, Q82, Q83, Q84, Q85, Q86, Q87, Q88, Q89, Q90, Q91, Q92, Q93, Q94, Q95, Q96, Q97, Q98, Q99, Q100).



MAIN SCHEMATIC DIAGRAM



SERVO/SYSTEM CONTROL SCHEMATIC DIAGRAM

