


5-7 SIMPLEX PHONEPATCH

While pushing the F key, push the  /C.ON key to toggle the simplex phone patch function ON and OFF.

This function emits a DTMF "C" code each time the PTT key is released.

5-8 BATTERY SAVE FUNCTION

This function can be set by your Dealer only. Battery saving is automatically carried out to increase the life of the batteries.

Even when this function is set by your Dealer, battery saving is not carried out during DTMF operation or scanning.


6. SELECTIVE CALLING

When contacting a specific station, a subaudible tone is superimposed over your voice using tone squelch, or a DTMF code is transmitted prior to your voice transmission using DTMF squelch. It is possible to use either method individually or in combination with each other.

6-1 TONE SQUELCH

For the purpose of transmitting to a specific station, a subaudible tone is superimposed over your voice signal. This function may be preset by your Dealer beforehand, or can be set by the user if so permitted and programmed by your Dealer.

(1) Setting the tone frequency




1. Push the TONE key; the tone frequency is displayed.
2. Rotate the dial control clockwise to move up and counter-clockwise to move down. Choose from 1 of 38 different tone frequencies as listed below.

67.0	71.9	74.4	77.0	79.7	82.5
85.4	88.5	91.5	94.8	97.4	100.0
103.5	107.2	110.9	114.8	118.8	123.0
127.3	131.8	136.5	141.3	146.2	151.4
156.7	162.2	167.9	173.8	179.9	186.2
192.8	203.5	210.7	218.1	225.7	233.6
241.8	250.3				

(2) Tone encoder/tone squelch function setting

3. After the tone frequency appears, push the TONE key to step through the function settings as indicated below.



4. Push the ANS key to return the beginning display.

NOTE: If you push the TONE key and tone setting is not performed (even though KL is not displayed) operation has been disallowed by your Dealer.