


3. PANEL DESCRIPTION

3-1 FRONT, TOP AND SIDE VIEW



1 MIC connector

Connects optional earphone microphone, speaker microphone, or headsets. (Not to be used when EJ-18U is Installed)

2 SP connector

Connects an optional speaker.

3 Antenna connector

Connects the supplied antenna. An external antenna can be connected with a BNC connector.

4 Squelch control

Mutes audio noise. Rotate clockwise to close the squelch and counterclockwise to open the squelch.

6-2-4 Autodial

This function sends a DTMF code in memory automatically. 7 code memories can each hold one DTMF code of up to 24 digits.

Setting an auto-dial code

1. Set mode

While pushing the F key, push the DIAL key. The last 3 digits of the presently set DTMF code appears.

NOTE: If no data has yet been entered "----" appears.


2. Select a code memory No.

Rotate the dial control to select one of memories 1 to 7.

3. Enter a code

Use the keyboard to enter the desired code. (All 16 keys can be used.) When pushing a key, the entering digit appears to the right and the previously entered digit appears to the left. Up to 24 digits can be entered per code.

If you make a mistake while entering, while pushing the F key, rotate the dial control clockwise. The most recently input digit disappears. Enter the desired digit. To advance the display, while pushing the F key, rotate the dial control counterclockwise.



4. Clearing a code

To clear a code you are entering, or to clear a code that has already been entered: while pushing F, push C.