Self Diagnosis Supported model

SERVICE MANUAL RA-4A CHASSIS

MODEL	COMMANDER	DEST.	CHASSIS NO.
KP-53XBR300	RM-Y902	US	SCC-P21A-A
KP-53XBR300	RM-Y902	Canadian	SCC-P21A-A
KP-61XBR300	RM-Y902	US	SCC-P21B-A
KP-61XBR300	RM-Y902	Canadian	SCC-P21B-A

MODEL	COMMANDER	DEST.	CHASSIS NO.



RM-Y902



KP-53XBR300



KP-61XBR300

MICROFILM

∗ Please file according to model size. ..... ☐

53 61

COLOR REAR VIDEO PROJECTOR

SONY®

SPECIFICATIONS

Projection system
3 picture tubes, 3 lenses, horizontal in-line system

Picture tube
7-inch high-brightness monochrome tubes (6.3 raster size) with optical coupling and liquid cooling system

Projection lenses
High performance, large diameter hybrid lens F1.1

Television system
American TV standard

Channel coverage
VHF: 2–13/UHF: 14 –69/CATV: 1 – 125

Antenna
75 ohm external terminal for VHF/UHF

Screen size (measured diagonally)
53 inches (KP-53XBR300)
61 inches (KP-61XBR300)

Inputs/outputs
VIDEO 1/3 IN
VIDEO 2 INPUT
S VIDEO IN (4-pin mini DIN):
Y: 1 Vp-p, 75-ohms unbalanced, sync negative
C: 0.286 Vp-p (Burst signal), 75 ohms
VIDEO (phono jack): 1 Vp-p, 75-ohms unbalanced, sync negative
AUDIO (phono jacks): 500 mVrms (100% modulation), Impedance: 47 kilohms
VIDEO 4 IN
S VIDEO IN (4-pin mini DIN):
Y: 1 Vp-p, 75-ohms unbalanced, sync negative
C: 0.286 Vp-p (Burst signal), 75 ohms
VIDEO (phono jack): 1 Vp-p, 75-ohms unbalanced, sync negative
AUDIO (phono jacks): 500 mVrms (100% modulation), Impedance: 47 kilohms
Y: 1 Vp-p, 75 ohms, sync negative
PB: 0.7 Vp-p, 75 ohms
PR: 0.7 Vp-p, 75 ohms

VIDEO 5 (DTV) IN
Maximum scanning rate: 1080i
Y: 1 Vp-p, 75 ohms, negative or tri-level sync
PB: 0.7 Vp-p, 75 ohms
PR: 0.7 Vp-p, 75 ohms
or
G: 0.7 Vp-p
B: 0.7 Vp-p
R: 0.7 Vp-p
HD: 0.5–5 Vp-p, 2.2 kilohms
VD: 0.6–5 Vp-p, 2.2 kilohms
Note:
The VIDEO 5 (DTV) IN jacks are not compatible with a computer's 5BNC (R/G/B/HD/VD) video output connectors.
AUDIO (phono jacks): 500 mVrms (100% modulation), Impedance: 47 kilohms
SELECT OUT
VIDEO (phono jack): 1 Vp-p, 75-ohms unbalanced, sync negative
AUDIO (phono jacks): 470 mVrms (100% modulation), Impedance: 47 kilohms
AUDIO (VAR) OUT (phono jacks): 950 mVrms (100% modulation)
AUDIO (FIX) OUT (phono jacks): 500 mVrms (100% modulation)
CONTROL S IN/OUT: minijacks

Speaker
Front (Tweeter): 50 mm (2") × 2
Front (Woofer):
130 mm (5") × 2 (KP-53XBR300)
160 mm (6 3/8") × 2 (KP-61XBR300)
Front (Center): 100 mm (4") × 2
Rear: 70 mm (2 3/4") × 4

Speaker output
Front: 20 W × 2
Center: 20 W × 1
Rear: 10 W × 2

Power requirement
120 V AC, 60 Hz

Power consumption
In use (Max.): 300 W
In standby: 1 W

Dimensions (W/H/D)
1,322 × 1,439 × 621 mm (52 1/8 × 56 3/4 × 24 1/2 inches) (KP-53XBR300)
1,573 × 1,533 × 702 mm (62 × 60 3/8 × 27 3/4 inches) (KP-61XBR300)

Mass
127 kg (282 lbs) (KP-53XBR300)
160 kg (355 lbs) (KP-61XBR300)

Supplied accessories
Remote control RM-Y902 (1)
Batteries size AA (R6) (2)
Rear speakers (2)
Speaker cords (2)

Optional accessories
Connecting cables
RK-G34, RK-74A, RKG-69HG, VMC-10HG, VMC-720M, VMC-810S/820S, YC-15V/30V
U/V mixer EAC-66
Side rack
SU-53XBR200 (for KP-53XBR300)
SU-61XBR200 (for KP-61XBR300)

Design and specifications are subject to change without notice.

SAFETY CHECK-OUT

(US model only)

After correcting the original service problem, perfom the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, through functioning, show obvious signs of deterioration. Point them out to the customer and recom mend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the condition of the monopole antenna (if any). Make sure the end is not broken off, and has the plastic cap on it. Point out the danger of impalement on a broken antenna to the customer, and recommend the antenna's replacement.
8. Check the B+ and HV to see they are at the values specified. Make sure your instruments are accurate;be suspicious of your HV meter if sets always have low HV.
9. Check the antenna temminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5mA (500 microampers) . Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to usc these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. NearIy all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground;the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-l00 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)



Fig. A. Using an AC voltmeter to check AC leakage.



Fig. B. Checking for earth ground.

SELF DIAGNOSIS FUNCTION

1. Summary of Self-Diagnosis Function

- This device includes a self-diagnosis function.
- In case of abnormalities, the TIMER/STANDBY indicator automatically blinks. It is possible to predict the abnormality location by the number of blinks. The Instruction Manual describes blinking of the TIMER/STANDBY indicator.
- If the symptom is not reproduced sometimes in case of a malfunction, there is recording of whether a malfunction was generated or not. Operate the remote command to confirm the matter on the screen and to predict the location of the abnormality.

2. Diagnosis Items and Prediction of Malfunction Location

- When a malfunction occurs the TIMER/STANDBY indicator only blinks for one of the following diagnosis items. In case of two or more malfunctions, the item which first occurred blinks. If the malfunctions occurred simultaneously, the item with the lower blink count blinks first.
- The screen display displays the results regarding all the diagnosis items listed below. The display " 0 " means that no malfunctions occurred.

Diagnosis item	TIMER/STANDBY Indicater Number of blinks	Supposed malfunction	Condition	Self-diagnosis screen display, Diagnosis item: Results
• Power not ON	0	[Standby Power Supply System] F601 open. R607 open. Q601 short circuit [Main Power Supply System] IC601 and R612 are broken. VDR601 short-circuit	Cannot turn on the power. LED doesn't blink.	
+B OCP detection	2 times	Short circuit of power supply system in each circuit.	Goes to the standby mode Short circuit of +B line	2 : +B OCP 000
+B OVP detection	3 times	IC6005 is broken. IC6101 is broken.	Goes to the standby mode Malfunction of power supply circuit	3 : +B OVP 000
Vertical deflection stop	4 times	IC5004(V out) is broken. IC512 (VDSP) is broken.	Raster goes to one line horizontally.	4 : V Stop 000
Video out abnormality detection	5 times	Video out, IC7101, 7201, 7301 and others in C board circuit. Q510,516,524 (A board)	TIMER/STANDBY LED blinks approx. 30 seconds, and then blinks for the self diagnosis.	5 : AKB 000
Horizontal deflection stop	6 times	Q5013 (H OUT) is broken. IC507 (H Jungle) is broken.	Raster doesn't appear.	6 : H Stop 000
High voltage abnormality detection	7 times	Q8008 is broken	Raster doesu't appear.	7 : HV 000
Audio abnormality detection	8 times	IC2601, 2602, 2603 are broken. PS6103, 6104 are broken.	The sound is not out. Goes to the standby mode	8 : Audio 000

* : 000 the range of values for number of operations is 000-255. For 256 or higher there is no count up and the number remains at 255.

3. Blinking count display of TIMER/STANDBY indicator

* One blink is not used for self-diagnosis.



Release of TIMER/STANDBY indicator blinking.

- The TIMER/STANDBY indicator blinking display is released by turning OFF the power switch on the TV main unit or removing the plug from the power.

4. Self-diagnosis screen displays

- In cases of malfunctions where it is not possible to determine the symptom such as when the power goes off occasionally or when the screen disappears occasionally, there is a screen display on whether the malfunction occurred or not in the past (and whether the detection circuit operated or not) in order to allow confirmation.

<Screen Display Method>

- Quickly press the remote command button in the following order from the standby state.

DISPLAY ➡ Channel 5 ➡ VOL – ➡ POWER

⇧

Be aware that this differs from the method of entering the service mode (volume +).

Self-diagnosis screen display



5. Self-Diagnosis Screen Display

- The results display is not automatically cleared. In case of repairs and after repairs, check the self-diagnosis screen and be sure to return the results display to " 0 ".
- If the results display is not returned to " 0 " it will not be possible to judge a new malfunction after completing repairs.

<Method of Clearing Results Display>

1. Power off (Set to the standby mode)
2. DISPLAY ➡ Channel 5 ➡ VOL + ➡ POWER (Service Mode)
3. Channel 8 ➡ ENTER (Test reset = Factory preset condition)

<Method of Ending Self Diagnosis Screen>

- When ending the self-diagnosis screen completely, turn the power switch OFF on the remote commander or the main unit.

6. Self-diagnosis function operation

OCP Low B and +B line detect DET SHORT, and shut-down POWER ON RELAY.
Reset by turning power on/off.
In case of +B is loaded approx. 1.5A or more, microcomputer detects it via IC6102.

OVP In case of +B becomes approx. 150V or more, POWER ON RELAY shuts down and microcomputer detects it via IC6102.
Reset by turning power on/off just the same as OCP.

V Stop In case of V Drive disappeared, Q5005 detecs it and shut-down POWER ON RELAY. Microcomputer detects it and makes LED blinking.

AKB IK detection. Makes LED blinking in case of microcomputer doesn't detect IK returns of IC511 (CXA2101AQ) 30 seconds or more.

H Stop In case of H DRIVE is disappeared, Q5006 detects it and shut-down POWER ON RELAY shuts down.
Microcomputer receives H Stop data from Q5006 and makes LED blinking.

HV Stop In case of HV becomes 33KV or more. IC8006 and IC8010 detect it and shut-down POWER ON RELAY. Microcomputer makes LED blinking.

Audio In case of DC component overlaps the output of Audio Amp., POWER ON RELAY shuts down.
Microcomputer detects it and makes LED blinking.

Self-diagnosis block diagram



TABLE OF CONTENTS

Section Title Page

SELF DIAGNOSIS FUNCTION 4

1. GENERAL
Remote Control 9
Installing and Connecting the Projection TV 9
Basic Set Up 18
Using Your New Projection TV 19
Adjusting Your SET UP (menus) 23
Operating Video Equipment 34
Operating a Cable Box or DBS Receiver 35

2. DISASSEMBLY
2-1. Screen Frame Assy and HC Board Removal 37
2-2. Rear Board Removal 37
2-3. Main Bracket Removal 37
2-4. Service Position 37
2-5. G Board Removal 38
2-6. Terminal Board and U Board Removal 38
2-7. K Board Removal 38
2-8. BM, BR and BD Board Removal 38
2-9. BA Board Removal 39
2-10. DS Board Removal 39
2-11. A and D Board Removal 39
2-12. Reflection Mirror Removal 40
2-13. HA and HB Board Removal 40
2-14. Picture Tube Removal 41
2-15. High-Voltage Cable Installation and Removal 41

3. SET-UP ADJUSTMENTS
3-1. Screen Voltage Adjustment (Rough Alignment) 42
3-2. Focus Lens Adjustment 42
3-3. Screen (G2) Adjustment 42
3-4. Focus VR Adjustment 42
3-5. Deflection York Tilt Adjustment 43
3-6. 2-Pole Magnet Adjustment (Green, Red) 43
3-7. 4-Pole Magnet Adjustment 43
3-8. Defocus Adjustment (Blue) 43
3-9. Electrical Adjustment by Remote Commander 44
3-10. Registration Adjustment 50
3-11. Auto Registration Error Code List 53

4. SAFETY RELATED ADJUSTMENTS
4-1. HV Regulation Circuit Check and Adjustment 54
4-2. HV Hold Down Circuit Operation and Adjustment .. 54
4-3. +B OVP Confirmation 54

5. CIRCUIT ADJUSTMENTS
5-1. TV Input Sub Contrast Adjustment (MCD1 SCON) 55
5-2. Video Input Sub-Contrast Adjustment (MCD3-SCON) 55
5-3. P & P Sub-Contrast Adjustment (MCD2-SCON) 55
5-4. P & P Sub-Contrast Adjustment (MCD4-SCON) 55
5-5. 480 I Sub-Contrast Adjustment(MCP2-SCON) 56
5-6. Video 5 Input Sub-Contrast Adjustment (MCP3-scon) 56
5-7. Sub-HUE and Sub-Color Adjustment (MCD1-SHUE,SCOL) 56
5-8. Video Input Sub-HUE and Sub-Color Adjustment (MCD3-SHUE,SCOL) 56
5-9. P & P Sub-HUE and Sub-Color Adjustment (MCD2-SHUE,SCOL) 57
5-10. P & P Sub-HUE and Sub-Color Adjustment (MCD4-SHUE,SCOL) 57
5-11. P & P Sub Contrast Adjustment (MCD1-SCON) 57
5-12. P & P Sub Contrast Adjustment (MCD2-SCON) 57
5-13. Sub-HUE and Sub-Color Adjustment (SCD1-SHUE,SCOL) 58
5-14. Sub-HUE and Sub-Color Adjustment (SCD2-SHUE,SCOL) 58
5-15. Video 5 Input Sub-HUE and Sub-Color Adjustment (MCP3-SHUE,SCOL) 58
5-16. Display Position Adjustment (OSD-HPOS) 59
5-17. Caption Vision Position Adjustment (MCCD-CCDH) 59
5-18. Mid Display Position Adjustment (MID-HPOS) 59

6. DIAGRAMS
6-1. Block Diagram (1) 61
Block Diagram (2) 64
Block Diagram (3) 67
Block Diagram (4) 69
Block Diagram (5) 71
Block Diagram (6) 74
Block Diagram (7) 77
Block Diagram (8) 79
6-2. Frame Schematic Diagram 81
6-3. Circuit Boards Location 84
6-4. Printed Wiring Boards and Schematic Diagrams 84
• A (1/4)Board 89
• A (2/4)Board 93
• A (3/4)Board 97
• A (4/4)Board 100
• BA Board 104
• BM Board 107
• BR Board 115
• BD Board 120
• DS Board 123
• D(1/2) Board 127
• D(2/2) Board 130
• K Board 139
• CR Board 143
• CG Board 144
• CB Board 145
• ZR Board 147
• ZG Board 148
• ZB Board 150
• U Board 151
• HA Board 153
• HB Board 153
• HC Board 153
• G Board 157
6-5. Semiconductors 160

7. EXPLODED VIEWS
7-1. Cover (KP-53XBR300) 162
7-2. Cover (KP-61XBR300) 163
7-3. Chassis 164
7-4. Picture Tube 165

8. ELECTRICAL PARTS LIST 166

(CAUTION)

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.
THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK ⚠ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESECOMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFEOPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

(ATTENTION)

APRES AVOIR DECONNECTE LE CAP DE L'ANODE, COURTCIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTE SUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.

ATTENTION!!

AFIN D'EVITER TOUT RISQUE DELECTROCUTION PROVENANT D'UN CHÁSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DEPANNAGE.
LE CHÁSSIS DE CE RECEPTEUR EST DIRECTEMENT RACCORDÉ Á L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS ÁLA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE MAPQUE ⚠ SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIECES CONT D'UNEIMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÉCE EST INDIQUÉ DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIES DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.

SECTION 1
GENERAL

The operating instructions mentioned here are partial abstracts from the Operating Instructions Manual. The page numbers of the Operating Instruction Manual remain as in the manual. (Part no : 3-867-651-11)

Remote Control

In the instructions that follow, we will refer to the buttons on your remote control. Keep this flap unfolded and use this page for reference.

For a detailed explanation of most buttons, see "Watching the TV" on page 23.





Getting to know the buttons on the remote control

Names of the buttons on the remote control are presented in different colors to represent the available functions.

Button color

Transparent: Press to select the component you want to control; e.g. VTR (VCR)/MDP/DVD Player, DBS (Direct Broadcast Satellite)/CABLE, or projection TV.

Green: Buttons relevant to power operations, like turning the projection TV, DBS/CABLE, or VTR (VCR)/MDP/DVD Player on or off

Label color

White: TV/VTR (VCR)/MDP/DVD Player/DBS (Direct Broadcast Satellite)/CABLE operation buttons

Yellow: PIP, P&P, and CHANNEL INDEX operation buttons

Blue: DBS operation buttons

Pink: DVD Player operation buttons

* The SYSTEM OFF button does not function with this projection TV.

Installing and Connecting the Projection TV

Carrying Your Projection TV

Carrying the projection TV requires three or more people.

The projection TV has been equipped with casters for easy movement on a hard surface. Please move your projection TV using the casters.

Installing the Projection TV

Recommended viewing area (Horizontal)



Recommended viewing area (Vertical)



Mounting the Supplied Rear Speakers

For enhanced surround effect, connect the supplied rear speakers to your projection TV.

Connecting the rear speakers

Using the supplied speaker cords, connect REAR SPEAKER OUT L on your projection TV to the speaker terminal on one rear speaker, and connect REAR SPEAKER OUT R to the terminal on the other one.

(Rear of projection TV)



(continued)

Installation

For optimum surround effect, mount the rear speakers in the following places (as shown in the illustration):

- on a wall, a little higher or lower than the listener's ears.
- on a table, a little lower than the listener's ears.
- at the corner where the wall and ceiling meet.



Note:

- Match the colors of the speaker cords and the terminals. If the colors are reversed, sound will be distorted.

Connector Types

You may find it necessary to use some of the following connector types during set up.

Coaxial cable

Standard TV cable and antenna cable

Plug Type



Screw-on Type



S Video cable

High quality video cable for enhanced picture quality

Audio/Video cable

Video - Yellow
Audio (Left) - White
Audio (Right) - Red

Some DVD Players are equipped with the following three video connectors.

Y - Green
PB (CB, Cb or B–Y) - Blue
PR (CR, Cr or R–Y) - Red

Composite video cable for a DTV receiver



G/Y - Green
B/PB - Blue
R/PR - Red
HD - Gray
VD - Black

CONTROL S cable

Sony cable for CONTROL S connections. These features are exclusive to Sony products and allow greater control of all Sony equipment.

About the CONTROL S IN/OUT jacks

To control other Sony equipment with the projection TV's remote control, connect the CONTROL S IN jack of the equipment to the CONTROL S OUT jack on the projection TV with the CONTROL S cable.

To control the projection TV with a remote control for another Sony product, connect the CONTROL S OUT jack of the equipment to the CONTROL S IN jack on the projection TV with the CONTROL S cable.



Making Connections

Connecting Directly to a Cable or an Antenna

The connection you choose will depend on the cable found in your home. Newer homes will be equipped with standard coaxial cable (see **A**); older homes will probably have 300-ohm twin lead cable (see **B**); still other homes may contain both (see **C**).

A



B



C



Cable or antenna

This is the simplest connection. Connection is made directly from the cable or antenna to the projection TV.



Cable and antenna

You may find it convenient to use the following set up if your cable provider does not feature local channels that you are able to receive using an antenna.



Select Cable or ANT mode by pressing ANT on the remote control.

(continued)

Connecting a Cable Box

Some pay cable TV systems use scrambled or encoded signals that require a cable box* to view all channels.

Also, set CABLE to ON in the CHANNEL SET UP menu. (see page 37)



Note:

- If you will be controlling all channel selection through your cable box, you should consider using the CHANNEL FIX feature. (see "CHANNEL FIX" on page 37)

Cable box and cable

Some pay cable TV systems use scrambled or encoded signals requiring a cable box* only for certain channels (e.g. HBO, SHOWTIME, etc.)



For this set up, you can switch between scrambled channels (through your cable box), and normal (CATV) channels by pressing ANT on your remote control.

Notes:

- You may be able to program your Sony remote control to operate your cable box. (see "Operating a Cable Box or DBS Receiver" on page 54)
- During PIP, P&P, CHANNEL INDEX or FAVORITE CHANNEL viewing, the AUX input can only be viewed in the main picture.
- If you are connecting a cable box through the AUX input and would like to switch between the AUX and normal (CATV) input, you should consider using CHANNEL FIX. (see "CHANNEL FIX" on page 37)

Connecting an Antenna/Cable TV System to a VCR

1 Attach the coaxial cable from the incoming cable connection or antenna to IN on the VCR.

2 Using a coaxial cable, connect OUT on the VCR to VHF/UHF on the projection TV.

3 Using AUDIO and S VIDEO* cables, connect AUDIO and S VIDEO OUT on the VCR to AUDIO and S VIDEO IN on the projection TV (White-AUDIO Left, Red-AUDIO Right).

* If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

Note:

- If you are connecting a monaural VCR, connect only the single audio output to the left (MONO) input on the projection TV.

Disconnect all power sources before making any connections.



Connecting a VCR and Projection TV to a Cable Box

1 Connect the single (input) jack of the splitter to the incoming cable connection, and connect the other two (output) jacks (using the coaxial cable) to IN on the cable box and VHF/UHF on the projection TV.

2 Using a coaxial cable, connect OUT on the cable box to IN on the VCR.

3 Using AUDIO and S VIDEO* cables, connect AUDIO and S VIDEO OUT on the VCR to AUDIO and S VIDEO IN on the projection TV (White-AUDIO Left, Red-AUDIO Right).

* If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

Note:

- To view scrambled channels through the cable box, select the video input which the cable box is connected to by pressing TV/VIDEO.

Disconnect all power sources before making any connections.



Connecting a DTV (Digital Television) Receiver

Before connecting, be sure to read the Operating Instructions of the DTV receiver.

Connecting a DTV (digital television) receiver with the G/B/R/ HD/VD jacks

1 Attach the coaxial cable from the roof antenna to VHF/UHF on the DTV receiver.

2 Using a composite video cable for DTV receiver, connect G, B, R, HD and VD of VIDEO OUT on the DTV receiver to G, B, R, HD and VD respectively of VIDEO 5 (DTV) IN on the projection TV.
If the composite video cable is not available, proceed to step 2 in "Connecting a DTV receiver with the Y/PB/PR (component video input) jacks" on page 10.

3 Using an AUDIO cable, connect AUDIO OUT on the DTV receiver to AUDIO of VIDEO 5 (DTV) IN on the projection TV (White-AUDIO Left, Red-AUDIO Right).

4 Select the SET UP menu and set DTV INPUT to R.G.B. (see "DTV INPUT" on page 42)

5 Set the DOWN CONVERTER ON/OFF switch on the DTV receiver to OFF.

Disconnect all power sources before making any connections.



(continued)

Connecting a DTV (digital television) receiver with the Y/PB/PR (component video input) jacks

1 Attach the coaxial cable from the roof antenna to VHF/UHF on the DTV receiver.

2 Using three VIDEO cables, connect Y, P_B and P_R of COMPONENT VIDEO OUT on the DTV receiver to Y, P_B and P_R of VIDEO 5 (DTV) IN on the projection TV.

3 Using an AUDIO cable, connect LINE OUT on the DTV receiver to AUDIO of VIDEO 5 (DTV) IN on the projection TV (White-AUDIO Left, Red-AUDIO Right).

4 Select the SET UP menu and set DTV INPUT to Y PB PR. (see "DTV INPUT" on page 42)

5 Set the DOWN CONVERTER ON/OFF switch on the DTV receiver to OFF.

Note:

- Some DTV receiver terminals may be labeled differently. If so, connect as follows:
  Connect Y (green) to Y.
  Connect P_B (blue) to C_B, C_b or B-Y.
  Connect P_R (red) to C_R, C_r or R-Y.



Connecting a DBS (Direct Broadcast Satellite) Receiver

1 Connect the cable from the satellite antenna to the DBS receiver.

2 Attach the coaxial cable from the incoming cable connection or antenna to VHF/UHF on the projection TV.

3 Using AUDIO and S VIDEO cables, connect AUDIO and S VIDEO OUT on the DBS receiver to AUDIO and S VIDEO IN on the projection TV (White-AUDIO Left, Red-AUDIO Right).

Note:

- To view input from the DBS, select the video input which the DBS receiver is connected to by pressing TV/VIDEO on the remote control.



Connecting a DBS (Direct Broadcast Satellite) Receiver and VCR

1 Connect the cable from the satellite antenna to the satellite receiver.

2 Attach the coaxial cable from the incoming cable connection or antenna to VHF/UHF IN on the VCR.

3 Using a coaxial cable, connect VHF/UHF OUT on the VCR to VHF/UHF on the projection TV.

4 Using AUDIO and S VIDEO* cables, connect AUDIO and S VIDEO OUT on the DBS receiver to AUDIO and S VIDEO IN on the VCR.

5 Using AUDIO and S VIDEO* cables, connect AUDIO and S VIDEO OUT on the VCR to AUDIO and S VIDEO IN on the projection TV (White-AUDIO Left, Red-AUDIO Right).

* If your VCR or DBS receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

Note:

- To view input from the DBS or VCR, select the video input which your DBS receiver or VCR is connected to by pressing TV/VIDEO on the remote control.

Disconnect all power sources before making any connections.



Connecting a Camcorder

Use this connection to view a picture directly from your camcorder.

1 Using AUDIO and S VIDEO* cables, connect AUDIO and S VIDEO OUT on the camcorder to AUDIO and S VIDEO IN inside the drop-down panel on the front of the projection TV (White-AUDIO Left, Red-AUDIO Right**).

2 Press VIDEO 2 to select the video inputs from a camcorder.

* If your camcorder is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

**If you are connecting a monaural camcorder, connect only the single audio output to the left (MONO) input on the projection TV.

Disconnect all power sources before making any connections.



Connecting Two VCRs for Tape Editing

SELECT OUT gives you the ability to use a second VCR to record a program being played by the primary VCR or to perform tape editing and dubbing.

1 Connect the VCR intended for playback using the connection instructions on page 7 of this manual.

2 Using an AUDIO/VIDEO cable, connect AUDIO and VIDEO IN on the VCR intended for recording to AUDIO and VIDEO OUT of SELECT OUT on the projection TV.

Notes:

- Do not change the input signal while editing through SELECT OUT.
- When connecting a single VCR to the projection TV: if VCR LINE OUT is connected to VIDEO IN on the projection TV, do not connect the SELECT OUT on the projection TV to the VCR LINE INPUT (see right). Doing so will cause program interference and other viewing problems.
- You can select the output signal from SELECT OUT from the SET UP menu. (see "SELECT OUT" on page 40)



Connecting a DVD Player With S Video or Composite Video Output Connectors

Using an AUDIO and S VIDEO cables, connect AUDIO and S VIDEO IN on the projection TV to AUDIO and S VIDEO OUT on the DVD Player (White-AUDIO Left, Red-AUDIO Right).

Note:

- Since the high quality pictures on a DVD disc contain a lot of information, picture noise may appear. In this case, adjust NR in the VIDEO menu. (see "NR" on page 33)



Connecting a DVD Player With Component Video Output Connectors

1 Using an AUDIO cable, connect AUDIO R and L of LINE OUT on the DVD Player to AUDIO R and L of VIDEO 4 IN or VIDEO 5 (DTV) IN on the projection TV (White-AUDIO Left, Red-AUDIO Right).

2 Using three VIDEO cables, connect Y, PB and PR of the COMPONENT VIDEO OUT on the DVD Player to Y, PB and PR of VIDEO 4 IN or VIDEO 5 (DTV) IN on the projection TV.

Notes:

- If your DVD Player has 480p format capability, connect it to the Y, PB and PR of VIDEO 5 (DTV) IN on the projection TV.
- Some DVD Player terminals may be labeled differently. If so, connect as follows:
  Connect Y (green) to Y.
  Connect PB (blue) to CB, CB or B-Y.
  Connect PR (red) to CR, CR or R-Y.
- Since the high quality pictures on a DVD disc contain a lot of information, picture noise may appear. In this case, adjust NR in the VIDEO menu. (see "NR" on page 33)



Connecting an AV Receiver

For greater control of all audio and video equipment, connect an AV receiver.

1-2 Perform as described on page 7.

3 Using a VIDEO cable, connect VIDEO of VIDEO 1 IN on the projection TV to MONITOR OUT on the AV receiver.

4 Using an AUDIO/VIDEO cable, connect SELECT OUT on the projection TV to VIDEO 2 IN on the AV receiver.

5 Using an AUDIO/VIDEO cable, connect the video equipment to the AV receiver.

6 Select the SET UP menu and set SELECT OUT to TV OUT. (see "SELECT OUT" on page 40)

Note:

- You may want to use CHANNEL FIX to fix your TV's input to the AV receiver (VIDEO 1). (see "CHANNEL FIX" on page 37)



Connecting an Audio System

For more dynamic sound, connect an audio system to the projection TV.

1 Using an AUDIO cable, connect AUDIO (VAR) OUT on the projection TV to one of the unused Line inputs (e.g. Tape-2, AUX1, etc.) on the stereo (White-AUDIO Left, Red-AUDIO Right).

2 Set the stereo to the chosen Line input and use the AUDIO menu to switch the TV's speakers off. (see "SPEAKER" on page 34)

Note:

- You can adjust VOLUME, BASS, TREBLE and BALANCE through the projection TV on AUDIO (VAR) OUT only.

Disconnect all power sources before making any connections.



Connecting an Amplifier That Supports Dolby Pro Logic Decoder

If you use an amplifier with a Dolby Pro Logic decoder instead of the projection TV's audio system, you can still use the projection TV's center speaker.

1 Using the speaker cords (supplied with the amplifier), connect the speaker terminals on the amplifier to CENTER SPEAKER IN +/– on the projection TV.

2 Using an AUDIO cable, connect AUDIO (FIX) OUT on the projection TV to one of the unused Line inputs (e.g. Tape-2, AUX1, etc.) on the amplifier (White-AUDIO Left, red-AUDIO Right).

3 Set the amplifier to the chosen Line input and use the AUDIO menu to set "SPEAKER" to "CENTER IN" on the projection TV. (see "SPEAKER" on page 34)

Disconnect all power sources before making any connections.



Using the Remote Control

Inserting the batteries

Insert two size AA (R6) batteries (supplied) by matching the + and – on the batteries to the diagram inside the remote control's battery compartment.



Notes:

- Remove the batteries to avoid damage from possible battery leakage whenever you anticipate that the remote control will not be used for an extended period.
- Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater or where the humidity is high.
- Your remote control can be programmed to operate most video equipment. (see "Operating Video Equipment" on page 52)

Using the remote control joystick



The supplied remote control has a joystick which moves the on-screen selector in eight directions. In most cases, moving the joystick up, down, left or right will cause the selector to move in the selected direction.

In some cases, the selector may move in eight directions according to the function. Pressing down on the center of the joystick (⊕) will activate the selected item.

You may also move the joystick right to activate a selected item. (There are some exceptions to this option.)

Adjusting sliders

When menu items present a slider (▬ or ═), move the joystick up, down, left or right to adjust the setting.

On-line help/instructions

Several menu windows will provide prompts and instructions to assist you in navigating through the different functions.

Setting Up the Projection TV Automatically

The AUTO SET UP feature will allow you to set the on-screen language and set all receivable channels. The AUTO SET UP screen will appear every time you turn on the projection TV until you perform AUTO PROGRAM.

The AUTO SET UP feature does not apply for installations that use a cable box for all channel selection.

You can also set up the projection TV manually. (see "Using the CHANNEL SET UP Menu" on page 36)

Notes:

- Perform this function during the day, with the antenna and/or cable properly connected, to ensure that all available channels will be broadcasting and receivable.
- Before you perform AUTO SET UP again, make sure that the input from ANT (not AUX) is selected by pressing ANT until "AUX" does not appear next to the channel number.
- When you perform AUTO PROGRAM, your CHANNEL FIX and ON/OFF TIMER settings will be erased.
- When you perform AUTO PROGRAM, all the settings in the VIDEO and AUDIO menus are reset to the factory settings.

Using the buttons on the front panel and inside the drop-down panel on the projection TV:



1 Press POWER to turn on the projection TV.

2 Press SET UP inside the drop-down panel.

The AUTO SET UP screen appears.



3 Press CHANNEL + to select English, CHANNEL – to select Spanish or VOLUME + to select French.

The screen will change to reflect your choice.



4 Press VOLUME – to continue.



5 Press CHANNEL + to preset channels automatically.



"AUTO PROGRAM" appears and the projection TV starts scanning and presetting channels automatically. While scanning, the received channel will be displayed on the sub screen. When all the receivable channels are stored, the lowest numbered channel will be displayed. If the projection TV receives cable TV channels, CABLE is set to ON automatically.

(continued)

To perform AUTO SET UP again

- Press SET UP inside the drop-down panel on the projection TV, and perform steps 3-5 on page 21.
- Press CHANNEL +, CHANNEL – or VOLUME + to select a language.
- Press VOLUME – to restore factory settings ("CONTINUE TO AUTO PROGRAM?" will appear on the screen. Press CHANNEL + to execute or CHANNEL – to exit).
- Press SET UP to exit.

Adjusting the Convergence Automatically (FLASH FOCUS)

The projection tube image appears on the screen in three layers (red, green and blue). If they do not converge, the color is poor and the picture blurs.

Before you use your projection TV, be sure to adjust the convergence.

The FLASH FOCUS feature allows you to adjust the convergence automatically.

Tip

- It is recommended to perform FLASH FOCUS about 30 minutes after the projection TV is first turned on.



1 Receive a TV or cable TV program.

2 Press FLASH FOCUS.

The cross pattern appears and FLASH FOCUS begins to work. The adjustment is completed when the cross pattern becomes white.



To obtain an optimum convergence

The optimum convergence alignment varies with digital TV formats. Therefore, perform FLASH FOCUS periodically on conventional and digital TV programs. Also, whenever you find that the picture blurs, press FLASH FOCUS.

Note:

- You cannot perform any other functions until FLASH FOCUS has completed its cycle.
- If you perform any other operation while FLASH FOCUS is in progress, FLASH FOCUS operation is canceled.

Using Your New Projection TV

Watching the TV

Many TV features can be accessed directly through the remote control. The following will explain the function of some buttons found on your remote control.

Using the white labeled buttons for projection TV operations

REFER TO THE ILLUSTRATION OF THE REMOTE CONTROL ON THE INSIDE FRONT COVER OF THIS MANUAL AS YOU REVIEW THE FOLLOWING DESCRIPTIONS

TV (FUNCTION)

Activates the remote control for use with the projection TV.

ANT
— (AUX input)

Press to change between the VHF/UHF input and the AUX input. (for detailed connection information, see "Cable and antenna" on page 5 or "Cable box and cable" on page 6).

TV POWER

Turns the projection TV on and off. If a video input indication (e.g., VIDEO 1, VIDEO 2) appears on the screen, press TV/VIDEO until a channel number appears.

0 - 9 and ENTER

Use for direct channel selection. Press 0-9 to select a channel (for example, to select channel 10, press 1 and 0). The channel will change after 2 seconds, or you can press ENTER for immediate selection.

CH +/–

Press to scan through the channels (+ up or – down).

VOL +/–

Press to adjust the volume (+ up or – down).

JUMP

Press to alternate or jump back and forth between two channels. The projection TV will jump between the current channel and the last channel selected using the 0-9 buttons.

MUTING

Press to mute the sound. "MUTING" will appear on the screen and will dim three seconds later. To restore sound, press again or press VOL +.

FREEZE
— (yellow labeled button)

This is useful when you need to copy down information that appears on the TV's screen.

Press to freeze the picture.

Press again or press OFF to cancel.

If you select TWIN as a FREEZE MODE in the SET UP menu, you can freeze the desired scene and display it on the left while viewing the normal picture on the right. (see "FREEZE MODE" on page 41)

(continued)

Notes:
- The FREEZE button does not function with the picture from VIDEO 5 (DTV) IN.
- If the frozen picture mode is not canceled for more than an hour, the normal picture is resumed automatically.

SLEEP

Press repeatedly until the projection TV displays the approximate time in minutes (30, 60, or 90) that you want the projection TV to remain on before shutting off automatically.

Cancel by pressing until "SLEEP OFF" appears.

DISPLAY

Press to display the channel number, current time, channel caption (if set), and MTS mode (if SAP is selected). The SAP indication disappears and the other indications dim three seconds later.

To turn the display off, press DISPLAY again.

CC

Press repeatedly to scroll through available displays:

XDS (Extended Data Service)

Displays a network name, program name, program type, program length, program description, call letters and time of the show if the broadcaster offers this service.

Caption Vision

Displayed on the screen if the broadcaster offers this service. (see "CAPTION VISION" on page 40)

No display

"OFF" appears and the display is canceled.

TV/VIDEO

Press repeatedly to scroll through available video inputs:

TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4 and VIDEO 5

If you select SKIP as a VIDEO LABEL in the SET UP menu, your projection TV will skip the video input you selected. (see "VIDEO LABEL" on page 41)

MTS

Press to scroll through the Multi-channel TV Sound (MTS) options. (see "MTS" on page 33)

PICTURE MODE

Press PICTURE MODE repeatedly to directly choose one of five different video modes that best suits the program you are watching.

VIVID:

Select for enhanced picture contrast and sharpness.

STANDARD:

Select to display a standard picture for normal viewing environments.

MOVIE:

Select to display a finely detailed picture for low light environments.

GAME:

Select to display graphics such as a video game.

PRO (Professional):

Select to display a picture with minimum enhancements.

When you select each mode, you can also adjust the picture quality (such as BRIGHTNESS, COLOR, etc.) to suit your taste.

For details, see "MODE" on page 32.

Watching Digital TV

When you have connected the DTV receiver, you can enjoy digital TV programs. This projection TV is capable of receiving the 1080i, 480p and 480i digital TV formats.

Note:

This projection TV is not suitable for 720p digital TV format. When a 720p format signal is received, the picture will dim and "This signal is not available" is displayed on the screen.

To view a digital TV program

1 Connect the DTV receiver to VIDEO 5 (DTV) IN on the projection TV. (for details, see pages 9 and 10)

2 Press TV/VIDEO to select VIDEO 5. The digital TV format being received is displayed on the screen for three seconds.

Note:
- You cannot select VIDEO 5 unless a DTV receiver is connected.



3 Select a digital channel on the DTV receiver. For details, see the Operating Instructions of the DTV receiver.

4 Adjust the volume on the DTV receiver.

Tip

The optimum convergence alignment varies with digital TV formats. Whenever you find that the picture blurs, press FLASH FOCUS. (for details, see page 22)

Note:
- The FREEZE button does not function with digital TV programs.

If the picture appears stretched vertically

Select the SET UP menu and set ASPECT RATIO to 16:9. (for details, see page 42)



16:9 picture (ASPECT RATIO is set to 4:3.)

16:9 picture (ASPECT RATIO is set to 16:9.)

If the picture appears compressed vertically

Select the SET UP menu and set ASPECT RATIO to 4:3. (for details, see page 42)



4:3 compressed picture (ASPECT RATIO is set to 16:9)

4:3 picture (ASPECT RATIO is set to 4:3)

Watching Two Programs at One Time — PIP

The Picture-in-Picture (PIP) feature allows you to view two channels simultaneously, one in the full size "main" picture and one in a smaller "window" picture.

You can move the window picture to any location on the screen.

Note:

- The PIP feature is not available for the inputs from VIDEO 5 (DTV) IN.



Using the yellow labeled buttons for PIP operations

REFER TO THE ILLUSTRATION OF THE REMOTE CONTROL ON THE INSIDE FRONT COVER OF THIS MANUAL AS YOU REVIEW THE FOLLOWING DESCRIPTION

Tip

If you press RESET in PIP mode, the window picture will move to the bottom right (factory-preset location).

Press to display a window picture.

Each time you press this button, the picture size will change (1/4 → 1/9 → 1/16).

Press (OFF) to close the window picture.

POSITION

Press to change the location of the window picture (counterclockwise) around the main picture.

ACTIVE

Press to select either the main or window picture in order to change the TV channel or video source using the white labeled buttons below. The symbol "➧" (or "➧") will appear to indicate which picture's channel or input mode can be changed.

— (white labeled button)

To change the location of the window picture, move the joystick in any direction and release it when the picture is in the desired location.

TV/VIDEO *— (white labeled button)*

Press repeatedly to scroll through the available video inputs for the picture on which the symbol "➧" (or "➧") is displayed. (see "TV/VIDEO" on page 24)

CH or **0**-**9** or **JUMP** and **ENTER**

— (white labeled button)

Press to select the TV channel on which the symbol "➧" (or "➧") is displayed. (for details, see "Watching the TV" on page 23)

ANT *— (white labeled button)*

Press to change between the VHF/UHF input and the AUX input for the picture on which the symbol "➧" (or "➧") is displayed.

AUDIO

Press to alternate sound between the main picture and the window picture. The symbol "♪" will appear for a few seconds to indicate which picture's sound is being received.

FREEZE

This is useful when you need to copy down information that appears on the TV's screen.

Press to freeze the main and window pictures. The symbols "➧" and "♪" and the channel number disappear.

Press again to resume PIP viewing. Press (OFF) to cancel and resume normal TV viewing.

SWAP

Press to switch the audio and video of the main picture and the window picture.

Each time you press SWAP, the picture and sound of the two will be exchanged.

Press to access CHANNEL INDEX for direct channel selection. (see "Using CHANNEL INDEX" on page 29)

(OFF)

Press to cancel the PIP function and return to normal viewing.

Notes:

- If one of the pictures received through PIP is snowy, the entire screen may become unstable. In this case, erase the snowy channel. (see "CHANNEL SKIP" on page 36)
- If you select VIDEO 5 when the main picture is active, the window picture disappears and you can view the picture from VIDEO 5 (DTV) IN. When the window picture is active, you cannot view the picture from VIDEO 5 (DTV) IN.

Watching Two Programs at One Time — P&P (Twin View™)

The Picture-and-Picture (P&P) feature allows you to view two channels simultaneously, both in a reduced size screen. The main picture will appear on the right.

You can change the size of both pictures to suit your personal preference.

Note:

- The P&P feature is not available for the inputs from VIDEO 5 (DTV) IN.



(continued)

Using the yellow labeled buttons for P&P operations

REFER TO THE ILLUSTRATION OF THE REMOTE CONTROL ON THE INSIDE FRONT COVER OF THIS MANUAL AS YOU REVIEW THE FOLLOWING DESCRIPTIONS

Tip

If you press RESET in P&P mode, the right and left pictures will be reset to the same size (factory-preset size.)

Press to display right (main) and left pictures.

Press (OFF) to close the sub picture.

ZOOM IN (LEFT) (RIGHT) or
— (white labeled button)

Press and hold either RIGHT or LEFT to zoom in on the selected picture.
Release at the desired size. The other picture will be zoomed out simultaneously.

Moving the joystick right or left will activate the same function.



ACTIVE

Press to select either the right or left picture in order to change the TV channel or video source using the white labeled buttons below. The symbol "➔" (or "➔") will appear to indicate which picture's channel or input mode can be changed.

TV/VIDEO *— (white labeled button)*

Press repeatedly to scroll through the available video inputs for the picture on which the symbol "➔" (or "➔") is displayed. (see "TV/VIDEO" on page 24)

CH + or − or 0-9 or JUMP and ENTER
— (white labeled button)

Press to select the TV channel on which the symbol "➔" (or "➔") is displayed. (for details, see "Watching the TV" on page 23)

ANT *— (white labeled button)*

Press to change between the VHF/UHF input and the AUX input for the picture on which the symbol "➔" (or "➔") is displayed.

AUDIO

Press to alternate sound between the right and left pictures. The symbol "♪" will appear for a few seconds to indicate which picture's sound is being received.

FREEZE

This is useful when you need to copy down information that appears on the TV's screen.

Press to freeze both the right and left pictures.

Press again to resume P&P viewing or press (OFF) to cancel and resume normal TV viewing.

SWAP

Press to switch the audio and video of the right and left pictures.

Each time you press SWAP, the picture and sound of the two will be exchanged.

OFF

Press to cancel the P&P function and return to normal viewing.

Notes:

- If one of the pictures received through P&P is snowy, the entire screen may become unstable. In this case, erase the snowy channel. (see "CHANNEL SKIP" on page 36)
- If you select VIDEO 5 when the right picture is active, the left picture disappears and you can view the picture from VIDEO 5 (DTV) IN. When the left picture is active, you cannot view the picture from VIDEO 5 (DTV) IN.

Using CHANNEL INDEX

You can use the CHANNEL INDEX feature to display multiple channels and select one directly.

Channels used for CHANNEL INDEX will come directly from the TV's list of receivable channels (those set during AUTO PROGRAM or through the CHANNEL SET UP menu).

Note:

- The CHANNEL INDEX feature is not available for the inputs from VIDEO 5 (DTV) IN.

1 Press (▦).

The current channel will be reduced in size and displayed in the center of the screen in normal motion picture format. The first twelve receivable channels will appear one after another, clockwise, around the center picture. These small pictures are updated in intervals of one second. The channel number and channel caption (if set) on the second and later appearances will dim.



A cyan-colored frame will appear to indicate current channel selection.

2 Move the joystick in any direction to move the cyan frame to the picture that you wish to view, and press ⊕.



The selected channel will zoom in and move to the center, and the sound of that channel will be heard.



3 If you wish to view another channel, repeat step 2.

To view the normal picture of the selected channel, proceed to step 4.

4 Press ⊕.

The center picture will be enlarged for normal viewing.

(continued)

Notes:

- You cannot move the cyan frame until all of the surrounding pictures appear.
- The projection TV will continually update each of the surrounding pictures while the CHANNEL INDEX screen is displayed.
- Sound will only be heard from the center picture.
- If one of the pictures received through CHANNEL INDEX is snowy, the entire screen may become unstable. In this case, erase the snowy channel. (see "CHANNEL SKIP" on page 36)
- If you leave the CHANNEL INDEX screen displayed for an hour without any additional operation, CHANNEL INDEX is canceled and the normal picture reappears.

Using the yellow labeled buttons for CHANNEL INDEX operations

REFER TO THE ILLUSTRATION OF THE REMOTE CONTROL ON THE INSIDE FRONT COVER OF THIS MANUAL AS YOU REVIEW THE FOLLOWING DESCRIPTIONS

Press to display the next twelve receivable channels.

Press to cancel the current operation and return to normal TV viewing.

Press to freeze the center picture.

Press again to cancel the frozen picture and resume normal center picture viewing.

Using the white labeled buttons for center picture operations

REFER TO THE ILLUSTRATION OF THE REMOTE CONTROL ON THE INSIDE FRONT COVER OF THIS MANUAL AS YOU REVIEW THE FOLLOWING DESCRIPTIONS

Press to scroll the center picture through the video inputs.

The surrounding channels will not change.

Note:

- Even if the DTV receiver is connected to VIDEO 5 (DTV) IN, the VIDEO 5 input will be skipped.

Press to switch the center picture between the VHF/UHF input and the AUX input.



Press to select a channel for the center picture. (for details, see "Watching the TV" on page 23)

Adjusting Your SET UP (menus)

Learning Menu Selection

Use the MENU button to access a menu and use the joystick to alter the settings. Use the following example to learn how to modify settings.

1 Press the MENU button.

The main menu appears.



2 Move the joystick up or down to highlight the desired menu and press ⊕ (press down on the center of the joystick) to activate it.



You may also move the joystick right to activate your selection.

3 Move the joystick up or down to highlight the desired option.



4 Press ⊕ (press down on the center of the joystick).

Options for your selection (Pop-up menu or Adjusting menu) will be displayed.

Pop-up menu



Adjusting menu



5 Move the joystick up or down to make your selection and press ⊕ to activate it.

The previous screen will reappear.



Some adjustment menus may require further operations. For details, see each menu option.

To return to the previous screen (except for the slider adjustment menus), choose ↩ at the bottom of the menu and press ⊕ or move the joystick left.

6 Once you have completed all menu corrections, press MENU to exit the menu screens.

To exit from the menus at any time

Press MENU.

Using the VIDEO Menu



For detailed information on using the remote control to modify menu settings, refer to "Learning Menu Selection" on page 31.

To select the VIDEO menu:

Display ➡ Highlight ➡ Select



MODE
— Customized picture viewing

You can choose one of five different video modes that best suits the program you are watching. You can also adjust the picture quality (such as BRIGHTNESS, COLOR, etc.) for each MODE to suit your taste.

First select each MODE individually before adjusting the picture quality.

VIVID:
Select for enhanced picture contrast and sharpness.

STANDARD:
Select to display a standard picture for normal viewing environments.

MOVIE:
Select to display a finely detailed picture for low light environments.

GAME:
Select to display graphics such as a video game.

PRO (Professional):
Select to display a picture with minimum enhancements.

Press PICTURE MODE on the remote control for direct selection of a MODE setting.

PICTURE
— Picture Adjustment

Adjust slider right (up) to increase picture contrast.

Adjust slider left (down) to decrease picture contrast.

BRIGHTNESS
— Picture Adjustment

Adjust slider right (up) to brighten the picture.

Adjust slider left (down) to darken the picture.

COLOR
— Picture Adjustment

Adjust slider right (up) to increase color intensity.

Adjust slider left (down) to decrease color intensity.

HUE
— Picture Adjustment

Adjust slider right (up) to increase the green tones.

Adjust slider left (down) to increase the red tones.

SHARPNESS
— Picture Adjustment

Adjust slider right (up) to sharpen the picture.

Adjust slider left (down) to soften the picture.

TRINITONE
— White Intensity Adjustment

HIGH:
Select to give the white colors a blueish tint.

MEDIUM:
Select to give the white colors a neutral tint.

NTSC STD:
Select to give the white colors a reddish tint.

NR
— Picture Noise Reduction

Select **ON** to reduce picture noise.

Select **OFF** to cancel the feature.

NR can be set separately from the MODE settings of the VIDEO menu.

DYNAMIC PICTURE
— Black Intensity Adjustment

Select **ON** to emphasize the black level and to produce a bolder dynamic picture.

Select **OFF** to cancel the feature.

To restore the factory settings

Press RESET on the remote control while the VIDEO menu is selected. To restore each MODE to the factory setting, press RESET after selecting the mode to be reset.

NR is not reset to the factory setting even if you press RESET.

Using the AUDIO Menu



For detailed information on using the remote control to modify menu settings, refer to "Learning Menu Selection" on page 31.

To select the AUDIO menu:

Display ➡ Highlight ➡ Select



TREBLE
— Sound Adjustment

Adjust slider right (up) to increase high pitched sounds.

Adjust slider left (down) to decrease high pitched sounds.

BASS
— Sound Adjustment

Adjust slider right (up) to increase low pitched sounds.

Adjust slider left (down) to decrease low pitched sounds.

BALANCE
— Sound Adjustment

Adjust slider right (up) to emphasize right speaker volume.

Adjust slider left (down) to emphasize left speaker volume.

MTS
— Enjoy stereo, bilingual and mono programs

STEREO:
Select for stereo reception when viewing a program broadcast in stereo.

SAP:
Select to listen to a bilingual broadcast. (non-SAP programs will be muted when this feature is selected)

MONO:
Select for mono reception. (use to reduce noise during stereo broadcasts)

Quick MTS access:

Press MTS on your remote control to cycle through the MTS options as follows: (STEREO ➡ SAP ➡ MONO ➡ STEREO)

(continued)

SPEAKER
— Custom selection of audio output source

ALL ON:
Select to listen to the sound from the projection TV speakers alone.

L/R OFF:
Select to turn off the projection TV left and right speakers and listen to the left and right channel sounds through a separate audio system's speakers.

ALL OFF:
Select to turn off the projection TV speakers and listen to the projection TV's sound only through an external audio system's speakers.

CENTER IN:
Select to use the projection TV center speaker as center speaker when you connect an amplifier with a Dolby Pro Logic decoder. (see "Connecting an

DD 3 STEREO:
Produces a dynamic three dimensional sound without using the rear speakers. The sound of the rear channel is output from the front speakers.

SIMULATED:
Adds a surround-like effect to mono programs.

LIVE:
Produces surround effects with the atmosphere of a concert hall.

GAME:
Produces maximum audio impact. Most effective for video games.

OFF:
Normal stereo or mono reception.

SURROUND LEVEL
— Speaker volume adjustment for

Adjusting the Speaker Volume for Customized Surround Mode

After you set SURROUND to one of the modes, adjust the volume of the front, center and rear speakers to the same level so that the projection TV's sound will be even and natural. For DDPRO LOGIC and DD3 STEREO, adjust the speaker volume using the test tone feature.

Adjusting the speaker volume

1 Select SURROUND LEVEL from the AUDIO menu. (see pages 33 and 34)



3 Move the joystick up or down to select PARENTAL LOCK, and press ⊕.



4 Move the joystick up or down to select OFF, and press ⊕.



5 Press MENU to exit the menu.

To unlock the PARENTAL CONTROL feature temporarily

When you select a PARENTAL CONTROL program, no sound or picture except for a channel number will appear. The 🔒 indicator is displayed. To view the program, follow the steps below.

1 Press ENTER to display the "Password" screen.

2 Enter your password using the 0–9 buttons. PARENTAL CONTROL will be canceled (PARENTAL LOCK set to OFF) until you turn your projection TV off.

Selecting a Custom Rating in U.S.A.

If you want to select the ratings to be blocked from CUSTOM once you have activated the PARENTAL CONTROL feature (page 42), follow the procedure below.

For a detailed description of each rating, see pages 49 and 50.

1 Select PARENTAL CONTROL from the SET UP menu. (see page 39)



2 Enter your four digit password using the 0–9 buttons.

The PARENTAL CONTROL menu appears.

Make sure that COUNTRY is set to U.S.A.

3 Move the joystick up or down to select RATING, and press ⊕.



4 Move the joystick up or down to select CUSTOM, and press ⊕.

First, select a TV rating.

5 Move the joystick up or down to select TV RATING, and press ⊕.



6 Move the joystick up or down to select the TV rating to be blocked, and press ⊕.



7 Move the joystick up or down to select 🔒, and press ⊕.

The 🔒 indicator automatically appears beside the selected rating and all "higher" ratings, indicating that the programs that match the ratings will be blocked.



Some ratings have additional content ratings called "extenders." The extenders are defined as follows: D (sexually suggestive Dialog), FV (Fantasy Violence), L (coarse Language), S (Sexual situations) and V (Violence). By setting the extenders, you can define additional viewing limits. For more details of extenders, see page 50.

All of the extenders included in the selected ratings will be blocked. If you wish to allow any of them to be viewed, go to step 8.

8 Move the joystick left or right to select the extender to be viewed, and press ⊕.



9 Move the joystick up or down to select "–," and press ⊕.

"–" appears beside the selected extender, indicating that the programs that match the extender can be viewed.

If you select 🔒, 🔓 is displayed to show that the programs that match the extender will be blocked again.



10 Repeat steps 8 and 9 for other extenders.

All programs that match the ratings you select and higher, except for the extenders that were canceled, will be blocked.

11 After setting of the TV rating is complete, move the joystick up or down to select ↩, and press ⊕.



Second, select a movie rating.

12 Move the joystick up or down to select MOVIE RATING, and press ⊕.



(continued)

13 Move the joystick up or down to select the movie rating to be blocked, and press ⊕.



14 Move the joystick up or down to select 🔒, and press ⊕.

The 🔒 indicator automatically appears beside the selected rating and all "higher" ratings, indicating that the programs that match the ratings will be blocked.



15 Press MENU to exit the menu.

To block TV programs and/or movies for which a rating signal is not given (NR and N/A)

For a description of the NR and N/A ratings, see page 49.

1 Perform steps 1–4 of "Selecting a Custom Rating in U.S.A." on page 44.

2 Move the joystick up or down to select UNRATED, and press ⊕.



3 Move the joystick up or down to select the type of programs to be blocked, and press ⊕.



To block ...	Select ...
No program (to view any unrated TV program and movie)	VIEW ALL
Unrated TV programs	TV
Unrated movies	MOVIE
Unrated TV programs and movies	BOTH

4 Press MENU to exit the menu.

Selecting a Custom Rating in Canada

If you want to select the ratings to be blocked from CUSTOM once you have activated thePARENTAL CONTROL feature (page 42), follow the procedure below.

For a detailed description of each rating, see "Ratings in Canada" on pages 50 and 51.

1 Select PARENTAL CONTROL from the SET UP menu. (see page 39)



2 Enter your four digit password using the 0-9 buttons.

The PARENTAL CONTROL menu appears. Make sure that COUNTRY is set to CANADA.

3 Move the joystick up or down to select RATING, and press ⊕.



4 Move the joystick up or down to select CUSTOM, and press ⊕.



5 Move the joystick up or down to select the rating you want to block, and press ⊕.

The selected rating appears.

Canadian English Rating



Canadian French Rating



U.S. TV Rating



6 Move the joystick up or down to select the TV rating to be blocked, and press ⊕.

Example: Canadian English Rating



(continued)

7 Move the joystick up or down to select 🔒, and press ⊕.

The 🔒 indicator automatically appears beside the selected rating and all "higher" ratings, indicating that the programs that match the ratings will be blocked.



Some U.S. TV ratings have additional content ratings called "extenders," such as D, FV, L, S and V. By setting the extenders, see steps 7 to 10 of "Selecting a Custom Rating in U.S.A." on pages 44 to 46. For more details of extenders, see page 50.

All of the extenders included in the selected ratings will be blocked. If you wish to allow any of them to be viewed, go to step 8 on page 45.

8 Press MENU to exit the menu.

Changing the Password

1 Select PARENTAL CONTROL from the SET UP menu. (see page 39)



2 Enter your four digit password using the 0–9 buttons.

The PARENTAL CONTROL menu appears.

3 Move the joystick up or down to select CHANGE PASSWORD, and press ⊕.



4 Enter a new four digit password using the 0–9 buttons.



5 Enter the password set in step 4 again to confirm.

If you entered it incorrectly, "Password incorrect" appears.

Re-enter the correct password.

6 Press MENU to exit the menu.

If you have forgotten your password

In step 2 of "Changing the Password," enter the master password "4357" (corresponding to "HELP" on a phone number pad). You can then store a new password.

Notes:

- If you entered "4357" as your password the first time, you cannot store a new password. (see step 2 of "Activating the PARENTAL CONTROL feature" on page 42)
- When you select a PARENTAL CONTROL program and the 🔒 indicator is displayed on the screen, you cannot view that program even if you enter "4357." (see "To unlock the PARENTAL CONTROL feature temporarily" on page 44)

What the Ratings Mean

Rating in U.S.A.

Sony's predetermined ratings

These are original ratings that Sony predetermined according to the viewer's age. Each rating allows you to view the certain programs, as follows.

See the center column to page 50 for a description of TV and movie ratings.

CHILD:

Suitable for children under the age of 6.
Viewable U.S. movie ratings: G, NR, and N/A
Viewable U.S. TV ratings: TV-Y, TV-G, and TV-NR

YOUTH:

Suitable for children aged 7 and older.
Viewable U.S. movie ratings: G, PG, NR, and N/A
Viewable U.S. TV ratings: TV-Y, TV-Y7, TV-G, TV-PG, and TV-NR

YOUNG ADULT:

Suitable for children aged 13 and older.
Viewable U.S. movie ratings: G, PG, PG-13, NR, and N/A
Viewable U.S. TV ratings: TV-Y, TV-Y7, TV-G, TV-PG, TV-14, and TV-NR

U.S. movie ratings

U.S. movie ratings are for movies (including those shown on TV) rated according to the Motion Picture Association of America (MPAA) Guidelines.

G (General Audiences—All Ages Admitted):

In G-rated films no strong words are used, the violence is at a minimum, nudity and sex scenes are not present, nor is there any drug use.

PG (Parental Guidance Suggested. Some Material May Not Be Suitable For Children):

This is a film which may need to be monitored first by parents.

PG-13 (Parents Strongly Cautioned. Some Material May Be Inappropriate For Children Under 13):

Parents are alerted to be very careful about the attendance of their under-teenage children when viewing.

R (Restricted, Under 17 Require Accompanying Parent Or Adult Guardian):

This film includes hard language, tough violence, nudity, drug abuse or other elements of concern.

NC-17 or X (No One 17 Or Under Admitted.):

This is a film that most parents would consider not suitable for children aged 17 and under. There may be violence, sex, abberrational behavior, drug abuse or other elements of concern.

NR (Not Rated):

This is a film that a producer has not rated, intending to have his film widely released.

N/A (Not Applicable):

This is a film that a producer considers outside the scope of the MPAA ratings.

Note:

- NR and N/A ratings are shown together as UNRATED in the menu.

U.S. TV ratings

U.S. TV ratings are for TV programs rated according to the U.S. Television Parental Guidelines.

TV-Y (All Children):

This program is designed for young children aged 2–6 and is appropriate for all children.

TV-Y7 (Directed to Older Children):

This program is designed for children aged 7 and above. Themes and elements in this program may include mild fantasy violence or slapstick violence, or may frighten children under the age of 7.

TV-G (General Audience):

Most parents would find this program suitable for all ages. It contains little or no violence, no strong language and little or no sexual dialog or situations.

TV-PG (Parental Guidance Suggested):

This program contains some material that parents may find unsuitable for younger children.

(continued)

TV-14 (Parents Strongly Cautioned):
This program contains some material that many parents would find unsuitable for children under the age of 14.

TV-MA (Mature Audience Only):
This program is specifically designed to be viewed by adults and therefore may be unsuitable for children under the age of 17.

TV-NR (Not Rated/Unrated):
This is a program broadcast without any rating, such as news, news flashes or sports.

Note:
- The TV-NR rating is shown as UNRATED in the menu.

About the extenders of U.S. TV ratings

TV-Y7, TV-PG, TV-14 and TV-MA ratings have additional content ratings called "extenders" to define additional viewing limits. The extenders are defined as follows:

D (sexually suggestive Dialog):
Programs containing suggestive dialog, or sexual innuendo

FV (Fantasy Violence):
Programs containing cartoon violence occurring in TV-Y7 programs only

L (coarse Language):
Programs containing coarse language

S (Sexual situations):
Programs containing sexual content

V (Violence):
Programs containing violence

There may be some profanity, violence or brief nudity in these programs.

Ratings in Canada

Sony's predetermined ratings

These are original ratings that Sony predetermined according to the viewer's age. Each rating allows you to view the certain programs, as follows.

See the right column to page 51 for a description of each rating.

CHILD:
Suitable for children under the age of 7.

Viewable Canadian English Language ratings: C and G

Viewable Canadian French Language ratings: G

Viewable U.S. TV ratings: TV-Y, TV-G, and TV-NR

YOUTH:
Suitable for children aged 8 and older.

Viewable Canadian English Language ratings: C, G, C8+ and PG

Viewable Canadian French Language ratings: G and 8 ans+

Viewable U.S. TV ratings: TV-Y, TV-Y7, TV-G, TV-PG, and TV-NR

YOUNG ADULT:
Suitable for children aged 14 and older.

Viewable Canadian English Language ratings: C, G, C8+, PG and 14+

Viewable Canadian French Language ratings: G, 8 ans+, 13 ans+

Viewable U.S. TV ratings: TV-Y, TV-Y7, TV-G, TV-PG, TV-14, and TV-NR

Canadian English Language ratings

The Canadian English Language Ratings are for TV programs in English broadcast in Canada.

C (Programming intended for children under age 8):
There will be no realistic scenes of violence or no offensive language, nudity or sexual content. Careful attention is paid to themes, which could threaten children's sense of security and well-being.

C8+ (Programming generally considered acceptable for children 8 years and over to watch on their own):
Violence will not be portrayed as the preferred, acceptable, or only way to resolve conflict; or encourage children to imitate dangerous acts which they may see on television. There will be no profanity, nudity or sexual content.

G (General Audience):
Will contain very little violence, either physical or verbal or emotional. There may by some inoffensive slang, no profanity and no nudity.

PG (Parental Guidance):
Programming intended for a general audience but which may not be suitable for younger children. Parents may consider some content inappropriate for unsupervised viewing by children aged 8 – 13.

14+ (Programming contains themes or content which may not be suitable for viewers under the age of 14):
Parents are strongly cautioned to exercise discretion in permitting viewing by pre-teens and early teens.

18+ (Adult):
May contain violence integral to the development of the plot, character or theme, intended for adult audiences. May contain graphic language and explicit portrayals of nudity and/or sex.

E (Exempt):
Exempt programming includes: news, sports documentaries and other information programming: talk shows, music videos, and variety programming.

Note:
- The E (Exempt) rating is not shown in the menu.

Canadian French Language ratings

The Canadian French Language Ratings are for TV programs in French broadcast in Canada.

G (General):
Programming intended for audience of all ages. Contains no violence, or the violence it contains is minimal or is depicted appropriately with humor or caricature or in an unrealistic manner.

8 ans+ (8+ General - Not recommended for young children):
Programming intended for a broad audience but contains light or occasional violence that could disturb young children. Viewing with an adult is recommended for young children (under the age of 8).

13 ans+ (Programming may not suitable for children under the age of 13):
Viewing with an adult is strongly recommended for children under 13.

16 ans+ (Programming is not suitable for children under the age of 16):
Contains frequent scenes of violence or intense violence.

18 ans+ (Programming restricted to adults):
Contains constant violence or scenes of extreme violence.

E (Exempt):
Exempt programming.

Note:
- The E (Exempt) rating is not shown in the menu.

Operating Video Equipment

Setting the Manufacturer's Code

You can use the supplied remote control to operate Sony or non-Sony video equipment that has an infrared sensor.

1 Set the VTR 1/2/3/DVD/MDP switch to the input through which you would like to access your video equipment.

The following Sony equipment is preset to each input as shown below:

VTR1 (303)	Beta, ED Beta VCRs
VTR2 (302)	8 mm VCR
VTR3 (301)	VHS VCR
DVD/MDP (751)	DVD Player

2 Press CODE SET, DVD/VTR (FUNCTION), and the 0-9 buttons to enter the manufacturer's code number (see the following chart), then press ENTER.

For example, to operate a Sony 8mm VCR:



If the remote control doesn't work

- See the tips on page 54.

VCR manufacturer code numbers

Manufacturer	Code
Sony	301, 302, 303
Aiwa	338
Admiral (M. Ward)	327
Audio Dynamic	314, 337
Bell & Howell (M. Ward)	330, 343
Broksonic	319, 317
Canon	309, 308
Citizen	332
Craig	315, 302, 332
Criterion	315
Curtis Mathis	304, 338, 309
Daewoo	341, 312, 309
DBX	314, 336, 337
Dimensia	304
Emerson	319, 320, 316, 317, 318, 341
Fisher	330, 334, 335, 333
Funai	338
General Electric	329, 304, 309
Go Video	340, 339, 322
Goldstar	332
Hitachi	306, 304, 305, 338
Instant Replay	309, 308
JC Penney	309, 305, 304, 330, 314, 336, 337
JVC	314, 336, 337
Kenwood	314, 336, 332, 337
LXI (Sears)	332, 305, 333, 334, 330, 335, 338
Magnavox	308, 309, 310
Marantz	314, 336, 337
Marta	332
Memorex	309, 335
Minolta	305, 304
Mitsubishi/MGA	323, 324, 325, 326
Multitech	325, 338, 321
NEC	314, 336, 337
Olympic	309, 308
Optimus	327
Panasonic	308, 309, 306, 307
Pentax	305, 304
Philco	308, 309
Philips	308, 309, 310
Pioneer	308
Quasar	308, 309, 306
RCA/PROSCAN	304, 305, 308, 309, 311, 329, 312, 313, 310
Realistic	309, 330, 328, 335, 324, 338
Sansui	314
Singer	315
Samsung	322, 313, 321
Sanyo	330, 335
Scott	312, 313, 321, 335, 323, 324, 325, 326
Sharp	327, 328
Shintom	315
Signature 2000 (M. Ward)	338, 327
Sylvania	308, 309, 338, 310
Symphonic	338
SV2000	338
Tashiro	332
Tatung	314, 336, 337
Teac	314, 336, 338, 337
Technics	309, 308
Teknica	342, 338
Toshiba	312, 311
Wards	327, 328, 335, 331, 332
XR-1000	315
Yamaha	330, 314, 336, 337
Zenith	331

MDP manufacturer code numbers

Manufacturer	Code
Sony	701
Panasonic	704
Pioneer	702

DVD Player manufacturer code numbers

Manufacturer	Code
Sony	751
Panasonic	753
Pioneer	752
RCA	755
Toshiba	754

Tips

- *In some rare cases, you may not be able to operate your non-Sony video equipment with the supplied remote control. In this case, please use the equipment's own remote control.*
- *When you remove the batteries, the code number may revert to the factory setting.*

Operating video equipment

1 Set the VTR1/2/3/DVD/MDP switch to the input through which you would like to access your video equipment.

2 Press DVD/VTR (FUNCTION).

3 Use the VCR/DVD/MDP operation buttons indicated in the following tables.

Operating a VCR using the remote control

To turn On/Off	Press DVD/VTR (POWER). [Green Button]
To select a channel	Press the 0 – 9 buttons.
To change channels	Press CH +/–.
To record	Press ⏺ (REC) while pressing ▭ (lower).
To play	Press ▶.
To stop	Press ■.
To fast forward	Press ▶▶.
To rewind the tape	Press ◀◀.
To pause	Press ❚❚. Press again to resume normal playback.
To search the picture forward or backward	Press ▶▶ or ◀◀ during playback. Release to resume normal playback.
To change input mode	Press TV/VTR.

Operating an MDP using the remote control

To turn On/Off	Press DVD/VTR (POWER). [Green Button]
To play	Press ▶.
To stop	Press ■.
To pause	Press ❚❚. Press again to resume normal playback.
To search the picture forward or backward	Press ▶▶ or ◀◀ during playback. Release to resume normal playback.
To search a chapter forward or backward	Press CH +/–.

Operating a DVD Player using the remote control

To turn On/Off	Press DVD/VTR (POWER). [Green Button]
To play	Press ▶.
To stop	Press ■.
To pause	Press ❚❚. Press again to resume normal playback.
To step through different tracks of an audio disc	Press ▶▶ to step forward or ◀◀ to step backward.
To step through different chapters of a video disc	Press CH+ to step forward or CH– to step backward.
To display the Title menu	Press TITLE.
To display the DVD menu	Press DVD MENU.
To select tracks directly	Press 0-9 buttons.
To display the menu (Set up)	Press MENU.

Operating a Cable Box or DBS Receiver

Setting the Manufacturer's Code

You can program the supplied remote control to operate a cable box or DBS receiver.

Press CODE SET, DBS/CABLE (FUNCTION), and the 0-9 buttons to enter the manufacturer's code number (see the following chart), then press ENTER.

For example, to operate a Sony DBS receiver:



Manufacturer code numbers (cable box)

Manufacturer	Code
Gemini	233
Hamlin/Regal	222, 223, 224, 225, 226
Jerrold/G. I.	201, 202, 203, 204, 205, 222, 206, 207, 208, 218
Macom	230, 231, 232
Magnavox	234
Oak	227, 228, 229
Panasonic	219, 220, 221
Philips	236, 237, 238, 239, 240, 241
Pioneer	214, 215
Samsung	235
Scientific Atlanta	209, 210, 211
Tocom	216, 217
Zenith	212, 213

Manufacturer code numbers (DBS receiver)

Manufacturer	Code number
Sony	801 (preset code for remote control)
General Electric	802
RCA/PROSCAN	802

Operating a cable box or DBS receiver

1 Press DBS/CABLE (POWER) [Green Button] to turn on/off the cable box or DBS receiver.

2 Press DBS/CABLE (FUNCTION).

3 For other operations, refer to the operating instructions that come with the equipment. Blue-labeled buttons such as the GUIDE button can be used only with a DBS receiver.

If the remote control doesn't work

- Try repeating the set up procedures using the other codes listed for your equipment.

To operate the projection TV

Press TV (FUNCTION). Then use the projection TV control buttons to control the projection TV.

Tips

- *If more than one code number is listed, try entering them one by one until you come to the correct code for your equipment.*
- *If you enter a new code number, the code number you previously entered at that setting is erased.*
- *In some rare cases, you may not be able to operate your equipment with the supplied remote control. In this case, use the equipment's own remote control unit.*
- *Whenever you remove the batteries — to replace them, for example — if too much time is taken, the code numbers may revert to the factory setting and must be reset.*

Additional Information

Troubleshooting

If, after reading the following instructions, you have additional questions related to the use of your Sony projection TV, please call one of the following numbers (English only).
Customers in the continental United States contact the Direct Response Center at:
1-800-222-SONY (7669)
Customers in Canada contact the Customer Relations Center at:
(416) 499-SONY (7669)

The picture turns off and the TIMER/ STAND BY indicator on the front panel flashes (self-diagnosis function)

- The projection TV is equipped with a self-diagnosis function. If there is a problem with your projection TV, the TIMER/STAND BY indicator on the front panel will flash repeatedly. Counting the number of flashes helps you inform qualified Sony personnel of the projection TV's condition.



1 Count how many times the TIMER/STAND BY indicator flashes in total. It flashes twice at 3 seconds' intervals. If, for example, the indicator flashes twice, stops flashing for 3 seconds, and flashes twice again, that counts as twice.

2 Press POWER on the projection TV to turn it off, then inform qualified Sony personnel or the above Direct Response Center of the number of flashes.

No picture (screen not lit), no sound

- Make sure the power cord is plugged in.
- Operate with the buttons on both the projection TV and the remote control.
- Check to see if the TV/VIDEO setting is correct: when watching TV, set to TV, and when watching video tapes, set to VIDEO 1, 2, 3, 4 or 5.
- Try another channel. *It could be station trouble.*
- Perform AUTO SET UP again using the SET UP button to return to the factory preset condition. (see "To perform AUTO SET UP again" on page 22)
- The PARENTAL CONTROL feature is activated. (see "Using the PARENTAL CONTROL Feature" on page 42)

Remote control does not operate

- Batteries could be weak. Replace the batteries.
- Press TV (FUNCTION) when operating your projection TV.
- Make sure the projection TV's power cord is connected securely to the wall outlet.
- Locate the projection TV at least 3-4 feet away from fluorescent lights.
- Check the polarity of the batteries.

Dark, poor or no picture (screen lit), good sound

- Adjust PICTURE in the VIDEO menu. (see "PICTURE" on page 32)
- Adjust BRIGHTNESS in the VIDEO menu. (see "BRIGHTNESS" on page 32)
- Check antenna/cable connections.
- Perform AUTO SET UP again using the SET UP button to return to the factory preset condition. (see "To perform AUTO SET UP again" on page 22)
- Adjust the convergence again using the FLASH FOCUS button. (see "Adjusting the Convergence Automatically (FLASH FOCUS)" on page 22)

Good picture, no sound

- Press MUTING so that "MUTING" disappears from the screen. (see "MUTING" on page 23)
- Check the MTS setting in the AUDIO menu. (see "MTS" on page 33)
- Make sure SPEAKER is set to ALL ON or L/R OFF in the AUDIO menu. (see "SPEAKER" on page 34)
- Perform AUTO SET UP again using the SET UP button to return to the factory preset condition. (see "To perform AUTO SET UP again" on page 22).

(continued)

Cannot receive digital channels (when a DTV receiver is connected)

- Check the DTV INPUT setting in the SET UP menu. (see "DTV INPUT" on page 42)
- Check the connections between the DTV receiver and the projection TV. (see pages 9 and 10)
- Check your local listings to find out if you can receive digital broadcasts in your area.

Cannot receive upper channels (UHF) when using an antenna

- Make sure CABLE is OFF in the CHANNEL SET UP menu. (see "CABLE" on page 37)
- Use AUTO PROGRAM to add receivable channels that are not presently in the TV's memory. (see "AUTO PROGRAM" on page 37)

No color

- Adjust the COLOR in the VIDEO menu. (see "COLOR" on page 32)
- Black and white programs cannot be seen in color.
- Perform AUTO SET UP again using the SET UP button to return to the factory preset condition. (see "To perform AUTO SET UP again" on page 22)

Only snow and noise appear on the screen

- Check the CABLE setting in the CHANNEL SET UP menu. (see "CABLE" on page 37)
- Check the antenna/cable connections.
- Make sure the channel is broadcasting programs.
- Press ANT to change the input mode. (see "ANT" on page 23)

Dotted lines or stripes

- Adjust the antenna.
- Keep the projection TV away from noise sources such as cars, neon signs or hair-dryers.

TV is fixed to one channel

- Use AUTO PROGRAM to add receivable channels that are not presently in TV's memory. (see "AUTO PROGRAM" on page 37)
- Try turning CHANNEL FIX off. (see "CHANNEL FIX" on page 37)

Double images or ghosts

- Use a highly directional outdoor antenna or a cable (when the problem is caused by reflections from nearby mountains or tall buildings).

Cannot operate the menu

- If the item you want to choose appears in gray, you cannot select it.
- Press the projection TV's power button off and on again.

Cannot receive any channels when using cable TV

- Check the connection with a cable box again. (see pages 6 and 8)
- Make sure CABLE is ON in the CHANNEL SET UP menu. (see "CABLE" on page 37)
- Use AUTO PROGRAM to add receivable channels that are not presently in the TV's memory. (see "AUTO PROGRAM" on page 37)

Cannot gain enough volume when using a cable box

- Increase the volume at the cable box. Then press TV (FUNCTION) and adjust the projection TV's volume.

CHANNEL INDEX does not display all available channels

- Make sure CABLE is ON in the CHANNEL SET UP menu. (see "CABLE" on page 37)
- Use AUTO PROGRAM to add receivable channels that are not presently in the TV's memory. (see "AUTO PROGRAM" on page 37)

FAVORITE CHANNEL does not display your choices

- Verify that FAVORITE CHANNEL is set to MANUAL in the CHANNEL SET UP menu. (see "Setting FAVORITE CHANNEL manually" on page 38)

Some video sources do not appear when you press TV/VIDEO

- Ensure that VIDEO LABEL is not set to SKIP. (see "VIDEO LABEL" on page 41)

Recording through SELECT OUT does not function properly when recording in PIP or P&P mode

- SELECT OUT will not record both images in PIP or P&P. Only the main picture will be recorded.
- If you are recording the main picture and you switch to the sound of the sub picture using the AUDIO button, the main picture will be recorded with sound from the other program.

Cannot play shooting games

- Some shooting games which involve pointing a light beam at the TV screen with an electronic gun or rifle cannot be used with this projection TV. For details, see the instruction manual supplied with the video game software.

SECTION 2
DISASSEMBLY

2-1. SCREEN FRAME ASSY AND HC BOARD REMOVAL



2-2. REAR BOARD REMOVAL



2-3. MAIN BRACKET REMOVAL



2-4. SERVICE POSITION



2-5. G BOARD REMOVAL



2-6. TERMINAL BOARD AND U BOARD REMOVAL



2-7. K BOARD REMOVAL



2-8. BM, BR AND BD BOARD REMOVAL



2-9. BA BOARD REMOVAL



2-10. DS BOARD REMOVAL



2-11. A AND D BOARD REMOVAL



2-12. REFLECTION MIRROR REMOVAL



2-13. HA AND HB BOARD REMOVAL



2-14. PICTURE TUBE REMOVAL

CAUTION: Removing the arrow-marked screws is strictly prohibited. If removed, it may cause liquid spill.



2-15. HIGH-VOLTAGE INSTALLATION AND REMOVAL



SECTION 3
SET-UP ADJUSTMENTS

3-1. SCREEN VOLTAGE ADJUSTMENT (ROUGH ALIGNMENT)

1. Receive the Monoscope signal.
2. Set 50% BRIGHTNESS and minimum PICTURE.
3. Turn the red VR on the FOCUS block all the way to the left and then gradually turn it to the right until the point where you can see the retrace line.
4. Next gradually turn it to the left to the position where the retrace line disappears.



FOCUS block **Fig. 3-1**

3-2. FOCUS LENS ADJUSTMENT

In this adjustment, use the remote commander in the service mode.
For details of the usage of the service mode and the remote commander, please refer the item 3-9. ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER.

1. Loosen the lens screw.
2. Set to the service mode.
3. Receive the all-white signal.
4. Set MCP1 07 RON to “000”, 08 GON to “001” and 09 BON to “000” to show only the green color.
5. Set to PJE, and press 6 to display the test signal (crosshatch)“ on the screen.
6. Turn the green lens to adjust to the optimum focus point with the test signal.
7. Tighten the lens screw.
8. Set MCP1 07 RON to “001”, 08 GON to “000” and 09 BON to “000” to show only the red color.
9. Set to PJE, and press 6 to display the test signal (crosshatch)“ on the screen.
10. Adjust red CRT lens just the same as green.
11. Set MCP1 07 RON to “000”, 08 GON to “000” and 09 BON to “001” to show only the blue color.



Test signal **Fig. 3-2**

12. Set to PJE, and press 6 to display the test signal (crosshatch)“ on the screen.
13. Adjust blue CRT lens just the same as green.

*: Every time you press 6, the test signal changes to “crosshatch+video signal” - “dots+video signal” - “crosshach(black)” - “dots(black)” - off.

Note: Instead of items 4, 8 and 11, you can use the lens caps to cut off the unnecessary color beams.

3-3. SCREEN (G2) ADJUSTMENT

1. Select VIDEO1 mode without signals.
2. Connect an oscilloscope to the TP7103(KR), TP7203(KG) and TP7303(KB) of CR board, CG board and CB board.
3. Adjust R, G and B screen voltage to 175 ± 2V with screen VR on the Focus block.



Fig. 3-3

3-4. FOCUS VR ADJUSTMENT

1. Set to the service mode.
2. Receive the all-white signal.
3. Set MCP1 07 RON to “000”, 08 GON to “001” and 09 BON to “000” to show only the green color.
4. Set to PJE, and press 6 to display the test signal (crosshatch) on the screen.
5. Turn the green VR on the focus block to adjust to the optimum focus point with the test signal.
6. Set MCP1 07 RON to “001”, 08 GON to “000” and 09 BON to “000” to show the red color.
7. Set to PJE, and press 6 to display the test signal (crosshatch) on the screen.
8. Turn the red VR on the focus block to adjust to the optimum focus point with the test signal.
9. Set MCP1 07 RON to “000”, 08 GON to “000” and 09 BON to “001” to show the blue color.
10. Set to PJE, and press 6 to display the test signal (crosshatch) on the screen.
11. Turn the blue VR on the focus block to adjust to the optimum focus point with the test signal.

Note: Instead of items 3, 6 and 9, you can use the lens caps to cut off the unnecessary color beams.



Lens **Fig. 3-4**



Fig. 3-5

3-5. DEFLECTION YOKE TILT ADJUSTMENT

1. Receive the Monoscope signal.
2. Set in service mode.
3. Set MCP1 07 GON to “001” 08 RON to “000” and 09 BON to “000” to show only the green color.
4. Loosen the deflection yoke set screw and align the tilt of the Deflection Yoke so that the bars at the center of the monoscope pattern are horizontal.
5. After aligning the deflection yoke, fasten it securely to the funnel-shaped portion (neck) of the CRT.
6. The tilt of the deflection yoke for red is aligned in the mode MCP1 07 RON “001”, 08 GON “000”, 09 BON “000” on the service mode menu, and the tilt of the deflection yoke for blue is aligned with in the mode MCP1 07 RON “000”, 08 GON “000”, 09 BON “001” on the service menu, is aligned the same as was done for green.

Note: Instead of item 3, you can use the lens caps to cut off the unnecessary color beams.



Fig. 3-6

3-6. 2-POLE MAGNET ADJUSTMENT (GREEN,RED)

1. Receive the Dot signal.
2. Set in service mode.
3. Set MCP1 07 GON to “001” 08 RON to “000” and 09 BON to “000” to show only the green color.
4. Turn the green VR on the focus block to the right and set to overfocus to enlarge the spot.
5. Now align the 2-Pole Magnet so that the enlarged spot is in the center of the Just Focus spot.
6. Align the green focus VR and set for just (precise) focus.
7. Perform the same alignment for red.

Use the center dot



Fig. 3-7

3-7. 4-POLE MAGNET ADJUSTMENT

1. Receive the Dot signal.
2. Set in service mode.
3. Set MCP1 07 GON to “001” 08 RON to “000” and 09 BON to “000” to show only the green color.
4. Turn the green VR on the focus block to the left and set to underfocus to enlarge the spot.
5. Now align the 4-Pole Magnet so that the enlarged spot becomes a perfect circle for green and red.
6. Perform the same alignment for blue.

Use the center dot



Fig. 3-8

3-8. DEFOCUS ADJUSTMENT (BLUE)

1. Select the video menu and set the mode to “VIVID” mode.
2. Set to the service mode.
3. Change TV mode to the video input mode.
4. Set to PJE, and press 6 to display the test signal (dots) on the screen.
5. Turn the blue VR on the focus block to adjust to the diameter of the dots as shown in the figure below.

[Focus adjustment point]

Inch	53"	61"
L	8	9

Fig. 3-9

3-9. ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER

By using Remote Commander (RM-Y902),all circuit adjustments can be made.

NOTE : Test Equipment Required.

1. Pattern Generator (with component outputs)
2. Frequency counter
3. Digital multimeter
4. Audio oscillator

1. METHOD OF SETTING THE SERVICE ADJUSTMENT MODE

SERVICE MODE PROCEDURE

1. Standby mode. (Power off)
2. DISPLAY → 5 → VOL (+) → TV POWER
   on the Remote Commander.
   (Press each button within a second.)

SERVICE MODE ADJUSTMENT



(SCREEN DISPLAY)

3. The SCREEN displays the item being adjusted.
4. Press 1 or 4 on the Remote Commander to select the adjustment item.
5. Press 3 or 6 on the Remote Commander to change the data.
6. Press 2 or 5 on the Remote Commander to select the category.
7. If you want to recover the latest values press 0 then ENTER to read the memory.
8. Press MUTING then ENTER to write into memory.
9. Turn power off.

Note: Press 8 then ENTER on the Remote Commander to initialize or turn set off and on to exit.

2. MEMORY WRITE CONFIRMATION METHOD

1. After adjustment, remove the plug from AC outlet, and then replace the plug in AC outlet again.
2. Turn the power switch ON and set to Service Mode.
3. Call the adjusted items again and confirm they were adjusted.

3. ADJUST BUTTONS AND INDICATOR



RM-Y902

Note : In the PJE mode these are different a little. See page 47.

4. SERVICE MODE LIST

: Fixed data

VDSP

( ) : 1080I

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
VDSP	00	VPOS	31	0–63	V SHIFT	CXD2018Q
	01	VANG	7	0–15	V ANGLE	
	02	VBOW	7	0–15	V BOW	
	03	VLIN	7	0–15	V LIN	
	04	VSIZ	31 (10)	0–63	V SIZE	
	05	VSCO	7	0–15	S CORRECTION	
	06	HPOS	41	0–63	H SHIFT	
	07	HSIZ	31	0–63	H SIZE	
	08	HKEY	11	0–15	TILT	
	09	PAMP	15	0–63	PIN AMP	
	10	UPIN	7	0–15	UPPER CORNER PIN	
	11	LPIN	7	0–15	LOWER CORNER PIN	

MCP

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
MCP 1	00	RDRV	31	0–63	R DRIVE	CXA2101AQ
	01	GDRV	31	0–63	G DRIVE	
	02	BDRV	31	0–63	B DRIVE	
	03	RCUT	31	0–63	R CUTOFF	
	04	GCUT	10	0–63	G CUTOFF	
	05	BCUT	31	0–63	B CUTOFF	
	06	P ON	1	0,1	PICON	
	07	R ON	1	0,1	R ON	
	08	G ON	1	0,1	G ON	
	09	B ON	1	0,1	B ON	
	10	PABL	15	0–15	PEAK ABL LEVEL	
	11	LTIL	0	0–3	LTI LEVEL	
	12	CTIL	0	0,1	CTI LEVEL	
	13	LIMT	2	0–3	INPUT LEVEL LIMIT	
	14	CB01	7	0–15	CB OFFSET 1	
	15	CR01	7	0–15	CR OFFSET 1	
	16	CB02	7	0–15	CB OFFSET 2	
	17	CR02	7	0–15	CR OFFSET 2	
	18	DCTR	1	0–3	DC TRAN	
	19	DPIC	1	0–3	D PIC	
	20	ABLT	3	0–3	ABL T/H (ACTIVE ON 16 :9)	
	21	VTC	2	0–3	V SYNC SFP TC	
	22	CB03	7	0–15	CB OFFSET3	
	23	CR03	7	0–15	CR OFFSET3	

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
MCP2	00	SCON	5	0-15	SUB CONTRAST	
(DRC/480ip)	01	SBRT	31	0-63	SUB BRIGHTNESS	
	02	SHUE	7	0-15	SUB HUE	
	03	SCOL	12	0-15	SUB COLOR	
MCP3	00	SCON	3	0-15	SUB CONTRAST	
(1080i)	01	SBRT	31	0-63	SUB BRIGHTNESS	
	02	SHUE	7	0-15	SUB HUE	
	03	SCOL	5	0-15	SUB COLOR	
MCP 4	00	SSHP	3	0–3	SUB SHARPNESS	
(STANDARD)	01	SHPF	1	0–3	SHARPNESS f0	
	02	VMDL	3	0–3	VM DELAY	
	03	SYS	2	0–3	SYSTEM	
	04	PREO	2	0–3	PRE/OVER RATIO	
MCP 5	00	SSHP	3	0–3	SUB SHARPNESS	
(VIVID)	01	SHPF	1	0–3	SHARPNESS f0	
	02	VMDL	3	0–3	VM DELAY	
	03	SYS	2	0–3	SYSTEM	
	04	PREO	1	0–3	PRE/OVER RATIO	
MCP6	00	SSHP	3	0–3	SUB SHARPNESS	
(1080 - 480)	01	SHPF	2	0–3	SHARPNESS f0	
	02	VMDL	3	0–3	VM DELAY	
	03	SYS	2	0–3	SYSTEM	
	04	PREO	0	0–3	PRE/OVER RATIO	
MCP 7	00	UPIC	63	0–63	USER PICTURE(VIVID)	
			44	0–63	USER PICTURE(STANDARD)	
			40	0–63	USER PICTURE(MOVIE)	
			38	0–63	USER PICTURE(GAME)	
			38	0–63	USER PICTURE(PRO)	
	01	UBRT	28	0–63	USER BRIGHTNESS(VIVID)	
			31	0–63	USER BRIGHTNESS(STANDARD)	
			31	0–63	USER BRIGHTNESS(MOVIE)	
			27	0–63	USER BRIGHTNESS(GANE)	
			31	0–63	USER BRIGHTNESS(PRO)	
	02	UCOL	31	0–63	USER COLOR(VIVID)	
			31	0–63	USER COLOR(STANDARD)	
			31	0–63	USER COLOR(MOVIE)	
			31	0–63	USER COLOR(GAME)	
			31	0–63	USER COLOR(PRO)	
	03	USHP	40	0–63	USER SHARPNESS(VIVID)	
			40	0–63	USER SHARPNESS(STANDARD)	
			33	0–63	USER SHARPNESS(MOVIE)	
			36	0–63	USER SHARPNESS(GAME)	
			40	0–63	USER SHARPNESS(PRO)	

RM-Y902

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
	04	UTRI	2	0–3	USER TRINITONE(VIVID)	
			1	0–3	USER TRINITONE(STANDARD)	
			0	0–3	USER TRINITONE(MOVIE)	
			2	0–3	USER TRINITONE(GAME)	
			1	0–3	USER TRINITONE(PRO)	
	05	UNR	0	0–3	USER NR MODE(VIVID)	
			0	0–3	USER NR MODE(STANDARD)	
			0	0–3	USER NR MODE(MOVIE)	
			0	0–3	USER NR MODE(GAME)	
			0	0–3	USER NR MODE(PRO)	
	06	UDPI	1	0,1	USER DYNAMIC PICTURE(VIVID)	
			1	0,1	USER DYNAMIC PICTURE(STANDARD)	
			0	0,1	USER DYNAMIC PICTURE(MOVIE)	
			0	0,1	USER DYNAMIC PICTURE(GAME)	
			1	0,1	USER DYNAMIC PICTURE(PRO)	
	07	UVML	3	0–3	USER VM LEVEL(VIVID)	
			2	0–3	USER VM LEVEL(STANDARD)	
			1	0–3	USER VM LEVEL(MOVIE)	
			3	0–3	USER VM LEVEL(GAME)	
			1	0–3	USER VM LEVEL(PRO)	

MCD

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
MCD 1 (DRC-TV)	00	SCON	5	0–15	SUB CONTRAST	CXA2019AQ
	01	SHUE	6	0–15	SUB HUE	
	02	SCOL	4	0–15	SUB COLOR	
MCD 2 (P&P-TV)	00	SCON	5	0–15	SUB CONTRAST	
	01	SHUE	6	0–15	SUB HUE	
	02	SCOL	5	0–15	SUB COLOR	
MCD 3 (DRC-VIDEO)	00	SCON	5	0–15	SUB CONTRAST	
	01	SHUE	8	0–15	SUB HUE	
	02	SCOL	5	0–15	SUB COLOR	
MCD 4 (P&P-VIDEO)	00	SCON	5	0–15	SUB CONTRAST	
	01	SHUE	7	0–15	SUB HUE	
	02	SCOL	7	0–15	SUB COLOR	
MCD 5	00	MYDR	3	0–31	YDRIVE	
	01	Y2DR	31	0–31	Y2 DRIVE	
	02	U2DR	15	0–31	U2 DRIVE	
	03	V2DR	15	0–31	V2 DRIVE	
	04	MUPE	7	0–15	U PED	
	05	MVPE	7	0–15	V PED	
	06	U2PE	7	0–15	U2 PED	
	07	V2PE	7	0–15	V2 PED	
	08	DPIC	1	0,1	D PIC	
	09	DCTR	0	0–7	DC TRAN	

SCD

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
SCD 1 (TV)	00	SCON	6	0–15	SUB CONTRAST(TV)	CXA2019AQ
	01	SHUE	6	0–15	SUB HUE(TV)	
	02	SCOL	6	0–15	SUB COLOR(TV)	
SCD 2 (VIDEO)	00	SCON	6	0–15	SUB CONTRAST(VIDEO)	
	01	SHUE	6	0–15	SUB HUE(VIDEO)	
	02	SCOL	6	0–15	SUB COLOR(VIDEO)	
SCD 3	00	MYDR	3	0–31	YDRIVE	
	01	Y2DR	31	0–31	Y2 DRIVE	
	02	U2DR	15	0–31	U2 DRIVE	
	03	V2DR	15	0–31	V2 DRIVE	
	04	MUPE	7	0–15	U PED	
	05	MVPE	7	0–15	V PED	
	06	U2PE	7	0–15	U2 PED	
	07	V2PE	7	0–15	V2 PED	
	08	DPIC	1	0,1	D PIC	
	09	DCTR	0	0–7	DC TRAN	

3DCM

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
3DCM 1 (YCS)	00	NRMD	0	0–3	NRMD	UPD64081
	01	DYCO	2	0,1	DYCOR	
	02	DYGA	11	0–15	DYGAIN	
	03	DCCO	1	0,1	DCCOR	
	04	DCGA	12	0–15	DCGAIN	
	05	SELD	1	0,1	SELD	
	06	D2GA	4	0–7	D2GAIN	
3DCM 2 (YCNR)	00	NRMD	3	0–3	NRMD	
	01	DYCO	2	0,1	DYCOR	
	02	DYGA	11	0–15	DYGAIN	
	03	DCCO	1	0,1	DCCOR	
	04	DCGA	12	0–15	DCGAIN	
	05	SELD	1	0,1	SELD	
	06	D2GA	4	0–7	D2GAIN	
3DCM 3 (TV)	00	WSC	0	0–3	WSC	
	01	VTRH	1	0–3	VTRH	
	02	VTRR	1	0–3	VTRR	
	03	LDSR	3	0–3	LDSR	
	04	YPFT	3	0–3	YPFT(TV:NR OFF)	
	05	YPFG	12	0–15	YPFG(TV:NR OFF)	
	06	YPFC	0	0,1	YPFT CORING(TV:NR OFF)	

VDSP

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
3DCM 4 (VIDEO)	00	WSC	0	0–3	WSC	
	01	VTRH	1	0–3	VTRH	
	02	VTRR	1	0–3	VTRR	
	03	LDSR	1	0–3	LDSR	
	04	YPFT	3	0–3	YPFT(VIDEO:NR OFF)	
	05	YPFG	12	0–15	YPFG(VIDEO:NR OFF)	
	06	YPFC	0	0,1	YPFT CORING(VIDEO:NR OFF)	
3DCM 5	00	MSS	0	0–3	MSS	
	01	YNKI	2	0–3	YNRK & YNRIV	
	02	YNRL	0	0–3	YNRLIM	
	03	CNKI	2	0–3	CNRK & CNRINV	
	04	CNRL	0	0–3	CNRLIM	
	05	V1PS	2	0–3	V1PS	
	06	VEGS	1	0–3	VEGS	
	07	CC3N	0	0,1	CC3N	
	08	HDP	4	0–7	HDP	
	09	CDL	3	0–7	CDL	
	10	HSSL	12	0–15	HSSL	
	11	VSSL	3	0–15	VSSL	
	12	HPLF	1	0,1	HPLLFS	
	13	BPLF	1	0,1	BPLLFS	
	14	FSCF	0	0,1	FSCFG	
	15	EXAD	1	0,1	ADIN	
	16	WSLT	2	3	WSL THRESHHOLD	

SNNR

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
SNNR1	00	SSHP	3	0-3	MCP SUB SHARPNESS	
	01	LTIL	0	0-3	MCP LTI	
	02	YPFT	3	0-3	3DCM YPFT	
	03	YPFG	10	0-15	3DCM YPFG	
	04	YPFC	0	0,1	3DCM YPFC	
	05	WSLT	15	0-255	3DCM WSL THRESHOLD	
SNNR2	00	SSHP	3	0-3	MCP SUB SHARPNESS	
	01	LTIL	0	0-3	MCP LTI	
	02	YPFT	3	0-3	3DCM YPFT	
	03	YPFG	9	0-15	3DCM YPFG	
	04	YPFC	0	0,1	3DCM YPFC	
	05	WSLT	79	0-255	3DCM WSL THRESHOLD	
SNNR3	00	SSHP	3	0-3	MCP SUB SHARPNESS	
	01	LTIL	0	0-3	MCP LTI	
	02	YPFT	1	0-3	4DCM YPFT	
	03	YPFG	7	0-15	4DCM YPFG	
	04	YPFC	1	0,1	4DCM YPFC	
	05	WSLT	175	0-255	4DCM WSL THRESHOLD	
SNNR4	00	SSHP	2	0-3	MCP SUB SHARPNESS	
	01	LTIL	0	0-3	MCP LTI	
	02	YPFT	1	0-3	4DCM YPFT	
	03	YPFG	5	0-15	4DCM YPFG	
	04	YPFC	1	0,1	4DCM YPFC	

OSD

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
OSD	00	FREQ	95	0–255	OSD FREQ	MB9091 & OSD U-COM
	01	HPOS	26	0–255	H POSITION	
	02	VPOS	30	0–255	V POSITION	

MCCD

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
MCCD	00	CRIL	2	0–15	CRI COUNT LOW	MAIN U-COM
	01	CFLD	5	0–15	CAPTION FIXED-FIELD COUNT	
	02	CCDI	3	0–7	CCD INT	
	03	CRIP	4	0–7	CRI & PARITY	
	04	CRIT	1	0–3	CRI TIME CONSTANT(MASK=1,OTP=2)	
	05	CSB1	3	0–3	SYNC SLICE BIAS 1	

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
	06	CSB2	4	0–7	SYNC SLICE BIAS 2	
	07	CREP	142	0–255	CRI SIGNAL END POSITION	
	08	CDSD	8	0–31	DATA START DELAY	
	09	CCDS	9	0–31	CAPTION DATA THRESHOLD	
	10	CHMK	42	0–63	P8 HMASK	
	11	CHSY	136	0–255	P8 HSYNC	
	12	CCDH	27	0–63	CCD H POSITION	

APLR

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
APLR	00	SVOL	0	0–15	SUB VOLUME	TDA7321
	01	ATTL	0	0–15	ATT LCH	
	02	ATTR	0	0–15	ATT RCH	
	03	SBAS	7	0–15	SUB BASS	
	04	STRE	7	0–15	SUB TREBLE	

APCS

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
APCS	00	SVOL	0	0–15	SUB VOLUME	TDA7321
	01	ATTC	0	0–15	ATT CCH	
	02	ATTS	0	0–15	ATT SCH	
	03	SBAS	7	0–15	SUB BASS	
	04	STRE	7	0–15	SUB TREBLE	

MID

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
MID	00	DLYC	3	0–7	DELAY(Y OUTPUT DELAY)	CXD2079Q & MID U-COM
	01	YSDY	1	0–7	YSDY(YS DELAY)	
	02	VJTC	0	0–3	VJITTC(V JITTER MODE)	
	03	HPHA	43	0–255	HPHASA(ACH H PHASE)	
	04	VPHA	11	0–255	VPHASA(ACH V PHASE)	
	05	DLYA	4	0–7	DELAYA(ACH Y DELAY)	
	06	HPOA	87	0–255	HPOSIA(ACH H POSITION:NOT USE)	
	07	VPOA	64	0–255	VPOSIA(ACH V POSITION:NOT USE)	
	08	HPHB	43	0–255	HPHASB(BCH H PHASE)	
	09	VPHB	11	0–255	VPHAHB(BCH V PHASE)	
	10	DLYB	4	0–7	DELAYB(BCH Y DELAY)	
	11	HPOB	4	0–15	HPOSIB(BCH H POSITION:PIP ONLY)	
	12	VPOB	6	0–15	VPOSIB(BCH V POSITION:PIP ONLY)	
	13	BPDY	0	0–15	BPDELAY(BP DELAY)	

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
	14	ADSW	1	0,1	A/BCH ADC INT/EXT(EXT=1)	
	15	OSDH	25	0–63	OSD H POSITION	
	16	OSDV	7	0–63	OSD V POSITION	
	17	WCOL	2	0–3	WKCA/WKCB(A/BCH WINDOW COLOR)	

OP

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
OP	00	AGCA	152	0–255	AGC ATT LEVEL	MAIN U-COM
	01	16:9	0	0,1	16:9 ON/OFF (ON = 1)	
	02	DRCP	0	0,1	DRC INTERLACE/PROGRESSIVE	
	03	1080	0	0,1	FORCED 1080I(VIDEO5)	
	04	IDXT	2	0-15	INDEX CH SCAN TIME	
	05	VPI	0	0-3	PICTURE BOOSTER SETTING(VIVID)	

PJED

( ) : 1080I < > 16 :9

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
PJED	00	FDIS	00	0,1	FINE ADJUST DISPLAY ON(ON=1, OFF=0)	CM0006AF & PJED U-COM
	01	OSDH	32	0–255	PJED OSD H POSITION	
	02	OSDV	55	0–255	PJED OSD V POSITION	
	03	FVST	51(00)	0–255	FINE V START LINE	
	04	V1ST	00	0–255	V1 START	
	05	V1CU	31(29)	0–255	V1 COUNT UP	
	06	COHP	00(248)	0–255	COARSE H PHASE	
	07	FIHP	206(200)	0–255	FINE H PHASE	
	08	TPHP	49(55)<46>	0–255	TEST PATTERN H PHASE	
	09	DFHP	00	0–255	DF H PHASE	
	10	DFHG	95	-128–+127	DF H GAIN	
	11	DFVG	15	-128–+127	DF V GAIN	
	12	PWM1	00	0–255	PWM1	
	13	PWM2	29	0–255	PWM2	
	14	HBLD	222(212)	0–255	HBLKOUT H DELAY	
	15	HBLW	00(10)<10>	0–63	HBLKOUT PULSE WIDTH	
	16	BLKP	44(75)<49>	0-255	V BLANKING PULSE	
	17	COGV	00	-127–+127	GV CENTER OFFSET OF AUTO REGI	
	18	CORV	00	-127–+127	RV CENTER OFFSET OF AUTO REGI	
	19	COBV	00	-127–+127	BV CENTER OFFSET OF AUTO REGI	
	20	COGH	00	-127–+127	GH CENTER OFFSET OF AUTO REGI	
	21	CORH	00	-127–+127	RH CENTER OFFSET OF AUTO REGI	
	22	COBH	00	-127–+127	BH CENTER OFFSET OF AUTO REGI	

RM-Y902

Category	Item number	Adjustment item	Standard data	Data range	Note	Device
	23	SOGV	00	-127–+127	GV SKEW OFFSET OF AUTO REGI	
	24	SORV	00	-127–+127	RV SKEW OFFSET OF AUTO REGI	
	25	SOBV	00	-127–+127	BV SKEW OFFSET OF AUTO REGI	
	26	SOGH	00	-127–+127	GH SKEW OFFSET OF AUTO REGI	
	27	SORH	00	-127–+127	RH SKEW OFFSET OF AUTO REGI	
	28	SOBH	00	-127–+127	BH SKEW OFFSET OF AUTO REGI	
	29	ERR	00		AUTO REGI ERROR CODE	
	30	ADTM	144	0-255	AUTO REGI AD TIMING	
	31	VUP	01	0-255	AUTO REGI VUP POS	
	32	VMID	120(120)	0-255	AUTO REGI VMID POS	
	33	VLOW	240(238)	0-255	AUTO REGI VLOW POS	
	34	HPR	01	0-255	AUTO REGI H POS REGIS	
	35	SFTF	00	0,1	V SIZE SHIFT FAST	
	36	ACTL	00	0-255	ACTIVE CRT TIME(LOW BYTE)	
	37	ACTH	00	0-255	ACTIVE CRT TIME(HIGH BYTE)	
		CENT	000 / 000	-512 - +511	COARSE GREEN H/V CENT	
		SKEW	000 / 000	-512 - +511	COARSE GREEN H/V SKEW	
	GRN	SIZE	000 / 000	-512 - +511	COARSE GREEN H/V SIZE	
		LIN	XXXX / XXXX	-	COARSE GREEN H/V LIN	
		KEY	XXXX / XXXX	-	COARSE GREEN H/V KEY	
		PIN	000 / XXXX	-512 - +511	COARSE GREEN H/V PIN	
		CENT	000 / 000	-512 - +511	COARSE BLUE H/V CENT	
		SKEW	000 / 000	-512 - +511	COARSE BLUE H/V SKEW	
	BLU	SIZE	000 / 000	-512 - +511	COARSE BLUE H/V SIZE	
		LIN	000 / XXXX	-512 - +511	COARSE BLUE H/V LIN	
		KEY	XXXX / 000	-512 - +511	COARSE BLUE H/V KEY	
		PIN	000 / XXXX	-512 - +511	COARSE BLUE H/V PIN	
		CENT	000 / 000	-512 - +511	COARSE RED H/V CENT	
		SKEW	000 / 000	-512 - +511	COARSE RED H/V SKEW	
	RED	SIZE	000 / 000	-512 - +511	COARSE RED H/V SIZE	
		LIN	000 / XXXX	-512 - +511	COARSE RED H/V LIN	
		KEY	XXXX / 000	-512 - +511	COARSE RED H/V KEY	
		PIN	000 / XXXX	-512 - +511	COARSE RED H/V PIN	

3-10. REGISTRATION ADJUSTMENT

• ADJUST BUTTONS AND INDICATOR



[SETUP FOR ADJUSTMENT]

- Current flow in circuit should be stable before attempting adjustment. So wait 5 minutes after turning on the TV power.
- The adjustments should be done in the 4 : 3 mode, 16 : 9 mode and VIDEO 5 1080i mode respectively.
  Adjust every color registrations in one mode.
  Forced 16 : 9 mode setting:
  In the service mode, set OP 01 16 : 9 to 001.
  VIDEO 5 forced 1080i mode setting:
  Connect RCA pin plug to VIDEO IN 5 red pin jack, and set OP 03 1080 to 001 in the service mode.

1. Set to the service mode by pressing quickly keys on the remote commander in the standby mode in the following order:
   DISPLAY → 5 → VOL+ → TV POWER



(SCREEN DISPLAY)

2. Change TV mode to the video input mode.
3. Change the VDSP mode to the PJE 00 FDIS.
4. Set FDIS data to “01” to display the registration data of each spot in the fine adjustment.



5. Press 6 to display the test signal (crosshatch) on the screen.
6. Select GRN CENT(*) with the 1 and 4 keys on the remote commander and check that the adjustment data is now “000” both vertically and horizontally.



*: In the factory preset, “GRN CENT” appears on the screen first. In case of other colors “RED” or “BLU”, change color by every pressing 3 key.

7. Set MCP1 07 RON to “000”, 08 GON to “001” and 09 BON to “000” to show only the green color.
8. Change the MCP1 mode to the PJE mode.

SUB DEFLECTION ADJUSTMENT ITEM

Adjustment O : Yes – : No

Display	Adjustment item	Adjustment type		
		G	R	B
		H/V	H/V	H/V
CENT	CENT	O/O	O/O	O/O
SKEW	SKEW	O/O	O/O	O/O
SIZE	SIZE	O/O	O/O	O/O
LIN	LIN	–/–	O/–	O/–
KEY	KEY	–/–	–/O	–/O
PIN	PIN	–/O	–/O	–/O

[GREEN REGISTRATION ADJUSTMENT]

<GREEN CENTER, SIZE>

1. Select GRN CENT or GRN SIZE with the 1 and 4 keys on the remote commander.
2. Adjust the crosshatch line goes center horizontally (GRN CENT) and set the size correctly (GRN SIZE) with the joystick on the remote commander.



<GREEN SKEW>

1. Select GRN SKEW with the 1 and 4 keys on the remote commander.
2. Adjust the crosshatch line goes straight vertically and horizontally with the joystick on the remote commander.



<GREEN PINCUSHION>

1. Select GRN PIN with the 1 and 4 keys on the remote commander.
2. Adjust the crosshatch line goes straight vertically and horizontally with the joystick on the remote commander.



<FINE ADJUSTMENT>

1. Press 9 key on the remote commander to shift to the fine adjustment mode.
   The green marker (in the GRN mode) appears on the center of the screen.
2. Use the 1 and 4 keys or the joystick on the remote commander, move the marker (see below) everywhere you want to adjust and adjust with the joystic keys on the remote commander.
   Marker movement by the 1 and 4 keys:



   Press once the joystick the marker turns sreen to white.
   Then you can move the marker up and down left and right.



3. Press 9 key on the remote commander to shift to the rough adjustment mode.

[RED REGISTRATION ADJUSTMENT]

<RED CENTER>

1. Change to MCP1 mode and set MCP1 07 RON to “001”, 08 GON to “001” and 09 BON to “000” to show the green and red colors.
2. Change the MCP1 mode to the PJE mode.
3. Press [3] key on the remote commander to shift the GRN mode to the RED mode.
4. Select RED CENT with the [1] and [4] keys on the remote commander.
5. Adjust the red crosshatch lines go straight vertically and horizontally and overlaps the green lines with the joystick on the remote commander.

<RED SKEW>

1. Select RED SKEW with the [1] and [4] keys on the remote commander.
2. Adjust the red crosshatch lines go straight vertically and horizontally and overlaps the green lines with the joystick on the remote commander.

<RED LINEARITY>

1. Select RED SIZE (vertically and horizontally) or RED LIN (vertically) with the [1] and [4] keys on the remote commander and adjust while tracking each other alternately.
2. Adjust the red crosshatch lines go straight vertically and horizontally and overlaps the green lines with the joystick on the remote commander.

<RED KEY>

1. Select RED KEY with the [1] and [4] keys on the remote commander.
2. Adjust the red crosshatch lines go straight horizontally and overlaps the green lines

with the joystick on the remote commander.

<RED PINCUSHION>

1. Select RED PIN with the [1] and [4] keys on the remote commander.
2. Adjust the red crosshatch lines go straight horizontally and overlaps the green lines with the joystick on the remote commander.

<FINE ADJUSTMENT>

1. Press [9] key on the remote commander to shift to the fine adjustment mode.
   The red marker (in the RED mode) appears on the center of the screen.
2. Use the [1] and [4] keys or the joystick on the remote commander, move the marker everywhere you want to adjust and adjust with the joystick on the remote commander.

[BLUE REGISTRATION ADJUSTMENT]

1. Change to MCP1 mode and set MCP1 07 RON to “001”, 08 GON to “001” and 09 BON to “001” to show full color.
2. Change the VPNT mode to the PJE mode.
3. Press [3] key on the remote commander to shift the RED mode to the BLU mode.
4. Adjust BLU CENT, BLU SKEW, BLU SIZE, BLU LIN, BLU KEY and BLU PIN in the same procedure of the red registration adjustment.

[FINAL CHECK]

1. Store the new adjustment (offset) value on the remote control by pressing [MUTING] and [ENTER].
2. Press the FLASH FOCUS button on the front panel.
   (The Offset value is now automatically stored.)
3. Check that no error message appears.
   If an error message appears, recheck.

3-11. AUTO REGISTRATION ERROR CODE LIST

[ERROR CODE LIST]

ERROR CODE	DISCRIPTION	NOTE
00	No Error	
10	Sensor Output Level Low	* Check wiring, beam position, sensor. 0 : Upper Center 1 : Middle Left 2 : Middle Right 3 : Lower Center
20	Sensor Output Level High	* Check OP-amp circuit. 0 : Upper Center 1 : Middle Left 2 : Middle Right 3 : Lower Center
30	Adjustment Loop Counter Overflow	* Check the data go far from the standard or not.
40	Regi Data Overflow	* Check the data go far from the standard or not.
50	Regi Data Overflow	* Check the data go far from the standard or not.
60	Offset Overflow	* Check the data go far from the standard or not.
70	Offset Overdrow	* Check the data go far from the standard or not.

* In case of multiple error, last error is displayed.

• ERROR CODE SCREEN DISPLAY



* Error code will be displayed on center of screen for 3 seconds.

[SENSOR POSITION]



0 : UPPER SENSOR
1 : LEFT SENSOR
2 : RIGHT SENSOR
3 : LOWER SENSOR
4 : UL
5 : UR
6 : LL
7 : LR

• ERROR CODE DISPLAY IN REGI SERVICE MODE



SECTION 4
SAFETY RELATED ADJUSTMENTS

[D BOARD]

4-1. HV REGULATION CIRCUIT CHECK AND ADJUSTMENT

When replacing the following components marked with ◪ on the schematic diagram always check HV regulation, and if necessary re-adjust.

▣: R8194, R8202
◪: C8064, C8066, C8070, C8074, C8076,C8082
D8042
IC8002, IC8007, IC8008
Q8022
R8093, R8095, R8096, R8105, R8108
R8112, R8113, R8114, R8115, R8126
R8128, R8136, R8138, R8139, R8154
R8157, R8168, R8173, R8174, R8177
R8178, R8195, R8196, R8201
T8002 (LOT), T8003 (FBT)
HV BLOCK, D BOARD

OPERATION CHECK

1. Connect a HV static voltmeter to the unconnected plug of the high-voltage block.
2. Connect a 33kΩ variable resistor, set to maximum value, across CN8008.
3. Power on the set.
4. Receive dot signal pattern.
5. Gradually lower the value of the variable resistor and check that the hold-down circuit operates at a static voltmeter reading of 31.0 ± 0.5kV dc when the raster disappears.

HV HOLD-DOWN ADJUSTMENT

1. REPART STEPS ① ~ ⑤ as above.
2. Just at the point hold-down circuit begins to operate switch off the set.
3. Remove the VR connected across CN8008, and measure it's resistance.
4. Solder a resistor value, nearest to the measured value, across CN8008.
5. Reconfirm operation check.



Fig. 4-1

4-2. HV HOLD DOWN CIRCUIT OPERATION CHECK AND ADJUSTMENT

When replacing the following components marked with ◪ on the schematic diagram always check hold-down voltage and if necessary re-adjust.

▣: R8196, R8201
◪: D8026, D8032, D8035, D8050
IC8006, IC8009, IC8010
Q8021, Q8031
R8092, R8094, R8097, R8109, R8110,R8117,
R8118, R8121, R8123, R8125, R8129, R8135,
R8140, R8155, R8190, R8191, R8192, R8193,
R8194, R8198, R8202
T8002 (LOT), T8003(FBT)
HV BLOCK, D BOARD

OPERATION CHECK

1. Connect a HV static voltmeter to the unconnected plug of the high-voltage block.
2. Power on the set.
3. Receive dot signal patterm.
4. Check that the HV static voltmeter is readind 34.0 ± 0.5V dc.

HV Regulation ADJUSTMENT

1. Repart step ① as above.
2. Connect 33kΩ variable resistor, set to maximum value, to CN8008.
3. Power on the set.
4. Receive dot signal pattern.
5. Gradually lower the value of the variable resistor until the static voltmeter is reading 34.0 ± 0.5 kVdc.
6. Switch off the swt.
7. Remove the VR connected across CN8008, and measure its value.
8. Solder a resistor value, nearest to the measured value, across CN8008.
9. Reconfirm operation check.

4-3. +B OVP CONFIRMATION

1. Connect a voltmeter to TP. OVP and ground.
2. Supply 120VAC to variable autotransformer.
3. Power on the Set.
4. Supply 150VDC to TP. OVP.
5. Check the OVP operate.

SECTION 5
CIRCUIT ADJUSTMENTS

[MCD MODE]

5-1. TV INPUT SUB CONTRAST ADJUSTMENT (MCD1-SCON)

1. Receive the color-bar signal.
2. Set to service mode.
3. Connect an oscilloscope between pin ② of CN511 (A board) and ground.
4. Select " MCD1-SCON ", and adjust so that the waveform level is 0.525 ± 0.015Vp-p.
5. Write the data into memory.
   MUTING → ENTER



Fig. 5-1

5-2. VIDEO INPUT SUB CONTRAST ADJUSTMENT (MCD3-SCON)

1. VIDEO 1 input the color-bar signal.
2. Set to service mode.
3. Connect an oscilloscope between pin ② of CN511 (A board) and ground.
4. Select " MCD3-SCON ", and adjust so that the waveform level is 0.525 ± 0.015Vp-p.
5. Write the data into memory.
   MUTING → ENTER



Fig. 5-2

5-3. P & P SUB CONTRAST ADJUSTMENT (MCD2-SCON)

1. Receive the signal.
   TV terminal (main) : color-bar signal
   VIDEO terminal (sub) : no signal
2. Set to P & P mode, set to service mode.
3. Connect an oscilloscope between pin ⑳ of CN513 (A board) and ground.
4. Select " MCD2-SCON ", and adjust so that the waveform level is 0.525 ± 0.015Vp-p.
5. Write the data into memory.
   MUTING → ENTER



Fig. 5-3

5-4. P & P SUB CONTRAST ADJUSTMENT (MCD4-SCON)

1. Receive the signal.
   TV terminal (sub) : no signal
   VIDEO terminal (main) : color-bar signal
2. Set to P & P mode, and set to service mode.
3. Connect an oscilloscope between pin ⑳ of CN513 (A board) and ground.
4. Select " MCD4-SCON ", and adjust so that the waveform level is 0.525 ± 0.015Vp-p.
5. Write the data into memory.
   MUTING → ENTER



Fig. 5-4

5-5. SUB-CONTRAST ADJUSTMENT (MCP2-SCON)

1. Receive the color-bar signal.
2. VIDEO MODE : PRO
   PICTURE : maximum
   COLOR : minimum
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP2-SBRT : 25
3. Set to service mode.
4. Connect an oscilloscope between pin ③ of CN503 (A board) connecter and ground.
5. Select " MCP 2-SCON ", and adjust so that the waveform level is 1.750 ± 0.030Vp-p.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-5

5-6. VIDEO 5 INPUT SUB-CONTRAST ADJUSTMENT (MCP3-SCON)

1. VIDEO 5 input the color-bar signal.
2. PICTURE : maximum
   COLOR : minimum
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP3-SBRT : 25
3. Set to service mode.
4. Connect an oscilloscope between pin ③ of CN503 (A board) connecter and ground.
5. Select " MCP 3-SCON ", and adjust so that the waveform level is 1.750 ± 0.030Vp-p.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-6

5-7. SUB-HUE AND SUB-COLOR ADJUSTMENT (MCD1-SHUE, SCOL)

1. Receive the color-bar signal.
2. VIDEO MODE : PRO
   PICTURE : maximum
   COLOR : center
   HUE : HUE
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP2-SBRT : 25
   MCP2-SHUE : 7
   MCP2-SCOL : 12
3. Set to service mode.
4. Connect an oscilloscope between pin ⑤ of CN503 (A board) connecter and ground.
5. Select " MCD 1-SHUE, SCOL ", and adjust them to have VB1 = VB4 and VB2 = VB3 in the waveform levels.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-7

5-8. VIDEO INPUT SUB-HUE AND SUB-COLOR ADJUSTMENT (MCD3-SHUE, SCOL)

1. VIDEO input the color-bar signal.
2. VIDEO MODE : PRO
   PICTURE : maximum
   COLOR : center
   HUE : HUE
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP2-SBRT : 25
   MCP2-SHUE : 7
   MCP2-SCOL : 12
3. Set to service mode.
4. Connect an oscilloscope between pin ⑤ of CN503 (A board) connecter and ground.
5. Select " MCD 3-SHUE, SCOL ", and adjust them to have VB1 = VB4 and VB2 = VB3 in the waveform levels.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-8

5-9. P & P SUB-HUE AND SUB-COLOR ADJUSTMENT (MCD2-SHUE, SCOL)

1. Receive the signal.
   TV terminal (main) : color-bar signal
   VIDEO terminal (sub) : no signal
2. VIDEO MODE : PRO
   PICTURE : maximum
   COLOR : center
   HUE : HUE
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP2-SBRT : 25
   MCP2-SHUE : 7
   MCP2-SCOL : 12
3. Set to P & P mode, set to service mode.
4. Connect an oscilloscope between pin ⑤ of CN503 (A board) connecter and ground.
5. Select " MCD 2-SHUE, SCOL ", and adjust them to have VB1 = VB4 and VB2 = VB3 in the waveform levels.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-9

5-10. P & P SUB-HUE AND SUB-COLOR ADJUSTMENT (MCD4-SHUE, SCOL)

1. Receive the signal.
   TV terminal (main) : no signal
   VIDEO terminal (sub) : color-bar signal
2. VIDEO MODE : PRO
   PICTURE : maximum
   COLOR : center
   HUE : HUE
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP2-SBRT : 25
   MCP2-SHUE : 7
   MCP2-SCOL :12
3. Set to P & P mode, set to service mode.
4. Connect an oscilloscope between pin ⑤ of CN503 (A board) connecter and ground.
5. Select " MCD 4-SHUE, SCOL ", and adjust them to have VB1 = VB4 and VB2 = VB3 in the waveform levels.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-10

[SCD MODE]

5-11. P & P SUB CONTRAST ADJUSTMENT (SCD1-SCON)

1. Receive the signal.
   TV terminal (sub) : color-bar signal
   VIDEO terminal (main) : no signal
2. Set to P & P mode, and set to service mode.
3. Connect an oscilloscope between pin ⑳ of CN513 (A board) and ground.
4. Select " SCD1-SCON ", and adjust so that the wave from level is 0.525 ± 0.015Vp-p.
5. Write the data into memory.
   MUTING → ENTER



Fig. 5-11

5-12. P & P SUB CONTRAST ADJUSTMENT (SCD2-SCON)

1. Receive the signal.
   TV terminal (main) : no signal
   VIDEO terminal (sub) : color-bar signal
2. Set to P & P mode, and set to service mode.
3. Connect an oscilloscope between pin ⑳ of CN513 (A board) and ground.
4. Select " SCD2-SCON ", and adjust so that the wave from level is 0.525 ± 0.015Vp-p.
5. Write the data into memory.
   MUTING → ENTER



Fig. 5-12

5-13. SUB-HUE AND SUB-COLOR ADJUSTMENT (SCD1-HUE, SCOL)

1. Receive the color-bar signal.
2. VIDEO MODE : PRO
   PICTURE : maximum
   COLOR : center
   HUE : HUE
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP2-SBRT : 25
   MCP2-SHUE : 7
   MCP2-SCOL : 12
3. Set to service mode.
4. Connect an oscilloscope between pin ⑤ of CN503 (A board) connecter and ground.
5. Select " SCD1-SHUE, SCOL ", and adjust them to have VB1 = VB4 and VB2 = VB3 in the waveform levels.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-11

5-14. SUB-HUE AND SUB-COLOR ADJUSTMENT (SCD2-HUE, SCOL)

1. Receive the color-bar signal.
2. VIDEO MODE : PRO
   PICTURE : maximum
   COLOR : center
   HUE : HUE
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP2-SBRT : 25
   MCP2-SHUE : 7
   MCP2-SCOL : 12
3. Set to service mode.
4. Connect an oscilloscope between pin ⑤ of CN503 (A board) connecter and ground.
5. Select " SCD2-HUE, SCOL ", and adjust them to have VB1 = VB4 and VB2 = VB3 in the waveform levels.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-12

5-15. VIDEO 5 INPUT SUB-HUE AND SUB-COLOR ADJUSTMENT (MCP3-SHUE, SCOL)

1. VIDEO 5 input the color-bar signal.
2. PICTURE : maximum
   COLOR : minimum
   HUE : HUE
   BRIGHTNESS : center
   TRINITONE : medium
   SERVICE DATA MCP3-SBRT : 25
3. Set to service mode.
4. Connect an oscilloscope between pin ③ of CN503 (A board) connecter and ground.
5. Select " MCP 3-SHUE, SCOL ", and adjust them to have VB1 = VB4 and VB2 = VB3 in the waveform levels.
6. Write the data into memory.
   MUTING → ENTER



Fig. 5-15

[MCD MODE]

5-16. DISPLAY POSITION ADJUSTMENT (OSD-HPOS)

1. Receive the monoscope signal.
2. Set to Service mode.
3. Select " OSD-HPOS ", and adjust so that the left edge of MENU is as shown to the spec.
4. Write the data into memory.
   MUTING → ENTER



Fig. 5-16

5-17. CAPTION VISION POSITION ADJUSTMENT (MCCD-CCDH)

1. Receive signal with CAPTION VISION data.
2. Set to Service mode.
3. Display TEXT BOX.
4. Select " MCCD-CCDH ", and adjust data so that A≒B .
5. Write the data into memory.
   MUTING → ENTER



Fig. 5-17

5-18. MID DISPLAY POSITION ADJUSTMENT (MID-HPOS)

1. Display 1/9 size PIP.
2. Set to Service mode.
3. Select " MID-HPOS ", and adjust data so that A≒B .
4. Write the data into memory.
   MUTING → ENTER



Fig. 5-18

SECTION 6
DIAGRAMS

6-1. BLOCK DIAGRAM (1)



BLOCK DIAGRAM (2)



BLOCK DIAGRAM (3)



BLOCK DIAGRAM (4)



BR (TBC, UP CONVERTER, A/D CONVERTER)

KP-53-61XBR200-BD-3-M

BLOCK DIAGRAM (5)



BLOCK DIAGRAM (6)



BLOCK DIAGRAM (7)



BLOCK DIAGRAM (8)



6-2. FRAME SCHEMATIC DIAGRAM



6-3. CIRCUIT BOARDS LOCATION



6-4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

Note:

- Capacitors without voltage indication are all 50V.
- All resistors are in ohms.
  kΩ=1000Ω, MΩ=1000kΩ
- Indication of resistance, which dose not have one for rating electrical power, is as follows.

  Pitch : 5mm
  Rating electrical power : 1/4 W
- : nonflammable resistor.
- : fusible resistor.
- : internal component.
- : panel designation and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- : earth-chassis.
- The components identified by ⋈ in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.
  Should replacement be required, replace only with the value originally used.
- When replacing components identified by ◪ make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by ⋈ and repeat the adjustment until the specified value is achieved. (Refer to R8194, R8196, R8201 and R8202 adjustment on Page 54.)
- When replacing the part in below table, be sure to perform the related adjustment.

Part replaced (◪)	Adjustment (⋈)
C8064, C8066, C8070, C8074, C8076,C8082, D8042, IC8002, IC8007, IC8008, Q8022, R8093, R8095, R8096, R8105, R8108, R8112, R8113, R8114, R8115,R8126, R8128, R8136, R8138, R8139, R8154, R8157, R8168,R8173, R8174, R8177, R8178, R8195, R8196, R8201, T8002 (LOT), T8003 (FBT), HV BLOCK, D BOARD	HV Reagurator (R8194, R8202)
D8026, D8032, D8035, D8050, IC8006, IC8009, IC8010, Q8021, Q8031, R8092, R8094, R8097, R8109, R8110,R8117, R8118, R8121, R8123, R8125, R8129, R8135, R8140, R8155, R8190, R8191, R8192, R8193, R8194, R8198, R8202, T8002 (LOT), T8003(FBT) HV BLOCK, D BOARD	HV HOLD-DOWN (R8196, R8201)

- Readings are taken with a color-bar signal input.
- Readings are taken with a 10MΩ digital multimeter.
- Voltages are dc with respect to ground unless otherwise noted.
- Voltage variations may be noted due to normal production tolerances.
- All voltages are in V.
  * : Measurement impossibility.
- Circled numbers are waveform references.
- ——— : B+ bus.
- - - - : B– bus.
- ⇨ : signal path.(RF)

Reference information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RW	NONFLAMMABLE WIREWOUND
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: ※	ADJUSTMENT RESISTOR
COIL	: LF-SL	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

Note: The symbol ⋈ display is on the component side.

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

The symbol ⋈ indicate fast operating fuse. Replace only with fuse of same rating as maked.

Note: Les composants identifiés par un tramé et une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Le symbole ⋈ indique une fusible a action rapide. Doit etre remplacee par une fusible de meme yaleur, comme maque.

Terminal name of semiconductors in silk screen printed circuit (*)

	Device	Printed symbol	Terminal name	Circuit
①	Transistor		Collector / Base / Emitter	
②	Transistor		Collector / Base / Emitter	
③	Diode		Cathode / Anode	
④	Diode		Cathode / Anode (NC)	
⑤	Diode		Cathode / Anode (NC)	
⑥	Diode		Common / Anode / Cathode	
⑦	Diode		Common / Anode / Cathode	
⑧	Diode		Common / Anode / Anode	
⑨	Diode		Common / Anode / Anode	
⑩	Diode		Common / Cathode / Cathode	
⑪	Diode		Common / Cathode / Cathode	
⑫	Diode		Anode / Cathode / Anode / Anode / Cathode / Anode	
⑬	Transistor (FET)		Drain / Source / Gate	
⑭	Transistor (FET)		Drain / Source / Gate	
–	Discrete semiconductor			

(Chip semiconductors that are not actually used are included.)

Ver.1.0

A (1/4) [TUNER, AV SW, JUNGLE, VIDEO PROCESSOR] **A (2/4)** [YUV SW, CHROMA DECODER] **A (3/4)** [U COM OSD] **A (4/4)** [REGI SENSOR I/F]

– A Board –



< Component Side >



< Conductor Side >

A BOARD

DIODE			
	L	R	*
D501		D-2	⑤
D502		L-1	⑤
D503		B-4	⑤
D504		L-4	⑤
D505		M-3	⑤
D506		E-3	⑤
D508		D-3	⑤
D509		D-3	⑤
D511		K-4	⑤
D512		B-4	⑤
D513		K-3	⑤
D514		B-4	⑤
D515	A-6		⑤
D516	A-6		⑤
D517	A-6		⑤
D518		E-3	⑤
D519		K-9	⑤
D520		K-9	⑤
D521	D-10		⑤
D522		J-9	⑤
D523	J-10		⑤
D524		G-9	⑤
D525		F-10	⑤
D526		H-9	⑤
D527		H-9	⑤
D528		I-9	⑤
D529		I-9	⑤
D530	F-8		⑤
D531		F-3	⑤
D532		G-9	⑤
D533		H-9	⑤
D534		I-9	⑤
D535		J-9	⑤
D536	J-10		⑤
D537		G-9	⑤
D538		H-9	⑤
D539		I-9	⑤
D540		K-10	⑤
D541		K-10	⑤
D542	J-10		⑤
D543		F-10	⑤
D544		H-9	⑤
D545		I-9	⑤
D546		J-9	⑤
D547		J-9	⑤
D548		F-3	⑤
D550		G-10	⑤
D551		H-9	⑤
D552		I-9	⑤
D555		K-9	⑤
D556		K-9	⑤
D557		J-9	⑤
D558		J-1	⑤
D559		K-10	⑤
D560		K-10	⑤
D1001		H-4	⑤
D1002		H-4	⑤
D1003		G-5	⑤
D1005		I-3	⑤
D1006		I-3	⑤
D1007		I-3	⑤
D1008		I-5	⑤
D1009		I-5	⑤
D1601		B-3	⑤
D1602		C-3	⑤
D1603		B-3	⑤
D1604		B-3	⑤
D1605		B-3	⑤
D1614		A-3	⑤
D1615		B-3	⑤
D1616		C-3	⑤
D1618		A-2	⑤
D1620		B-2	⑤
D1623		B-2	⑤
D1625		B-2	⑤
D1626		B-2	⑤
D1628		B-2	⑤
D1630		B-2	⑤
D1632		C-2	⑤
D1634	B-5		⑤

TRANSISTOR			
	L	R	*
Q501		D-2	①
Q502		M-5	①
Q503		D-1	①
Q504		C-1	①
Q505		C-1	①
Q506		M-4	①
Q507		L-3	①
Q508		E-3	①
Q509		D-3	①
Q510		D-2	①
Q511		E-4	①
Q512		K-4	①
Q513		E-4	①
Q514		B-4	①
Q515		D-4	①
Q516		D-2	①
Q517		M-4	①
Q518		L-4	①
Q519		D-4	①
Q520		E-3	①
Q521		D-4	①
Q522		A-4	①
Q523		D-4	①
Q524		E-2	①
Q525		E-3	①
Q526		L-4	①
Q527		D-1	①
Q528	L-4		②
Q530		E-5	①
Q531	L-4		②
Q532	K-4		②
Q533	L-4		②
Q535		L-9	①
Q536	K-4		②
Q537		L-9	①
Q538		D-2	①
Q539		D-2	①
Q540		F-2	①
Q541		K-9	①
Q542		L-10	①
Q543		L-10	①
Q544		L-10	①
Q545		K-9	①
Q546		E-5	①
Q547	J-10		②
Q548		M-9	①
Q549	B-7		②
Q550	B-7		②
Q551	B-7		②
Q552	E-9		②
Q553	E-9		②
Q554	C-10		②
Q560		E-3	①
Q1011		H-5	①
Q1012		G-5	①
Q1015	I-9		②
Q1018		F-5	①
Q1020		F-5	①
Q1022		F-5	①
Q1301	E-4		②
Q1302	F-5		②
Q1303	E-5		②
Q1304	H-4		②
Q1305		F-9	①
Q1306	H-5		②
Q1307	H-5		②
Q1308		F-10	①
Q1309		F-10	①
Q1311	H-5		②
Q1312	E-4		②
Q1313		H-7	①
Q1315	F-5		②
Q1317		G-7	①
Q1318		G-7	①
Q1319		H-7	①
Q1320		G-7	①
Q1321		G-9	①
Q1322		G-9	①
Q1323		H-9	①
Q1324	F-2		②
Q1325	F-2		②
Q1326	F-2		②
Q1327	F-2		②
Q1328	H-3		②
Q1329	F-4		②
Q1330	I-4		②
Q1331	I-4		②
Q1332	H-4		②
Q1333	E-4		②
Q1335	E-4		②
Q1336	F-4		②
Q1338		G-8	①
Q1343	F-3		②
Q1366		F-10	①
Q1367		F-10	①
Q1402	F-7		②
Q1403	F-7		②
Q1404	E-6		②
Q1405		J-8	①
Q1406	E-6		②
Q1407		J-7	①
Q1408		J-7	①
Q1413		E-8	①
Q1414		E-8	①
Q1415		E-9	①
Q1416		E-9	①
Q1417		E-8	①
Q1418		E-9	①
Q1419		E-9	①
Q1420		E-9	①
Q1421		E-8	①
Q1422		E-9	①
Q1601	A-2		①
Q1602	B-2		①
Q1603	B-2		①
Q1604	B-2		①
Q1605	B-2		①
Q1606	B-2		①
Q1607	B-2		①
Q1608	C-2		①
Q1609	A-9		①
Q1610	B-9		①
Q1611	B-9		①
Q1612	B-9		①
Q1613	B-9		①
Q1614	B-9		①
Q1615	B-9		①
Q1616	C-9		①
Q1617	B-8		②
Q1621	B-5		②
Q1628	E-5		①
Q1629	B-5		②
Q1630	A-5		②
Q1631	B-6		②

IC		
	L	R
IC501	E-10	E-1
IC503	C-9	C-2
IC504	G-10	G-2
IC505	I-10	I-2
IC506	G-8	G-3
IC507	B-7	B-4
IC508	C-8	
IC509	E-7	
IC510	E-9	
IC511	E-8	
IC512	B-6	
IC513	F-8	
IC514	B-6	
IC515	L-3	
IC516	F-8	
IC517	C-8	
IC518	A-6	
IC519	F-9	
IC520	H-8	
IC1002		I-4
IC1003	G-7	
IC1004	H-7	
IC1005	H-9	
IC1007		J-5
IC1008	J-7	
IC1009	J-8	
IC1010		K-7
IC1301	H-5	
IC1302	F-4	
IC1303	F-1	
IC1305	G-3	
IC1307	F-3	
IC1401	E-5	
IC1402		F-7
IC1403	E-3	
IC1601	B-10	
IC1603	B-8	
IC1604	B-10	
IC1605	B-9	
IC1606	B-9	
IC1608	D-7	
IC1609	C-7	
IC1623	C-7	
IC1624	D-7	

L ; component side
R ; conductor side

• A(1/4) BOARD WAVEFORMS




A (4/4)
A (3/4)
A (2/4)
A (1/4)
TUNER 4V 5K JUNGLE
VIDEO PROCESSOR, I/O
A(1/4) BOARD : IC507 LA7856
A(1/4) BOARD : IC508
TC74HC74AF (EL)
A(1/4) BOARD : IC517, 519
TC74HC4538AF (EL)
A(1/4) BOARD : IC509 MC74HC4052EL
A(1/4) BOARD : IC515 CXA1845AQ
A(1/4) BOARD : IC512 CXD2018Q
ANT SW
IC511 CXA1201AQ-TL VIDEO PROCESSOR
IC515 CXA1845Q-TL AVU SWITCH
IC512 CXD2018Q DIGITAL PART
ANALOG PART
IC507 LA7856 H JUNGLE
IC508 TC74HC74AF(EL) MODE/EVEN
IC509 TC74HC4052AF(EL) SYNC SW
IC517 TC74HC4538AF(EL) H BLK DELAY
IC519 TC74HC4538AF(EL) H/L MASK
IC516 LM358DGR AMP
IC514 LM358DGR AMP
IC506 PQ05RV31 5V REG
IC504 PQ05RF21 5V REG
IC505 PQ09RF21 9V REG
IC501 NJM7812FA 12V REG
Q503 LM2940S-5.0 5V REG
TO ZR BOARD CN4102
TO CR BOARD CN4101
TO G BOARD CN4104
TO G BOARD CN4105
TO H4 BOARD CN5101
TO K BOARD CN2102
TO G BOARD CN4105
TO BA BOARD CN2401
TO BH BOARD CN502
TO BH BOARD CN501
TO BG BOARD CN1702
TO BG BOARD CN1701
TO (I/J) BOARD CN5004
TO (I/J) BOARD CN5011
TO (I/J) BOARD CN5009
TO (I/J) BOARD CN5010
TO U BOARD CN5501
TO K BOARD CN2105
TO HB BOARD CN3201
BUS CONNECTOR
S VIDEO
VIDEO 1
VIDEO 2
VIDEO 3
VIDEO 4
VIDEO 5 (EXT)
SELECT OUT



Schematic diagram
← A (1/4) board

Schematic diagram
A (2/4) board →

A(2/4) BOARD : IC1301, 1305 CXA2019AQ-T4



A(2/4) BOARD : IC1302, 1307 CXA2119M



• A(2/4) BOARD WAVEFORMS



A(2/4)BOARD : IC1403 MC14053BFEL





• A(3/4) BOARD WAVEFORMS

① 12MHz 5Vp-p (H)

② 1.8Vp-p (H)

③ 8MHz 5.5Vp-p (H)

A(4/4) BOARD : IC1609, 1608 TC74HC163AF(EL)



A(4/4) BOARD : IC1603 MC14053BFEL









• BA BOARD WAVEFORMS



BA [3D COMB FILTER]

– BA Board –



< Component Side >



< Conductor Side >

BA BOARD

TRANSISTOR	L	R	*
Q2401	C-4		②
Q2402	C-4		②
Q2403	C-4		②
Q2404		C-2	①
Q2405	C-4		②
Q2406		C-2	①
Q2407		C-2	①
Q2408	B-4		②
Q2409	B-4		②
Q2410		B-2	①
Q2411		A-2	①
Q2412	A-5		②
Q2413	A-4		②
Q2414		A-2	①
Q2415		B-2	①
Q2416	B-5		②
Q2417	B-4		②
Q2418	C-3		②
Q2419		B-2	①
Q2421		C-3	①
Q2422	C-3		②

IC	L	R
IC2401	B-1	
IC2402	B-2	
IC2403	B-3	

L ; component side
R ; conductor side

BM BOARD : IC002, 008, 011 TLC2932IPW



• BM BOARD WAVEFORMS





BM [MID]

– BM Board –



< Component Side >



< Conductor Side >

BM BOARD

DIODE

	L	R	*
D001		F-4	③
D002		C-3	③
D003		C-3	③

TRANSISTOR

	L	R	*
Q001		B-2	①
Q002		B-2	①
Q006		B-2	①
Q007		B-2	①
Q009		B-3	①
Q010		B-3	①
Q018		G-3	①
Q019		C-3	①
Q020		G-4	①
Q021		D-3	①
Q022		G-5	①
Q023		C-3	①
Q025		G-4	①
Q026		D-4	①
Q027		G-5	①
Q028		G-5	①
Q029		C-4	①
Q030		D-4	①
Q031		E-4	①
Q032		B-4	①

IC

	L	R
IC001	F-5	
IC002	E-5	
IC003	D-5	
IC004	E-4	
IC005	B-3	
IC006	B-3	
IC007	G-4	
IC008	G-4	
IC009	C-3	
IC010	E-4	
IC011	E-3	
IC012	E-3	
IC013	F-3	
IC014	D-2	

L ; component side

R ; conductor side

BR [DRC]

– BR Board –

BR BOARD

DIODE			
	L	R	*
D301		F-3	③
D2301	E-3		③

TRANSISTOR			
	L	R	*
Q301		B-4	①
Q302		F-3	①
Q303		B-3	①
Q306	F-5		②
Q308	E-4		②
Q312	F-3		②
Q317	E-4		②
Q318		D-4	①
Q319	D-2		②
Q322		C-4	①
Q323	C-2		②
Q325		C-4	①
Q326		C-4	①
Q401	B-4		①
Q403	B-2		②
Q2301		F-4	
Q2302	G-3		②
Q2303	F-3		②
Q2304	G-3		②
Q2305		E-4	①
Q2306		F-4	①
Q2307	G-3		②
Q2308	F-3		②
Q2309		F-4	①
Q2310		F-4	①
Q2311	G-3		②
Q2312	F-2		②
Q2313		F-4	①

IC		
	L	R
IC301	B-3	
IC302	A-5	
IC303	E-3	
IC304	C-5	
IC305	D-4	
IC306	E-4	
IC466	F-3	
IC2301	F-2	

L ; component side
R ; conductor side



< Component Side >



< Conductor Side >



BR BOARD : IC303 TLC2932IPW



• BR BOARD WAVEFORMS



BD BOARD : IC1713, 1714, 1715, 1719, 1720, 1721 PCM56P-L



BD BOARD : IC1722 TLC2935IPW



BD BOARD : IC1716 TC74HC74AF (EL)



• BD BOARD WAVEFORMS





Schematic diagram ← BR board

Schematic diagram BD board →

BD [DIGITAL REGI]

– BD Board –



< Component Side >



< Conductor Side >

BD BOARD

DIODE

	L	R	*
D1701	G-2		③
D1702	F-2		③
D1703	F-2		③
D1704	F-2		③
D1705		G-2	③
D1706		E-4	③

TRANSISTOR

	L	R	*
Q001		B-2	①
Q1701	E-3		②
Q1702	G-2		②
Q1703	E-2		②
Q1709	F-3		②
Q1710	E-3		②

IC

	L	R
IC1702	D-4	
IC1703	F-4	
IC1704	E-3	
IC1705	D-3	
IC1706	C-4	
IC1707	F-2	
IC1708	C-3	
IC1709	B-4	
IC1710	B-3	
IC1712	E-4	
IC1713	B-2	B-4
IC1714	C-2	C-4
IC1715	D-2	D-4
IC1716	G-2	
IC1717	G-3	
IC1718	E-3	
IC1719	D-2	D-4
IC1720	C-2	C-4
IC1721	B-2	B-4
IC1722	G-1	
IC1723	G-2	
IC1725	E-2	

L ; component side
R ; conductor side

DS [SHADING]

– DS Board –



< Component Side >

< Conductor Side >


K
AUDIO AMP
AP
DOLBY
I/O
IC2301
NJM4558D
VAR. OUT AMP
IC2302
TDA7312
L,R TONE CONT.
IC2303
TDA7312
C,S TONE CONT.
IC2105
NJW1103
PROLOGIC DECODER
IC2601
TDA7265
L,R AMP
IC2602
TDA2052
C AMP
IC2603
TDA7265
S AMP
IC2102
MC7805CT
5V REG
IC2103
PQ09RF21
9V REG
IC2104
MC7812CT
12V REG
CN2103
WHT
6P
S-MICRO
CN2102
WHT
6P
S-MICRO
CN2101
WHT
8P
VH
CN2601
4P
WHT
S-MICRO
CN2602
4P
WHT
WING(LCK)
CN2603
2P
WHT
WING(LCK)
TO A (1/4) BOARD CN512
TO A (1/4) BOARD CN510
TO G BOARD CN602
VAR L
VAR R
FIXED L
FIXED R
L VAR/FIX AUDIO OUT
R VAR/FIX AUDIO OUT
TEEETER (L)
TEEETER (R)
SPEAKER (R)
SPEAKER (L)
CENTER SPEAKER IN
CENTER SPEAKER
REAR L SP OUT
REAR R SP OUT
K BOARD : IC2105 NJW1103
BY-PASS
PRO LOGIC DECODER
Adaptive Matrix
Noise Shaper
Input Buffer Amp
Channel Mode Control
7kHz LPF & Modified B NR
DIGITAL DELAY
LPF
A/D
16k SRAM
D/A
LPF
TRIMMER
MCU INTERFACE
K BOARD : IC2302, 2303 TDA7312
OUT (L)
IN (L)
ADDR1
BOUT (L)
BIN (L)
TREBLE (L)
SPKR ATT
MUTE
VOL
BASS
TREBLE
INPUT SELECTOR • GAIN
SERIAL BUS DECODER • LATCHES
SUPPLY
L OUT
DIG OUT 2
SCL
SDA
DIGGND
DIG OUT 1
R OUT
K BOARD : IC2601, 2603 TDA7265
K BOARD : IC2602 TDA2052
K BOARD : IC2301 NJM4558D

CR [CRT I/F RED] **CG** [CRT I/F GREEN] **CB** [CRT I/F BLUE]

CR BOARD : IC7101 TDA6111Q/N4
CG BOARD : IC7201 TDA6111Q/N4
CB BOARD : IC7301 TDA6111Q/N4



– CR Board –



– CG Board –



– CB Board –



• CR BOARD WAVEFORMS

• CG BOARD WAVEFORMS

• CB BOARD WAVEFORMS



Schematic diagram
← K board

Schematic diagram
CR CG CB board →



Schematic diagram
ZR ZG board

ZR [DY I/F RED] ZG [DY I/F GREEN]

– ZR Board –



– ZB Board –



Schematic diagram
ZB U board

ZB [DY I/F BLUE] U [SIRCS IN/OUT, DTV HD/VD INPUT]



– ZB Board –



– U Board –



< Component Side >



< Conductor Side >



HA [FUNCTION KEY] **HB** [VIDEO-2 INPUT] **HC** [SIRCS RECEIVER]

– HA Board –



– HB Board –



– HC Board –



G [POWER SUPPLY]

– G Board –

G BOARD

DIODE	
D6001	G-8
D6002	H-7
D6003	G-9
D6004	I-2
D6005	F-9
D6006	F-9
D6007	H-6
D6009	H-5
D6010	J-4
D6011	F-8
D6012	F-8
D6013	J-7
D6014	J-4
D6015	E-8
D6016	H-3
D6017	H-3
D6018	H-3
D6019	H-3
D6020	I-3
D6021	H-2
D6022	G-3
D6023	A-9
D6024	A-9
D6025	H-2
D6026	H-1
D6027	H-1
D6028	H-2
D6029	H-1
D6030	G-2
D6031	I-2
D6032	H-5
D6033	I-2
D6034	J-3
D6035	J-3
D6101	C-5
D6102	D-8
D6103	D-6
D6104	D-6
D6105	E-7
D6106	D-7
D6107	D-7
D6108	C-9
D6109	D-5
D6110	A-4
D6111	B-9
D6112	B-9
D6113	E-8
D6114	D-1
D6116	C-1
D6117	D-9
D6119	D-10
D6120	E-10
D6121	B-4
D6122	B-4
D6123	A-9
D6124	A-9
D6125	B-9

TRANSISTOR	
Q6001	J-3
Q6002	J-4
Q6003	J-2
Q6004	I-4
Q6005	J-4
Q6006	J-4
Q6007	F-4
Q6008	G-3
Q6009	F-2
Q6010	G-2
Q6011	J-3
Q6012	J-3
Q6013	J-3
Q6101	B-4
Q6102	B-9
Q6103	B-9
Q6104	C-9
Q6106	C-10

IC	
IC6001	F-8
IC6002	I-3
IC6003	J-2
IC6004	E-2
IC6005	E-1
IC6011	E-1
IC6101	C-4
IC6102	C-4
IC6103	C-4
IC6104	C-10
IC6301	D-2



Schematic diagram
← HA HB HC board

7-2. COVER (KP-61XBR300)

▲ : +BVTP 3X12 7-685-648-79
● : +BVTP 3X16 7-685-650-79



REF. NO.	PART NO.	DESCRIPTION	REMARK
51	* X-4037-192-1	FRAME ASSY, SCREEN	
52	* A-1372-450-A	HC BOARD, COMPLETE	
53	4-044-726-11	HOLDER (L), SCREEN	
54	4-044-727-01	HOLDER (S), SCREEN	
55	4-065-813-01	SCREEN (61AR), CONTRAST	
56	4-070-283-11	PLATE (L), DIFFUSION	
57	4-066-082-11	PLATE (F), DIFFUSION	
58	X-4035-890-1	PANEL ASSY, FRONT	
59	X-4037-196-1	GRILLE (L) ASSY,BOTTOM SPEAKER	
60	X-4037-195-1	GRILLE (R) ASSY,BOTTOM SPEAKER	
61	4-054-709-01	STRIKE	
62	4-045-250-01	DAMPER	
63	3-703-035-11	SHAFT, LID	
64	4-042-192-01	CATCHER, PUSH	
65	* A-1372-448-A	HA BOARD, COMPLETE	
66	4-063-408-02	BUTTON, MULTI	
67	4-063-409-01	GUIDE, LED	

REF. NO.	PART NO.	DESCRIPTION	REMARK
68	4-063-405-01	PANEL, CONTROL	
69	4-065-741-11	PANEL (ASSY)	
70	* A-1372-449-A	HB BOARD, COMPLETE	
71	X-4037-193-1	GRILLE (L) ASSY, TOP SPEAKER	
72	X-4037-194-1	GRILLE (R) ASSY, TOP SPEAKER	
73	1-505-917-11	SPEAKER (16cm)	
74	1-505-914-11	SPEAKER (10cm)	
75	1-505-916-11	SPEAKER (5.2cm)	
76	4-063-421-01	LATCH (K)	
77	* 4-063-422-01	BRACKET, SENSOR	
78	1-528-911-11	BATTERY, SOLAR	
79	4-030-850-01	SOCKET, CASTER	
80	4-065-810-01	CASTER (50MM), PLP	
81	4-378-522-31	SCREW (4X20), TAPPING	
82	4-063-426-11	LABEL, SUB CONTROL	
83	4-069-115-01	CUSHION, DOOR	
84	4-378-522-11	SCREW, TAPPING, HEXAGON HEAD	

7-3. CHASSIS

● : +BVTP 3X16 7-685-650-79
■ : +BVTP 4X12 7-685-661-14



Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.		PART NO.	DESCRIPTION	REMARK
101		4-065-769-01	MIRROR (61XBR), REFLECTION (61XBR)	
101		4-065-781-01	MIRROR, REFLECTION (53XBR)	
102	*	A-1380-618-A	K BOARD, COMPLETE	
103	*	A-1298-973-A	A BOARD, COMPLETE	
104	*	A-1131-470-A	BM BOARD, COMPLETE	
105	*	A-1131-462-A	BR BOARD, COMPLETE	
106	*	A-1131-460-A	BD BOARD, COMPLETE	
107		8-598-431-20	TUNER, FSS BTF-WA411(TU501)	
108		8-598-431-20	TUNER, FSS BTF-WA411(TU502)	
109	*	A-1346-873-A	D BOARD, COMPLETE (53XBR)	
	*	A-1346-899-A	D BOARD, COMPLETE (61XBR)	
110	⚠	1-453-285-11	FBT ASSY NX-4006/X4P	
111	*	A-1316-400-A	G BOARD, COMPLETE	
112	⚠	1-783-595-11	CORD, NOISE FILTER WITH POWER	
113	*	1-556-945-21	CABLE, P-P	
114	*	1-557-056-31	CABLE, P-P	
115		1-251-321-12	SELECTOR, ANTENNA	
116	*	A-1373-761-A	U BOARD, COMPLETE	
117		4-065-812-21	TERMINAL BOARD (ASSY)	
118		4-052-894-01	SCREW (4X20), HEAD TAPPING	
119		4-378-522-31	SCREW (4X20), TAPPING	
120		4-071-136-01	LABEL (A), TERMINAL	
121		4-063-425-01	LABEL (B), TERMINAL	
122		4-059-099-01	SPACER, FOAM	
123	*	A-1343-712-A	DS BOARD, COMPLETE	
124	*	A-1131-461-A	BA BOARD, COMPLETE	
125		4-378-522-11	SCREW, TAPPING, HEXAGON HEAD	
126		1-543-653-11	CORE ASSY, BEAD(DIVISION TYPE)	
127		1-500-021-11	CLAMP, SLEEVE FERRITE	

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

7-4. PICTURE TUBE



REF. NO.	PART NO.	DESCRIPTION	REMARK
151	4-065-715-01	LENS (DELTA 37.AB)	
152	⚠ 8-736-089-05	CRT 07MZC3(R) (53XBR)	
152	⚠ 8-736-091-05	CRT 07MZC4(R) (61XBR)	
153	⚠ 1-451-510-11	DEFLECTION YORK	
154	* A-1390-950-A	ZR BOARD, COMPLETE	
155	⚠ 1-452-790-21	NECK ASSY	
156	* A-1331-972-A	CR BOARD, COMPLETE	
157	⚠ 8-736-087-05	CRT 07MZC2(G)	
158	* A-1390-951-A	ZG BOARD, COMPLETE	
159	* A-1331-973-A	CG BOARD, COMPLETE	
160	⚠ 8-736-088-05	CRT 07MZC3(B) (53XBR)	
	⚠ 8-736-090-05	CRT 07MZC4(B) (61XBR)	

REF. NO.	PART NO.	DESCRIPTION	REMARK
161	* A-1390-952-A	ZB BOARD, COMPLETE	
162	* A-1331-974-A	CB BOARD, COMPLETE	
163	⚠ 1-223-925-51	RESISTOR ASSY (HIGH-VOLTAGE) (FOCUS PACK)	
164	* 4-063-403-01	BRACKET, FOCUS PACK	
165	* 4-057-596-01	BRACKET, HV	
166	⚠ 8-598-955-12	BLOCK ASSY, HIGH-VOLTAGE	
167	4-373-137-01	CAP (Z), RUBBER	
168	4-069-677-01	BOARD (L), SIDE	
169	4-069-678-01	BOARD (R), SIDE	
170	* 4-072-791-01	SPACER, BOTTOM	

BD

SECTION 8
ELECTRICAL PARTS LIST

The components identified by shading and mark ⚠ are critial for safety.
Replace only with part number specified.

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite.
Ne les remplacer que par une piece portant le numero specifie.

When indicating parts by reference number, please include the board name.

- The components identified by in ⊠ this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS
- All resistors are in ohms
- F : nonflammable

- CAPACITORS
  PF : μμ F
- There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please include the board name.

REF. NO.	PART NO.	DESCRIPTION			REMARK
*	A-1131-460-A	BD BOARD, COMPLETE			
		**********			
		<CAPACITOR>			
C1703	1-163-275-11	CERAMIC CHIP	0.001μF	5%	50V
C1705	1-164-346-11	CERAMIC CHIP	1μF		16V
C1707	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1708	1-104-664-11	ELECT	47μF	20%	25V
C1709	1-126-964-11	ELECT	10μF	20%	50V
C1710	1-164-346-11	CERAMIC CHIP	1μF		16V
C1711	1-164-690-91	CERAMIC CHIP	0.0022μF	5%	50V
C1712	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1713	1-104-664-11	ELECT	47μF	20%	25V
C1714	1-164-346-11	CERAMIC CHIP	1μF		16V
C1717	1-163-275-11	CERAMIC CHIP	0.001μF	5%	50V
C1718	1-164-690-91	CERAMIC CHIP	0.0022μF	5%	50V
C1719	1-163-237-11	CERAMIC CHIP	27pF	5%	50V
C1721	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1722	1-104-664-11	ELECT	47μF	20%	25V
C1723	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1724	1-104-664-11	ELECT	47μF	20%	25V
C1725	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C1727	1-164-690-91	CERAMIC CHIP	0.0022μF	5%	50V
C1729	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1730	1-104-664-11	ELECT	47μF	20%	25V
C1737	1-163-275-11	CERAMIC CHIP	0.001μF	5%	50V
C1738	1-164-690-91	CERAMIC CHIP	0.0022μF	5%	50V
C1739	1-104-664-11	ELECT	47μF	20%	25V
C1740	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1741	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1744	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1745	1-104-664-11	ELECT	47μF	20%	25V
C1747	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1748	1-104-664-11	ELECT	47μF	20%	25V
C1749	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1750	1-104-664-11	ELECT	47μF	20%	25V
C1753	1-163-275-11	CERAMIC CHIP	0.001μF	5%	50V
C1757	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1758	1-104-664-11	ELECT	47μF	20%	25V
C1761	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1762	1-104-664-11	ELECT	47μF	20%	25V
C1763	1-104-664-11	ELECT	47μF	20%	25V
C1764	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1768	1-163-275-11	CERAMIC CHIP	0.001μF	5%	50V
C1772	1-115-339-11	CERAMIC CHIP	0.1μF	10%	50V
C1773	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1774	1-104-664-11	ELECT	47μF	20%	25V
C1775	1-164-161-11	CERAMIC CHIP	0.0022μF	10%	50V
C1776	1-104-664-11	ELECT	47μF	20%	25V
C1777	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1779	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C1780	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1781	1-104-664-11	ELECT	47μF	20%	25V
C1785	1-163-275-11	CERAMIC CHIP	0.001μF	5%	50V
C1786	1-164-690-91	CERAMIC CHIP	0.0022μF	5%	50V
C1787	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1788	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1789	1-104-664-11	ELECT	47μF	20%	25V
C1790	1-104-664-11	ELECT	47μF	20%	25V
C1791	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C1792	1-104-664-11	ELECT	47μF	20%	25V
C1793	1-104-664-11	ELECT	47μF	20%	25V
C1794	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1796	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1797	1-104-664-11	ELECT	47μF	20%	25V
C1798	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1799	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1801	1-104-664-11	ELECT	47μF	20%	25V
C1802	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C1803	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1804	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1805	1-104-664-11	ELECT	47μF	20%	25V
C1806	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1807	1-104-664-11	ELECT	47μF	20%	25V
C1808	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1809	1-104-664-11	ELECT	47μF	20%	25V
C1810	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1811	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C1812	1-163-038-91	CERAMIC CHIP	0.1μF		25V
C1814	1-104-664-11	ELECT	47μF	20%	25V

REF. NO.	PART NO.	DESCRIPTION			REMARK
C1815	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1816	1-104-664-11	ELECT	47µF	20%	25V
C1817	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1818	1-104-664-11	ELECT	47µF	20%	25V
C1819	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1820	1-163-235-11	CERAMIC CHIP	22pF	5%	50V
C1821	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1822	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1823	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1824	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1825	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1830	1-115-339-11	CERAMIC CHIP	0.1µF	10%	50V
C1831	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1832	1-104-664-11	ELECT	47µF	20%	25V
C1833	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C1834	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1835	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1836	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1837	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1838	1-104-664-11	ELECT	47µF	20%	25V
C1839	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1840	1-104-664-11	ELECT	47µF	20%	25V
C1841	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1842	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1844	1-104-664-11	ELECT	47µF	20%	25V
C1845	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1846	1-104-664-11	ELECT	47µF	20%	25V
C1847	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1849	1-164-690-91	CERAMIC CHIP	0.0022µF	5%	50V
C1855	1-104-664-11	ELECT	47µF	20%	25V
C1856	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1857	1-104-664-11	ELECT	47µF	20%	25V
C1858	1-104-664-11	ELECT	47µF	20%	25V
C1859	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C1860	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1861	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1862	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1863	1-163-001-11	CERAMIC CHIP	220pF	10%	50V
C1864	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1877	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1878	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C1879	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1880	1-163-038-91	CERAMIC CHIP	0.1µF		25V

<CONNECTOR>

CN1701	1-573-301-21	CONNECTOR, BOARD TO BOARD 20P	
CN1702	1-573-301-21	CONNECTOR, BOARD TO BOARD 20P	

<DIODE>

D1701	8-719-073-01	DIODE	MA111-(K8).S0
D1702	8-719-073-01	DIODE	MA111-(K8).S0
D1703	8-719-073-01	DIODE	MA111-(K8).S0
D1704	8-719-073-01	DIODE	MA111-(K8).S0
D1705	8-719-073-01	DIODE	MA111-(K8).S0
D1706	8-719-073-01	DIODE	MA111-(K8).S0

REF. NO.	PART NO.	DESCRIPTION	REMARK

<IC>

IC1702	8-759-106-02	IC	µPC4570G2
IC1703	8-752-910-92	IC	CXP86324-023Q
IC1704	8-759-468-90	IC	ST24E16FM6TR
IC1705	8-759-106-02	IC	µPC4570G2
IC1706	8-759-106-02	IC	µPC4570G2
IC1707	8-759-589-66	IC	CM0006CF
IC1708	8-759-106-02	IC	µPC4570G2
IC1709	8-759-106-02	IC	µPC4570G2
IC1710	8-759-106-02	IC	µPC4570G2
IC1712	8-759-032-20	IC	MC74HC32AF
IC1713	8-759-998-22	IC	PCM56P
IC1714	8-759-998-22	IC	PCM56P
IC1715	8-759-998-22	IC	PCM56P
IC1716	8-759-032-23	IC	MC74HC74AF
IC1717	8-759-488-29	IC	TC7W66FU(TE12R)
IC1718	8-759-352-91	IC	PST9143NL
IC1719	8-759-998-22	IC	PCM56P
IC1720	8-759-998-22	IC	PCM56P
IC1721	8-759-998-22	IC	PCM56P
IC1722	8-759-295-09	IC	TLC2932IPW
IC1723	8-759-485-79	IC	TC7SET08FU(TE85L)
IC1725	8-759-485-79	IC	TC7SET08FU(TE85L)

<CHIPCONDUCTOR>

JR1701	1-216-295-91	SHORT	0

<COIL>

L1703	1-469-555-21	INDUCTOR	10µH
L1704	1-469-555-21	INDUCTOR	10µH
L1707	1-469-555-21	INDUCTOR	10µH
L1708	1-469-555-21	INDUCTOR	10µH
L1709	1-414-234-22	INDUCTOR CHIP	0µH
L1710	1-469-555-21	INDUCTOR	10µH
L1713	1-469-555-21	INDUCTOR	10µH
L1714	1-414-234-22	INDUCTOR CHIP	0µH
L1715	1-469-555-21	INDUCTOR	10µH
L1716	1-469-555-21	INDUCTOR	10µH
L1719	1-469-555-21	INDUCTOR	10µH
L1720	1-469-555-21	INDUCTOR	10µH
L1721	1-414-234-22	INDUCTOR CHIP	0µH
L1724	1-469-555-21	INDUCTOR	10µH
L1725	1-414-234-22	INDUCTOR CHIP	0µH
L1726	1-469-555-21	INDUCTOR	10µH
L1729	1-414-234-22	INDUCTOR CHIP	0µH
L1730	1-469-555-21	INDUCTOR	10µH
L1731	1-469-555-21	INDUCTOR	10µH
L1732	1-414-234-22	INDUCTOR CHIP	0µH
L1733	1-414-234-22	INDUCTOR CHIP	0µH
L1734	1-414-234-22	INDUCTOR CHIP	0µH
L1735	1-414-234-22	INDUCTOR CHIP	0µH
L1736	1-414-234-22	INDUCTOR CHIP	0µH
L1737	1-414-234-22	INDUCTOR CHIP	0µH
L1738	1-414-234-22	INDUCTOR CHIP	0µH

REF. NO.	PART NO.	DESCRIPTION	REMARK
L1739	1-414-234-22	INDUCTOR CHIP 0µH	
L1740	1-414-234-22	INDUCTOR CHIP 0µH	
L1741	1-414-234-22	INDUCTOR CHIP 0µH	
L1742	1-414-234-22	INDUCTOR CHIP 0µH	
L1744	1-414-234-22	INDUCTOR CHIP 0µH	
L1745	1-414-234-22	INDUCTOR CHIP 0µH	
L1746	1-414-234-22	INDUCTOR CHIP 0µH	
L1747	1-414-234-22	INDUCTOR CHIP 0µH	
L1748	1-414-234-22	INDUCTOR CHIP 0µH	
L1750	1-414-234-22	INDUCTOR CHIP 0µH	
L1751	1-414-234-22	INDUCTOR CHIP 0µH	
L1753	1-414-234-22	INDUCTOR CHIP 0µH	
L1754	1-414-234-22	INDUCTOR CHIP 0µH	
L1756	1-414-234-22	INDUCTOR CHIP 0µH	
L1757	1-414-234-22	INDUCTOR CHIP 0µH	
L1759	1-414-234-22	INDUCTOR CHIP 0µH	
L1760	1-414-234-22	INDUCTOR CHIP 0µH	
L1762	1-414-234-22	INDUCTOR CHIP 0µH	
L1763	1-414-234-22	INDUCTOR CHIP 0µH	
L1764	1-414-234-22	INDUCTOR CHIP 0µH	
L1765	1-414-234-22	INDUCTOR CHIP 0µH	
L1766	1-414-234-22	INDUCTOR CHIP 0µH	
L1767	1-414-234-22	INDUCTOR CHIP 0µH	
L1768	1-414-234-22	INDUCTOR CHIP 0µH	
L1769	1-414-234-22	INDUCTOR CHIP 0µH	
L1770	1-414-234-22	INDUCTOR CHIP 0µH	
		<TRANSISTOR>	
Q1701	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1702	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1703	8-729-900-53	TRANSISTOR DTC114EK	
Q1709	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1710	8-729-422-27	TRANSISTOR 2SD601A-Q	
		<RESISTOR>	
R1701	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R1702	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R1703	1-208-799-11	METAL CHIP 5.1K 0.50% 1/10W	
R1704	1-216-295-91	SHORT 0	
R1705	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1706	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1707	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1708	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1709	1-216-041-00	RES,CHIP 470 5% 1/10W	
R1710	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1711	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1712	1-216-295-91	SHORT 0	
R1713	1-216-041-00	RES,CHIP 470 5% 1/10W	
R1714	1-216-295-91	SHORT 0	
R1715	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1716	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1717	1-216-073-00	RES,CHIP 10K 5% 1/10W	
R1718	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1719	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1720	1-216-073-00	RES,CHIP 10K 5% 1/10W	

REF. NO.	PART NO.	DESCRIPTION	REMARK
R1721	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1722	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
R1723	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1724	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1725	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R1727	1-216-033-00	RES,CHIP 220 5% 1/10W	
R1728	1-216-033-00	RES,CHIP 220 5% 1/10W	
R1729	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1730	1-208-850-11	METAL CHIP 680K 0.50% 1/10W	
R1731	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1732	1-208-799-11	METAL CHIP 5.1K 0.50% 1/10W	
R1733	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1735	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1736	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1737	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R1738	1-216-295-91	SHORT 0	
R1739	1-216-295-91	SHORT 0	
R1740	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1741	1-216-033-00	RES,CHIP 220 5% 1/10W	
R1742	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1743	1-216-033-00	RES,CHIP 220 5% 1/10W	
R1744	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1745	1-216-033-00	RES,CHIP 220 5% 1/10W	
R1746	1-216-033-00	RES,CHIP 220 5% 1/10W	
R1747	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1748	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1749	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R1750	1-216-295-91	SHORT 0	
R1751	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1752	1-208-799-11	METAL CHIP 5.1K 0.50% 1/10W	
R1753	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1754	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1755	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1756	1-208-799-11	METAL CHIP 5.1K 0.50% 1/10W	
R1759	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1760	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1761	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
R1762	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
R1763	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1764	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1765	1-216-033-00	RES,CHIP 220 5% 1/10W	
R1766	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1767	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1768	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1769	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
R1770	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1771	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1772	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1773	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1774	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1775	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R1777	1-208-799-11	METAL CHIP 5.1K 0.50% 1/10W	
R1778	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R1779	1-216-071-00	RES,CHIP 8.2K 5% 1/10W	
R1780	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1781	1-216-025-91	RES,CHIP 100 5% 1/10W	
R1782	1-216-071-00	RES,CHIP 8.2K 5% 1/10W	

REF. NO.	PART NO.	DESCRIPTION			REMARK
R1783	1-216-033-00	RES,CHIP	220	5%	1/10W
R1784	1-216-025-91	RES,CHIP	100	5%	1/10W
R1785	1-216-025-91	RES,CHIP	100	5%	1/10W
R1786	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R1787	1-216-025-91	RES,CHIP	100	5%	1/10W
R1788	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R1789	1-216-025-91	RES,CHIP	100	5%	1/10W
R1790	1-216-295-91	SHORT	0		
R1791	1-216-025-91	RES,CHIP	100	5%	1/10W
R1792	1-216-025-91	RES,CHIP	100	5%	1/10W
R1793	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1794	1-208-801-11	METAL CHIP	6.2K	0.50%	1/10W
R1795	1-216-037-00	RES,CHIP	330	5%	1/10W
R1796	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R1798	1-208-799-11	METAL CHIP	5.1K	0.50%	1/10W
R1799	1-208-802-11	METAL CHIP	6.8K	0.50%	1/10W
R1800	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1801	1-208-816-11	METAL CHIP	27K	0.50%	1/10W
R1802	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1803	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R1804	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1805	1-216-025-91	RES,CHIP	100	5%	1/10W
R1806	1-216-295-91	SHORT	0		
R1807	1-216-037-00	RES,CHIP	330	5%	1/10W
R1808	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1809	1-216-025-91	RES,CHIP	100	5%	1/10W
R1810	1-216-025-91	RES,CHIP	100	5%	1/10W
R1811	1-216-025-91	RES,CHIP	100	5%	1/10W
R1819	1-216-025-91	RES,CHIP	100	5%	1/10W
R1820	1-216-025-91	RES,CHIP	100	5%	1/10W
R1821	1-216-025-91	RES,CHIP	100	5%	1/10W
R1822	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1823	1-208-799-11	METAL CHIP	5.1K	0.50%	1/10W
R1824	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R1826	1-216-037-00	RES,CHIP	330	5%	1/10W
R1827	1-216-295-91	SHORT	0		
R1828	1-216-025-91	RES,CHIP	100	5%	1/10W
R1830	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1831	1-216-025-91	RES,CHIP	100	5%	1/10W
R1834	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1835	1-216-025-91	RES,CHIP	100	5%	1/10W
R1836	1-216-025-91	RES,CHIP	100	5%	1/10W
R1840	1-216-025-91	RES,CHIP	100	5%	1/10W
R1841	1-216-025-91	RES,CHIP	100	5%	1/10W
R1844	1-216-025-91	RES,CHIP	100	5%	1/10W
R1846	1-216-025-91	RES,CHIP	100	5%	1/10W
R1847	1-216-025-91	RES,CHIP	100	5%	1/10W
R1848	1-216-025-91	RES,CHIP	100	5%	1/10W
R1849	1-216-025-91	RES,CHIP	100	5%	1/10W
R1850	1-216-025-91	RES,CHIP	100	5%	1/10W
R1851	1-216-025-91	RES,CHIP	100	5%	1/10W
R1852	1-216-295-91	SHORT	0		
R1853	1-216-025-91	RES,CHIP	100	5%	1/10W
R1854	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1855	1-216-025-91	RES,CHIP	100	5%	1/10W
R1856	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1857	1-216-025-91	RES,CHIP	100	5%	1/10W
R1858	1-216-033-00	RES,CHIP	220	5%	1/10W
R1859	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1860	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1861	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1862	1-216-025-91	RES,CHIP	100	5%	1/10W
R1864	1-208-850-11	METAL CHIP	680K	0.50%	1/10W
R1865	1-208-799-11	METAL CHIP	5.1K	0.50%	1/10W
R1866	1-208-799-11	METAL CHIP	5.1K	0.50%	1/10W
R1867	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R1868	1-208-799-11	METAL CHIP	5.1K	0.50%	1/10W
R1869	1-208-799-11	METAL CHIP	5.1K	0.50%	1/10W
R1870	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R1877	1-216-295-91	SHORT	0		
R1878	1-216-295-91	SHORT	0		
R1879	1-216-295-91	SHORT	0		
R1880	1-216-295-91	SHORT	0		
R1881	1-216-295-91	SHORT	0		
R1882	1-216-295-91	SHORT	0		
R1883	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1885	1-208-793-11	METAL CHIP	3K	0.50%	1/10W
R1886	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1887	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R1888	1-216-033-00	RES,CHIP	220	5%	1/10W
R1889	1-216-033-00	RES,CHIP	220	5%	1/10W
R1890	1-216-295-91	SHORT	0		
R1907	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1908	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1909	1-216-041-00	RES,CHIP	470	5%	1/10W
R1910	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1913	1-208-799-11	METAL CHIP	5.1K	0.50%	1/10W
R1914	1-216-025-91	RES,CHIP	100	5%	1/10W
R1915	1-216-033-00	RES,CHIP	220	5%	1/10W
R1916	1-216-025-91	RES,CHIP	100	5%	1/10W
R1917	1-216-033-00	RES,CHIP	220	5%	1/10W
R1919	1-216-033-00	RES,CHIP	220	5%	1/10W
R1920	1-216-033-00	RES,CHIP	220	5%	1/10W
R1921	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1922	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1924	1-216-025-91	RES,CHIP	100	5%	1/10W
R1926	1-216-033-00	RES,CHIP	220	5%	1/10W

<CRYSTAL>

X1701	1-767-925-21	VIBRATOR, CRYSTAL			

****

* A-1131-461-A BA BOARD, COMPLETE
****

<CAPACITOR>

C2401	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C2402	1-104-664-11	ELECT	47µF	20%	25V
C2403	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2404	1-163-038-91	CERAMIC CHIP	0.1µF		25V

BA

REF. NO.	PART NO.	DESCRIPTION			REMARK
C2405	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2406	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2407	1-164-505-11	CERAMIC CHIP	2.2µF		16V
C2408	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2409	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2410	1-104-664-11	ELECT	47µF	20%	25V
C2411	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2412	1-104-664-11	ELECT	47µF	20%	25V
C2414	1-126-964-11	ELECT	10µF	20%	50V
C2415	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C2416	1-163-133-00	CERAMIC CHIP	470pF	5%	50V
C2417	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C2418	1-104-664-11	ELECT	47µF	20%	25V
C2420	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2421	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2422	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2424	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2425	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2426	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2427	1-115-339-11	CERAMIC CHIP	0.1µF	10%	50V
C2429	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2430	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2431	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2432	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2434	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C2436	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2437	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2439	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2440	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2441	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2442	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2443	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2444	1-164-505-11	CERAMIC CHIP	2.2µF		16V
C2445	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2446	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2447	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C2448	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2449	1-163-031-11	CERAMIC CHIP	0.01µF		50V
C2450	1-126-964-11	ELECT	10µF	20%	50V
C2451	1-163-227-11	CERAMIC CHIP	10pF	0.5pF	50V
C2452	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2453	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2454	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2455	1-164-505-11	CERAMIC CHIP	2.2µF		16V
C2456	1-163-031-11	CERAMIC CHIP	0.01µF		50V
C2457	1-163-241-11	CERAMIC CHIP	39pF	5%	50V
C2458	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2459	1-126-935-11	ELECT	470µF	20%	6.3V
C2461	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C2462	1-163-249-11	CERAMIC CHIP	82pF	5%	50V
C2463	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2464	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2466	1-164-505-11	CERAMIC CHIP	2.2µF		16V
C2467	1-163-121-00	CERAMIC CHIP	150pF	5%	50V
C2468	1-104-664-11	ELECT	47µF	20%	25V
C2471	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2472	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2474	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C2475	1-126-934-11	ELECT	220µF	20%	10V
C2476	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2477	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2478	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2479	1-126-963-11	ELECT	4.7µF	20%	50V
C2480	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C2481	1-126-961-11	ELECT	2.2µF	20%	50V
C2482	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2483	1-163-038-91	CERAMIC CHIP	0.1µF		25V
		<CONNECTOR>			
CN2401*	1-691-632-21	CONNECTOR, BOARD TO BOARD 15P			
		<FILTER>			
FL2401	1-239-847-11	FILTER, LOW PASS			
FL2402	1-239-847-11	FILTER, LOW PASS			
FL2403	1-239-847-11	FILTER, LOW PASS			
FL2404	1-239-847-11	FILTER, LOW PASS			
		<IC>			
IC2401	8-759-568-27	IC MSM514265C-60JSDR1			
IC2402	8-759-536-12	IC µPD64081BGF-3BA			
IC2403	8-759-161-24	IC µPC659AGS-E2			
		<COIL>			
L2401	1-469-555-21	INDUCTOR	10µH		
L2402	1-414-234-22	INDUCTOR CHIP	0µH		
L2403	1-414-234-22	INDUCTOR CHIP	0µH		
L2404	1-414-234-22	INDUCTOR CHIP	0µH		
L2405	1-469-555-21	INDUCTOR	10µH		
L2406	1-469-555-21	INDUCTOR	10µH		
L2407	1-414-234-22	INDUCTOR CHIP	0µH		
L2408	1-414-234-22	INDUCTOR CHIP	0µH		
L2409	1-469-555-21	INDUCTOR	10µH		
L2410	1-414-234-22	INDUCTOR CHIP	0µH		
L2411	1-414-234-22	INDUCTOR CHIP	0µH		
L2412	1-414-234-22	INDUCTOR CHIP	0µH		
L2413	1-414-234-22	INDUCTOR CHIP	0µH		
L2414	1-414-234-22	INDUCTOR CHIP	0µH		
L2415	1-414-234-22	INDUCTOR CHIP	0µH		
L2416	1-414-234-22	INDUCTOR CHIP	0µH		
L2417	1-414-234-22	INDUCTOR CHIP	0µH		
L2418	1-414-234-22	INDUCTOR CHIP	0µH		
L2420	1-414-234-22	INDUCTOR CHIP	0µH		
L2421	1-414-234-22	INDUCTOR CHIP	0µH		
L2422	1-414-234-22	INDUCTOR CHIP	0µH		
L2423	1-469-555-21	INDUCTOR	10µH		
L2424	1-469-555-21	INDUCTOR	10µH		
L2425	1-414-234-22	INDUCTOR CHIP	0µH		
L2427	1-216-295-91	SHORT	0		
L2428	1-216-295-91	SHORT	0		

REF. NO.	PART NO.	DESCRIPTION			REMARK
L2429	1-216-295-91	SHORT	0		
L2430	1-469-555-21	INDUCTOR	10µH		
		<TRANSISTOR>			
Q2401	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2402	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2403	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2404	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2405	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2406	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2407	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2408	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2409	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2410	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2411	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2412	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2413	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2414	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2415	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2416	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2417	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q2418	1-801-806-11	TRANSISTOR	DTC144EKA-T146		
Q2419	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2421	8-729-216-22	TRANSISTOR	2SA1162-G		
Q2422	8-729-422-27	TRANSISTOR	2SD601A-Q		
		<RESISTOR>			
R2401	1-216-295-91	SHORT	0		
R2402	1-216-295-91	SHORT	0		
R2403	1-216-295-91	SHORT	0		
R2404	1-216-021-00	RES,CHIP	68	5%	1/10W
R2405	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2406	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R2407	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R2408	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R2409	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2410	1-216-295-91	SHORT	0		
R2411	1-216-033-00	RES,CHIP	220	5%	1/10W
R2413	1-216-025-91	RES,CHIP	100	5%	1/10W
R2414	1-216-025-91	RES,CHIP	100	5%	1/10W
R2415	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2416	1-216-105-91	RES,CHIP	220K	5%	1/10W
R2417	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2418	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R2419	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R2420	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2421	1-216-041-00	RES,CHIP	470	5%	1/10W
R2422	1-216-025-91	RES,CHIP	100	5%	1/10W
R2423	1-216-033-00	RES,CHIP	220	5%	1/10W
R2424	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2425	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R2426	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R2427	1-216-025-91	RES,CHIP	100	5%	1/10W
R2428	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R2429	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R2430	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2431	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2432	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R2433	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R2434	1-216-085-00	RES,CHIP	33K	5%	1/10W
R2435	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R2436	1-216-025-91	RES,CHIP	100	5%	1/10W
R2438	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2439	1-208-784-11	METAL CHIP	1.2K	0.50%	1/10W
R2440	1-216-047-91	RES,CHIP	820	5%	1/10W
R2441	1-216-075-00	RES,CHIP	12K	5%	1/10W
R2442	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2444	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R2445	1-216-025-91	RES,CHIP	100	5%	1/10W
R2446	1-216-025-91	RES,CHIP	100	5%	1/10W
R2447	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2448	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R2449	1-208-784-11	METAL CHIP	1.2K	0.50%	1/10W
R2450	1-216-085-00	RES,CHIP	33K	5%	1/10W
R2451	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2452	1-216-025-91	RES,CHIP	100	5%	1/10W
R2453	1-216-025-91	RES,CHIP	100	5%	1/10W
R2454	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R2455	1-216-295-91	SHORT	0		
R2456	1-216-017-91	RES,CHIP	47	5%	1/10W
R2457	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2458	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2459	1-208-778-11	METAL CHIP	680	0.50%	1/10W
R2460	1-216-047-91	RES,CHIP	820	5%	1/10W
R2461	1-216-075-00	RES,CHIP	12K	5%	1/10W
R2462	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2464	1-216-025-91	RES,CHIP	100	5%	1/10W
R2465	1-216-025-91	RES,CHIP	100	5%	1/10W
R2466	1-216-025-91	RES,CHIP	100	5%	1/10W
R2467	1-216-025-91	RES,CHIP	100	5%	1/10W
R2468	1-216-025-91	RES,CHIP	100	5%	1/10W
R2469	1-216-025-91	RES,CHIP	100	5%	1/10W
R2470	1-216-025-91	RES,CHIP	100	5%	1/10W
R2471	1-216-025-91	RES,CHIP	100	5%	1/10W
R2472	1-216-025-91	RES,CHIP	100	5%	1/10W
R2476	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R2477	1-216-025-91	RES,CHIP	100	5%	1/10W
R2478	1-208-758-11	METAL CHIP	100	0.50%	1/10W
R2479	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R2480	1-216-295-91	SHORT	0		
R2481	1-216-295-91	SHORT	0		
R2482	1-216-295-91	SHORT	0		
R2483	1-216-295-91	SHORT	0		
R2484	1-216-295-91	SHORT	0		
R2485	1-216-295-91	SHORT	0		
R2486	1-216-295-91	SHORT	0		
R2487	1-216-295-91	SHORT	0		
R2489	1-208-822-11	METAL CHIP	47K	0.50%	1/10W
R2490	1-208-810-11	METAL CHIP	15K	0.50%	1/10W

****

REF. NO.	PART NO.	DESCRIPTION			REMARK
	* A-1131-462-A	BR BOARD, COMPLETE			
		**********			
		<CAPACITOR>			
C301	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C302	1-124-779-00	ELECT CHIP	10µF	20%	16V
C303	1-126-204-11	ELECT CHIP	47µF	20%	16V
C304	1-124-779-00	ELECT CHIP	10µF	20%	16V
C305	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C306	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C307	1-124-779-00	ELECT CHIP	10µF	20%	16V
C308	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C309	1-126-204-11	ELECT CHIP	47µF	20%	16V
C310	1-163-037-11	CERAMIC CHIP	0.022µF	10%	50V
C311	1-126-204-11	ELECT CHIP	47µF	20%	16V
C312	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C313	1-126-204-11	ELECT CHIP	47µF	20%	16V
C314	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C315	1-117-681-11	ELECT CHIP	100µF	20%	16V
C316	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C317	1-126-204-11	ELECT CHIP	47µF	20%	16V
C320	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C321	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C322	1-126-603-11	ELECT CHIP	4.7µF	20%	35V
C326	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C328	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C329	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C331	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C343	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C347	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C355	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C359	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C360	1-126-204-11	ELECT CHIP	47µF	20%	16V
C364	1-126-206-11	ELECT CHIP	100µF	20%	6.3V
C368	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C375	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C376	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C377	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C378	1-126-204-11	ELECT CHIP	47µF	20%	16V
C379	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C380	1-126-204-11	ELECT CHIP	47µF	20%	16V
C384	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C385	1-126-204-11	ELECT CHIP	47µF	20%	16V
C386	1-124-779-00	ELECT CHIP	10µF	20%	16V
C388	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C389	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C393	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C394	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C395	1-126-206-11	ELECT CHIP	100µF	20%	6.3V
C396	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C397	1-124-779-00	ELECT CHIP	10µF	20%	16V
C398	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C399	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C400	1-126-204-11	ELECT CHIP	47µF	20%	16V
C401	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C402	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C403	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C405	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C406	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C407	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C409	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C410	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C411	1-126-204-11	ELECT CHIP	47µF	20%	16V
C412	1-164-690-91	CERAMIC CHIP	0.0022µF	5%	50V
C414	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C419	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C420	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C421	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C422	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C423	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C424	1-126-204-11	ELECT CHIP	47µF	20%	16V
C425	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C426	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C427	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C428	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C429	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C430	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C431	1-126-204-11	ELECT CHIP	47µF	20%	16V
C432	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C433	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C434	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C435	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C436	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C437	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C438	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C439	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C440	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C441	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C442	1-126-204-11	ELECT CHIP	47µF	20%	16V
C2301	1-126-204-11	ELECT CHIP	47µF	20%	16V
C2303	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2304	1-126-204-11	ELECT CHIP	47µF	20%	16V
C2305	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2306	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2307	1-126-204-11	ELECT CHIP	47µF	20%	16V
C2308	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2309	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2310	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2311	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2312	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2313	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C2314	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C2315	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
		<CONNECTOR>			
CN301	1-573-301-21	CONNECTOR, BOARD TO BOARD 20P			
CN302	1-573-979-21	CONNECTOR, BOARD TO BOARD 11P			
		<DIODE>			
D301	8-719-422-12	DIODE MA8039			
D2301	8-719-041-97	DIODE MA113-(TX)			

REF. NO.	PART NO.	DESCRIPTION	REMARK
		<FILTER>	
FL301	1-233-877-11	FILTER, LOW PASS	
FL302	1-233-504-21	FILTER, LOW PASS	
FL303	1-233-504-21	FILTER, LOW PASS	
FL304	1-234-112-21	FILTER, LOW PASS	
FL305	1-234-112-21	FILTER, LOW PASS	
FL306	1-234-113-21	FILTER, LOW PASS	
FL307	1-233-736-21	FILTER, EMI	
FL308	1-233-736-21	FILTER, EMI	
FL309	1-233-736-21	FILTER, EMI	
		<IC>	
IC301	8-759-430-32	IC TLC2933IPWR	
IC302	8-759-388-31	IC PQ20VZ1U	
IC303	8-759-295-09	IC TLC2932IPW	
IC305	8-752-398-47	IC CXD2090Q	
IC306	8-759-447-90	IC TLC5733AIPM	
IC466	8-759-239-55	IC TC74HC123AF	
IC2301	8-759-572-04	IC TDA9178T/N1.118	
		<COIL>	
L302	1-414-234-22	INDUCTOR CHIP 0µH	
L303	1-414-234-22	INDUCTOR CHIP 0µH	
L305	1-414-234-22	INDUCTOR CHIP 0µH	
L306	1-414-234-22	INDUCTOR CHIP 0µH	
L312	1-469-555-21	INDUCTOR 10µH	
L313	1-469-555-21	INDUCTOR 10µH	
L315	1-469-555-21	INDUCTOR 10µH	
L316	1-469-555-21	INDUCTOR 10µH	
L317	1-469-555-21	INDUCTOR 10µH	
L319	1-216-295-91	SHORT 0	
L320	1-469-555-21	INDUCTOR 10µH	
L321	1-469-555-21	INDUCTOR 10µH	
L322	1-469-555-21	INDUCTOR 10µH	
L323	1-469-555-21	INDUCTOR 10µH	
L324	1-469-555-21	INDUCTOR 10µH	
L2301	1-469-555-21	INDUCTOR 10µH	
L2302	1-469-555-21	INDUCTOR 10µH	
L2303	1-469-555-21	INDUCTOR 10µH	
		<TRANSISTOR>	
Q301	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q302	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q303	8-729-216-22	TRANSISTOR 2SA1162-G	
Q306	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q308	8-729-216-22	TRANSISTOR 2SA1162-G	
Q312	8-729-216-22	TRANSISTOR 2SA1162-G	
Q317	8-729-216-22	TRANSISTOR 2SA1162-G	
Q318	8-729-216-22	TRANSISTOR 2SA1162-G	
Q319	8-729-216-22	TRANSISTOR 2SA1162-G	
Q322	8-729-216-22	TRANSISTOR 2SA1162-G	
Q323	8-729-216-22	TRANSISTOR 2SA1162-G	
Q325	8-729-216-22	TRANSISTOR 2SA1162-G	
Q326	8-729-216-22	TRANSISTOR 2SA1162-G	
Q2301	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2302	8-729-216-22	TRANSISTOR 2SA1162-G	
Q2303	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2304	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2305	8-729-216-22	TRANSISTOR 2SA1162-G	
Q2306	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2307	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2308	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2309	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2310	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2311	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2312	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q2313	8-729-422-27	TRANSISTOR 2SD601A-Q	
		<RESISTOR>	
R302	1-216-089-91	RES,CHIP 47K 5% 1/10W	
R303	1-216-037-00	RES,CHIP 330 5% 1/10W	
R304	1-216-037-00	RES,CHIP 330 5% 1/10W	
R305	1-208-795-11	METAL CHIP 3.6K 0.50% 1/10W	
R306	1-216-097-91	RES,CHIP 100K 5% 1/10W	
R307	1-216-113-00	RES,CHIP 470K 5% 1/10W	
R308	1-216-295-91	SHORT 0	
R309	1-216-295-91	SHORT 0	
R311	1-216-117-00	RES,CHIP 680K 5% 1/10W	
R312	1-216-081-00	RES,CHIP 22K 5% 1/10W	
R313	1-216-033-00	RES,CHIP 220 5% 1/10W	
R314	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R315	1-208-799-11	METAL CHIP 5.1K 0.50% 1/10W	
R317	1-216-061-00	RES,CHIP 3.3K 5% 1/10W	
R318	1-216-295-91	SHORT 0	
R320	1-216-295-91	SHORT 0	
R321	1-216-295-91	SHORT 0	
R322	1-216-055-00	RES,CHIP 1.8K 5% 1/10W	
R323	1-216-295-91	SHORT 0	
R324	1-216-295-91	SHORT 0	
R325	1-216-047-91	RES,CHIP 820 5% 1/10W	
R326	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R327	1-216-117-00	RES,CHIP 680K 5% 1/10W	
R328	1-216-117-00	RES,CHIP 680K 5% 1/10W	
R333	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R334	1-216-033-00	RES,CHIP 220 5% 1/10W	
R335	1-208-782-11	METAL CHIP 1K 0.50% 1/10W	
R337	1-216-295-91	SHORT 0	
R338	1-216-025-91	RES,CHIP 100 5% 1/10W	
R340	1-216-037-00	RES,CHIP 330 5% 1/10W	
R341	1-216-295-91	SHORT 0	
R344	1-216-295-91	SHORT 0	
R345	1-216-295-91	SHORT 0	
R346	1-216-295-91	SHORT 0	
R347	1-216-025-91	RES,CHIP 100 5% 1/10W	
R349	1-216-295-91	SHORT 0	
R355	1-216-295-91	SHORT 0	
R358	1-216-055-00	RES,CHIP 1.8K 5% 1/10W	
R359	1-216-061-00	RES,CHIP 3.3K 5% 1/10W	
R360	1-208-798-11	METAL CHIP 4.7K 0.50% 1/10W	

REF. NO.	PART NO.	DESCRIPTION			REMARK
R361	1-216-055-00	RES,CHIP	1.8K	5%	1/10W
R362	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R363	1-216-025-91	RES,CHIP	100	5%	1/10W
R364	1-216-041-00	RES,CHIP	470	5%	1/10W
R365	1-216-295-91	SHORT	0		
R366	1-216-025-91	RES,CHIP	100	5%	1/10W
R367	1-216-041-00	RES,CHIP	470	5%	1/10W
R368	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R370	1-216-025-91	RES,CHIP	100	5%	1/10W
R371	1-216-025-91	RES,CHIP	100	5%	1/10W
R372	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R375	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R376	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R377	1-216-295-91	SHORT	0		
R378	1-216-041-00	RES,CHIP	470	5%	1/10W
R380	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R381	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R382	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R383	1-216-295-91	SHORT	0		
R384	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R386	1-216-295-91	SHORT	0		
R390	1-216-295-91	SHORT	0		
R392	1-216-295-91	SHORT	0		
R393	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R394	1-216-295-91	SHORT	0		
R397	1-216-041-00	RES,CHIP	470	5%	1/10W
R400	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R401	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R402	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R403	1-216-295-91	SHORT	0		
R404	1-216-077-91	RES,CHIP	15K	5%	1/10W
R405	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R406	1-216-049-91	RES,CHIP	1K	5%	1/10W
R407	1-216-295-91	SHORT	0		
R408	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R413	1-216-025-91	RES,CHIP	100	5%	1/10W
R414	1-208-765-11	METAL CHIP	200	0.50%	1/10W
R416	1-216-077-91	RES,CHIP	15K	5%	1/10W
R417	1-216-077-91	RES,CHIP	15K	5%	1/10W
R418	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R421	1-208-777-11	METAL CHIP	620	0.50%	1/10W
R422	1-216-049-91	RES,CHIP	1K	5%	1/10W
R423	1-216-025-91	RES,CHIP	100	5%	1/10W
R424	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R425	1-216-295-91	SHORT	0		
R426	1-216-295-91	SHORT	0		
R428	1-216-295-91	SHORT	0		
R429	1-208-765-11	METAL CHIP	200	0.50%	1/10W
R430	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R431	1-216-295-91	SHORT	0		
R433	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R434	1-216-295-91	SHORT	0		
R437	1-216-295-91	SHORT	0		
R438	1-208-768-11	METAL CHIP	270	0.50%	1/10W
R439	1-216-049-91	RES,CHIP	1K	5%	1/10W
R440	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R441	1-208-752-11	METAL CHIP	56	0.50%	1/10W
R442	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R443	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R444	1-216-295-91	SHORT	0		
R445	1-208-765-11	METAL CHIP	200	0.50%	1/10W
R447	1-216-295-91	SHORT	0		
R448	1-216-295-91	SHORT	0		
R449	1-216-295-91	SHORT	0		
R450	1-216-049-91	RES,CHIP	1K	5%	1/10W
R451	1-414-234-22	INDUCTOR CHIP	0µH		
R452	1-216-049-91	RES,CHIP	1K	5%	1/10W
R453	1-216-295-91	SHORT	0		
R454	1-216-295-91	SHORT	0		
R455	1-216-295-91	SHORT	0		
R456	1-216-295-91	SHORT	0		
R457	1-216-295-91	SHORT	0		
R458	1-216-295-91	SHORT	0		
R459	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R460	1-216-025-91	RES,CHIP	100	5%	1/10W
R461	1-216-049-91	RES,CHIP	1K	5%	1/10W
R462	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R463	1-216-025-91	RES,CHIP	100	5%	1/10W
R464	1-216-049-91	RES,CHIP	1K	5%	1/10W
R465	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R466	1-216-025-91	RES,CHIP	100	5%	1/10W
R467	1-216-045-00	RES,CHIP	680	5%	1/10W
R468	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R469	1-216-025-91	RES,CHIP	100	5%	1/10W
R474	1-216-295-91	SHORT	0		
R475	1-216-295-91	SHORT	0		
R477	1-216-295-91	SHORT	0		
R478	1-216-295-91	SHORT	0		
R480	1-216-073-00	RES,CHIP	10K	5%	1/10W
R481	1-216-073-00	RES,CHIP	10K	5%	1/10W
R482	1-216-073-00	RES,CHIP	10K	5%	1/10W
R483	1-216-073-00	RES,CHIP	10K	5%	1/10W
R484	1-216-073-00	RES,CHIP	10K	5%	1/10W
R485	1-216-073-00	RES,CHIP	10K	5%	1/10W
R486	1-216-073-00	RES,CHIP	10K	5%	1/10W
R487	1-216-073-00	RES,CHIP	10K	5%	1/10W
R488	1-216-073-00	RES,CHIP	10K	5%	1/10W
R489	1-216-073-00	RES,CHIP	10K	5%	1/10W
R490	1-216-073-00	RES,CHIP	10K	5%	1/10W
R491	1-216-073-00	RES,CHIP	10K	5%	1/10W
R492	1-216-073-00	RES,CHIP	10K	5%	1/10W
R493	1-216-073-00	RES,CHIP	10K	5%	1/10W
R494	1-216-073-00	RES,CHIP	10K	5%	1/10W
R495	1-216-073-00	RES,CHIP	10K	5%	1/10W
R496	1-216-073-00	RES,CHIP	10K	5%	1/10W
R497	1-216-073-00	RES,CHIP	10K	5%	1/10W
R498	1-216-073-00	RES,CHIP	10K	5%	1/10W
R499	1-216-295-91	SHORT	0		
R2301	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2302	1-216-025-91	RES,CHIP	100	5%	1/10W
R2303	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R2304	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2305	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R2306	1-216-025-91	RES,CHIP	100	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R2307	1-208-778-11	METAL CHIP	680	0.50%	1/10W
R2308	1-208-772-11	METAL CHIP	390	0.50%	1/10W
R2309	1-216-025-91	RES,CHIP	100	5%	1/10W
R2310	1-208-780-11	METAL CHIP	820	0.50%	1/10W
R2311	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2312	1-208-780-11	METAL CHIP	820	0.50%	1/10W
R2314	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R2315	1-216-025-91	RES,CHIP	100	5%	1/10W
R2316	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2317	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2318	1-216-025-91	RES,CHIP	100	5%	1/10W
R2319	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R2320	1-216-025-91	RES,CHIP	100	5%	1/10W
R2321	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R2322	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R2323	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R2325	1-216-025-91	RES,CHIP	100	5%	1/10W
R2326	1-216-025-91	RES,CHIP	100	5%	1/10W
R2327	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2328	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2329	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R2330	1-216-025-91	RES,CHIP	100	5%	1/10W
R2331	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R2332	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2333	1-208-810-11	METAL CHIP	15K	0.50%	1/10W
R2334	1-208-804-11	METAL CHIP	8.2K	0.50%	1/10W
R2335	1-208-804-11	METAL CHIP	8.2K	0.50%	1/10W
R2336	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2337	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2338	1-208-808-11	METAL CHIP	12K	0.50%	1/10W
R2339	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2340	1-216-089-91	RES,CHIP	47K	5%	1/10W

****

* A-1131-470-A BM BOARD, COMPLETE
****

<CAPACITOR>

C001	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C002	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C003	1-104-760-11	CERAMIC CHIP	0.047µF	10%	50V
C004	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C005	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C006	1-126-204-11	ELECT CHIP	47µF	20%	16V
C009	1-126-204-11	ELECT CHIP	47µF	20%	16V
C010	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C011	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C012	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C013	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C014	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C015	1-126-204-11	ELECT CHIP	47µF	20%	16V
C016	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C017	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C018	1-126-204-11	ELECT CHIP	47µF	20%	16V
C019	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C021	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C022	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C023	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C024	1-126-204-11	ELECT CHIP	47µF	20%	16V
C025	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C026	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C028	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C030	1-124-779-00	ELECT CHIP	10µF	20%	16V
C031	1-164-346-11	CERAMIC CHIP	1µF		16V
C032	1-164-346-11	CERAMIC CHIP	1µF		16V
C034	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C035	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C036	1-126-204-11	ELECT CHIP	47µF	20%	16V
C037	1-126-204-11	ELECT CHIP	47µF	20%	16V
C038	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C039	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C040	1-126-204-11	ELECT CHIP	47µF	20%	16V
C042	1-104-760-11	CERAMIC CHIP	0.047µF	10%	50V
C043	1-163-235-11	CERAMIC CHIP	22pF	5%	50V
C044	1-163-235-11	CERAMIC CHIP	22pF	5%	50V
C045	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C046	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C047	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C050	1-126-206-11	ELECT CHIP	100µF	20%	6.3V
C052	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C053	1-126-204-11	ELECT CHIP	47µF	20%	16V
C054	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C055	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C056	1-126-204-11	ELECT CHIP	47µF	20%	16V
C058	1-164-005-11	CERAMIC CHIP	0.47µF		16V
C059	1-126-204-11	ELECT CHIP	47µF	20%	16V
C060	1-163-233-11	CERAMIC CHIP	18pF	5%	50V
C062	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C063	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C064	1-126-204-11	ELECT CHIP	47µF	20%	16V
C066	1-163-017-00	CERAMIC CHIP	0.0047µF	10%	50V
C067	1-164-005-11	CERAMIC CHIP	0.47µF		16V
C068	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C069	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C070	1-126-204-11	ELECT CHIP	47µF	20%	16V
C071	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C072	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C073	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C074	1-126-204-11	ELECT CHIP	47µF	20%	16V
C075	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C076	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C077	1-126-204-11	ELECT CHIP	47µF	20%	16V
C078	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C081	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C082	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C083	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C084	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C085	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C086	1-126-204-11	ELECT CHIP	47µF	20%	16V
C087	1-163-251-11	CERAMIC CHIP	100pF	5%	50V

REF. NO.	PART NO.	DESCRIPTION			REMARK
C089	1-163-237-11	CERAMIC CHIP	27pF	5%	50V
C090	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C091	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C092	1-126-204-11	ELECT CHIP	47µF	20%	16V
C093	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C094	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C095	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C096	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C097	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C098	1-126-204-11	ELECT CHIP	47µF	20%	16V
C100	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C101	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C102	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C103	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C104	1-126-204-11	ELECT CHIP	47µF	20%	16V
C105	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C106	1-126-204-11	ELECT CHIP	47µF	20%	16V
C107	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C108	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C109	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C110	1-124-779-00	ELECT CHIP	10µF	20%	16V
C111	1-124-779-00	ELECT CHIP	10µF	20%	16V
C112	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C113	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C114	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C115	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C116	1-126-204-11	ELECT CHIP	47µF	20%	16V
C117	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C118	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C119	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C120	1-104-760-11	CERAMIC CHIP	0.047µF	10%	50V
C121	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C122	1-124-779-00	ELECT CHIP	10µF	20%	16V
C123	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C124	1-126-204-11	ELECT CHIP	47µF	20%	16V
C125	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C126	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C127	1-126-204-11	ELECT CHIP	47µF	20%	16V
C128	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C129	1-126-204-11	ELECT CHIP	47µF	20%	16V
C130	1-124-779-00	ELECT CHIP	10µF	20%	16V
C131	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C132	1-126-204-11	ELECT CHIP	47µF	20%	16V
C133	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C134	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C135	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C136	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C137	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C138	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C141	1-124-779-00	ELECT CHIP	10µF	20%	16V
C142	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C143	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C144	1-126-204-11	ELECT CHIP	47µF	20%	16V
C145	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C146	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C147	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C148	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C149	1-126-204-11	ELECT CHIP	47µF	20%	16V
C150	1-126-204-11	ELECT CHIP	47µF	20%	16V
C151	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C152	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C153	1-124-779-00	ELECT CHIP	10µF	20%	16V
C154	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C155	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C156	1-124-779-00	ELECT CHIP	10µF	20%	16V
C157	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C158	1-126-204-11	ELECT CHIP	47µF	20%	16V
C159	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C160	1-126-204-11	ELECT CHIP	47µF	20%	16V
C161	1-163-038-91	CERAMIC CHIP	0.1µF		25V

<CONNECTOR>

CN001	1-573-301-21	CONNECTOR, BOARD TO BOARD 20P
CN002	1-573-301-21	CONNECTOR, BOARD TO BOARD 20P

<DIODE>

D001	8-719-073-01	DIODE MA111-(K8).S0
D002	8-719-073-01	DIODE MA111-(K8).S0
D003	8-719-073-01	DIODE MA111-(K8).S0

<FILTER>

FL001	1-233-505-21	FILTER, LOW PASS
FL002	1-233-504-21	FILTER, LOW PASS
FL003	1-233-504-21	FILTER, LOW PASS
FL007	1-233-505-21	FILTER, LOW PASS
FL008	1-233-945-21	FILTER, LOW PASS
FL009	1-233-944-21	FILTER, LOW PASS
FL010	1-233-504-21	FILTER, LOW PASS
FL011	1-233-944-21	FILTER, LOW PASS
FL012	1-233-504-21	FILTER, LOW PASS

<IC>

IC001	8-759-467-22	IC MSM548331TS-K
IC002	8-759-295-09	IC TLC2932IPW
IC003	8-752-388-98	IC CXD2303AQ
IC004	8-759-485-79	IC TC7SET08FU(TE85L)
IC005	8-759-527-74	IC M24C02-MN6T
IC006	8-759-352-91	IC PST9143NL
IC007	8-759-485-79	IC TC7SET08FU(TE85L)
IC008	8-759-295-09	IC TLC2932IPW
IC009	8-752-910-91	IC CXP85840A-034Q
IC010	8-752-392-55	IC CXD2079Q
IC011	8-759-295-09	IC TLC2932IPW
IC012	8-759-485-79	IC TC7SET08FU(TE85L)
IC013	8-759-467-22	IC MSM548331TS-K
IC014	8-752-388-98	IC CXD2303AQ

<COIL>

L001	1-414-234-22	INDUCTOR CHIP 0µH

REF. NO.	PART NO.	DESCRIPTION			REMARK
L002	1-414-234-22	INDUCTOR CHIP	0µH		
L003	1-414-234-22	INDUCTOR CHIP	0µH		
L004	1-414-234-22	INDUCTOR CHIP	0µH		
L005	1-414-234-22	INDUCTOR CHIP	0µH		
L006	1-414-234-22	INDUCTOR CHIP	0µH		
L007	1-414-754-11	INDUCTOR	10µH		
L008	1-414-754-11	INDUCTOR	10µH		
L009	1-414-754-11	INDUCTOR	10µH		
L010	1-414-234-22	INDUCTOR CHIP	0µH		
L011	1-414-754-11	INDUCTOR	10µH		
L012	1-414-754-11	INDUCTOR	10µH		
L013	1-414-234-22	INDUCTOR CHIP	0µH		
L014	1-414-754-11	INDUCTOR	10µH		
L015	1-414-234-22	INDUCTOR CHIP	0µH		
L016	1-414-234-22	INDUCTOR CHIP	0µH		
L017	1-414-234-22	INDUCTOR CHIP	0µH		
L018	1-414-234-22	INDUCTOR CHIP	0µH		
L019	1-414-234-22	INDUCTOR CHIP	0µH		
L020	1-414-234-22	INDUCTOR CHIP	0µH		
L021	1-414-234-22	INDUCTOR CHIP	0µH		
L022	1-414-234-22	INDUCTOR CHIP	0µH		
L023	1-414-234-22	INDUCTOR CHIP	0µH		
L024	1-414-234-22	INDUCTOR CHIP	0µH		
L025	1-414-234-22	INDUCTOR CHIP	0µH		
L026	1-414-234-22	INDUCTOR CHIP	0µH		
L027	1-414-234-22	INDUCTOR CHIP	0µH		
L028	1-414-234-22	INDUCTOR CHIP	0µH		
		<TRANSISTOR>			
Q001	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q002	8-729-216-22	TRANSISTOR	2SA1162-G		
Q006	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q007	8-729-216-22	TRANSISTOR	2SA1162-G		
Q009	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q010	8-729-216-22	TRANSISTOR	2SA1162-G		
Q018	8-729-216-22	TRANSISTOR	2SA1162-G		
Q019	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q020	8-729-216-22	TRANSISTOR	2SA1162-G		
Q021	8-729-216-22	TRANSISTOR	2SA1162-G		
Q022	8-729-216-22	TRANSISTOR	2SA1162-G		
Q023	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q025	8-729-216-22	TRANSISTOR	2SA1162-G		
Q026	8-729-216-22	TRANSISTOR	2SA1162-G		
Q027	8-729-216-22	TRANSISTOR	2SA1162-G		
Q028	8-729-216-22	TRANSISTOR	2SA1162-G		
Q029	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q030	8-729-216-22	TRANSISTOR	2SA1162-G		
Q031	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q032	1-801-806-11	TRANSISTOR	DTC144EKA-T146		
		<RESISTOR>			
R001	1-216-117-00	RES,CHIP	680K	5%	1/10W
R002	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R003	1-216-295-91	SHORT	0		
R007	1-216-041-00	RES,CHIP	470	5%	1/10W
R008	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R009	1-216-049-91	RES,CHIP	1K	5%	1/10W
R010	1-216-295-91	SHORT	0		
R012	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R013	1-216-041-00	RES,CHIP	470	5%	1/10W
R014	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R016	1-216-013-00	RES,CHIP	33	5%	1/10W
R018	1-216-295-91	SHORT	0		
R019	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R020	1-216-049-91	RES,CHIP	1K	5%	1/10W
R021	1-216-049-91	RES,CHIP	1K	5%	1/10W
R022	1-216-049-91	RES,CHIP	1K	5%	1/10W
R023	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R024	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R025	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R026	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R027	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R028	1-208-770-11	METAL CHIP	330	0.50%	1/10W
R029	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R030	1-216-049-91	RES,CHIP	1K	5%	1/10W
R032	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R033	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R035	1-216-013-00	RES,CHIP	33	5%	1/10W
R036	1-216-013-00	RES,CHIP	33	5%	1/10W
R037	1-216-033-00	RES,CHIP	220	5%	1/10W
R038	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R039	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R040	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R042	1-216-049-91	RES,CHIP	1K	5%	1/10W
R046	1-216-037-00	RES,CHIP	330	5%	1/10W
R048	1-216-025-91	RES,CHIP	100	5%	1/10W
R050	1-216-049-91	RES,CHIP	1K	5%	1/10W
R052	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R059	1-216-295-91	SHORT	0		
R060	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R061	1-216-025-91	RES,CHIP	100	5%	1/10W
R064	1-216-041-00	RES,CHIP	470	5%	1/10W
R065	1-216-025-91	RES,CHIP	100	5%	1/10W
R066	1-216-033-00	RES,CHIP	220	5%	1/10W
R067	1-216-033-00	RES,CHIP	220	5%	1/10W
R070	1-216-033-00	RES,CHIP	220	5%	1/10W
R072	1-216-295-91	SHORT	0		
R073	1-216-295-91	SHORT	0		
R074	1-216-295-91	SHORT	0		
R075	1-216-295-91	SHORT	0		
R076	1-216-295-91	SHORT	0		
R077	1-216-295-91	SHORT	0		
R078	1-208-797-11	METAL CHIP	4.3K	0.50%	1/10W
R079	1-216-025-91	RES,CHIP	100	5%	1/10W
R080	1-216-025-91	RES,CHIP	100	5%	1/10W
R081	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R082	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R086	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R087	1-216-117-00	RES,CHIP	680K	5%	1/10W
R090	1-216-025-91	RES,CHIP	100	5%	1/10W
R091	1-216-295-91	SHORT	0		
R093	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R094	1-216-051-00	RES,CHIP	1.2K	5%	1/10W

BM

REF. NO.	PART NO.	DESCRIPTION			REMARK
R098	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R099	1-216-117-00	RES,CHIP	680K	5%	1/10W
R100	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R101	1-216-295-91	SHORT	0		
R102	1-216-041-00	RES,CHIP	470	5%	1/10W
R106	1-216-085-00	RES,CHIP	33K	5%	1/10W
R107	1-216-295-91	SHORT	0		
R108	1-216-017-91	RES,CHIP	47	5%	1/10W
R109	1-216-295-91	SHORT	0		
R110	1-216-017-91	RES,CHIP	47	5%	1/10W
R111	1-216-295-91	SHORT	0		
R112	1-216-049-91	RES,CHIP	1K	5%	1/10W
R113	1-216-033-00	RES,CHIP	220	5%	1/10W
R118	1-216-025-91	RES,CHIP	100	5%	1/10W
R119	1-216-085-00	RES,CHIP	33K	5%	1/10W
R120	1-216-295-91	SHORT	0		
R121	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R122	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R123	1-216-025-91	RES,CHIP	100	5%	1/10W
R124	1-216-049-91	RES,CHIP	1K	5%	1/10W
R125	1-208-762-11	METAL CHIP	150	0.50%	1/10W
R127	1-216-049-91	RES,CHIP	1K	5%	1/10W
R128	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R129	1-216-025-91	RES,CHIP	100	5%	1/10W
R130	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R131	1-216-033-00	RES,CHIP	220	5%	1/10W
R132	1-216-025-91	RES,CHIP	100	5%	1/10W
R133	1-216-025-91	RES,CHIP	100	5%	1/10W
R134	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R135	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R136	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R137	1-208-769-11	METAL CHIP	300	0.50%	1/10W
R138	1-208-770-11	METAL CHIP	330	0.50%	1/10W
R139	1-216-025-91	RES,CHIP	100	5%	1/10W
R140	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R141	1-216-117-00	RES,CHIP	680K	5%	1/10W
R142	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R143	1-216-049-91	RES,CHIP	1K	5%	1/10W
R144	1-216-041-00	RES,CHIP	470	5%	1/10W
R145	1-216-085-00	RES,CHIP	33K	5%	1/10W
R146	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R147	1-216-049-91	RES,CHIP	1K	5%	1/10W
R148	1-208-769-11	METAL CHIP	300	0.50%	1/10W
R149	1-216-025-91	RES,CHIP	100	5%	1/10W
R150	1-208-762-11	METAL CHIP	150	0.50%	1/10W
R151	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R153	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R154	1-216-025-91	RES,CHIP	100	5%	1/10W
R155	1-208-798-11	METAL CHIP	4.7K	0.50%	1/10W
R156	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R157	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R159	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R160	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R161	1-216-295-91	SHORT	0		
R163	1-208-762-11	METAL CHIP	150	0.50%	1/10W
R164	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R165	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R166	1-216-049-91	RES,CHIP	1K	5%	1/10W
R167	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R170	1-216-019-00	RES,CHIP	56	5%	1/10W
R171	1-216-121-91	RES,CHIP	1M	5%	1/10W
R172	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R173	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R175	1-216-049-91	RES,CHIP	1K	5%	1/10W
R176	1-216-049-91	RES,CHIP	1K	5%	1/10W
R177	1-216-049-91	RES,CHIP	1K	5%	1/10W
R178	1-216-025-91	RES,CHIP	100	5%	1/10W
R181	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R182	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R183	1-216-049-91	RES,CHIP	1K	5%	1/10W
R185	1-216-049-91	RES,CHIP	1K	5%	1/10W
R194	1-216-295-91	SHORT	0		
R195	1-216-049-91	RES,CHIP	1K	5%	1/10W
R198	1-216-025-91	RES,CHIP	100	5%	1/10W
R200	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R201	1-216-033-00	RES,CHIP	220	5%	1/10W
R202	1-216-037-00	RES,CHIP	330	5%	1/10W
R203	1-216-049-91	RES,CHIP	1K	5%	1/10W
R204	1-216-049-91	RES,CHIP	1K	5%	1/10W
R205	1-216-049-91	RES,CHIP	1K	5%	1/10W
R206	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R207	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R208	1-208-770-11	METAL CHIP	330	0.50%	1/10W
R210	1-216-013-00	RES,CHIP	33	5%	1/10W
R212	1-216-013-00	RES,CHIP	33	5%	1/10W
R214	1-216-041-00	RES,CHIP	470	5%	1/10W
R215	1-216-295-91	SHORT	0		
R216	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R217	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R218	1-216-117-00	RES,CHIP	680K	5%	1/10W
R219	1-216-013-00	RES,CHIP	33	5%	1/10W
R220	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R221	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R222	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R223	1-208-754-11	METAL CHIP	68	0.50%	1/10W
R226	1-216-295-91	SHORT	0		
R227	1-216-295-91	SHORT	0		
R228	1-216-295-91	SHORT	0		
R229	1-216-295-91	SHORT	0		
R230	1-216-295-91	SHORT	0		
R231	1-216-295-91	SHORT	0		
R232	1-216-295-91	SHORT	0		
R233	1-216-295-91	SHORT	0		
R234	1-216-295-91	SHORT	0		
R235	1-216-295-91	SHORT	0		
R236	1-216-295-91	SHORT	0		
R237	1-216-295-91	SHORT	0		
R238	1-216-295-91	SHORT	0		
R239	1-216-295-91	SHORT	0		
R240	1-216-295-91	SHORT	0		
R241	1-216-295-91	SHORT	0		
R242	1-216-295-91	SHORT	0		
R243	1-216-295-91	SHORT	0		

REF. NO.	PART NO.	DESCRIPTION			REMARK
R244	1-216-295-91	SHORT	0		
R245	1-216-295-91	SHORT	0		
R246	1-216-295-91	SHORT	0		
R247	1-216-295-91	SHORT	0		
R248	1-216-295-91	SHORT	0		
R249	1-216-295-91	SHORT	0		
R250	1-216-295-91	SHORT	0		
R251	1-216-295-91	SHORT	0		
R252	1-216-295-91	SHORT	0		
R253	1-216-295-91	SHORT	0		
R254	1-216-049-91	RES,CHIP	1K	5%	1/10W
R257	1-216-295-91	SHORT	0		
R258	1-216-049-91	RES,CHIP	1K	5%	1/10W
R259	1-216-295-91	SHORT	0		
R260	1-216-295-91	SHORT	0		
R261	1-216-295-91	SHORT	0		
R262	1-216-295-91	SHORT	0		
R263	1-216-295-91	SHORT	0		
R273	1-216-033-00	RES,CHIP	220	5%	1/10W
R274	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
		<CRYSTAL>			
X001	1-767-924-21	VIBRATOR, CRYSTAL			
X002	1-767-654-21	VIBRATOR, CRYSTAL			

****

* A-1298-973-A A BOARD, COMPLETE
****

4-382-854-11 SCREW(M3X10), P, SW (+)

<CAPACITOR>

C501	1-126-933-11	ELECT	100µF	20%	16V
C502	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C503	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C504	1-104-665-11	ELECT	100µF	20%	25V
C505	1-163-031-11	CERAMIC CHIP	0.01µF		50V
C506	1-164-505-11	CERAMIC CHIP	2.2µF		16V
C507	1-126-933-11	ELECT	100µF	20%	16V
C508	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C509	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C510	1-126-916-11	ELECT	1000µF	20%	6.3V
C511	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C512	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C513	1-126-933-11	ELECT	100µF	20%	16V
C514	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C515	1-104-664-11	ELECT	47µF	20%	25V
C516	1-104-664-11	ELECT	47µF	20%	25V
C517	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C518	1-126-933-11	ELECT	100µF	20%	16V
C519	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C520	1-126-964-11	ELECT	10µF	20%	50V
C521	1-163-145-00	CERAMIC CHIP	0.0015µF	5%	50V
C522	1-163-143-00	CERAMIC CHIP	0.0012µF	5%	50V
C523	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C524	1-104-664-11	ELECT	47µF	20%	25V
C525	1-163-275-11	CERAMIC CHIP	0.001µF	5%	50V
C526	1-163-017-00	CERAMIC CHIP	0.0047µF	10%	50V
C527	1-126-933-11	ELECT	100µF	20%	16V
C528	1-126-916-11	ELECT	1000µF	20%	6.3V
C529	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C530	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C531	1-126-933-11	ELECT	100µF	20%	16V
C532	1-126-933-11	ELECT	100µF	20%	16V
C533	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C534	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C535	1-104-665-11	ELECT	100µF	20%	25V
C536	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C537	1-104-664-11	ELECT	47µF	20%	25V
C538	1-126-964-11	ELECT	10µF	20%	50V
C539	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C540	1-126-918-11	ELECT	4700µF	20%	6.3V
C541	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C542	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C543	1-126-960-11	ELECT	1µF	20%	50V
C544	1-163-243-11	CERAMIC CHIP	47pF	5%	50V
C545	1-126-964-11	ELECT	10µF	20%	50V
C546	1-163-145-00	CERAMIC CHIP	0.0015µF	5%	50V
C548	1-163-012-00	CERAMIC CHIP	0.0018µF	5%	50V
C550	1-163-127-00	CERAMIC CHIP	270pF	5%	50V
C551	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C552	1-126-934-11	ELECT	220µF	20%	16V
C553	1-126-960-11	ELECT	1µF	20%	50V
C554	1-163-809-11	CERAMIC CHIP	0.047µF	10%	25V
C555	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C557	1-126-960-11	ELECT	1µF	20%	50V
C558	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C559	1-126-963-11	ELECT	4.7µF	20%	50V
C560	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C561	1-104-664-11	ELECT	47µF	20%	25V
C562	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C563	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C564	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C567	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C569	1-163-809-11	CERAMIC CHIP	0.047µF	10%	25V
C570	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C571	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C572	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C574	1-126-960-11	ELECT	1µF	20%	50V
C575	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C576	1-164-182-11	CERAMIC CHIP	0.0033µF	10%	50V
C577	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C580	1-164-182-11	CERAMIC CHIP	0.0033µF	10%	50V
C581	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C582	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C583	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C584	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C585	1-126-933-11	ELECT	100µF	20%	16V
C586	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C587	1-104-664-11	ELECT	47µF	20%	25V
C588	1-163-038-91	CERAMIC CHIP	0.1µF		25V

A

REF. NO.	PART NO.	DESCRIPTION			REMARK
C589	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C590	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C591	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C592	1-104-664-11	ELECT	47µF	20%	25V
C593	1-126-963-11	ELECT	4.7µF	20%	50V
C595	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C596	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C598	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C599	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C600	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C601	1-164-489-11	CERAMIC CHIP	0.22µF	10%	16V
C602	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C603	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C604	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C605	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C606	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C607	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C608	1-126-964-11	ELECT	10µF	20%	50V
C610	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C611	1-115-339-11	CERAMIC CHIP	0.1µF	10%	50V
C612	1-104-664-11	ELECT	47µF	20%	25V
C613	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C614	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C615	1-126-933-11	ELECT	100µF	20%	16V
C616	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C617	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C618	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C619	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C621	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C622	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C623	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C624	1-104-664-11	ELECT	47µF	20%	25V
C625	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C626	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C627	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C628	1-104-664-11	ELECT	47µF	20%	25V
C629	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C630	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C631	1-164-346-11	CERAMIC CHIP	1µF	16V	
C632	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C636	1-163-263-11	CERAMIC CHIP	330pF	5%	50V
C637	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C638	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C639	1-126-933-11	ELECT	100µF	20%	16V
C640	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C641	1-104-664-11	ELECT	47µF	20%	25V
C642	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C643	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C644	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C645	1-126-965-11	ELECT	22µF	20%	50V
C646	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C647	1-104-664-11	ELECT	47µF	20%	25V
C648	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C649	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C650	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C651	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V

REF. NO.	PART NO.	DESCRIPTION			REMARK
C652	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C653	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C654	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C655	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C656	1-126-964-11	ELECT	10µF	20%	50V
C657	1-163-009-11	CERAMIC CHIP	0.001µF	10%	50V
C658	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C659	1-104-664-11	ELECT	47µF	20%	25V
C660	1-163-009-11	CERAMIC CHIP	0.001µF	10%	50V
C661	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C662	1-126-965-11	ELECT	22µF	20%	50V
C663	1-126-965-11	ELECT	22µF	20%	50V
C664	1-104-664-11	ELECT	47µF	20%	25V
C665	1-104-664-11	ELECT	47µF	20%	25V
C666	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C667	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C668	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C669	1-126-935-11	ELECT	470µF	20%	16V
C670	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C671	1-104-664-11	ELECT	47µF	20%	25V
C672	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C673	1-126-965-11	ELECT	22µF	20%	50V
C674	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C675	1-110-501-11	CERAMIC CHIP	0.33µF	10%	16V
C676	1-104-664-11	ELECT	47µF	20%	25V
C677	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C678	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C679	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C680	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C681	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C683	1-163-017-00	CERAMIC CHIP	0.0047µF	10%	50V
C685	1-126-960-11	ELECT	1µF	20%	50V
C686	1-126-965-11	ELECT	22µF	20%	50V
C687	1-126-960-11	ELECT	1µF	20%	50V
C688	1-126-960-11	ELECT	1µF	20%	50V
C689	1-126-965-11	ELECT	22µF	20%	50V
C690	1-126-960-11	ELECT	1µF	20%	50V
C691	1-126-964-11	ELECT	10µF	20%	50V
C692	1-126-964-11	ELECT	10µF	20%	50V
C693	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C694	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C696	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C697	1-126-965-11	ELECT	22µF	20%	50V
C698	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C699	1-126-965-11	ELECT	22µF	20%	50V
C700	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C701	1-126-965-11	ELECT	22µF	20%	50V
C702	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C703	1-164-182-11	CERAMIC CHIP	0.0033µF	10%	50V
C704	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C705	1-164-182-11	CERAMIC CHIP	0.0033µF	10%	50V
C706	1-126-965-11	ELECT	22µF	20%	50V
C707	1-126-960-11	ELECT	1µF	20%	50V
C708	1-126-960-11	ELECT	1µF	20%	50V
C709	1-126-965-11	ELECT	22µF	20%	50V
C710	1-126-960-11	ELECT	1µF	20%	50V
C711	1-126-960-11	ELECT	1µF	20%	50V

REF. NO.	PART NO.	DESCRIPTION			REMARK
C712	1-126-965-11	ELECT	22µF	20%	50V
C713	1-126-960-11	ELECT	1µF	20%	50V
C714	1-126-960-11	ELECT	1µF	20%	50V
C716	1-126-960-11	ELECT	1µF	20%	50V
C717	1-126-960-11	ELECT	1µF	20%	50V
C718	1-126-935-11	ELECT	470µF	20%	16V
C771	1-126-965-11	ELECT	22µF	20%	50V
C772	1-126-965-11	ELECT	22µF	20%	50V
C773	1-126-960-11	ELECT	1µF	20%	50V
C774	1-126-960-11	ELECT	1µF	20%	50V
C775	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1001	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1002	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1003	1-104-664-11	ELECT	47µF	20%	25V
C1005	1-104-664-11	ELECT	47µF	20%	25V
C1006	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1007	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1012	1-163-235-11	CERAMIC CHIP	22pF	5%	50V
C1013	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1014	1-163-235-11	CERAMIC CHIP	22pF	5%	50V
C1015	1-163-235-11	CERAMIC CHIP	22pF	5%	50V
C1016	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1017	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1019	1-164-489-11	CERAMIC CHIP	0.22µF	10%	16V
C1020	1-164-346-11	CERAMIC CHIP	1µF		16V
C1021	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C1022	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1023	1-126-935-11	ELECT	470µF	20%	6.3V
C1025	1-126-965-11	ELECT	22µF	20%	50V
C1026	1-163-809-11	CERAMIC CHIP	0.047µF	10%	25V
C1027	1-110-501-11	CERAMIC CHIP	0.33µF	10%	16V
C1029	1-164-346-11	CERAMIC CHIP	1µF		16V
C1030	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C1031	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1032	1-104-664-11	ELECT	47µF	20%	25V
C1033	1-126-964-11	ELECT	10µF	20%	50V
C1034	1-164-346-11	CERAMIC CHIP	1µF		16V
C1035	1-163-237-11	CERAMIC CHIP	27pF	5%	50V
C1036	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C1037	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1038	1-104-664-11	ELECT	47µF	20%	25V
C1039	1-164-346-11	CERAMIC CHIP	1µF		16V
C1040	1-163-237-11	CERAMIC CHIP	27pF	5%	50V
C1041	1-163-233-11	CERAMIC CHIP	18pF	5%	50V
C1042	1-163-233-11	CERAMIC CHIP	18pF	5%	50V
C1043	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1044	1-163-017-00	CERAMIC CHIP	0.0047µF	10%	50V
C1045	1-163-143-00	CERAMIC CHIP	0.0012µF	5%	50V
C1046	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1048	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1049	1-104-664-11	ELECT	47µF	20%	25V
C1050	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1051	1-104-664-11	ELECT	47µF	20%	25V
C1052	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1058	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1301	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1302	1-104-664-11	ELECT	47µF	20%	25V
C1303	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1305	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C1306	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C1307	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C1308	1-117-720-11	CERAMIC CHIP	4.7µF		10V
C1309	1-163-227-11	CERAMIC CHIP	10pF	0.5pF	50V
C1310	1-163-227-11	CERAMIC CHIP	10pF	0.5pF	50V
C1311	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C1312	1-163-227-11	CERAMIC CHIP	10pF	0.5pF	50V
C1313	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1315	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C1316	1-117-720-11	CERAMIC CHIP	4.7µF		10V
C1317	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1321	1-163-017-00	CERAMIC CHIP	0.0047µF	10%	50V
C1323	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1325	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C1326	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1327	1-126-963-11	ELECT	4.7µF	20%	50V
C1328	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1329	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1330	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1331	1-163-133-00	CERAMIC CHIP	470pF	5%	50V
C1332	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C1334	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1335	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1336	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1337	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1338	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1339	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1340	1-126-960-11	ELECT	1µF	20%	50V
C1341	1-163-133-00	CERAMIC CHIP	470pF	5%	50V
C1342	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C1343	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1344	1-104-664-11	ELECT	47µF	20%	25V
C1345	1-104-664-11	ELECT	47µF	20%	25V
C1346	1-104-664-11	ELECT	47µF	20%	25V
C1347	1-104-664-11	ELECT	47µF	20%	25V
C1348	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1349	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C1351	1-126-934-11	ELECT	220µF	20%	16V
C1352	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1353	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1354	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1355	1-104-664-11	ELECT	47µF	20%	25V
C1357	1-126-934-11	ELECT	220µF	20%	16V
C1358	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1359	1-104-664-11	ELECT	47µF	20%	25V
C1363	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1364	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1376	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1380	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C1381	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C1383	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1385	1-163-017-00	CERAMIC CHIP	0.0047µF	10%	50V
C1389	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C1392	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V

A

REF. NO.	PART NO.	DESCRIPTION			REMARK
C1400	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1401	1-126-963-11	ELECT	4.7µF	20%	50V
C1402	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1403	1-163-135-00	CERAMIC CHIP	560pF	5%	50V
C1405	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1406	1-163-021-91	CERAMIC CHIP	0.01µF	10%	50V
C1407	1-164-344-11	CERAMIC CHIP	0.068µF	10%	25V
C1408	1-163-019-00	CERAMIC CHIP	0.0068µF	10%	50V
C1409	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1410	1-163-133-00	CERAMIC CHIP	470pF	5%	50V
C1411	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1412	1-163-259-91	CERAMIC CHIP	220pF	5%	50V
C1413	1-126-960-11	ELECT	1µF	20%	50V
C1414	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1415	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1417	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1418	1-104-664-11	ELECT	47µF	20%	25V
C1419	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1420	1-104-664-11	ELECT	47µF	20%	25V
C1421	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1422	1-163-231-11	CERAMIC CHIP	15pF	5%	50V
C1423	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1424	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1425	1-104-664-11	ELECT	47µF	20%	25V
C1426	1-117-720-11	CERAMIC CHIP	4.7µF		10V
C1428	1-126-934-11	ELECT	220µF	20%	16V
C1431	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1432	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1455	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1456	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1457	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1462	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1463	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1464	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1465	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1466	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1467	1-164-004-11	CERAMIC CHIP	0.1µF	10%	25V
C1470	1-104-664-11	ELECT	47µF	20%	25V
C1471	1-104-664-11	ELECT	47µF	20%	25V
C1472	1-104-664-11	ELECT	47µF	20%	25V
C1481	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C1482	1-104-664-11	ELECT	47µF	20%	25V
C1483	1-104-664-11	ELECT	47µF	20%	25V
C1484	1-126-934-11	ELECT	220µF	20%	16V
C1485	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1601	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1602	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1603	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1604	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1605	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1606	1-165-319-11	CERAMIC CHIP	0.1µF		50V
C1608	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1609	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1610	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1611	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1612	1-163-016-00	CERAMIC CHIP	0.0039µF	10%	50V
C1613	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1614	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1615	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1617	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1619	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1621	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1623	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1624	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1626	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1628	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1629	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1631	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1633	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1634	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C1640	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1641	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1642	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1643	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1644	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C1646	1-104-664-11	ELECT	47µF	20%	25V
C1647	1-109-982-11	CERAMIC CHIP	1µF	10%	10V
C1648	1-163-275-11	CERAMIC CHIP	0.001µF	5%	50V
C1649	1-115-185-11	CERAMIC CHIP	0.033µF	10%	50V
C1650	1-163-275-11	CERAMIC CHIP	0.001µF	5%	50V
C1651	1-109-982-11	CERAMIC CHIP	1µF	10%	10V

<FILTERBLOCK>

CM501	1-467-554-21	FILTER BLOCK, COMB	

<CONNECTOR>

CN501	*	1-564-506-11	PLUG, CONNECTOR 3P
CN502	*	1-564-506-11	PLUG, CONNECTOR 3P
CN503	*	1-564-511-11	PLUG, CONNECTOR 8P
CN504	*	1-564-512-11	PLUG, CONNECTOR 9P
CN505	*	1-564-510-11	PLUG, CONNECTOR 7P
CN506	*	1-779-892-11	CONNECTOR, BOARD TO BOARD 10P
CN507		1-695-915-11	TAB (CONTACT)
CN508	*	1-564-507-11	PLUG, CONNECTOR 4P
CN509	*	1-779-892-11	CONNECTOR, BOARD TO BOARD 10P
CN510	*	1-564-510-11	PLUG, CONNECTOR 7P
CN511		1-573-298-21	CONNECTOR, BOARD TO BOARD 20P
CN512	*	1-564-513-11	PLUG, CONNECTOR 10P
CN513		1-573-298-21	CONNECTOR, BOARD TO BOARD 20P
CN514	*	1-564-509-11	PLUG, CONNECTOR 6P
CN515		1-764-334-11	PLUG, CONNECTOR 11P
CN516		1-573-978-21	CONNECTOR, BOARD TO BOARD 11P
CN517	*	1-779-892-11	CONNECTOR, BOARD TO BOARD 10P
CN518		1-573-298-21	CONNECTOR, BOARD TO BOARD 20P
CN519	*	1-779-892-11	CONNECTOR, BOARD TO BOARD 10P
CN520	*	1-691-616-21	CONNECTOR, BOARD TO BOARD 15P
CN521		1-573-979-21	CONNECTOR, BOARD TO BOARD 11P
CN522		1-573-298-21	CONNECTOR, BOARD TO BOARD 20P
CN523		1-573-298-21	CONNECTOR, BOARD TO BOARD 20P
CN524	*	1-564-509-11	PLUG, CONNECTOR 6P
CN525	*	1-564-511-11	PLUG, CONNECTOR 8P

REF. NO.	PART NO.	DESCRIPTION	REMARK
CN526	* 1-564-510-11	PLUG, CONNECTOR 7P	
		<DIODE>	
D501	8-719-073-01	DIODE MA111-(K8).S0	
D502	8-719-158-15	DIODE RD5.6SB	
D503	8-719-073-01	DIODE MA111-(K8).S0	
D504	8-719-073-01	DIODE MA111-(K8).S0	
D505	8-719-073-01	DIODE MA111-(K8).S0	
D506	8-719-056-84	DIODE UDZ-TE-17-7.5B	
D508	8-719-073-01	DIODE MA111-(K8).S0	
D509	8-719-056-84	DIODE UDZ-TE-17-7.5B	
D511	8-719-073-01	DIODE MA111-(K8).S0	
D512	8-719-073-01	DIODE MA111-(K8).S0	
D513	8-719-073-01	DIODE MA111-(K8).S0	
D514	8-719-073-01	DIODE MA111-(K8).S0	
D515	8-719-158-15	DIODE RD5.6SB	
D516	8-719-158-15	DIODE RD5.6SB	
D517	8-719-158-15	DIODE RD5.6SB	
D518	8-719-073-01	DIODE MA111-(K8).S0	
D519	8-719-977-28	DIODE DTZ10B	
D520	8-719-977-28	DIODE DTZ10B	
D521	8-719-073-01	DIODE MA111-(K8).S0	
D522	8-719-977-28	DIODE DTZ10B	
D523	8-719-073-01	DIODE MA111-(K8).S0	
D524	8-719-977-28	DIODE DTZ10B	
D525	8-719-977-28	DIODE DTZ10B	
D526	8-719-977-28	DIODE DTZ10B	
D527	8-719-977-28	DIODE DTZ10B	
D528	8-719-977-28	DIODE DTZ10B	
D529	8-719-977-28	DIODE DTZ10B	
D530	8-719-073-01	DIODE MA111-(K8).S0	
D531	8-719-073-01	DIODE MA111-(K8).S0	
D532	8-719-977-28	DIODE DTZ10B	
D533	8-719-977-28	DIODE DTZ10B	
D534	8-719-977-28	DIODE DTZ10B	
D535	8-719-977-28	DIODE DTZ10B	
D536	8-719-073-01	DIODE MA111-(K8).S0	
D537	8-719-977-28	DIODE DTZ10B	
D538	8-719-977-28	DIODE DTZ10B	
D539	8-719-977-28	DIODE DTZ10B	
D540	8-719-977-28	DIODE DTZ10B	
D541	8-719-977-28	DIODE DTZ10B	
D542	8-719-977-28	DIODE DTZ10B	
D543	8-719-977-28	DIODE DTZ10B	
D544	8-719-977-28	DIODE DTZ10B	
D545	8-719-977-28	DIODE DTZ10B	
D546	8-719-977-28	DIODE DTZ10B	
D547	8-719-977-28	DIODE DTZ10B	
D548	8-719-073-01	DIODE MA111-(K8).S0	
D550	8-719-977-28	DIODE DTZ10B	
D551	8-719-977-28	DIODE DTZ10B	
D552	8-719-977-28	DIODE DTZ10B	
D555	8-719-977-28	DIODE DTZ10B	
D556	8-719-977-28	DIODE DTZ10B	
D557	8-719-977-28	DIODE DTZ10B	
D558	8-719-977-81	DIODE DTZ33B	
D559	8-719-977-28	DIODE DTZ10B	
D560	8-719-977-28	DIODE DTZ10B	
D1001	8-719-073-01	DIODE MA111-(K8).S0	
D1002	8-719-073-01	DIODE MA111-(K8).S0	
D1003	8-719-073-01	DIODE MA111-(K8).S0	
D1005	8-719-073-01	DIODE MA111-(K8).S0	
D1006	8-719-073-01	DIODE MA111-(K8).S0	
D1007	8-719-073-01	DIODE MA111-(K8).S0	
D1008	8-719-073-01	DIODE MA111-(K8).S0	
D1009	8-719-073-01	DIODE MA111-(K8).S0	
D1601	8-719-976-99	DIODE DTZ5.1B	
D1602	8-719-976-99	DIODE DTZ5.1B	
D1603	8-719-976-99	DIODE DTZ5.1B	
D1604	8-719-976-99	DIODE DTZ5.1B	
D1605	8-719-976-99	DIODE DTZ5.1B	
D1614	8-719-976-99	DIODE DTZ5.1B	
D1615	8-719-976-99	DIODE DTZ5.1B	
D1616	8-719-976-99	DIODE DTZ5.1B	
D1618	8-719-073-01	DIODE MA111-(K8).S0	
D1620	8-719-073-01	DIODE MA111-(K8).S0	
D1623	8-719-073-01	DIODE MA111-(K8).S0	
D1625	8-719-073-01	DIODE MA111-(K8).S0	
D1626	8-719-073-01	DIODE MA111-(K8).S0	
D1628	8-719-073-01	DIODE MA111-(K8).S0	
D1630	8-719-073-01	DIODE MA111-(K8).S0	
D1632	8-719-073-01	DIODE MA111-(K8).S0	
D1634	8-719-073-01	DIODE MA111-(K8).S0	
		<FILTER>	
FL501	1-233-736-21	FILTER, EMI	
FL502	1-233-736-21	FILTER, EMI	
FL503	1-233-736-21	FILTER, EMI	
		<IC>	
IC501	8-759-701-79	IC NJM7812FA	
IC503	8-759-144-82	IC µPC2405HF	
IC504	8-759-513-71	IC PQ05RF21	
IC505	8-759-198-03	IC PQ09RF21	
IC506	8-759-520-49	IC PQ30RV21	
IC507	8-759-083-85	IC LA7856A	
IC508	8-759-032-23	IC MC74HC74AF	
IC509	8-759-011-64	IC MC74HC4052F	
IC510	8-759-988-13	IC LM393PS	
IC511	8-752-086-33	IC CXA2101AQ-TL	
IC512	8-752-379-93	IC CXD2018AQ-T6	
IC513	8-759-485-79	IC TC7SET08FU(TE85L)	
IC514	8-759-998-98	IC LM358D	
IC515	8-752-082-87	IC CXA1845Q-TL	
IC516	8-759-082-58	IC TC7W08FU	
IC517	8-759-239-34	IC TC74HC4538AF	
IC518	8-759-998-98	IC LM358D	
IC519	8-759-239-34	IC TC74HC4538AF	
IC1001	8-759-575-89	IC LH5317VP	
IC1002	8-759-927-72	IC TL1591CP	
IC1003	8-759-925-75	IC SN74HC05ANS	

A

REF. NO.	PART NO.	DESCRIPTION	REMARK
IC1004	8-759-575-90	IC MB90091A-150	
IC1005	8-759-352-91	IC PST9143NL	
IC1007	8-759-527-76	IC M24C08-MN6T	
IC1008	8-752-910-89	IC CXP85856A-033Q	
IC1009	8-752-910-90	IC CXP85460-225Q	
IC1010	8-759-352-91	IC PST9143NL	
IC1301	8-752-086-80	IC CXA2019AQ-T4	
IC1302	8-752-082-49	IC CXA2119M	
IC1303	8-759-353-02	IC NJM2533M(TE2)	
IC1305	8-752-086-80	IC CXA2019AQ-T4	
IC1307	8-752-082-49	IC CXA2119M	
IC1401	8-759-575-50	IC Z8613012SSC	
IC1402	8-759-082-58	IC TC7W08FU	
IC1403	8-759-009-07	IC MC14053BF	
IC1601	8-759-394-80	IC NJM2058M-TE2	
IC1603	8-759-009-07	IC MC14053BF	
IC1604	8-759-394-80	IC NJM2058M-TE2	
IC1605	8-759-394-80	IC NJM2058M-TE2	
IC1606	8-759-394-80	IC NJM2058M-TE2	
IC1608	8-759-232-74	IC TC74HC163AF	
IC1609	8-759-232-74	IC TC74HC163AF	
IC1623	8-759-082-57	IC TC7W04FU	
IC1624	8-759-082-58	IC TC7W08FU	

<JACK>

J502	1-774-749-11	JACK BLOCK, PIN (SELECT OUT)	
J505	1-774-751-11	TERMINAL BLOCK, S (VIDEO 1)	
J506	1-774-751-11	TERMINAL BLOCK, S (VIDEO 3)	
J507	1-774-751-11	TERMINAL BLOCK, S (VIDEO 4)	
J508	1-774-750-11	JACK BLOCK, PIN (VIDEO 5(DTV))	

<COIL>

L501	1-414-856-11	INDUCTOR	10µH
L502	1-414-856-11	INDUCTOR	10µH
L503	1-414-856-11	INDUCTOR	10µH
L504	1-414-856-11	INDUCTOR	10µH
L505	1-414-856-11	INDUCTOR	10µH
L506	1-414-856-11	INDUCTOR	10µH
L507	1-414-856-11	INDUCTOR	10µH
L508	1-414-856-11	INDUCTOR	10µH
L509	1-414-856-11	INDUCTOR	10µH
L510	1-414-856-11	INDUCTOR	10µH
L511	1-414-856-11	INDUCTOR	10µH
L512	1-414-856-11	INDUCTOR	10µH
L513	1-414-234-22	INDUCTOR CHIP	0µH
L514	1-414-856-11	INDUCTOR	10µH
L515	1-414-856-11	INDUCTOR	10µH
L517	1-414-234-22	INDUCTOR CHIP	0µH
L518	1-414-234-22	INDUCTOR CHIP	0µH
L519	1-414-234-22	INDUCTOR CHIP	0µH
L520	1-414-234-22	INDUCTOR CHIP	0µH
L523	1-414-856-11	INDUCTOR	10µH
L1001	1-414-234-22	INDUCTOR CHIP	0µH
L1002	1-414-234-22	INDUCTOR CHIP	0µH
L1004	1-469-555-21	INDUCTOR	10µH
L1005	1-469-555-21	INDUCTOR	10µH
L1006	1-469-555-21	INDUCTOR	10µH
L1008	1-469-555-21	INDUCTOR	10µH
L1009	1-414-234-22	INDUCTOR CHIP	0µH
L1301	1-414-234-22	INDUCTOR CHIP	0µH
L1302	1-414-234-22	INDUCTOR CHIP	0µH
L1304	1-414-234-22	INDUCTOR CHIP	0µH
L1306	1-469-555-21	INDUCTOR	10µH
L1307	1-469-555-21	INDUCTOR	10µH
L1308	1-469-555-21	INDUCTOR	10µH
L1314	1-414-234-22	INDUCTOR CHIP	0µH
L1319	1-469-555-21	INDUCTOR	10µH
L1320	1-469-555-21	INDUCTOR	10µH
L1329	1-469-555-21	INDUCTOR	10µH
L1401	1-414-234-22	INDUCTOR CHIP	0µH
L1402	1-414-234-22	INDUCTOR CHIP	0µH
L1403	1-414-234-22	INDUCTOR CHIP	0µH
L1404	1-469-555-21	INDUCTOR	10µH
L1405	1-414-234-22	INDUCTOR CHIP	0µH

<TRANSISTOR>

Q501	8-729-216-22	TRANSISTOR	2SA1162-G
Q502	8-729-422-27	TRANSISTOR	2SD601A-Q
Q503	8-729-422-27	TRANSISTOR	2SD601A-Q
Q504	8-729-422-27	TRANSISTOR	2SD601A-Q
Q505	8-729-422-27	TRANSISTOR	2SD601A-Q
Q506	8-729-422-27	TRANSISTOR	2SD601A-Q
Q507	8-729-216-22	TRANSISTOR	2SA1162-G
Q508	8-729-422-27	TRANSISTOR	2SD601A-Q
Q509	8-729-422-27	TRANSISTOR	2SD601A-Q
Q510	8-729-122-63	TRANSISTOR	2SA1226-E4
Q511	8-729-216-22	TRANSISTOR	2SA1162-G
Q512	8-729-216-22	TRANSISTOR	2SA1162-G
Q513	8-729-216-22	TRANSISTOR	2SA1162-G
Q514	8-729-422-27	TRANSISTOR	2SD601A-Q
Q515	8-729-216-22	TRANSISTOR	2SA1162-G
Q516	8-729-122-63	TRANSISTOR	2SA1226-E4
Q517	8-729-216-22	TRANSISTOR	2SA1162-G
Q518	8-729-216-22	TRANSISTOR	2SA1162-G
Q519	8-729-216-22	TRANSISTOR	2SA1162-G
Q520	8-729-422-27	TRANSISTOR	2SD601A-Q
Q521	8-729-216-22	TRANSISTOR	2SA1162-G
Q522	8-729-027-38	TRANSISTOR	DTA144EKA-T146
Q523	8-729-216-22	TRANSISTOR	2SA1162-G
Q524	8-729-122-63	TRANSISTOR	2SA1226-E4
Q525	8-729-422-27	TRANSISTOR	2SD601A-Q
Q526	8-729-422-27	TRANSISTOR	2SD601A-Q
Q527	8-729-422-27	TRANSISTOR	2SD601A-Q
Q528	8-729-422-27	TRANSISTOR	2SD601A-Q
Q530	8-729-422-27	TRANSISTOR	2SD601A-Q
Q531	8-729-422-27	TRANSISTOR	2SD601A-Q
Q532	8-729-422-27	TRANSISTOR	2SD601A-Q
Q533	8-729-216-22	TRANSISTOR	2SA1162-G
Q535	8-729-422-27	TRANSISTOR	2SD601A-Q
Q536	8-729-422-27	TRANSISTOR	2SD601A-Q
Q537	8-729-422-27	TRANSISTOR	2SD601A-Q

REF. NO.	PART NO.	DESCRIPTION	REMARK
Q538	8-729-216-22	TRANSISTOR 2SA1162-G	
Q539	8-729-216-22	TRANSISTOR 2SA1162-G	
Q540	8-729-216-22	TRANSISTOR 2SA1162-G	
Q541	8-729-027-38	TRANSISTOR DTA144EKA-T146	
Q542	8-729-216-22	TRANSISTOR 2SA1162-G	
Q543	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q544	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q545	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q546	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q547	8-729-216-22	TRANSISTOR 2SA1162-G	
Q548	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q549	8-729-027-38	TRANSISTOR DTA144EKA-T146	
Q550	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q551	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q552	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q553	8-729-216-22	TRANSISTOR 2SA1162-G	
Q554	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q560	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q561	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q562	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q563	8-729-216-22	TRANSISTOR 2SA1162-G	
Q564	8-729-216-22	TRANSISTOR 2SA1162-G	
Q801	8-729-027-38	TRANSISTOR DTA144EKA-T146	
Q1001	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1002	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1003	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1004	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1005	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1006	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1008	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1010	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1011	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1012	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1015	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1018	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1020	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1022	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1301	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1302	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1303	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1304	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1305	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1306	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1307	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1308	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1309	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1311	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1312	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1313	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1315	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1317	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1318	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1319	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1320	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1321	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1322	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1323	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1324	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1325	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1326	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1327	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1328	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1329	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1330	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1331	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1332	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1333	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1335	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1336	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1338	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1343	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1366	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1367	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1402	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1403	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1404	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1405	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1406	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1407	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1408	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1413	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1414	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1415	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1416	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1417	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1418	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1419	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1420	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1421	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1422	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1601	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1602	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1603	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1604	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1605	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1606	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1607	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1608	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1609	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1610	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1611	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1612	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1613	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1614	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1615	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1616	8-729-048-50	TRANSISTOR 2SK3018-T106	
Q1617	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1621	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1628	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1629	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1630	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q1631	8-729-422-27	TRANSISTOR 2SD601A-Q	

A

REF. NO.	PART NO.	DESCRIPTION			REMARK
		<RESISTOR>			
R501	1-216-073-00	RES,CHIP	10K	5%	1/10W
R502	1-216-073-00	RES,CHIP	10K	5%	1/10W
R503	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R504	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R505	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R506	1-216-025-91	RES,CHIP	100	5%	1/10W
R507	1-216-295-91	SHORT	0		
R508	1-249-393-11	CARBON	10	5%	1/4W F
R509	1-249-381-11	CARBON	1	5%	1/4W F
R510	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R511	1-216-295-91	SHORT	0		
R512	1-216-295-91	SHORT	0		
R513	1-216-295-91	SHORT	0		
R514	1-216-031-00	RES,CHIP	180	5%	1/10W
R515	1-249-381-11	CARBON	1	5%	1/4W F
R516	1-216-025-91	RES,CHIP	100	5%	1/10W
R517	1-216-101-00	RES,CHIP	150K	5%	1/10W
R518	1-216-295-91	SHORT	0		
R519	1-216-025-91	RES,CHIP	100	5%	1/10W
R520	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R521	1-216-049-91	RES,CHIP	1K	5%	1/10W
R522	1-216-295-91	SHORT	0		
R523	1-216-031-00	RES,CHIP	180	5%	1/10W
R524	1-216-081-00	RES,CHIP	22K	5%	1/10W
R525	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R526	1-216-031-00	RES,CHIP	180	5%	1/10W
R527	1-216-085-00	RES,CHIP	33K	5%	1/10W
R528	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R529	1-216-105-91	RES,CHIP	220K	5%	1/10W
R530	1-208-780-11	METAL CHIP	820	0.50%	1/10W
R531	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R532	1-216-049-91	RES,CHIP	1K	5%	1/10W
R533	1-216-368-11	METAL OXIDE	0.82	5%	2W F
R534	1-208-810-11	METAL CHIP	15K	0.50%	1/10W
R535	1-216-373-11	METAL OXIDE	2.2	5%	2W F
R536	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R537	1-208-818-11	METAL CHIP	33K	0.50%	1/10W
R538	1-216-083-00	RES,CHIP	27K	5%	1/10W
R539	1-216-689-11	RES,CHIP	39K	5%	1/10W
R540	1-208-808-11	METAL CHIP	12K	0.50%	1/10W
R541	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R542	1-216-043-91	RES,CHIP	560	5%	1/10W
R543	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R544	1-216-045-00	RES,CHIP	680	5%	1/10W
R545	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R546	1-208-826-11	METAL CHIP	68K	0.50%	1/10W
R547	1-216-073-00	RES,CHIP	10K	5%	1/10W
R548	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R549	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R550	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R551	1-216-097-91	RES,CHIP	100K	5%	1/10W
R552	1-216-081-00	RES,CHIP	22K	5%	1/10W
R553	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R554	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R555	1-216-043-91	RES,CHIP	560	5%	1/10W
R556	1-216-121-91	RES,CHIP	1M	5%	1/10W
R557	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R558	1-216-073-00	RES,CHIP	10K	5%	1/10W
R559	1-216-073-00	RES,CHIP	10K	5%	1/10W
R560	1-208-778-11	METAL CHIP	680	0.50%	1/10W
R561	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R562	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R563	1-216-097-91	RES,CHIP	100K	5%	1/10W
R564	1-216-097-91	RES,CHIP	100K	5%	1/10W
R565	1-216-097-91	RES,CHIP	100K	5%	1/10W
R566	1-216-069-00	RES,CHIP	6.8K	5%	1/10W
R567	1-216-049-91	RES,CHIP	1K	5%	1/10W
R569	1-216-073-00	RES,CHIP	10K	5%	1/10W
R570	1-208-798-11	METAL CHIP	4.7K	0.50%	1/10W
R571	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R572	1-216-097-91	RES,CHIP	100K	5%	1/10W
R573	1-216-049-91	RES,CHIP	1K	5%	1/10W
R574	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R575	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R576	1-216-097-91	RES,CHIP	100K	5%	1/10W
R577	1-216-075-00	RES,CHIP	12K	5%	1/10W
R578	1-216-073-00	RES,CHIP	10K	5%	1/10W
R580	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R581	1-216-073-00	RES,CHIP	10K	5%	1/10W
R582	1-216-049-91	RES,CHIP	1K	5%	1/10W
R583	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R584	1-216-097-91	RES,CHIP	100K	5%	1/10W
R585	1-216-097-91	RES,CHIP	100K	5%	1/10W
R586	1-216-049-91	RES,CHIP	1K	5%	1/10W
R587	1-216-295-91	SHORT	0		
R588	1-216-017-91	RES,CHIP	47	5%	1/10W
R589	1-216-049-91	RES,CHIP	1K	5%	1/10W
R590	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R591	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R592	1-216-025-91	RES,CHIP	100	5%	1/10W
R593	1-216-049-91	RES,CHIP	1K	5%	1/10W
R594	1-216-121-91	RES,CHIP	1M	5%	1/10W
R595	1-216-033-00	RES,CHIP	220	5%	1/10W
R596	1-216-049-91	RES,CHIP	1K	5%	1/10W
R597	1-216-025-91	RES,CHIP	100	5%	1/10W
R598	1-216-033-00	RES,CHIP	220	5%	1/10W
R599	1-216-105-91	RES,CHIP	220K	5%	1/10W
R600	1-216-041-00	RES,CHIP	470	5%	1/10W
R601	1-216-081-00	RES,CHIP	22K	5%	1/10W
R602	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R603	1-216-073-00	RES,CHIP	10K	5%	1/10W
R604	1-216-073-00	RES,CHIP	10K	5%	1/10W
R605	1-216-049-91	RES,CHIP	1K	5%	1/10W
R606	1-216-373-11	METAL OXIDE	2.2	5%	2W F
R607	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R608	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R609	1-216-033-00	RES,CHIP	220	5%	1/10W
R610	1-216-025-91	RES,CHIP	100	5%	1/10W
R611	1-216-107-00	RES,CHIP	270K	5%	1/10W
R612	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R613	1-216-073-00	RES,CHIP	10K	5%	1/10W
R614	1-216-073-00	RES,CHIP	10K	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R615	1-216-069-00	RES,CHIP	6.8K	5%	1/10W
R616	1-216-295-91	SHORT	0		
R617	1-216-017-91	RES,CHIP	47	5%	1/10W
R618	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R619	1-216-033-00	RES,CHIP	220	5%	1/10W
R620	1-216-049-91	RES,CHIP	1K	5%	1/10W
R621	1-216-025-91	RES,CHIP	100	5%	1/10W
R622	1-216-049-91	RES,CHIP	1K	5%	1/10W
R623	1-216-025-91	RES,CHIP	100	5%	1/10W
R624	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R625	1-216-025-91	RES,CHIP	100	5%	1/10W
R626	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R628	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R629	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R630	1-216-097-91	RES,CHIP	100K	5%	1/10W
R631	1-216-025-91	RES,CHIP	100	5%	1/10W
R632	1-216-025-91	RES,CHIP	100	5%	1/10W
R633	1-216-025-91	RES,CHIP	100	5%	1/10W
R634	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R635	1-216-295-91	SHORT	0		
R636	1-216-133-00	RES,CHIP	3.3M	5%	1/10W
R637	1-216-025-91	RES,CHIP	100	5%	1/10W
R638	1-216-025-91	RES,CHIP	100	5%	1/10W
R639	1-216-025-91	RES,CHIP	100	5%	1/10W
R640	1-216-025-91	RES,CHIP	100	5%	1/10W
R642	1-216-025-91	RES,CHIP	100	5%	1/10W
R643	1-216-025-91	RES,CHIP	100	5%	1/10W
R644	1-216-025-91	RES,CHIP	100	5%	1/10W
R645	1-216-025-91	RES,CHIP	100	5%	1/10W
R646	1-216-025-91	RES,CHIP	100	5%	1/10W
R647	1-216-025-91	RES,CHIP	100	5%	1/10W
R648	1-216-017-91	RES,CHIP	47	5%	1/10W
R649	1-216-025-91	RES,CHIP	100	5%	1/10W
R650	1-216-025-91	RES,CHIP	100	5%	1/10W
R651	1-216-073-00	RES,CHIP	10K	5%	1/10W
R652	1-216-025-91	RES,CHIP	100	5%	1/10W
R653	1-216-025-91	RES,CHIP	100	5%	1/10W
R654	1-216-025-91	RES,CHIP	100	5%	1/10W
R655	1-216-025-91	RES,CHIP	100	5%	1/10W
R656	1-216-025-91	RES,CHIP	100	5%	1/10W
R657	1-216-083-00	RES,CHIP	27K	5%	1/10W
R658	1-216-689-11	RES,CHIP	39K	5%	1/10W
R659	1-216-025-91	RES,CHIP	100	5%	1/10W
R660	1-216-025-91	RES,CHIP	100	5%	1/10W
R661	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R662	1-216-025-91	RES,CHIP	100	5%	1/10W
R663	1-216-025-91	RES,CHIP	100	5%	1/10W
R664	1-208-776-11	METAL CHIP	560	0.50%	1/10W
R665	1-216-025-91	RES,CHIP	100	5%	1/10W
R666	1-216-049-91	RES,CHIP	1K	5%	1/10W
R667	1-216-109-00	RES,CHIP	330K	5%	1/10W
R668	1-216-025-91	RES,CHIP	100	5%	1/10W
R669	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R670	1-216-069-00	RES,CHIP	6.8K	5%	1/10W
R671	1-216-025-91	RES,CHIP	100	5%	1/10W
R672	1-216-049-91	RES,CHIP	1K	5%	1/10W
R673	1-216-025-91	RES,CHIP	100	5%	1/10W
R674	1-216-025-91	RES,CHIP	100	5%	1/10W
R675	1-216-083-00	RES,CHIP	27K	5%	1/10W
R676	1-216-025-91	RES,CHIP	100	5%	1/10W
R677	1-216-025-91	RES,CHIP	100	5%	1/10W
R678	1-216-025-91	RES,CHIP	100	5%	1/10W
R679	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R680	1-216-025-91	RES,CHIP	100	5%	1/10W
R681	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R682	1-208-778-11	METAL CHIP	680	0.50%	1/10W
R683	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R685	1-216-025-91	RES,CHIP	100	5%	1/10W
R686	1-216-077-91	RES,CHIP	15K	5%	1/10W
R687	1-216-295-91	SHORT	0		
R688	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R689	1-216-025-91	RES,CHIP	100	5%	1/10W
R690	1-216-025-91	RES,CHIP	100	5%	1/10W
R692	1-208-808-11	METAL CHIP	12K	0.50%	1/10W
R693	1-216-025-91	RES,CHIP	100	5%	1/10W
R694	1-216-033-00	RES,CHIP	220	5%	1/10W
R695	1-216-025-91	RES,CHIP	100	5%	1/10W
R696	1-208-822-11	METAL CHIP	47K	0.50%	1/10W
R697	1-216-025-91	RES,CHIP	100	5%	1/10W
R698	1-216-049-91	RES,CHIP	1K	5%	1/10W
R699	1-208-798-11	METAL CHIP	4.7K	0.50%	1/10W
R700	1-216-043-91	RES,CHIP	560	5%	1/10W
R701	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R702	1-216-295-91	SHORT	0		
R703	1-216-049-91	RES,CHIP	1K	5%	1/10W
R705	1-216-025-91	RES,CHIP	100	5%	1/10W
R707	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R708	1-216-025-91	RES,CHIP	100	5%	1/10W
R709	1-216-091-00	RES,CHIP	56K	5%	1/10W
R710	1-216-025-91	RES,CHIP	100	5%	1/10W
R712	1-216-025-91	RES,CHIP	100	5%	1/10W
R713	1-216-025-91	RES,CHIP	100	5%	1/10W
R714	1-216-295-91	SHORT	0		
R716	1-216-025-91	RES,CHIP	100	5%	1/10W
R717	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R719	1-216-295-91	SHORT	0		
R720	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R721	1-216-025-91	RES,CHIP	100	5%	1/10W
R722	1-216-025-91	RES,CHIP	100	5%	1/10W
R723	1-216-295-91	SHORT	0		
R725	1-208-782-11	METAL CHIP	1K	0.50%	1/10W
R726	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R727	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R728	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R729	1-216-295-91	SHORT	0		
R730	1-216-049-91	RES,CHIP	1K	5%	1/10W
R734	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R735	1-216-025-91	RES,CHIP	100	5%	1/10W
R736	1-216-025-91	RES,CHIP	100	5%	1/10W
R739	1-216-073-00	RES,CHIP	10K	5%	1/10W
R740	1-216-017-91	RES,CHIP	47	5%	1/10W
R741	1-216-093-91	RES,CHIP	68K	5%	1/10W

A

REF. NO.	PART NO.	DESCRIPTION			REMARK
R743	1-216-025-91	RES,CHIP	100	5%	1/10W
R744	1-216-025-91	RES,CHIP	100	5%	1/10W
R745	1-216-025-91	RES,CHIP	100	5%	1/10W
R746	1-216-025-91	RES,CHIP	100	5%	1/10W
R747	1-216-085-00	RES,CHIP	33K	5%	1/10W
R748	1-216-025-91	RES,CHIP	100	5%	1/10W
R749	1-216-025-91	RES,CHIP	100	5%	1/10W
R751	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R753	1-216-025-91	RES,CHIP	100	5%	1/10W
R754	1-216-025-91	RES,CHIP	100	5%	1/10W
R755	1-216-295-91	SHORT	0		
R756	1-216-045-00	RES,CHIP	680	5%	1/10W
R757	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R759	1-216-295-91	SHORT	0		
R760	1-216-295-91	SHORT	0		
R763	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R765	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R766	1-216-019-00	RES,CHIP	56	5%	1/10W
R768	1-216-081-00	RES,CHIP	22K	5%	1/10W
R772	1-216-025-91	RES,CHIP	100	5%	1/10W
R773	1-216-025-91	RES,CHIP	100	5%	1/10W
R774	1-216-025-91	RES,CHIP	100	5%	1/10W
R777	1-216-025-91	RES,CHIP	100	5%	1/10W
R779	1-208-818-11	METAL CHIP	33K	0.50%	1/10W
R780	1-216-025-91	RES,CHIP	100	5%	1/10W
R781	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R783	1-216-025-91	RES,CHIP	100	5%	1/10W
R784	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R787	1-216-025-91	RES,CHIP	100	5%	1/10W
R788	1-216-073-00	RES,CHIP	10K	5%	1/10W
R789	1-216-073-00	RES,CHIP	10K	5%	1/10W
R790	1-216-025-91	RES,CHIP	100	5%	1/10W
R791	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R794	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R795	1-216-025-91	RES,CHIP	100	5%	1/10W
R799	1-216-025-91	RES,CHIP	100	5%	1/10W
R800	1-216-025-91	RES,CHIP	100	5%	1/10W
R801	1-216-081-00	RES,CHIP	22K	5%	1/10W
R802	1-216-041-00	RES,CHIP	470	5%	1/10W
R803	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R804	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R806	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R807	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R808	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R809	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R810	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R812	1-216-025-91	RES,CHIP	100	5%	1/10W
R814	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R815	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R816	1-216-295-91	SHORT	0		
R817	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R818	1-216-049-91	RES,CHIP	1K	5%	1/10W
R819	1-216-025-91	RES,CHIP	100	5%	1/10W
R820	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R821	1-216-025-91	RES,CHIP	100	5%	1/10W
R822	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R823	1-216-025-91	RES,CHIP	100	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R824	1-216-025-91	RES,CHIP	100	5%	1/10W
R825	1-216-025-91	RES,CHIP	100	5%	1/10W
R826	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R827	1-216-025-91	RES,CHIP	100	5%	1/10W
R828	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R829	1-216-025-91	RES,CHIP	100	5%	1/10W
R830	1-216-025-91	RES,CHIP	100	5%	1/10W
R831	1-216-025-91	RES,CHIP	100	5%	1/10W
R832	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R833	1-216-025-91	RES,CHIP	100	5%	1/10W
R834	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R835	1-216-025-91	RES,CHIP	100	5%	1/10W
R836	1-216-025-91	RES,CHIP	100	5%	1/10W
R840	1-216-081-00	RES,CHIP	22K	5%	1/10W
R841	1-216-081-00	RES,CHIP	22K	5%	1/10W
R843	1-216-081-00	RES,CHIP	22K	5%	1/10W
R852	1-216-113-00	RES,CHIP	470K	5%	1/10W
R853	1-216-041-00	RES,CHIP	470	5%	1/10W
R854	1-216-041-00	RES,CHIP	470	5%	1/10W
R855	1-216-113-00	RES,CHIP	470K	5%	1/10W
R856	1-216-049-91	RES,CHIP	1K	5%	1/10W
R857	1-216-089-91	RES,CHIP	47K	5%	1/10W
R858	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R859	1-216-033-00	RES,CHIP	220	5%	1/10W
R860	1-216-033-00	RES,CHIP	220	5%	1/10W
R861	1-216-033-00	RES,CHIP	220	5%	1/10W
R862	1-216-049-91	RES,CHIP	1K	5%	1/10W
R864	1-216-049-91	RES,CHIP	1K	5%	1/10W
R865	1-216-049-91	RES,CHIP	1K	5%	1/10W
R867	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R868	1-216-033-00	RES,CHIP	220	5%	1/10W
R869	1-216-033-00	RES,CHIP	220	5%	1/10W
R870	1-216-113-00	RES,CHIP	470K	5%	1/10W
R871	1-216-113-00	RES,CHIP	470K	5%	1/10W
R872	1-216-113-00	RES,CHIP	470K	5%	1/10W
R873	1-216-113-00	RES,CHIP	470K	5%	1/10W
R875	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R876	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R877	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R878	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R879	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R880	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R883	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R884	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R885	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R886	1-216-113-00	RES,CHIP	470K	5%	1/10W
R887	1-216-033-00	RES,CHIP	220	5%	1/10W
R891	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R892	1-216-113-00	RES,CHIP	470K	5%	1/10W
R893	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R894	1-216-113-00	RES,CHIP	470K	5%	1/10W
R895	1-208-755-11	METAL CHIP	75	0.50%	1/10W
R896	1-216-113-00	RES,CHIP	470K	5%	1/10W
R898	1-216-113-00	RES,CHIP	470K	5%	1/10W
R899	1-216-033-00	RES,CHIP	220	5%	1/10W
R901	1-216-033-00	RES,CHIP	220	5%	1/10W
R903	1-216-009-91	RES,CHIP	22	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R904	1-216-009-91	RES,CHIP	22	5%	1/10W
R905	1-216-073-00	RES,CHIP	10K	5%	1/10W
R906	1-216-073-00	RES,CHIP	10K	5%	1/10W
R907	1-216-073-00	RES,CHIP	10K	5%	1/10W
R908	1-216-073-00	RES,CHIP	10K	5%	1/10W
R909	1-216-073-00	RES,CHIP	10K	5%	1/10W
R910	1-216-041-00	RES,CHIP	470	5%	1/10W
R911	1-216-025-91	RES,CHIP	100	5%	1/10W
R912	1-216-025-91	RES,CHIP	100	5%	1/10W
R913	1-216-025-91	RES,CHIP	100	5%	1/10W
R914	1-216-025-91	RES,CHIP	100	5%	1/10W
R1001	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1002	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1003	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1004	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1005	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1006	1-216-033-00	RES,CHIP	220	5%	1/10W
R1007	1-208-784-11	METAL CHIP	1.2K	0.50%	1/10W
R1008	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1009	1-216-033-00	RES,CHIP	220	5%	1/10W
R1010	1-208-784-11	METAL CHIP	1.2K	0.50%	1/10W
R1011	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1012	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1013	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R1014	1-216-025-91	RES,CHIP	100	5%	1/10W
R1015	1-216-025-91	RES,CHIP	100	5%	1/10W
R1016	1-216-025-91	RES,CHIP	100	5%	1/10W
R1017	1-216-025-91	RES,CHIP	100	5%	1/10W
R1018	1-216-025-91	RES,CHIP	100	5%	1/10W
R1019	1-216-025-91	RES,CHIP	100	5%	1/10W
R1020	1-216-025-91	RES,CHIP	100	5%	1/10W
R1021	1-216-033-00	RES,CHIP	220	5%	1/10W
R1022	1-208-784-11	METAL CHIP	1.2K	0.50%	1/10W
R1023	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1024	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1025	1-216-025-91	RES,CHIP	100	5%	1/10W
R1026	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1027	1-216-025-91	RES,CHIP	100	5%	1/10W
R1028	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1029	1-216-025-91	RES,CHIP	100	5%	1/10W
R1030	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1031	1-216-025-91	RES,CHIP	100	5%	1/10W
R1032	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1033	1-216-025-91	RES,CHIP	100	5%	1/10W
R1034	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1035	1-216-025-91	RES,CHIP	100	5%	1/10W
R1036	1-216-009-91	RES,CHIP	22	5%	1/10W
R1037	1-208-770-11	METAL CHIP	330	0.50%	1/10W
R1038	1-216-025-91	RES,CHIP	100	5%	1/10W
R1039	1-216-025-91	RES,CHIP	100	5%	1/10W
R1040	1-216-025-91	RES,CHIP	100	5%	1/10W
R1041	1-216-295-91	SHORT	0		
R1042	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1043	1-216-025-91	RES,CHIP	100	5%	1/10W
R1044	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1045	1-216-033-00	RES,CHIP	220	5%	1/10W
R1046	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1047	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1048	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1049	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1050	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R1051	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1052	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1053	1-216-083-00	RES,CHIP	27K	5%	1/10W
R1062	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1063	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1064	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1065	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1066	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1069	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1071	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1073	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1074	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1075	1-216-033-00	RES,CHIP	220	5%	1/10W
R1076	1-216-033-00	RES,CHIP	220	5%	1/10W
R1077	1-216-033-00	RES,CHIP	220	5%	1/10W
R1078	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1079	1-216-033-00	RES,CHIP	220	5%	1/10W
R1081	1-216-037-00	RES,CHIP	330	5%	1/10W
R1082	1-216-037-00	RES,CHIP	330	5%	1/10W
R1083	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1084	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1086	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1087	1-216-025-91	RES,CHIP	100	5%	1/10W
R1088	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R1089	1-216-025-91	RES,CHIP	100	5%	1/10W
R1090	1-208-798-11	METAL CHIP	4.7K	0.50%	1/10W
R1091	1-216-025-91	RES,CHIP	100	5%	1/10W
R1092	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1094	1-216-033-00	RES,CHIP	220	5%	1/10W
R1095	1-216-033-00	RES,CHIP	220	5%	1/10W
R1096	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R1097	1-216-033-00	RES,CHIP	220	5%	1/10W
R1098	1-216-033-00	RES,CHIP	220	5%	1/10W
R1099	1-216-033-00	RES,CHIP	220	5%	1/10W
R1100	1-216-033-00	RES,CHIP	220	5%	1/10W
R1101	1-216-025-91	RES,CHIP	100	5%	1/10W
R1102	1-216-033-00	RES,CHIP	220	5%	1/10W
R1103	1-216-033-00	RES,CHIP	220	5%	1/10W
R1104	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1105	1-216-033-00	RES,CHIP	220	5%	1/10W
R1106	1-216-033-00	RES,CHIP	220	5%	1/10W
R1107	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1108	1-216-025-91	RES,CHIP	100	5%	1/10W
R1109	1-216-295-91	SHORT	0		
R1110	1-216-033-00	RES,CHIP	220	5%	1/10W
R1111	1-216-033-00	RES,CHIP	220	5%	1/10W
R1112	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1113	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1114	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1115	1-216-033-00	RES,CHIP	220	5%	1/10W
R1116	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1117	1-216-041-00	RES,CHIP	470	5%	1/10W
R1118	1-216-049-91	RES,CHIP	1K	5%	1/10W

A

REF. NO.	PART NO.	DESCRIPTION			REMARK
R1119	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1120	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1121	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1122	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1124	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1125	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1126	1-216-025-91	RES,CHIP	100	5%	1/10W
R1130	1-216-033-00	RES,CHIP	220	5%	1/10W
R1131	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1133	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1134	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1135	1-216-033-00	RES,CHIP	220	5%	1/10W
R1136	1-216-033-00	RES,CHIP	220	5%	1/10W
R1137	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1138	1-216-033-00	RES,CHIP	220	5%	1/10W
R1139	1-216-033-00	RES,CHIP	220	5%	1/10W
R1140	1-216-033-00	RES,CHIP	220	5%	1/10W
R1141	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1142	1-216-033-00	RES,CHIP	220	5%	1/10W
R1143	1-216-033-00	RES,CHIP	220	5%	1/10W
R1144	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1145	1-216-033-00	RES,CHIP	220	5%	1/10W
R1146	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1147	1-216-025-91	RES,CHIP	100	5%	1/10W
R1148	1-216-033-00	RES,CHIP	220	5%	1/10W
R1149	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1150	1-216-025-91	RES,CHIP	100	5%	1/10W
R1151	1-216-033-00	RES,CHIP	220	5%	1/10W
R1152	1-216-025-91	RES,CHIP	100	5%	1/10W
R1153	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1154	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1155	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1156	1-216-033-00	RES,CHIP	220	5%	1/10W
R1157	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1158	1-216-033-00	RES,CHIP	220	5%	1/10W
R1159	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1161	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1162	1-216-025-91	RES,CHIP	100	5%	1/10W
R1163	1-216-025-91	RES,CHIP	100	5%	1/10W
R1164	1-216-033-00	RES,CHIP	220	5%	1/10W
R1165	1-216-033-00	RES,CHIP	220	5%	1/10W
R1166	1-216-033-00	RES,CHIP	220	5%	1/10W
R1167	1-216-121-91	RES,CHIP	1M	5%	1/10W
R1171	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1172	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1175	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R1178	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1180	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R1183	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1185	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R1188	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1301	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1302	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1303	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R1305	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R1306	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R1307	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1308	1-216-025-91	RES,CHIP	100	5%	1/10W
R1309	1-216-025-91	RES,CHIP	100	5%	1/10W
R1310	1-216-295-91	SHORT	0		
R1311	1-216-041-00	RES,CHIP	470	5%	1/10W
R1312	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1313	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1314	1-208-766-11	METAL CHIP	220	0.50%	1/10W
R1315	1-216-025-91	RES,CHIP	100	5%	1/10W
R1316	1-216-025-91	RES,CHIP	100	5%	1/10W
R1317	1-216-025-91	RES,CHIP	100	5%	1/10W
R1318	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R1319	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1320	1-216-025-91	RES,CHIP	100	5%	1/10W
R1321	1-216-025-91	RES,CHIP	100	5%	1/10W
R1322	1-216-025-91	RES,CHIP	100	5%	1/10W
R1323	1-216-037-00	RES,CHIP	330	5%	1/10W
R1324	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1325	1-216-111-00	RES,CHIP	390K	5%	1/10W
R1326	1-216-025-91	RES,CHIP	100	5%	1/10W
R1327	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R1328	1-216-025-91	RES,CHIP	100	5%	1/10W
R1329	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1330	1-216-025-91	RES,CHIP	100	5%	1/10W
R1331	1-216-025-91	RES,CHIP	100	5%	1/10W
R1332	1-216-025-91	RES,CHIP	100	5%	1/10W
R1333	1-216-043-91	RES,CHIP	560	5%	1/10W
R1334	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1335	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1337	1-216-025-91	RES,CHIP	100	5%	1/10W
R1338	1-216-025-91	RES,CHIP	100	5%	1/10W
R1339	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1341	1-216-025-91	RES,CHIP	100	5%	1/10W
R1342	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R1345	1-216-077-91	RES,CHIP	15K	5%	1/10W
R1348	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1349	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R1350	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1352	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1354	1-216-025-91	RES,CHIP	100	5%	1/10W
R1355	1-216-025-91	RES,CHIP	100	5%	1/10W
R1356	1-216-025-91	RES,CHIP	100	5%	1/10W
R1357	1-216-025-91	RES,CHIP	100	5%	1/10W
R1358	1-208-822-11	METAL CHIP	47K	0.50%	1/10W
R1363	1-216-025-91	RES,CHIP	100	5%	1/10W
R1364	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1365	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1366	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1368	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R1369	1-216-025-91	RES,CHIP	100	5%	1/10W
R1371	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R1372	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1374	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1375	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1377	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1379	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R1380	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R1381	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1383	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1389	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1392	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1393	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1394	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1395	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1396	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1397	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1398	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1400	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1401	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1402	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R1404	1-208-822-11	METAL CHIP	47K	0.50%	1/10W
R1405	1-216-037-00	RES,CHIP	330	5%	1/10W
R1406	1-216-025-91	RES,CHIP	100	5%	1/10W
R1407	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R1408	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1409	1-216-041-00	RES,CHIP	470	5%	1/10W
R1410	1-216-041-00	RES,CHIP	470	5%	1/10W
R1411	1-216-041-00	RES,CHIP	470	5%	1/10W
R1412	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1413	1-216-025-91	RES,CHIP	100	5%	1/10W
R1414	1-216-069-00	RES,CHIP	6.8K	5%	1/10W
R1415	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1416	1-216-025-91	RES,CHIP	100	5%	1/10W
R1417	1-216-025-91	RES,CHIP	100	5%	1/10W
R1418	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R1419	1-216-041-00	RES,CHIP	470	5%	1/10W
R1420	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1421	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1422	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1423	1-208-770-11	METAL CHIP	330	0.50%	1/10W
R1424	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1425	1-216-025-91	RES,CHIP	100	5%	1/10W
R1426	1-216-025-91	RES,CHIP	100	5%	1/10W
R1427	1-216-295-91	SHORT	0		
R1428	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1429	1-216-025-91	RES,CHIP	100	5%	1/10W
R1430	1-216-025-91	RES,CHIP	100	5%	1/10W
R1431	1-216-025-91	RES,CHIP	100	5%	1/10W
R1432	1-216-025-91	RES,CHIP	100	5%	1/10W
R1433	1-216-111-00	RES,CHIP	390K	5%	1/10W
R1434	1-216-295-91	SHORT	0		
R1435	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1436	1-216-295-91	SHORT	0		
R1437	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1438	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1439	1-208-768-11	METAL CHIP	270	0.50%	1/10W
R1440	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1441	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1442	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1443	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1444	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1445	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1446	1-216-043-91	RES,CHIP	560	5%	1/10W
R1447	1-216-081-00	RES,CHIP	22K	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R1448	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1449	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R1450	1-216-077-91	RES,CHIP	15K	5%	1/10W
R1451	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1452	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R1453	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1454	1-216-025-91	RES,CHIP	100	5%	1/10W
R1455	1-216-025-91	RES,CHIP	100	5%	1/10W
R1456	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1457	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1461	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1462	1-216-295-91	SHORT	0		
R1463	1-216-025-91	RES,CHIP	100	5%	1/10W
R1464	1-216-025-91	RES,CHIP	100	5%	1/10W
R1465	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1466	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1467	1-216-295-91	SHORT	0		
R1468	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1469	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1470	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1471	1-216-295-91	SHORT	0		
R1472	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1473	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R1474	1-208-790-11	METAL CHIP	2.2K	0.50%	1/10W
R1475	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1476	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1477	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1478	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R1479	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1480	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1482	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1483	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1484	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1485	1-216-025-91	RES,CHIP	100	5%	1/10W
R1501	1-216-025-91	RES,CHIP	100	5%	1/10W
R1503	1-216-025-91	RES,CHIP	100	5%	1/10W
R1511	1-216-295-91	SHORT	0		
R1517	1-216-295-91	SHORT	0		
R1518	1-216-295-91	SHORT	0		
R1521	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1527	1-216-025-91	RES,CHIP	100	5%	1/10W
R1528	1-216-025-91	RES,CHIP	100	5%	1/10W
R1529	1-216-025-91	RES,CHIP	100	5%	1/10W
R1530	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1536	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1537	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1538	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1540	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W
R1543	1-216-295-91	SHORT	0		
R1546	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1601	1-216-117-00	RES,CHIP	680K	5%	1/10W
R1602	1-216-113-00	RES,CHIP	470K	5%	1/10W
R1603	1-216-295-91	SHORT	0		
R1605	1-216-117-00	RES,CHIP	680K	5%	1/10W
R1607	1-216-117-00	RES,CHIP	680K	5%	1/10W
R1609	1-216-097-91	RES,CHIP	100K	5%	1/10W

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK
R1611	1-216-117-00	RES,CHIP	680K	5%	1/10W
R1612	1-216-113-00	RES,CHIP	470K	5%	1/10W
R1613	1-216-025-91	RES,CHIP	100	5%	1/10W
R1614	1-216-117-00	RES,CHIP	680K	5%	1/10W
R1617	1-216-117-00	RES,CHIP	680K	5%	1/10W
R1619	1-216-025-91	RES,CHIP	100	5%	1/10W
R1620	1-216-025-91	RES,CHIP	100	5%	1/10W
R1621	1-216-025-91	RES,CHIP	100	5%	1/10W
R1622	1-216-025-91	RES,CHIP	100	5%	1/10W
R1623	1-216-025-91	RES,CHIP	100	5%	1/10W
R1624	1-216-025-91	RES,CHIP	100	5%	1/10W
R1625	1-216-025-91	RES,CHIP	100	5%	1/10W
R1627	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1628	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1629	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1630	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1631	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1632	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1633	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1634	1-208-814-91	METAL CHIP	22K	0.50%	1/10W
R1640	1-208-758-11	METAL CHIP	100	0.50%	1/10W
R1641	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R1642	1-216-025-91	RES,CHIP	100	5%	1/10W
R1645	1-216-025-91	RES,CHIP	100	5%	1/10W
R1646	1-216-025-91	RES,CHIP	100	5%	1/10W
R1647	1-216-025-91	RES,CHIP	100	5%	1/10W
R1650	1-216-025-91	RES,CHIP	100	5%	1/10W
R1653	1-216-025-91	RES,CHIP	100	5%	1/10W
R1654	1-216-025-91	RES,CHIP	100	5%	1/10W
R1655	1-216-025-91	RES,CHIP	100	5%	1/10W
R1656	1-216-025-91	RES,CHIP	100	5%	1/10W
R1657	1-216-025-91	RES,CHIP	100	5%	1/10W
R1658	1-216-025-91	RES,CHIP	100	5%	1/10W
R1659	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1660	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1661	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1662	1-216-081-00	RES,CHIP	22K	5%	1/10W
R1663	1-216-025-91	RES,CHIP	100	5%	1/10W
R1664	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1665	1-216-113-00	RES,CHIP	470K	5%	1/10W
R1666	1-216-025-91	RES,CHIP	100	5%	1/10W
R1667	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1668	1-216-025-91	RES,CHIP	100	5%	1/10W
R1669	1-216-025-91	RES,CHIP	100	5%	1/10W
R1670	1-216-025-91	RES,CHIP	100	5%	1/10W
R1671	1-216-025-91	RES,CHIP	100	5%	1/10W
R1672	1-216-025-91	RES,CHIP	100	5%	1/10W
R1673	1-216-025-91	RES,CHIP	100	5%	1/10W
R1674	1-216-025-91	RES,CHIP	100	5%	1/10W
R1675	1-216-025-91	RES,CHIP	100	5%	1/10W
R1676	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1677	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1678	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1679	1-216-057-00	RES,CHIP	2.2K	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
		<TUNER>			
TU501	8-598-431-20	TUNER, FSS BTF-WA411			
TU502	8-598-431-20	TUNER, FSS BTF-WA411			
		<CRYSTAL>			
X1001	1-767-925-21	VIBRATOR, CRYSTAL			
X1002	1-579-125-11	VIBRATOR, CERAMIC			
X1301	1-577-611-11	OSCILALTOR, CERAMIC			
X1302	1-567-505-11	OSCILLATOR, CRYSTAL			
X1303	1-577-611-11	OSCILALTOR, CERAMIC			
X1305	1-567-505-11	OSCILLATOR, CRYSTAL			
**********					
		* A-1316-400-A G BOARD, COMPLETE			
		**********			
	1-533-223-11	CLIP,FUSE			
	4-382-854-11	SCREW(M3X10), P, SW (+)			
		<CAPACITOR>			
C6001 ⚠	1-104-708-11	MYLAR	0.47µF	20%	250V
C6002 ⚠	1-104-706-11	MYLAR	0.22µF	20%	250V
C6003 ⚠	1-119-906-51	CERAMIC	2200pF	20%	250V
C6004	1-119-906-51	CERAMIC	2200pF	20%	250V
C6006	1-161-964-91	CERAMIC	0.0047µF		250V
C6007	1-161-964-91	CERAMIC	0.0047µF		250V
C6008 ⚠	1-104-350-11	ELECT(BLOCK)	1000µF	20%	250V
C6009	1-107-671-91	ELECT	22µF	20%	400V
C6010 ⚠	1-104-350-11	ELECT(BLOCK)	1000µF	20%	250V
C6012	1-126-968-11	ELECT	100µF	20%	50V
C6013	1-126-964-11	ELECT	10µF	20%	50V
C6014	1-104-664-11	ELECT	47µF	20%	25V
C6015	1-137-605-11	MYLAR	0.01µF	10%	250V
C6016	1-126-961-11	ELECT	2.2µF	20%	50V
C6017	1-126-968-11	ELECT	100µF	20%	50V
C6018	1-102-112-00	CERAMIC	330pF	10%	50V
C6019	1-102-112-00	CERAMIC	330pF	10%	50V
C6020	1-136-165-00	MYLAR	0.1µF	5%	50V
C6021	1-126-960-11	ELECT	1µF	20%	50V
C6022	1-137-219-11	FILM	0.015µF	5%	0
C6023	1-115-405-11	FILM	0.039µF	3%	1KV
C6025	1-125-969-91	CERAMIC	680pF	10%	1KV
C6026	1-125-969-91	CERAMIC	680pF	10%	1KV
C6027	1-126-964-11	ELECT	10µF	20%	50V
C6028	1-136-479-11	FILM	0.001µF	2%	50V
C6029	1-102-112-00	CERAMIC	330pF	10%	50V
C6030	1-102-112-00	CERAMIC	330pF	10%	50V
C6031	1-126-960-11	ELECT	1µF	20%	50V
C6032	1-136-165-00	MYLAR	0.1µF	5%	50V
C6033	1-125-969-91	CERAMIC	680pF	10%	1KV
C6034	1-125-969-91	CERAMIC	680pF	10%	1KV
C6035	1-126-964-11	ELECT	10µF	20%	50V
C6036	1-136-165-00	MYLAR	0.1µF	5%	50V

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK
C6037	1-126-964-11	ELECT	10µF	20%	50V
C6102	1-104-665-11	ELECT	100µF	20%	25V
C6103	1-104-664-11	ELECT	47µF	20%	25V
C6104	1-101-810-00	CERAMIC	100pF	5%	500V
C6105	1-101-810-00	CERAMIC	100pF	5%	500V
C6108	1-104-664-11	ELECT	47µF	20%	25V
C6113	1-107-639-11	ELECT	47µF	20%	160V
C6114	1-107-641-11	ELECT	220µF	20%	160V
C6115	1-104-665-11	ELECT	100µF	20%	25V
C6116	1-126-968-11	ELECT	100µF	20%	50V
C6117	1-128-546-11	ELECT	10000µF	20%	10V
C6118	1-126-943-11	ELECT	2200µF	20%	25V
C6119	1-126-943-11	ELECT	2200µF	20%	25V
C6120	1-128-549-11	ELECT	3300µF	20%	35V
C6121	1-128-549-11	ELECT	3300µF	20%	35V
C6122	1-126-943-11	ELECT	2200µF	20%	25V
C6123	1-107-641-11	ELECT	220µF	20%	160V
C6124	1-128-549-11	ELECT	3300µF	20%	35V
C6125	1-128-549-11	ELECT	3300µF	20%	35V
C6126	1-104-665-11	ELECT	100µF	20%	25V
C6127	1-107-639-11	ELECT	47µF	20%	160V
C6128	1-128-549-11	ELECT	3300µF	20%	35V
C6129	1-128-549-11	ELECT	3300µF	20%	35V
C6131	1-104-665-11	ELECT	100µF	20%	25V
C6132	1-104-665-11	ELECT	100µF	20%	25V
C6133	1-104-665-11	ELECT	100µF	20%	25V
C6134	1-126-968-11	ELECT	100µF	20%	50V
C6135	1-126-968-11	ELECT	100µF	20%	50V
C6137	1-104-666-11	ELECT	220µF	20%	25V
C6140	1-104-665-11	ELECT	100µF	20%	25V
C6145	1-126-918-11	ELECT	4700µF	20%	6.3V
C6150	1-136-165-00	MYLAR	0.1µF	5%	50V
C6155	1-102-129-00	CERAMIC	0.01µF	10%	50V
C6156	1-102-050-00	CERAMIC	0.01µF	99%	500V
C6157	1-102-129-00	CERAMIC	0.01µF	10%	50V
C6158	1-102-129-00	CERAMIC	0.01µF	10%	50V
C6159	1-102-129-00	CERAMIC	0.01µF	10%	50V
C6160	1-102-129-00	CERAMIC	0.01µF	10%	50V

<CONNECTOR>

CN6004*	1-580-843-11	PIN, CONNECTOR (POWER)	
CN6101*	1-564-510-11	PLUG, CONNECTOR 7P	
CN6102*	1-691-757-11	PIN, CONNECTOR (PC BOARD) 8P	
CN6103	1-695-915-11	TAB (CONTACT)	
CN6104*	1-564-512-11	PLUG, CONNECTOR 9P	
CN6105*	1-564-509-11	PLUG, CONNECTOR 6P	
CN6106*	1-573-964-11	PIN, CONNECTOR (PC BOARD) 6P	
CN6107	1-695-915-11	TAB (CONTACT)	
CN6108	1-695-915-11	TAB (CONTACT)	

<DIODE>

D6002 ⚠	8-719-033-58	DIODE	RBV-1506
D6004	8-719-110-31	DIODE	RD12ESB2
D6005	8-719-979-64	DIODE	µF4005PKG23
D6006	8-719-059-23	DIODE	P6KE200AG23
D6007	8-719-991-33	DIODE	1SS133T-77
D6009	8-719-982-26	DIODE	MTZJ-33B
D6010	8-719-991-33	DIODE	1SS133T-77
D6011	8-719-923-60	DIODE	MTZJ-T-77-9.1A
D6012	8-719-991-33	DIODE	1SS133T-77
D6013	8-719-991-33	DIODE	1SS133T-77
D6014	8-719-991-33	DIODE	1SS133T-77
D6015	8-719-063-73	DIODE	D1NL20U-TR
D6016	8-719-979-64	DIODE	µF4005PKG23
D6017	8-719-110-53	DIODE	RD20ESB2
D6018	8-719-979-64	DIODE	µF4005PKG23
D6019	8-719-110-53	DIODE	RD20ESB2
D6020	8-719-210-53	DIODE	11ES4-TA1B
D6021	8-719-110-53	DIODE	RD20ESB2
D6022	8-719-110-53	DIODE	RD20ESB2
D6023	8-719-991-33	DIODE	1SS133T-77
D6024	8-719-991-33	DIODE	1SS133T-77
D6025	8-719-979-64	DIODE	µF4005PKG23
D6026	8-719-110-53	DIODE	RD20ESB2
D6027	8-719-979-64	DIODE	µF4005PKG23
D6028	8-719-110-53	DIODE	RD20ESB2
D6029	8-719-110-53	DIODE	RD20ESB2
D6030	8-719-110-53	DIODE	RD20ESB2
D6031	8-719-210-53	DIODE	11ES4-TA1B
D6032	8-719-979-64	DIODE	µF4005PKG23
D6033	8-719-991-33	DIODE	1SS133T-77
D6034	8-719-991-33	DIODE	1SS133T-77
D6035	8-719-110-31	DIODE	RD12ESB2
D6101	8-719-210-53	DIODE	11ES4-TA1B
D6102	8-719-057-96	DIODE	D10SC6M-4012
D6103	8-719-052-90	DIODE	D1NL40-TA2
D6104	8-719-031-78	DIODE	S2L40F
D6105	8-719-052-91	DIODE	D4SBS4-F
D6106	8-719-052-90	DIODE	D1NL40-TA2
D6107	8-719-031-78	DIODE	S2L40F
D6108	8-719-057-96	DIODE	D10SC6M-4012
D6109	8-719-049-92	DIODE	SF10SC3L
D6110	8-719-982-27	DIODE	MTZJ-33C
D6111	8-719-991-33	DIODE	1SS133T-77
D6112	8-719-991-33	DIODE	1SS133T-77
D6113	8-719-991-33	DIODE	1SS133T-77
D6114	8-719-072-30	DIODE	D25SC6MRF04
D6116	8-719-072-29	DIODE	D25SC6µF04
D6117	8-719-988-31	DIODE	D10SC6MR
D6119	8-719-110-31	DIODE	RD12ESB2
D6120	8-719-063-73	DIODE	D1NL20U-TR
D6121	8-719-921-63	DIODE	MTZJ-7.5B
D6122	8-719-991-33	DIODE	1SS133T-77
D6123	8-719-991-33	DIODE	1SS133T-77
D6124	8-719-991-33	DIODE	1SS133T-77
D6125	8-719-991-33	DIODE	1SS133T-77

<FUSE>

F6001 ⚠	1-576-048-11	FUSE, GLASS TUBE 10A/125V	
F6002 ⚠	1-533-759-11	FUSE	
F6105 ⚠	1-533-790-31	LINK, IC	

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK
F6106 ⚠	1-533-790-31	LINK, IC	
		<FERRITEBEAD>	
FB6001	1-410-397-21	FERRITE 1.1µH	
FB6002	1-410-397-21	FERRITE 1.1µH	
FB6003	1-410-397-21	FERRITE 1.1µH	
FB6004	1-410-397-21	FERRITE 1.1µH	
FB6005	1-410-397-21	FERRITE 1.1µH	
FB6006	1-410-397-21	FERRITE 1.1µH	
FB6007	1-410-397-21	FERRITE 1.1µH	
FB6008	1-410-397-21	FERRITE 1.1µH	
FB6101	1-410-397-21	FERRITE 1.1µH	
FB6102	1-410-397-21	FERRITE 1.1µH	
		<IC>	
IC6001	8-759-468-89	IC TOP209P	
IC6002	8-759-185-47	IC IR2112	
IC6003	8-759-077-25	IC IR3M02A	
IC6004	8-759-185-47	IC IR2112	
IC6005⚠	8-749-010-64	PHOTO COUPLER PC123F2	
IC6011⚠	8-749-010-64	PHOTO COUPLER PC123F2	
IC6101	8-749-920-61	IC SE-135N	
IC6102	8-759-103-93	IC µPC393C	
IC6103	8-759-198-31	IC µPC1093J-1-T	
IC6104	8-759-450-47	IC BA05T	
IC6301	8-759-198-31	IC µPC1093J-1-T	
		<COIL>	
L6001 ⚠	1-431-116-11	TRANSFORMER, LINE FILTER	
L6002 ⚠	1-431-116-11	TRANSFORMER, LINE FILTER	
L6103	1-412-523-25	INDUCTOR 6.8µH	
L6104	1-412-523-25	INDUCTOR 6.8µH	
L6105	1-412-525-31	INDUCTOR 10µH	
L6106	1-412-525-31	INDUCTOR 10µH	
L6107	1-406-659-11	INDUCTOR 10µH	
L6108	1-412-525-31	INDUCTOR 10µH	
L6109	1-412-525-31	INDUCTOR 10µH	
L6110	1-412-525-31	INDUCTOR 10µH	
L6111	1-412-525-31	INDUCTOR 10µH	
L6112	1-412-525-31	INDUCTOR 10µH	
		<IC LINK>	
PS6101⚠	1-533-597-31	LINK, IC	
PS6102⚠	1-533-597-31	LINK, IC	
PS6103⚠	1-533-790-31	LINK, IC	
PS6104⚠	1-533-790-31	LINK, IC	
		<TRANSISTOR>	
Q6001	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q6002	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q6003	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q6004	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q6005	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q6006	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q6007	8-729-044-42	TRANSISTOR IRFI644G-LF36	
Q6008	8-729-044-42	TRANSISTOR IRFI644G-LF36	
Q6009	8-729-044-42	TRANSISTOR IRFI644G-LF36	
Q6010	8-729-044-42	TRANSISTOR IRFI644G-LF36	
Q6011	8-729-140-97	TRANSISTOR 2SB734-34	
Q6012	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q6013	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q6101	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q6102	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q6103	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q6104	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q6106	8-729-119-76	TRANSISTOR 2SA1175-HFE	
		<RESISTOR>	
R6001 ⚠	1-219-776-11	CARBON 2.2M 10% 1/2W	
R6002	1-219-759-11	CARBON 1M 5% 1/2W	
R6004	1-260-131-11	CARBON 470K 5% 1/2W	
R6005	1-249-401-11	CARBON 47 5% 1/4W F	
R6006	1-260-127-11	CARBON 220K 5% 1/2W	
R6007	1-249-437-11	CARBON 47K 5% 1/4W	
R6008	1-260-127-11	CARBON 220K 5% 1/2W	
R6010	1-205-997-11	CEMENTED 2.2 5% 10W	
R6011	1-249-437-11	CARBON 47K 5% 1/4W	
R6012	1-212-849-00	FUSIBLE 4.7 5% 1/4W F	
R6013	1-247-895-91	CARBON 470K 5% 1/4W	
R6014	1-249-437-11	CARBON 47K 5% 1/4W	
R6015	1-249-437-11	CARBON 47K 5% 1/4W	
R6016	1-249-437-11	CARBON 47K 5% 1/4W	
R6017	1-249-417-11	CARBON 1K 5% 1/4W	
R6018	1-247-863-91	CARBON 22K 5% 1/4W	
R6019	1-249-429-11	CARBON 10K 5% 1/4W	
R6020	1-249-425-11	CARBON 4.7K 5% 1/4W	
R6021	1-247-791-91	CARBON 22 5% 1/4W	
R6022	1-249-437-11	CARBON 47K 5% 1/4W	
R6023	1-247-895-91	CARBON 470K 5% 1/4W	
R6024	1-249-397-11	CARBON 22 5% 1/4W F	
R6025	1-249-397-11	CARBON 22 5% 1/4W F	
R6026	1-249-425-11	CARBON 4.7K 5% 1/4W	
R6027	1-249-425-11	CARBON 4.7K 5% 1/4W	
R6028	1-215-427-00	METAL 1.8K 1% 1/4W	
R6029	1-247-863-91	CARBON 22K 5% 1/4W	
R6030	1-249-437-11	CARBON 47K 5% 1/4W	
R6031	1-249-425-11	CARBON 4.7K 5% 1/4W	
R6032	1-249-417-11	CARBON 1K 5% 1/4W	
R6033	1-215-444-00	METAL 9.1K 1% 1/4W	
R6034	1-249-417-11	CARBON 1K 5% 1/4W	
R6035	1-249-397-11	CARBON 22 5% 1/4W F	
R6036	1-249-397-11	CARBON 22 5% 1/4W F	
R6037	1-249-425-11	CARBON 4.7K 5% 1/4W	
R6038	1-249-425-11	CARBON 4.7K 5% 1/4W	
R6039	1-249-429-11	CARBON 10K 5% 1/4W	
R6040	1-249-429-11	CARBON 10K 5% 1/4W	
R6041	1-249-429-11	CARBON 10K 5% 1/4W	
R6042	1-249-437-11	CARBON 47K 5% 1/4W	
R6043	1-260-134-11	CARBON 820K 5% 1/2W	

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK
R6101	1-215-437-00	METAL	4.7K	1%	1/4W
R6102	1-215-479-00	METAL	270K	1%	1/4W
R6103	1-215-437-00	METAL	4.7K	1%	1/4W
R6104	1-215-413-00	METAL	470	1%	1/4W
R6105	1-249-417-11	CARBON	1K	5%	1/4W
R6106	1-249-417-11	CARBON	1K	5%	1/4W
R6108	1-249-425-11	CARBON	4.7K	5%	1/4W
R6109	1-249-425-11	CARBON	4.7K	5%	1/4W
R6110	1-249-417-11	CARBON	1K	5%	1/4W
R6111	1-215-900-11	METAL OXIDE	22K	5%	2W F
R6112	1-249-417-11	CARBON	1K	5%	1/4W
R6113	1-249-429-11	CARBON	10K	5%	1/4W
R6115	1-249-409-11	CARBON	220	5%	1/4W F
R6116	1-249-429-11	CARBON	10K	5%	1/4W
R6117	1-249-413-11	CARBON	470	5%	1/4W
R6118	1-216-361-00	METAL OXIDE	0.22	5%	2W F
R6119	1-249-429-11	CARBON	10K	5%	1/4W
R6120	1-249-429-11	CARBON	10K	5%	1/4W
R6121	1-249-429-11	CARBON	10K	5%	1/4W
R6122	1-249-377-11	CARBON	0.47	5%	1/4W F
R6123	1-249-377-11	CARBON	0.47	5%	1/4W F
R6124	1-249-377-11	CARBON	0.47	5%	1/4W F
R6125	1-249-425-11	CARBON	4.7K	5%	1/4W
R6126	1-249-417-11	CARBON	1K	5%	1/4W
R6128	1-249-417-11	CARBON	1K	5%	1/4W
R6129	1-249-421-11	CARBON	2.2K	5%	1/4W
R6130	1-249-425-11	CARBON	4.7K	5%	1/4W
R6132	1-249-417-11	CARBON	1K	5%	1/4W
R6133	1-249-425-11	CARBON	4.7K	5%	1/4W
R6134	1-249-417-11	CARBON	1K	5%	1/4W
R6135	1-249-425-11	CARBON	4.7K	5%	1/4W
R6136	1-249-425-11	CARBON	4.7K	5%	1/4W
R6141	1-249-401-11	CARBON	47	5%	1/4W F
R6142	1-249-425-11	CARBON	4.7K	5%	1/4W
R6143	1-249-425-11	CARBON	4.7K	5%	1/4W
R6301	1-215-454-00	METAL	24K	1%	1/4W
R6302	1-215-431-00	METAL	2.7K	1%	1/4W
R6303	1-249-417-11	CARBON	1K	5%	1/4W

<RELAY>

RY6001⚠	1-515-999-11	RELAY, POWER	
RY6002⚠	1-515-999-11	RELAY, POWER	

<TRANSFORMER>

T6001 ⚠	1-429-807-11	TRANSFORMER, CONVERTER (PIT)	
T6002 ⚠	1-431-897-11	TRANSFORMER, CONVERTER (PIT)	
T6003 ⚠	1-431-732-11	TRANSFORMER, CONVERTER (SRT)	

<VARISTOR>

VD6001	1-801-073-31	VARISTOR TNR14V471K660	

****

REF. NO.	PART NO.	DESCRIPTION			REMARK
*	A-1331-972-A	CR BOARD, COMPLETE			
		**********			
	4-382-854-51	SCREW(M3X8), P, SW (+)			

<CAPACITOR>

C7100	1-162-114-00	CERAMIC	0.0047µF		2KV
C7102	1-162-115-00	CERAMIC	330pF	10%	2KV
C7103	1-107-662-11	ELECT	22µF	20%	250V
C7104	1-126-768-11	ELECT	2200µF	20%	16V
C7105	1-162-115-00	CERAMIC	330pF	10%	2KV
C7106	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C7107	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C7108	1-126-967-11	ELECT	47µF	20%	50V
C7109	1-161-830-00	CERAMIC	0.0047µF		500V
C7110	1-102-050-00	CERAMIC	0.01µF	99%	500V
C7111	1-102-157-00	CERAMIC	560pF	10%	500V
C7112	1-163-087-00	CERAMIC CHIP	4pF	0.25pF	50V
C7113	1-126-964-11	ELECT	10µF	20%	50V
C7116	1-163-121-00	CERAMIC CHIP	150pF	5%	50V

<CONNECTOR>

CN7101*	1-564-511-11	PLUG, CONNECTOR 8P	
CN7102*	1-564-509-11	PLUG, CONNECTOR 6P	
CN7103*	1-564-512-11	PLUG, CONNECTOR 9P	
CN7104	1-785-879-11	CONNECTOR, ONE TOUCH	
CN7107	1-695-915-11	TAB (CONTACT)	

<DIODE>

D7102	8-719-921-86	DIODE MTZJ-13	
D7103	8-719-901-83	DIODE 1SS83	
D7104	8-719-901-83	DIODE 1SS83	
D7105	8-719-901-83	DIODE 1SS83	
D7106	8-719-901-83	DIODE 1SS83	
D7107	1-216-295-91	SHORT	0
D7109	8-719-921-86	DIODE MTZJ-13	
D7110	8-719-921-86	DIODE MTZJ-13	

<IC>

IC7101	8-759-360-83	IC TDA6111Q/N4	

<JACK>

J7101 ⚠	1-251-182-11	SOCKET, CRT	

<COIL>

L7102	1-414-223-11	INDUCTOR	470µH
L7103	1-414-181-11	INDUCTOR	4.7µH
L7104	1-414-187-11	INDUCTOR	47µH

<NEON LAMP>

NL7101	1-517-778-21	LAMP, NEON	

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK
NL7102	1-517-778-21	LAMP, NEON			
NL7103	1-517-778-21	LAMP, NEON			
		<TRANSISTOR>			
Q7101	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q7102	8-729-216-22	TRANSISTOR 2SA1162-G			
		<RESISTOR>			
R7101	1-260-132-11	CARBON	560K	5%	1/2W
R7102	1-249-389-11	CARBON	4.7	5%	1/4W F
R7103	1-216-295-91	SHORT	0		
R7105	1-260-117-11	CARBON	33K	5%	1/2W
R7106	1-219-743-11	CARBON	100	5%	1/2W
R7107	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R7108	1-260-133-11	CARBON	680K	5%	1/2W
R7109	1-208-808-11	METAL CHIP	12K	0.50%	1/10W
R7110	1-208-793-11	METAL CHIP	3K	0.50%	1/10W
R7111	1-216-033-00	RES,CHIP	220	5%	1/10W
R7112	1-249-424-11	CARBON	3.9K	5%	1/4W
R7113	1-216-029-00	RES,CHIP	150	5%	1/10W
R7114	1-208-791-11	METAL CHIP	2.4K	0.50%	1/10W
R7115	1-208-798-11	METAL CHIP	4.7K	0.50%	1/10W
R7116	1-215-904-11	METAL OXIDE	100K	5%	2W F
R7117	1-260-093-11	CARBON	330	5%	1/2W
R7118	1-260-087-11	CARBON	100	5%	1/2W
R7119	1-260-099-11	CARBON	1K	5%	1/2W
R7122	1-216-033-00	RES,CHIP	220	5%	1/10W
R7123	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R7126	1-208-802-11	METAL CHIP	6.8K	0.50%	1/10W
R7127	1-208-802-11	METAL CHIP	6.8K	0.50%	1/10W
		<SPARK GAP>			
SG7101	1-519-422-11	GAP, SPARK			
SG7102	1-519-422-11	GAP, SPARK			

****

* A-1331-973-A CG BOARD, COMPLETE
****

4-382-854-51 SCREW(M3X8), P, SW (+)

<CAPACITOR>

C7200	1-162-114-00	CERAMIC	0.0047µF		2KV
C7202	1-162-115-00	CERAMIC	330pF	10%	2KV
C7203	1-126-768-11	ELECT	2200µF	20%	16V
C7204	1-107-662-11	ELECT	22µF	20%	250V
C7205	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C7206	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C7207	1-162-115-00	CERAMIC	330pF	10%	2KV
C7208	1-126-967-11	ELECT	47µF	20%	50V
C7209	1-102-050-00	CERAMIC	0.01µF	99%	500V
C7210	1-161-830-00	CERAMIC	0.0047µF		500V
C7211	1-102-157-00	CERAMIC	560pF	10%	500V
C7213	1-163-085-00	CERAMIC CHIP	2pF	0.25pF	50V
C7214	1-126-964-11	ELECT	10µF	20%	50V
C7216	1-163-121-00	CERAMIC CHIP	150pF	5%	50V

<CONNECTOR>

CN7201*	1-564-509-11	PLUG, CONNECTOR 6P
CN7202*	1-564-508-11	PLUG, CONNECTOR 5P
CN7203*	1-564-512-11	PLUG, CONNECTOR 9P
CN7204*	1-564-512-11	PLUG, CONNECTOR 9P
CN7205	1-785-879-11	CONNECTOR, ONE TOUCH
CN7208	1-695-915-11	TAB (CONTACT)
CN7210*	1-564-506-11	PLUG, CONNECTOR 3P

<DIODE>

D7202	8-719-921-86	DIODE MTZJ-13
D7203	8-719-901-83	DIODE 1SS83
D7204	8-719-901-83	DIODE 1SS83
D7205	8-719-901-83	DIODE 1SS83
D7206	8-719-901-83	DIODE 1SS83
D7207	1-216-295-91	SHORT 0
D7208	8-719-073-01	DIODE MA111-(K8).S0
D7209	8-719-921-86	DIODE MTZJ-13
D7210	8-719-921-86	DIODE MTZJ-13

<IC>

IC7201 8-759-360-83 IC TDA6111Q/N4

<JACK>

J7201 ⚠ 1-251-182-11 SOCKET, CRT

<COIL>

L7201	1-414-223-11	INDUCTOR	470µH
L7203	1-414-181-11	INDUCTOR	4.7µH
L7204	1-414-187-11	INDUCTOR	47µH

<NEON LAMP>

NL7201	1-517-778-21	LAMP, NEON
NL7202	1-517-778-21	LAMP, NEON

<TRANSISTOR>

Q7201	8-729-422-27	TRANSISTOR 2SD601A-Q
Q7202	8-729-216-22	TRANSISTOR 2SA1162-G

<RESISTOR>

R7201	1-260-132-11	CARBON	560K	5%	1/2W
R7202	1-216-295-91	SHORT	0		
R7203	1-216-097-91	RES,CHIP	100K	5%	1/10W
R7204	1-219-743-11	CARBON	100	5%	1/2W
R7205	1-260-117-11	CARBON	33K	5%	1/2W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R7206	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R7207	1-208-808-11	METAL CHIP	12K	0.50%	1/10W
R7208	1-216-033-00	RES,CHIP	220	5%	1/10W
R7209	1-260-133-11	CARBON	680K	5%	1/2W
R7210	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R7211	1-249-424-11	CARBON	3.9K	5%	1/4W
R7212	1-208-788-11	METAL CHIP	1.8K	0.50%	1/10W
R7213	1-215-904-11	METAL OXIDE	100K	5%	2W F
R7214	1-216-029-00	RES,CHIP	150	5%	1/10W
R7216	1-260-093-11	CARBON	330	5%	1/2W
R7217	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R7219	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R7220	1-216-033-00	RES,CHIP	220	5%	1/10W
R7221	1-260-099-11	CARBON	1K	5%	1/2W
R7223	1-208-804-11	METAL CHIP	8.2K	0.50%	1/10W
R7224	1-208-802-11	METAL CHIP	6.8K	0.50%	1/10W
R7225	1-260-087-11	CARBON	100	5%	1/2W
		<SPARK GAP>			
SG7201	1-519-422-11	GAP, SPARK			
SG7202	1-519-422-11	GAP, SPARK			
SG7203	1-519-422-11	GAP, SPARK			

****

*	A-1331-974-A	CB BOARD, COMPLETE			
		**********			
	4-382-854-51	SCREW(M3X8), P, SW (+)			
		<CAPACITOR>			
C7300	1-162-114-00	CERAMIC	0.0047µF		2KV
C7302	1-162-115-00	CERAMIC	330pF	10%	2KV
C7303	1-162-115-00	CERAMIC	330pF	10%	2KV
C7304	1-126-768-11	ELECT	2200µF	20%	16V
C7305	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C7306	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C7307	1-107-662-11	ELECT	22µF	20%	250V
C7308	1-126-967-11	ELECT	47µF	20%	50V
C7310	1-161-830-00	CERAMIC	0.0047µF		500V
C7311	1-102-050-00	CERAMIC	0.01µF	99%	500V
C7312	1-102-157-00	CERAMIC	560pF	10%	500V
C7314	1-126-964-11	ELECT	10µF	20%	50V
C7315	1-163-085-00	CERAMIC CHIP	2pF	0.25pF	50V
C7316	1-163-121-00	CERAMIC CHIP	150pF	5%	50V
		<CONNECTOR>			
CN7301*	1-564-508-11	PLUG, CONNECTOR 5P			
CN7302*	1-564-512-11	PLUG, CONNECTOR 9P			
CN7303*	1-564-510-11	PLUG, CONNECTOR 7P			
CN7304	1-785-879-11	CONNECTOR, ONE TOUCH			
CN7307	1-695-915-11	TAB (CONTACT)			
CN7314*	1-564-507-11	PLUG, CONNECTOR 4P			

REF. NO.	PART NO.	DESCRIPTION			REMARK
		<DIODE>			
D7302	8-719-921-86	DIODE MTZJ-13			
D7303	8-719-901-83	DIODE 1SS83			
D7304	8-719-901-83	DIODE 1SS83			
D7305	8-719-901-83	DIODE 1SS83			
D7306	8-719-901-83	DIODE 1SS83			
D7307	8-719-073-01	DIODE MA111-(K8).S0			
D7310	8-719-991-33	DIODE 1SS133T-77			
D7311	8-719-921-86	DIODE MTZJ-13			
D7312	8-719-921-86	DIODE MTZJ-13			
D7313	1-216-295-91	SHORT	0		
		<IC>			
IC7301	8-759-360-83	IC TDA6111Q/N4			
		<JACK>			
J7301	⚠ 1-251-182-11	SOCKET, CRT			
		<COIL>			
L7301	1-414-223-11	INDUCTOR	470µH		
L7303	1-414-181-11	INDUCTOR	4.7µH		
L7304	1-414-187-11	INDUCTOR	47µH		
		<NEON LAMP>			
NL7301	1-517-778-21	LAMP, NEON			
NL7302	1-517-778-21	LAMP, NEON			
NL7303	1-517-778-21	LAMP, NEON			
		<TRANSISTOR>			
Q7301	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q7302	8-729-216-22	TRANSISTOR 2SA1162-G			
		<RESISTOR>			
R7301	1-219-743-11	CARBON	100	5%	1/2W
R7302	1-260-132-11	CARBON	560K	5%	1/2W
R7303	1-249-393-11	CARBON	10	5%	1/4W F
R7304	1-216-295-91	SHORT	0		
R7307	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R7308	1-260-133-11	CARBON	680K	5%	1/2W
R7309	1-208-791-11	METAL CHIP	2.4K	0.50%	1/10W
R7311	1-208-808-11	METAL CHIP	12K	0.50%	1/10W
R7312	1-208-793-11	METAL CHIP	3K	0.50%	1/10W
R7313	1-216-033-00	RES,CHIP	220	5%	1/10W
R7314	1-249-424-11	CARBON	3.9K	5%	1/4W
R7315	1-216-029-00	RES,CHIP	150	5%	1/10W
R7316	1-215-904-11	METAL OXIDE	100K	5%	2W F
R7317	1-260-093-11	CARBON	330	5%	1/2W
R7319	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R7320	1-260-087-11	CARBON	100	5%	1/2W
R7321	1-260-117-11	CARBON	33K	5%	1/2W
R7323	1-216-033-00	RES,CHIP	220	5%	1/10W

REF. NO.	PART NO.	DESCRIPTION			REMARK
R7324	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R7325	1-260-099-11	CARBON	1K	5%	1/2W
R7326	1-208-803-11	METAL CHIP	7.5K	0.50%	1/10W
R7327	1-208-802-11	METAL CHIP	6.8K	0.50%	1/10W
		<SPARK GAP>			
SG7301	1-519-422-11	GAP, SPARK			
SG7302	1-519-422-11	GAP, SPARK			

****

* A-1343-712-A DS BOARD, COMPLETE
****

<CAPACITOR>

C85011-126-964-11	ELECT	10µF	20%	50V
C85021-126-964-11	ELECT	10µF	20%	50V
C85041-137-371-11	MYLAR	0.015µF	5%	50V
C85051-104-664-11	ELECT	47µF	20%	25V
C85061-104-664-11	ELECT	47µF	20%	25V
C85071-104-664-11	ELECT	47µF	20%	25V
C85081-104-664-11	ELECT	47µF	20%	25V
C85091-104-664-11	ELECT	47µF	20%	25V
C85101-104-664-11	ELECT	47µF	20%	25V
C85111-104-664-11	ELECT	47µF	20%	25V
C85121-104-664-11	ELECT	47µF	20%	25V
C85131-163-038-91	CERAMIC CHIP	0.1µF		25V
C85141-163-038-91	CERAMIC CHIP	0.1µF		25V
C85151-163-038-91	CERAMIC CHIP	0.1µF		25V
C85161-163-038-91	CERAMIC CHIP	0.1µF		25V
C85171-137-374-11	MYLAR	0.047µF	5%	50V
C85181-126-964-11	ELECT	10µF	20%	50V
C85191-163-237-11	CERAMIC CHIP	27pF	5%	50V
C85201-163-237-11	CERAMIC CHIP	27pF	5%	50V
C85211-163-224-11	CERAMIC CHIP	7pF	0.25pF	50V
C85221-163-243-11	CERAMIC CHIP	47pF	5%	50V
C85231-126-964-11	ELECT	10µF	20%	50V
C85241-104-664-11	ELECT	47µF	20%	25V
C85251-104-664-11	ELECT	47µF	20%	25V
C85261-163-275-11	CERAMIC CHIP	0.001µF	5%	50V
C85271-163-009-11	CERAMIC CHIP	0.001µF	10%	50V

<CONNECTOR>

CN8501*1-691-632-21	CONNECTOR, BOARD TO BOARD 15P

<DIODE>

D85018-719-914-44	DIODE DAP202K
D85028-719-914-44	DIODE DAP202K
D85038-719-914-43	DIODE DAN202K
D85048-719-158-15	DIODE RD5.6SB
D85058-719-158-15	DIODE RD5.6SB

REF. NO.	PART NO.	DESCRIPTION	REMARK
		<IC>	
IC85018-759-251-31		IC CA0007AM	
IC85028-759-011-64		IC MC74HC4052F	
IC85038-759-251-31		IC CA0007AM	
IC85048-759-711-28		IC NJM2058D	
IC85058-759-251-31		IC CA0007AM	
IC85068-759-100-96		IC µPC4558G2	

<RESISTOR>

R85011-216-689-11	RES,CHIP	39K	5%	1/10W
R85021-216-113-00	RES,CHIP	470K	5%	1/10W
R85031-216-073-00	RES,CHIP	10K	5%	1/10W
R85041-216-061-00	RES,CHIP	3.3K	5%	1/10W
R85051-216-073-00	RES,CHIP	10K	5%	1/10W
R85061-216-065-00	RES,CHIP	4.7K	5%	1/10W
R85121-216-073-00	RES,CHIP	10K	5%	1/10W
R85131-216-093-91	RES,CHIP	68K	5%	1/10W
R85251-216-085-00	RES,CHIP	33K	5%	1/10W
R85261-216-039-00	RES,CHIP	390	5%	1/10W
R85271-216-057-00	RES,CHIP	2.2K	5%	1/10W
R85281-216-037-00	RES,CHIP	330	5%	1/10W
R85291-216-081-00	RES,CHIP	22K	5%	1/10W
R85301-216-107-00	RES,CHIP	270K	5%	1/10W
R85311-216-081-00	RES,CHIP	22K	5%	1/10W
R85321-216-073-00	RES,CHIP	10K	5%	1/10W
R85331-216-097-91	RES,CHIP	100K	5%	1/10W
R85341-216-073-00	RES,CHIP	10K	5%	1/10W
R85351-216-081-00	RES,CHIP	22K	5%	1/10W
R85361-216-079-00	RES,CHIP	18K	5%	1/10W
R85371-216-081-00	RES,CHIP	22K	5%	1/10W
R85381-216-099-00	RES,CHIP	120K	5%	1/10W
R85391-216-097-91	RES,CHIP	100K	5%	1/10W
R85401-216-073-00	RES,CHIP	10K	5%	1/10W
R85411-216-075-00	RES,CHIP	12K	5%	1/10W
R85421-216-103-00	RES,CHIP	180K	5%	1/10W
R85431-216-097-91	RES,CHIP	100K	5%	1/10W
R85441-216-097-91	RES,CHIP	100K	5%	1/10W
R85451-216-097-91	RES,CHIP	100K	5%	1/10W
R85461-216-073-00	RES,CHIP	10K	5%	1/10W
R85471-216-081-00	RES,CHIP	22K	5%	1/10W
R85481-216-057-00	RES,CHIP	2.2K	5%	1/10W
R85491-216-065-00	RES,CHIP	4.7K	5%	1/10W

****

* A-1346-873-A D BOARD, COMPLETE (53XBR300)
****
* A-1346-899-A D BOARD, COMPLETE (61XBR300)
****

4-363-414-00	SPACER, MICA
4-382-854-11	SCREW(M3X10), P, SW (+)
7-682-952-09	SCREW+PSW 3X16

REF. NO.	PART NO.	DESCRIPTION			REMARK
		<CAPACITOR>			
C5001	1-104-664-11	ELECT	47µF	20%	25V
C5002	1-126-960-11	ELECT	1µF	20%	50V
C5003	1-104-664-11	ELECT	47µF	20%	25V
C5004	1-101-002-00	CERAMIC	0.0022µF		50V
C5005	1-130-495-00	MYLAR	0.1µF	5%	50V
C5006	1-101-002-00	CERAMIC	0.0022µF		50V
C5007	1-102-973-00	CERAMIC	100pF	5%	50V
C5008	1-126-967-11	ELECT	47µF	20%	50V
C5010	1-102-973-00	CERAMIC	100pF	5%	50V
C5011	1-126-967-11	ELECT	47µF	20%	50V
C5012	1-107-645-11	ELECT	22µF	20%	160V
C5013	1-126-967-11	ELECT	47µF	20%	50V
C5014	1-101-002-00	CERAMIC	0.0022µF		50V
C5015	1-101-880-00	CERAMIC	47pF	5%	50V
C5016	1-106-383-00	MYLAR	0.047µF	10%	200V
C5017	1-126-967-11	ELECT	47µF	20%	50V
C5019	1-102-228-00	CERAMIC	470pF	10%	500V
C5020	1-130-495-00	MYLAR	0.1µF	5%	50V
C5023	1-126-960-11	ELECT	1µF	20%	50V
C5024	1-126-942-61	ELECT	1000µF	20%	25V
C5025	1-126-942-61	ELECT	1000µF	20%	25V
C5026	1-137-370-11	MYLAR	0.01µF	5%	50V
C5028	1-102-228-00	CERAMIC	470pF	10%	500V
C5029	1-164-096-11	CERAMIC	0.01µF		50V
C5032	1-126-972-11	ELECT	1000µF	20%	50V
C5033	1-101-002-00	CERAMIC	0.0022µF		50V
C5034	1-136-177-00	MYLAR	1µF	5%	50V
C5035	1-126-967-11	ELECT	47µF	20%	50V
C5036	1-164-096-11	CERAMIC	0.01µF		50V
C5037	1-126-969-11	ELECT	220µF	20%	50V
C5038	1-115-524-11	FILM	1.5µF	5%	250V
C5039	1-117-834-11	FILM	5600pF	3%	1.5KV
C5040	1-137-378-11	MYLAR	0.22µF	5%	50V
C5041	1-137-420-11	MYLAR	0.047µF	10%	100V
C5042	1-162-116-00	CERAMIC	680pF	10%	2KV
C5043	1-162-116-00	CERAMIC	680pF	10%	2KV
C5045	1-162-114-00	CERAMIC	0.0047µF		2KV
C5047	1-137-399-11	MYLAR	0.1µF	10%	100V
C5048	1-137-399-11	MYLAR	0.1µF	10%	100V
C5049	1-126-933-11	ELECT	100µF	20%	16V
C5050	1-136-479-11	FILM	0.001µF	5%	50V
C5051	1-162-318-11	CERAMIC	0.001µF	10%	500V
C5052	1-126-972-11	ELECT	1000µF	20%	50V
C5061	1-102-973-00	CERAMIC	100pF	5%	50V
C5062	1-102-973-00	CERAMIC	100pF	5%	50V
C5063	1-102-973-00	CERAMIC	100pF	5%	50V
C5064	1-102-973-00	CERAMIC	100pF	5%	50V
C5065	1-102-973-00	CERAMIC	100pF	5%	50V
C5066	1-102-973-00	CERAMIC	100pF	5%	50V
C5071	1-107-718-91	ELECT	100µF	20%	50V
C5072	1-107-718-91	ELECT	100µF	20%	50V
C5073	1-126-968-11	ELECT	100µF	20%	50V
C5074	1-126-968-11	ELECT	100µF	20%	50V
C5075	1-107-718-91	ELECT	100µF	20%	50V
C5076	1-107-718-91	ELECT	100µF	20%	50V
C5079	1-126-968-11	ELECT	100µF	20%	50V
C5080	1-126-968-11	ELECT	100µF	20%	50V
C5085	1-101-002-00	CERAMIC	0.0022µF		50V
C5086	1-130-495-00	MYLAR	0.1µF	5%	50V
C5087	1-130-495-00	MYLAR	0.1µF	5%	50V
C5088	1-115-524-11	FILM	1.5µF	5%	250V
C5089	1-106-220-00	MYLAR	0.1µF	10%	100V
C5090	1-126-960-11	ELECT	1µF	20%	50V
C5091	1-126-942-61	ELECT	1000µF	20%	25V
C5092	1-126-942-61	ELECT	1000µF	20%	25V
C5093	1-137-370-11	MYLAR	0.01µF	5%	50V
C5094	1-137-370-11	MYLAR	0.01µF	5%	50V
C5095	1-126-964-11	ELECT	10µF	20%	50V
C5097	1-126-933-11	ELECT	100µF	20%	16V
C5098	1-126-933-11	ELECT	100µF	20%	16V
C5099	1-104-999-11	MYLAR	0.1µF	10%	200V
C5100	1-124-347-51	ELECT	100µF	20%	160V
C5103	1-107-641-11	ELECT	220µF	20%	160V
C5105	1-137-372-11	MYLAR	0.022µF	5%	50V
C5107	1-130-495-00	MYLAR	0.1µF	5%	50V
C5108	1-130-048-00	FILM	220pF	5%	50V
C5112	1-104-664-11	ELECT	47µF	20%	16V
C5113	1-130-495-00	MYLAR	0.1µF	5%	50V
C5114	1-136-479-11	FILM	0.001µF	5%	50V
C5122	1-164-096-11	CERAMIC	0.01µF		50V
C5123	1-104-664-11	ELECT	47µF	20%	16V
C5124	1-164-096-11	CERAMIC	0.01µF		50V
C5203	1-136-356-11	MYLAR	470pF	5%	50V
C5204	1-137-368-11	MYLAR	0.0047µF	5%	50V
C5208	1-136-479-11	FILM	0.001µF	5%	50V
C8001	1-107-655-11	ELECT	47µF	20%	250V
C8002	1-124-347-51	ELECT	100µF	20%	160V
C8003	1-124-347-51	ELECT	100µF	20%	160V
C8004	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C8005	1-106-387-00	MYLAR	0.068µF	10%	200V
C8006	1-126-959-11	ELECT	0.47µF	20%	50V
C8007	1-137-150-11	MYLAR	0.01µF	10%	100V
C8008	1-102-030-00	CERAMIC	330pF	10%	500V
C8009	1-102-244-00	CERAMIC	220pF	10%	500V
C8010	1-130-481-00	MYLAR	0.0068µF	5%	50V
C8011	1-126-934-11	ELECT	220µF	20%	16V
C8012	1-130-338-91	FILM	0.01µF	5%	630V
C8013	1-126-964-11	ELECT	10µF	20%	50V
C8014	1-102-228-00	CERAMIC	470pF	10%	500V
C8015	1-126-933-11	ELECT	100µF	20%	16V
C8016	1-126-964-11	ELECT	10µF	20%	50V
C8017	1-126-964-11	ELECT	10µF	20%	50V
C8018	1-117-838-11	FILM	8200pF	3%	1.5KV
C8019	1-163-133-00	CERAMIC CHIP	470pF	5%	50V
C8020	1-162-318-11	CERAMIC	0.001µF	10%	500V
C8023	1-126-767-11	ELECT	1000µF	20%	16V
C8024	1-126-968-11	ELECT	100µF	20%	50V
C8025	1-128-562-11	ELECT	47µF	20%	100V
C8026	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C8028	1-137-368-11	MYLAR	0.0047µF	5%	50V
C8029	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C8030	1-126-967-11	ELECT	47µF	20%	50V

REF. NO.	PART NO.	DESCRIPTION			REMARK
C8032	1-106-387-00	MYLAR	0.068µF	10%	200V
C8033	1-130-495-00	MYLAR	0.1µF	5%	50V
C8034	1-126-967-11	ELECT	47µF	20%	50V
C8035	1-104-664-11	ELECT	47µF	20%	25V
C8037	1-130-495-00	MYLAR	0.1µF	5%	50V
C8038	1-126-967-11	ELECT	47µF	20%	50V
C8039	1-137-420-11	MYLAR	0.047µF	10%	100V
C8040	1-126-964-11	ELECT	10µF	20%	50V
C8041	1-130-495-00	MYLAR	0.1µF	5%	50V
C8042	1-126-967-11	ELECT	47µF	20%	50V
C8043	1-130-495-00	MYLAR	0.1µF	5%	50V
C8045	1-137-431-11	MYLAR	560pF	5%	50V
C8046	1-130-495-00	MYLAR	0.1µF	5%	50V
C8047	1-130-495-00	MYLAR	0.1µF	5%	50V
C8048	1-163-251-11	CERAMIC CHIP	100pF	5%	50V
C8049	1-126-967-11	ELECT	47µF	20%	50V
C8050	1-126-967-11	ELECT	47µF	20%	50V
C8051	1-126-967-11	ELECT	47µF	20%	50V
C8052	1-163-239-11	CERAMIC CHIP	33pF	5%	50V
C8053	1-126-960-11	ELECT	1µF	20%	50V
C8054	1-126-960-11	ELECT	1µF	20%	50V
C8055	1-126-961-11	ELECT	2.2µF	20%	50V
C8059	1-126-965-11	ELECT	22µF	20%	50V
C8060	1-126-963-11	ELECT	4.7µF	20%	50V
C8061	1-126-965-11	ELECT	22µF	20%	50V
C8062	1-126-965-11	ELECT	22µF	20%	50V
C8064	1-130-495-00	MYLAR	0.1µF	5%	50V
C8065	1-126-964-11	ELECT	10µF	20%	50V
C8066	1-130-471-00	MYLAR	0.001µF	5%	50V
C8067	1-104-661-91	ELECT	330µF	20%	16V
C8068	1-137-410-11	MYLAR	0.001µF	10%	100V
C8069	1-126-967-11	ELECT	47µF	20%	50V
C8070	1-102-110-00	CERAMIC	220pF	10%	50V
C8071	1-126-963-11	ELECT	4.7µF	20%	50V
C8072	1-126-964-11	ELECT	10µF	20%	50V
C8073	1-126-967-11	ELECT	47µF	20%	50V
C8074	1-137-410-11	MYLAR	0.001µF	10%	100V
C8075	1-126-965-11	ELECT	22µF	20%	50V
C8076	1-163-009-11	CERAMIC CHIP	0.001µF	10%	50V
C8077	1-137-370-11	MYLAR	0.01µF	5%	50V
C8078	1-130-495-00	MYLAR	0.1µF	5%	50V
C8079	1-126-967-11	ELECT	47µF	20%	50V
C8080	1-126-967-11	ELECT	47µF	20%	50V
C8081	1-126-967-11	ELECT	47µF	20%	50V
C8082	1-137-366-11	MYLAR	0.0022µF	5%	50V
C8083	1-126-964-11	ELECT	10µF	20%	50V
C8084	1-126-967-11	ELECT	47µF	20%	50V
C8085	1-104-661-91	ELECT	330µF	20%	16V
C8086	1-137-150-11	MYLAR	0.01µF	10%	100V
C8089	1-137-399-11	MYLAR	0.1µF	10%	100V
C8090	1-126-964-11	ELECT	10µF	20%	50V
C8091	1-126-967-11	ELECT	47µF	20%	50V
C8092	1-126-964-11	ELECT	10µF	20%	50V
C8093	1-126-964-11	ELECT	10µF	20%	50V
C8094	1-126-964-11	ELECT	10µF	20%	50V
C8095	1-126-967-11	ELECT	47µF	20%	50V
C8096	1-126-967-11	ELECT	47µF	20%	50V
C8097	1-126-967-11	ELECT	47µF	20%	50V
C8098	1-126-967-11	ELECT	47µF	20%	50V
C8099	1-126-964-11	ELECT	10µF	20%	50V
C8100	1-162-114-00	CERAMIC	0.0047µF	2KV	
C8102	1-102-125-00	CERAMIC	0.0047µF	10%	50V
C8103	1-126-964-11	ELECT	10µF	20%	50V
C8104	1-126-961-11	ELECT	2.2µF	20%	50V
C8109	1-102-125-00	CERAMIC	0.0047µF	10%	50V
C8111	1-126-933-11	ELECT	100µF	20%	16V
C8112	1-136-291-11	MYLAR	0.0068µF	5%	100V
C8113	1-102-125-00	CERAMIC	0.0047µF	10%	50V
C8114	1-104-664-11	ELECT	47µF	20%	25V
C8115	1-162-114-00	CERAMIC	0.0047µF		2KV

<CONNECTOR>

CN5001*	1-564-506-11	PLUG, CONNECTOR 3P	
CN5002*	1-573-964-11	PIN, CONNECTOR (PC BOARD) 6P	
CN5003*	1-564-509-11	PLUG, CONNECTOR 6P	
CN5004*	1-779-890-11	CONNECTOR, BOARD TO BOARD 10P	
CN5005*	1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P	
CN5006*	1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P	
CN5007*	1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P	
CN5008*	1-564-506-11	PLUG, CONNECTOR 3P	
CN5009*	1-779-890-11	CONNECTOR, BOARD TO BOARD 10P	
CN5010*	1-779-890-11	CONNECTOR, BOARD TO BOARD 10P	
CN5011*	1-779-890-11	CONNECTOR, BOARD TO BOARD 10P	
CN5012*	1-564-507-11	PLUG, CONNECTOR 4P	
CN5013*	1-564-507-11	PLUG, CONNECTOR 4P	
CN5014*	1-564-507-11	PLUG, CONNECTOR 4P	
CN8001*	1-573-986-11	PIN, CONNECTOR (PC BOARD) 5P	
CN8002	1-695-915-11	TAB (CONTACT)	
CN8003*	1-564-509-11	PLUG, CONNECTOR 6P	
CN8004*	1-564-510-11	PLUG, CONNECTOR 7P	
CN8005*	1-564-507-11	PLUG, CONNECTOR 4P	
CN8006*	1-564-507-11	PLUG, CONNECTOR 4P	
CN8007*	1-506-371-00	PIN, CONNECTOR 2P	
CN8008*	1-506-371-00	PIN, CONNECTOR 2P	
CN8009	1-695-915-11	TAB (CONTACT)	
CN8010	1-695-915-11	TAB (CONTACT)	
CN8011*	1-691-616-21	CONNECTOR, BOARD TO BOARD 15P	
CN8012*	1-564-506-11	PLUG, CONNECTOR 3P	

<DIODE>

D5001	8-719-991-33	DIODE	1SS133T-77
D5002	8-719-991-33	DIODE	1SS133T-77
D5003	8-719-302-43	DIODE	EL1Z
D5004	8-719-991-33	DIODE	1SS133T-77
D5005	8-719-109-89	DIODE	RD5.6ESB2
D5006	8-719-991-33	DIODE	1SS133T-77
D5007	8-719-302-43	DIODE	EL1Z
D5008	8-719-991-33	DIODE	1SS133T-77
D5009	8-719-979-85	DIODE	EGP20G
D5010	8-719-908-03	DIODE	GP08D
D5011	8-719-908-03	DIODE	GP08D

REF. NO.	PART NO.	DESCRIPTION	REMARK
D5013	8-719-979-99	DIODE ERD08M-15	
D5014	8-719-991-33	DIODE 1SS133T-77	
D5015	8-719-018-82	DIODE RGP02-20EL-6394	
D5016	8-719-110-61	DIODE RD24ESB1	
D5017	8-719-110-61	DIODE RD24ESB1	
D5019	8-719-302-43	DIODE EL1Z	
D5020	8-719-302-43	DIODE EL1Z	
D5021	8-719-920-67	DIODE ERC91-02	
D5022	8-719-991-33	DIODE 1SS133T-77	
D5025	8-719-991-33	DIODE 1SS133T-77	
D5027	8-719-923-86	DIODE MTZJ-T-77-15	
D5028	8-719-991-33	DIODE 1SS133T-77	
D8001	8-719-105-82	DIODE RD5.1M-B2	
D8002	8-719-914-43	DIODE DAN202K	
D8003	8-719-979-85	DIODE EGP20G	
D8004	8-719-914-43	DIODE DAN202K	
D8005	8-719-914-43	DIODE DAN202K	
D8006	8-719-914-43	DIODE DAN202K	
D8007	8-719-945-80	DIODE ERC06-15S	
D8008	8-719-106-81	DIODE RD13M-B3	
D8009	8-719-106-81	DIODE RD13M-B3	
D8010	8-719-054-52	DIODE D8LC20U-4015	
D8011	8-719-945-80	DIODE ERC06-15S	
D8013	8-719-920-67	DIODE ERC91-02	
D8014	8-719-302-43	DIODE EL1Z	
D8015	8-719-914-43	DIODE DAN202K	
D8017	8-719-914-43	DIODE DAN202K	
D8018	8-719-983-14	DIODE MTZJ-T-77-3.9	
D8021	8-719-914-43	DIODE DAN202K	
D8023	8-719-914-43	DIODE DAN202K	
D8024	8-719-914-43	DIODE DAN202K	
D8025	8-719-914-43	DIODE DAN202K	
D8026	8-719-914-43	DIODE DAN202K	
D8027	8-719-914-43	DIODE DAN202K	
D8029	8-719-914-43	DIODE DAN202K	
D8030	8-719-400-75	DIODE MA3091	
D8031	8-719-105-82	DIODE RD5.1M-B2	
D8032	8-719-302-43	DIODE EL1Z	
D8033	8-719-914-43	DIODE DAN202K	
D8034	8-719-028-00	DIODE MA3033-L	
D8035	8-719-105-82	DIODE RD5.1M-B2	
D8036	8-719-914-43	DIODE DAN202K	
D8037	8-719-914-43	DIODE DAN202K	
D8038	8-719-106-81	DIODE RD13M-B3	
D8039	8-719-110-17	DIODE RD10ESB2	
D8040	8-719-914-43	DIODE DAN202K	
D8041	8-719-106-81	DIODE RD13M-B3	
D8042	8-759-157-40	IC µPC574J	
D8045	8-719-400-75	DIODE MA3091	
D8046	8-719-402-57	DIODE MA3150H-TX	
D8047	8-719-402-57	DIODE MA3150H-TX	
D8048	8-719-914-43	DIODE DAN202K	
D8050	8-719-914-43	DIODE DAN202K	

<FERRITE BEAD>

FB5001	1-410-396-41	FERRITE	0.45µH
FB8001	1-410-396-41	FERRITE	0.45µH
FB8002	1-410-396-41	FERRITE	0.45µH
FB8003	1-410-397-21	FERRITE	1.1µH

<IC>

IC5001	8-759-701-88	IC NJM7912FA	
IC5002	8-759-701-79	IC NJM7812FA	
IC5004	8-759-192-71	IC STV9379	
IC5005	8-749-014-67	IC STK392-020	
IC5006	8-749-014-67	IC STK392-020	
IC5008	8-759-103-93	IC µPC393C	
IC5009	8-759-634-51	IC M5218AP	
IC8002	8-759-103-93	IC µPC393C	
IC8003	8-759-701-84	IC NJM7905FA	
IC8004	8-759-144-82	IC µPC2405HF	
IC8006	8-759-103-93	IC µPC393C	
IC8007	8-759-711-28	IC NJM2058D	
IC8008	8-759-135-80	IC µPC358C	
IC8009	8-759-135-80	IC µPC358C	
IC8010	8-759-103-93	IC µPC393C	
IC8011	8-759-711-28	IC NJM2058D	

<CHIP CONDUCTOR>

JR8001	1-216-295-00	SHORT	0
JR8002	1-216-295-00	SHORT	0
JR8003	1-216-295-00	SHORT	0
JR8004	1-216-295-00	SHORT	0

<COIL>

L5001	1-412-533-21	INDUCTOR	47µH
L5002	1-412-533-21	INDUCTOR	47µH
L5003	1-412-533-21	INDUCTOR	47µH
L5004	1-412-533-21	INDUCTOR	47µH
L5007	1-419-352-11	COIL, HORIZONTAL LINEARITY	
L5009	1-412-524-11	INDUCTOR	8.2µH
L5010	1-412-533-21	INDUCTOR	47µH
L5011	1-412-533-21	INDUCTOR	47µH
L5012	1-412-533-21	INDUCTOR	47µH
L5013	1-412-533-21	INDUCTOR	47µH
L5018	1-411-594-11	INDUCTOR	5mH
L5019	1-459-109-00	COIL,DUST CORE	
L5020	1-414-177-11	INDUCTOR	1µH
L8001	1-414-223-11	INDUCTOR	470µH
L8002	1-406-977-21	INDUCTOR	100µH
L8003	1-422-613-11	COIL, AIR CORE	
L8004	1-412-521-31	INDUCTOR	4.7µH
L8005	1-412-533-21	INDUCTOR	47µH
L8006	1-412-533-21	INDUCTOR	47µH
L8007	1-412-521-31	INDUCTOR	4.7µH

<NEON LAMP>

NL8001	1-517-778-21	LAMP, NEON	
NL8002	1-517-778-21	LAMP, NEON	
NL8003	1-517-778-21	LAMP, NEON	

D

REF. NO.	PART NO.	DESCRIPTION	REMARK
NL8004	1-517-778-21	LAMP, NEON	
		<IC LINK>	
PS5001	1-533-595-31	LINK, IC	
PS5002	1-533-595-31	LINK, IC	
PS5003	1-533-595-31	LINK, IC	
PS5004	1-533-595-31	LINK, IC	
PS5005	1-533-595-31	LINK, IC	
PS5006	1-533-595-31	LINK, IC	
PS5007	1-533-595-31	LINK, IC	
PS5008	1-533-595-31	LINK, IC	
PS8001	1-533-593-11	LINK, IC	
		<TRANSISTOR>	
Q5002	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5004	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5005	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5006	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5008	8-729-119-80	TRANSISTOR 2SC2688-LK	
Q5009	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5010	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5013	8-729-048-35	TRANSISTOR 2SC3997S-SONY-YB	
Q5014	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5015	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5016	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5019	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5022	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5023	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5024	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5025	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5026	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5027	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5029	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5030	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5031	8-729-038-83	TRANSISTOR 2SK2251-01-F19	
Q5034	8-729-231-55	TRANSISTOR 2SC2878-AB	
Q5035	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5036	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5037	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q8001	8-729-119-80	TRANSISTOR 2SC2688-LK	
Q8002	8-729-122-12	TRANSISTOR 2SA1221-L	
Q8003	8-729-119-80	TRANSISTOR 2SC2688-LK	
Q8004	8-729-823-81	TRANSISTOR 2SC4632LS-CB7	
Q8005	8-729-231-55	TRANSISTOR 2SC2878-AB	
Q8006	8-729-216-22	TRANSISTOR 2SA1162-G	
Q8007	8-729-017-64	TRANSISTOR 2SC3997-YB	
Q8008	8-729-024-30	TRANSISTOR IRFI640LF	
Q8009	8-729-216-22	TRANSISTOR 2SA1162-G	
Q8010	8-729-216-22	TRANSISTOR 2SA1162-G	
Q8013	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q8014	8-729-823-81	TRANSISTOR 2SC4632LS-CB7	
Q8015	8-729-140-93	TRANSISTOR 2SB733-34	
Q8016	8-729-140-96	TRANSISTOR 2SD774-34	
Q8017	8-729-216-22	TRANSISTOR 2SA1162-G	
Q8018	8-729-231-55	TRANSISTOR 2SC2878-AB	
Q8019	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q8020	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q8021	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q8022	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q8023	8-729-027-38	TRANSISTOR DTA144EKA-T146	
Q8024	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q8025	8-729-027-38	TRANSISTOR DTA144EKA-T146	
Q8026	8-729-216-22	TRANSISTOR 2SA1162-G	
Q8027	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q8028	8-729-422-27	TRANSISTOR 2SD601A-Q	
Q8030	8-729-823-81	TRANSISTOR 2SC4632LS-CB7	
Q8031	8-729-422-27	TRANSISTOR 2SD601A-Q	
		<RESISTOR>	
R5002	1-249-417-11	CARBON 1K 5% 1/4W	
R5003	1-249-417-11	CARBON 1K 5% 1/4W	
R5004	1-249-425-11	CARBON 4.7K 5% 1/4W	
R5007	1-216-472-00	METAL OXIDE 39 5% 3W F	(61XBR300)
R5007	1-216-474-11	METAL OXIDE 82 5% 3W F	(53XBR300)
R5008	1-216-472-00	METAL OXIDE 39 5% 3W F	(61XBR300)
R5008	1-216-474-11	METAL OXIDE 82 5% 3W F	(53XBR300)
R5009	1-249-421-11	CARBON 2.2K 5% 1/4W	
R5011	1-247-843-11	CARBON 3.3K 5% 1/4W	
R5012	1-249-425-11	CARBON 4.7K 5% 1/4W	
R5013	1-249-425-11	CARBON 4.7K 5% 1/4W	
R5016	1-249-429-11	CARBON 10K 5% 1/4W	
R5017	1-247-863-91	CARBON 22K 5% 1/4W	
R5018	1-247-843-11	CARBON 3.3K 5% 1/4W	
R5020	1-249-437-11	CARBON 47K 5% 1/4W	
R5021	1-215-445-00	METAL 10K 1% 1/4W	
R5022	1-247-863-91	CARBON 22K 5% 1/4W	
R5023	1-247-863-91	CARBON 22K 5% 1/4W	
R5026	1-216-462-00	METAL OXIDE 8.2K 5% 2W F	
R5027	1-215-897-11	METAL OXIDE 6.8K 5% 2W F	
R5028	1-249-377-11	CARBON 0.47 5% 1/4W F	
R5029	1-249-377-11	CARBON 0.47 5% 1/4W F	
R5030	1-249-437-11	CARBON 47K 5% 1/4W	
R5031	1-216-435-11	METAL OXIDE 2.7K 5% 1W F	
R5033	1-249-417-11	CARBON 1K 5% 1/4W	
R5034	1-249-429-11	CARBON 10K 5% 1/4W	
R5035	1-249-429-11	CARBON 10K 5% 1/4W	
R5039	1-249-429-11	CARBON 10K 5% 1/4W	
R5040	1-249-417-11	CARBON 1K 5% 1/4W	
R5042	1-249-425-11	CARBON 4.7K 5% 1/4W	
R5043	1-249-417-11	CARBON 1K 5% 1/4W	
R5046	1-216-389-11	METAL OXIDE 1 5% 3W F	
R5047	1-215-450-00	METAL 16K 1% 1/4W	
R5049	1-215-905-11	METAL OXIDE 10 5% 3W F	
R5050	1-247-807-31	CARBON 100 5% 1/4W	
R5051	1-249-435-11	CARBON 33K 5% 1/4W	
R5054	1-249-413-11	CARBON 470 5% 1/4W	
R5055	1-215-912-11	METAL OXIDE 150 5% 3W F	
R5057	1-249-429-11	CARBON 10K 5% 1/4W	

REF. NO.	PART NO.	DESCRIPTION			REMARK
R5058	1-249-430-11	CARBON	12K	5%	1/4W
R5059	1-249-383-11	CARBON	1.5	5%	1/4W F
R5061	1-249-429-11	CARBON	10K	5%	1/4W
R5062	1-247-735-11	SOLID	47	20%	1/2W
R5063	1-247-807-31	CARBON	100	5%	1/4W
R5067	1-214-800-11	METAL	2.2	1%	1/2W
R5068	1-249-429-11	CARBON	10K	5%	1/4W
R5069	1-249-429-11	CARBON	10K	5%	1/4W
R5070	1-260-321-71	CARBON	270	5%	1/2W
R5071	1-214-800-11	METAL	2.2	1%	1/2W
R5072	1-247-807-31	CARBON	100	5%	1/4W
R5073	1-215-433-00	METAL	3.3K	1%	1/4W
R5074	1-249-437-11	CARBON	47K	5%	1/4W
R5075	1-215-445-00	METAL	10K	1%	1/4W
R5076	1-215-857-11	METAL OXIDE	10	5%	1W F
R5077	1-216-477-11	METAL OXIDE	270	5%	3W F
R5081	1-247-807-31	CARBON	100	5%	1/4W
R5082	1-247-807-31	CARBON	100	5%	1/4W
R5083	1-247-807-31	CARBON	100	5%	1/4W
R5084	1-247-807-31	CARBON	100	5%	1/4W
R5085	1-247-807-31	CARBON	100	5%	1/4W
R5086	1-247-807-31	CARBON	100	5%	1/4W
R5087	1-247-843-11	CARBON	3.3K	5%	1/4W
R5088	1-247-843-11	CARBON	3.3K	5%	1/4W
R5089	1-247-843-11	CARBON	3.3K	5%	1/4W
R5090	1-247-843-11	CARBON	3.3K	5%	1/4W
R5091	1-249-417-11	CARBON	1K	5%	1/4W
R5092	1-249-417-11	CARBON	1K	5%	1/4W
R5093	1-247-843-11	CARBON	3.3K	5%	1/4W
R5095	1-247-843-11	CARBON	3.3K	5%	1/4W
R5097	1-249-417-11	CARBON	1K	5%	1/4W
R5098	1-249-405-11	CARBON	100	5%	1/4W F
R5099	1-249-417-11	CARBON	1K	5%	1/4W
R5100	1-249-405-11	CARBON	100	5%	1/4W F
R5101	1-214-808-11	METAL	4.7	1%	1/2W
R5102	1-214-808-11	METAL	4.7	1%	1/2W
R5103	1-214-808-11	METAL	4.7	1%	1/2W
R5104	1-214-808-11	METAL	4.7	1%	1/2W
R5105	1-214-808-11	METAL	4.7	1%	1/2W
R5106	1-214-808-11	METAL	4.7	1%	1/2W
R5107	1-249-417-11	CARBON	1K	5%	1/4W
R5108	1-249-417-11	CARBON	1K	5%	1/4W
R5109	1-214-808-11	METAL	4.7	1%	1/2W
R5110	1-214-808-11	METAL	4.7	1%	1/2W
R5111	1-214-808-11	METAL	4.7	1%	1/2W
R5112	1-214-808-11	METAL	4.7	1%	1/2W
R5113	1-214-808-11	METAL	4.7	1%	1/2W
R5114	1-214-808-11	METAL	4.7	1%	1/2W
R5117	1-214-808-11	METAL	4.7	1%	1/2W
R5118	1-214-808-11	METAL	4.7	1%	1/2W
R5121	1-214-808-11	METAL	4.7	1%	1/2W
R5122	1-214-808-11	METAL	4.7	1%	1/2W
R5123	1-214-808-11	METAL	4.7	1%	1/2W
R5124	1-214-808-11	METAL	4.7	1%	1/2W
R5127	1-214-808-11	METAL	4.7	1%	1/2W
R5128	1-214-808-11	METAL	4.7	1%	1/2W
R5129	1-214-808-11	METAL	4.7	1%	1/2W
R5130	1-214-808-11	METAL	4.7	1%	1/2W
R5131	1-214-808-11	METAL	4.7	1%	1/2W
R5132	1-214-808-11	METAL	4.7	1%	1/2W
R5133	1-214-808-11	METAL	4.7	1%	1/2W
R5134	1-214-808-11	METAL	4.7	1%	1/2W
R5135	1-214-808-11	METAL	4.7	1%	1/2W
R5136	1-214-808-11	METAL	4.7	1%	1/2W
R5137	1-214-808-11	METAL	4.7	1%	1/2W
R5138	1-214-808-11	METAL	4.7	1%	1/2W
R5143	1-249-429-11	CARBON	10K	5%	1/4W
R5144	1-249-429-11	CARBON	10K	5%	1/4W
R5145	1-249-429-11	CARBON	10K	5%	1/4W
R5146	1-249-429-11	CARBON	10K	5%	1/4W
R5147	1-249-429-11	CARBON	10K	5%	1/4W
R5148	1-249-429-11	CARBON	10K	5%	1/4W
R5149	1-249-429-11	CARBON	10K	5%	1/4W
R5150	1-249-429-11	CARBON	10K	5%	1/4W
R5151	1-249-429-11	CARBON	10K	5%	1/4W
R5152	1-249-429-11	CARBON	10K	5%	1/4W
R5153	1-249-429-11	CARBON	10K	5%	1/4W
R5154	1-249-429-11	CARBON	10K	5%	1/4W
R5155	1-249-425-11	CARBON	4.7K	5%	1/4W
R5156	1-215-425-00	METAL	1.5K	1%	1/4W
R5165	1-260-312-11	CARBON	47	5%	1/2W
R5166	1-247-887-00	CARBON	220K	5%	1/4W
R5167	1-260-312-11	CARBON	47	5%	1/2W
R5168	1-260-312-11	CARBON	47	5%	1/2W
R5169	1-249-429-11	CARBON	10K	5%	1/4W
R5170	1-215-471-00	METAL	120K	1%	1/4W
R5171	1-215-449-00	METAL	15K	1%	1/4W
R5172	1-247-895-91	CARBON	470K	5%	1/4W
R5173	1-247-895-91	CARBON	470K	5%	1/4W
R5174	1-249-439-11	CARBON	68K	5%	1/4W
R5175	1-216-395-00	METAL OXIDE	3.3	5%	3W F
R5177	1-215-469-00	METAL	100K	1%	1/4W
R5179	1-249-425-11	CARBON	4.7K	5%	1/4W
R5180	1-249-421-11	CARBON	2.2K	5%	1/4W
R5181	1-249-422-11	CARBON	2.7K	5%	1/4W
R5182	1-247-895-91	CARBON	470K	5%	1/4W
R5183	1-249-422-11	CARBON	2.7K	5%	1/4W
R5184	1-249-417-11	CARBON	1K	5%	1/4W
R5186	1-249-425-11	CARBON	4.7K	5%	1/4W
R5187	1-249-431-11	CARBON	15K	5%	1/4W
R5188	1-249-429-11	CARBON	10K	5%	1/4W
R5189	1-215-421-00	METAL	1K	1%	1/4W
R5190	1-249-377-11	CARBON	0.47	5%	1/4W F
R5191	1-249-417-11	CARBON	1K	5%	1/4W
R5192	1-215-429-00	METAL	2.2K	1%	1/4W
R5193	1-215-465-00	METAL	68K	1%	1/4W
R5194	1-215-425-00	METAL	1.5K	1%	1/4W
R5195	1-215-449-00	METAL	15K	1%	1/4W
R5196	1-215-445-00	METAL	10K	1%	1/4W
R5197	1-247-807-31	CARBON	100	5%	1/4W
R5200	1-249-429-11	CARBON	10K	5%	1/4W
R5203	1-249-436-11	CARBON	39K	5%	1/4W
R5204	1-249-429-11	CARBON	10K	5%	1/4W

D

REF. NO.	PART NO.	DESCRIPTION			REMARK
R5205	1-249-429-11	CARBON	10K	5%	1/4W
R5207	1-216-375-00	METAL OXIDE	3.3	5%	2W F
R5208	1-216-375-00	METAL OXIDE	3.3	5%	2W F
R5214	1-249-429-11	CARBON	10K	5%	1/4W
R5215	1-249-437-11	CARBON	47K	5%	1/4W
R5216	1-249-422-11	CARBON	2.7K	5%	1/4W
R5217	1-249-429-11	CARBON	10K	5%	1/4W
R5218	1-249-417-11	CARBON	1K	5%	1/4W
R8001	1-249-425-11	CARBON	4.7K	5%	1/4W F
R8002	1-249-431-11	CARBON	15K	5%	1/4W F
R8003	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R8004	1-260-328-11	CARBON	1K	5%	1/2W
R8005	1-215-925-11	METAL OXIDE	22K	5%	3W F
R8006	1-260-123-11	CARBON	100K	5%	1/2W
R8007	1-215-925-11	METAL OXIDE	22K	5%	3W F
R8008	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R8009	1-216-435-11	METAL OXIDE	2.7K	5%	1W F
R8010	1-216-025-00	RES,CHIP	100	5%	1/10W
R8011	1-216-065-00	RES,CHIP	4.7K	5%	1/10W
R8012	1-215-918-00	METAL OXIDE	1.5K	5%	3W F
R8013	1-216-065-00	RES,CHIP	4.7K	5%	1/10W
R8014	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8015	1-216-049-00	RES,CHIP	1K	5%	1/10W
R8016	1-215-918-00	METAL OXIDE	1.5K	5%	3W F
R8017	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8018	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8019	1-215-905-11	METAL OXIDE	10	5%	3W F
R8020	1-215-918-00	METAL OXIDE	1.5K	5%	3W F
R8021	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8022	1-216-097-91	RES,CHIP	100K	5%	1/10W
R8023	1-215-870-11	METAL OXIDE	1.5K	5%	1W F
R8024	1-249-427-11	CARBON	6.8K	5%	1/4W F
R8026	1-215-902-11	METAL OXIDE	47K	5%	2W F
R8027	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R8028	1-216-089-00	RES,CHIP	47K	5%	1/10W
R8030	1-215-902-11	METAL OXIDE	47K	5%	2W F
R8031	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8032	1-215-918-00	METAL OXIDE	1.5K	5%	3W F
R8033	1-215-902-11	METAL OXIDE	47K	5%	2W F
R8034	1-215-918-00	METAL OXIDE	1.5K	5%	3W F
R8035	1-215-918-00	METAL OXIDE	1.5K	5%	3W F
R8036	1-216-071-00	RES,CHIP	8.2K	5%	1/10W
R8037	1-216-085-00	RES,CHIP	33K	5%	1/10W
R8038	1-216-374-00	METAL OXIDE	2.7	5%	2W F
R8039	1-216-375-00	METAL OXIDE	3.3	5%	2W F
R8041	1-215-902-11	METAL OXIDE	47K	5%	2W F
R8044	1-216-049-00	RES,CHIP	1K	5%	1/10W
R8046	1-216-025-00	RES,CHIP	100	5%	1/10W
R8049	1-216-049-00	RES,CHIP	1K	5%	1/10W
R8050	1-260-117-11	CARBON	33K	5%	1/2W
R8051	1-216-025-00	RES,CHIP	100	5%	1/10W
R8055	1-260-087-11	CARBON	100	5%	1/2W
R8057	1-216-045-00	RES,CHIP	680	5%	1/10W
R8058	1-216-077-91	RES,CHIP	15K	5%	1/10W
R8059	1-216-069-00	RES,CHIP	6.8K	5%	1/10W
R8060	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R8064	1-216-377-11	METAL OXIDE	4.7	5%	2W F

REF. NO.	PART NO.	DESCRIPTION			REMARK
R8067	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R8069	1-216-445-11	METAL OXIDE	12	5%	2W F
R8070	1-260-316-51	CARBON	100	5%	1/2W
R8071	1-216-113-00	RES,CHIP	470K	5%	1/10W
R8074	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R8075	1-260-316-51	CARBON	100	5%	1/2W
R8076	1-216-105-91	RES,CHIP	220K	5%	1/10W
R8077	1-216-091-00	RES,CHIP	56K	5%	1/10W
R8080	1-216-063-91	RES,CHIP	3.9K	5%	1/10W
R8081	1-216-077-91	RES,CHIP	15K	5%	1/10W
R8082	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8083	1-216-077-91	RES,CHIP	15K	5%	1/10W
R8084	1-216-049-00	RES,CHIP	1K	5%	1/10W
R8085	1-249-377-11	CARBON	0.47	5%	1/4W F
R8086	1-216-049-00	RES,CHIP	1K	5%	1/10W
R8087	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8091	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R8092	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8093	1-216-049-00	RES,CHIP	1K	5%	1/10W
R8094	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R8095	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R8096	1-216-045-00	RES,CHIP	680	5%	1/10W
R8097	1-216-081-00	RES,CHIP	22K	5%	1/10W
R8099	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R8101	1-216-055-00	RES,CHIP	1.8K	5%	1/10W
R8102	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8103	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R8105	1-216-689-11	RES,CHIP	39K	5%	1/10W
R8106	1-216-089-00	RES,CHIP	47K	5%	1/10W
R8107	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R8108	1-216-055-00	RES,CHIP	1.8K	5%	1/10W
R8109	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R8110	1-208-810-11	METAL CHIP	15K	0.50%	1/10W
R8111	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R8112	1-216-077-91	RES,CHIP	15K	5%	1/10W
R8113	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8114	1-216-025-00	RES,CHIP	100	5%	1/10W
R8115	1-216-089-00	RES,CHIP	47K	5%	1/10W
R8116	1-216-097-91	RES,CHIP	100K	5%	1/10W
R8117	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R8118	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R8119	1-208-774-11	METAL CHIP	470	0.50%	1/10W
R8120	1-216-049-00	RES,CHIP	1K	5%	1/10W
R8121	1-249-377-11	CARBON	0.47	5%	1/4W F
R8122	1-216-097-91	RES,CHIP	100K	5%	1/10W
R8123	1-208-822-11	METAL CHIP	47K	0.50%	1/10W
R8125	1-208-822-11	METAL CHIP	47K	0.50%	1/10W
R8126	1-216-081-00	RES,CHIP	22K	5%	1/10W
R8127	1-216-037-00	RES,CHIP	330	5%	1/10W
R8128	1-216-073-00	RES,CHIP	10K	5%	1/10W
R8129	1-208-822-11	METAL CHIP	47K	0.50%	1/10W
R8132	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R8133	1-208-832-11	METAL CHIP	120K	0.50%	1/10W
R8134	1-208-834-11	METAL CHIP	150K	0.50%	1/10W
R8135	1-216-097-91	RES,CHIP	100K	5%	1/10W
R8136	1-216-097-91	RES,CHIP	100K	5%	1/10W

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety. Replace only with part number specified.

• The components identified by ⋈ in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

REF. NO.	PART NO.	DESCRIPTION			REMARK
R8137	1-208-806-11	METAL CHIP	10K	0.50% 1/10W	
R8138	1-216-025-00	RES,CHIP	100	5% 1/10W	
R8139	1-216-097-91	RES,CHIP	100K	5% 1/10W	
R8140	1-208-822-11	METAL CHIP	47K	0.50% 1/10W	
R8154	1-216-043-91	RES,CHIP	560	5% 1/10W	
R8155	1-216-049-00	RES,CHIP	1K	5% 1/10W	
R8156	1-214-745-00	METAL	4.7K	1% 1/4W	
R8157	1-208-774-11	METAL CHIP	470	0.50% 1/10W	
R8160	1-214-747-00	METAL	5.6K	1% 1/4W	
R8161	1-215-423-00	METAL	1.2K	1% 1/4W	
R8162	1-214-757-00	METAL	15K	1% 1/4W	
R8163	1-214-757-00	METAL	15K	1% 1/4W	
R8164	1-214-757-00	METAL	15K	1% 1/4W	
R8165	1-214-757-00	METAL	15K	1% 1/4W	
R8166	1-208-814-91	METAL CHIP	22K	0.50% 1/10W	
R8167	1-216-057-00	RES,CHIP	2.2K	5% 1/10W	
R8168	1-208-802-11	METAL CHIP	6.8K	0.50% 1/10W	
R8170	1-216-097-91	RES,CHIP	100K	5% 1/10W	
R8171	1-216-097-91	RES,CHIP	100K	5% 1/10W	
R8172	1-216-073-00	RES,CHIP	10K	5% 1/10W	
R8173	1-208-812-11	METAL CHIP	18K	0.50% 1/10W	
R8174	1-216-025-00	RES,CHIP	100	5% 1/10W	
R8175	1-216-073-00	RES,CHIP	10K	5% 1/10W	
R8176	1-216-073-00	RES,CHIP	10K	5% 1/10W	
R8177	1-216-462-00	METAL OXIDE	8.2K	5% 2W F	
R8178	1-215-897-11	METAL OXIDE	6.8K	5% 2W F	
R8181	1-215-900-11	METAL OXIDE	22K	5% 2W F	
R8182	1-215-901-00	METAL OXIDE	33K	5% 2W F	
R8183	1-260-292-11	CARBON	1	5% 1/2W	
R8186	1-216-037-00	RES,CHIP	330	5% 1/10W	
R8187	1-215-901-00	METAL OXIDE	33K	5% 2W F	
R8188	1-216-466-71	METAL OXIDE	39K	5% 2W F	
R8189	1-260-117-11	CARBON	33K	5% 1/2W	
R8190	1-208-798-11	METAL CHIP	4.7K	0.50% 1/10W	
R8191	1-208-806-11	METAL CHIP	10K	0.50% 1/10W	
R8192	1-208-802-11	METAL CHIP	6.8K	0.50% 1/10W	
R8193	1-208-814-91	METAL CHIP	22K	0.50% 1/10W	
⋈ R8194 ⚠		CARBON		1/4W	
R8195	1-208-814-91	METAL CHIP	22K	0.50% 1/10W	
⋈ R8196 ⚠		CARBON		1/4W	
R8197	1-260-087-11	CARBON	100	5% 1/2W	
R8198	1-214-769-00	METAL	47K	1% 1/4W	
R8199	1-260-288-11	CARBON	0.47	5% 1/2W	
R8200	1-260-127-11	CARBON	220K	5% 1/2W	
⋈ R8201 ⚠		METAL		1/4W	
⋈ R8202 ⚠		METAL		1/4W	
R8203	1-208-826-11	METAL CHIP	68K	0.50% 1/10W	
R8204	1-208-832-11	METAL CHIP	120K	0.50% 1/10W	
R8208	1-260-087-11	CARBON	100	5% 1/2W	
R8213	1-249-413-11	CARBON	470	5% 1/4W F	
R8214	1-216-379-11	METAL OXIDE	6.8	5% 2W F	
R8215	1-216-097-91	RES,CHIP	100K	5% 1/10W	
R8216	1-216-093-91	RES,CHIP	68K	5% 1/10W	
R8217	1-216-079-00	RES,CHIP	18K	5% 1/10W	
R8218	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R8219	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R8220	1-216-079-00	RES,CHIP	18K	5% 1/10W	

REF. NO.	PART NO.	DESCRIPTION			REMARK
R8221	1-216-097-91	RES,CHIP	100K	5% 1/10W	
R8222	1-216-093-91	RES,CHIP	68K	5% 1/10W	
R8223	1-216-079-00	RES,CHIP	18K	5% 1/10W	
R8224	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R8225	1-260-087-11	CARBON	100	5% 1/2W	
R8227	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R8228	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R8229	1-216-093-91	RES,CHIP	68K	5% 1/10W	
R8230	1-216-073-00	RES,CHIP	10K	5% 1/10W	
		<SPARK GAP>			
SG8002	1-519-422-11	GAP, SPARK			
		<TRANSFORMER>			
T5001	1-437-209-11	TRANSFORMER, HORIZONTAL DRIVE			
T5002	1-431-966-11	TRANSFORMER, FERRITE (HOT)			
T8001 ⚠	1-437-209-11	TRANSFORMER, HORIZONTAL DRIVE			
T8002 ⚠	1-431-955-11	TRANSFORMER, FERRITE (LOT)			
T8003 ⚠	1-453-285-11	FBT ASSY, NX-4006/X4P			
		<THERMISTOR>			
TH5001	1-800-193-00	THERMISTOR			
**********					
*	A-1372-448-A	HA BOARD, COMPLETE			
		**********			
		<CAPACITOR>			
C3101	1-136-165-00	MYLAR	0.1µF	5% 50V	
		<CONNECTOR>			
CN3101*	1-564-521-11	PLUG, CONNECTOR 6P			
CN3102*	1-564-518-11	PLUG, CONNECTOR 3P			
CN3103*	1-564-518-11	PLUG, CONNECTOR 3P			
		<DIODE>			
D3101	8-719-053-43	DIODE SLR-325VCT31 (STEREO)			
D3102	8-719-053-43	DIODE SLR-325VCT31 (TIMER)			
		<RESISTOR>			
R3101	1-215-417-00	METAL	680	1% 1/4W	
R3102	1-215-421-00	METAL	1K	1% 1/4W	
R3103	1-215-423-00	METAL	1.2K	1% 1/4W	
R3104	1-215-427-00	METAL	1.8K	1% 1/4W	
R3105	1-215-433-00	METAL	3.3K	1% 1/4W	

REF. NO.	PART NO.	DESCRIPTION			REMARK
		<SWITCH>			
S3101	1-572-198-11	SWITCH, KEYBOARD (POWER)			
S3102	1-572-198-11	SWITCH, KEYBOARD (CH +)			
S3103	1-572-198-11	SWITCH, KEYBOARD (CH -)			
S3104	1-572-198-11	SWITCH, KEYBOARD (VOL +)			
S3105	1-572-198-11	SWITCH, KEYBOARD (VOL -)			
S3106	1-572-198-11	SWITCH, KEYBOARD (TV/VIDEO)			

****

* A-1372-449-A HB BOARD, COMPLETE
****

		<CONNECTOR>			
CN3201*	1-564-526-11	PLUG, CONNECTOR 11P			
CN3202*	1-564-518-11	PLUG, CONNECTOR 3P			
		<DIODE>			
D3201	8-719-108-12	DIODE RD9.1EW			
D3202	8-719-108-12	DIODE RD9.1EW			
D3203	8-719-108-12	DIODE RD9.1EW			
D3204	8-719-108-12	DIODE RD9.1EW			
D3205	8-719-108-12	DIODE RD9.1EW			
D3206	8-719-108-12	DIODE RD9.1EW			
		<JACK>			
J3201	1-770-361-11	TERMINAL BLOCK, S (VIDEO-2 IN)			
		<RESISTOR>			
R3201	1-247-804-11	CARBON	75	5%	1/4W
R3202	1-249-417-11	CARBON	1K	5%	1/4W
R3203	1-247-804-11	CARBON	75	5%	1/4W
R3204	1-247-804-11	CARBON	75	5%	1/4W
R3205	1-247-895-91	CARBON	470K	5%	1/4W
R3206	1-247-895-91	CARBON	470K	5%	1/4W
R3207	1-215-441-00	METAL	6.8K	1%	1/4W
R3209	1-215-451-00	METAL	18K	1%	1/4W
		<SWITCH>			
S3201	1-572-198-11	SWITCH, KEYBOARD (FLASH FOCUS)			
S3202	1-572-198-11	SWITCH, KEYBOARD (SET UP)			

****

REF. NO.	PART NO.	DESCRIPTION			REMARK
		* A-1372-450-A HC BOARD, COMPLETE ********			
		<CONNECTOR>			
CN3301*	1-564-518-11	PLUG, CONNECTOR 3P			
		<DIODE>			
D3301	8-719-109-89	DIODE RD5.6ESB2			
D3302	8-719-109-89	DIODE RD5.6ESB2			
		<RESISTOR>			
R3301	1-247-807-31	CARBON	100	5%	1/4W
R3302	1-247-807-31	CARBON	100	5%	1/4W

****

* A-1373-761-A U BOARD, COMPLETE
****

		<CAPACITOR>			
C3501	1-164-489-11	CERAMIC CHIP	0.22µF	10%	16V
C3502	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C3504	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C3505	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
		<CONNECTOR>			
CN3501*	1-564-522-11	PLUG, CONNECTOR 7P			
		<DIODE>			
D3501	8-719-073-01	DIODE MA111-(K8).S0			
D3502	8-719-073-01	DIODE MA111-(K8).S0			
D3503	8-719-158-15	DIODE RD5.6SB			
D3504	8-719-158-15	DIODE RD5.6SB			
D3505	8-719-977-28	DIODE DTZ10B			
D3506	8-719-977-28	DIODE DTZ10B			
D3507	8-719-977-28	DIODE DTZ10B			
D3508	8-719-977-28	DIODE DTZ10B			
		<JACK>			
J3501	1-764-143-11	JACK 3P (CONTROL S IN)			
J3502	1-764-143-11	JACK 3P (CONTROL S OUT)			
J3503	1-793-795-11	JACK BLOCK, PIN 2P (VIDEO 5 (DTV) HD/VD)			
		<TRANSISTOR>			
Q3501	8-729-027-38	TRANSISTOR DTA144EKA-T146			
Q3502	1-801-806-11	TRANSISTOR DTC144EKA-T146			
Q3503	8-729-216-22	TRANSISTOR 2SA1162-G			

REF. NO.	PART NO.	DESCRIPTION			REMARK
Q3504	8-729-216-22	TRANSISTOR 2SA1162-G			
Q3505	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q3506	1-801-806-11	TRANSISTOR DTC144EKA-T146			
Q3507	8-729-422-27	TRANSISTOR 2SD601A-Q			
		<RESISTOR>			
R3501	1-216-089-91	RES,CHIP	47K	5%	1/10W
R3502	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R3503	1-216-009-91	RES,CHIP	22	5%	1/10W
R3504	1-216-073-00	RES,CHIP	10K	5%	1/10W
R3506	1-216-009-91	RES,CHIP	22	5%	1/10W
R3507	1-216-097-91	RES,CHIP	100K	5%	1/10W
R3508	1-216-097-91	RES,CHIP	100K	5%	1/10W
R3510	1-216-073-00	RES,CHIP	10K	5%	1/10W
R3511	1-216-295-91	SHORT	0		
R3512	1-216-073-00	RES,CHIP	10K	5%	1/10W
R3513	1-216-097-91	RES,CHIP	100K	5%	1/10W
R3514	1-216-097-91	RES,CHIP	100K	5%	1/10W
R3515	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R3516	1-216-025-91	RES,CHIP	100	5%	1/10W
R3517	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R3518	1-216-025-91	RES,CHIP	100	5%	1/10W

****

* A-1380-618-A K BOARD, COMPLETE
****

4-382-854-11 SCREW(M3X10), P, SW (+)

<CAPACITOR>

C2103	1-104-664-11	ELECT	47µF	20%	25V
C2104	1-104-664-11	ELECT	47µF	20%	25V
C2105	1-104-664-11	ELECT	47µF	20%	25V
C2106	1-104-664-11	ELECT	47µF	20%	25V
C2107	1-104-664-11	ELECT	47µF	20%	25V
C2108	1-104-664-11	ELECT	47µF	20%	25V
C2111	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2112	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2113	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2114	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2115	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2116	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2117	1-104-664-11	ELECT	47µF	20%	25V
C2118	1-130-495-00	MYLAR	0.1µF	5%	50V
C2121	1-126-965-11	ELECT	22µF	20%	50V
C2122	1-136-177-00	MYLAR	1µF	5%	50V
C2123	1-137-370-11	MYLAR	0.01µF	5%	50V
C2124	1-137-365-11	MYLAR	0.0015µF	5%	50V
C2125	1-137-375-11	MYLAR	0.068µF	5%	50V
C2126	1-130-495-00	MYLAR	0.1µF	5%	50V
C2127	1-130-495-00	MYLAR	0.1µF	5%	50V
C2128	1-137-375-11	MYLAR	0.068µF	5%	50V
C2129	1-137-370-11	MYLAR	0.01µF	5%	50V
C2130	1-137-434-11	MYLAR	0.0018µF	5%	50V
C2131	1-130-495-00	MYLAR	0.1µF	5%	50V
C2132	1-130-495-00	MYLAR	0.1µF	5%	50V
C2133	1-130-495-00	MYLAR	0.1µF	5%	50V
C2134	1-137-365-11	MYLAR	0.0015µF	5%	50V
C2135	1-136-356-11	MYLAR	470pF	5%	50V
C2136	1-136-357-11	MYLAR	680pF	5%	50V
C2137	1-137-437-11	MYLAR	0.0056µF	5%	50V
C2138	1-137-374-11	MYLAR	0.047µF	5%	50V
C2139	1-136-175-00	MYLAR	0.68µF	5%	50V
C2140	1-137-378-11	MYLAR	0.22µF	5%	50V
C2141	1-137-378-11	MYLAR	0.22µF	5%	50V
C2142	1-126-963-11	ELECT	4.7µF	20%	50V
C2143	1-126-963-11	ELECT	4.7µF	20%	50V
C2144	1-137-378-11	MYLAR	0.22µF	5%	50V
C2145	1-137-378-11	MYLAR	0.22µF	5%	50V
C2146	1-130-495-00	MYLAR	0.1µF	5%	50V
C2147	1-137-374-11	MYLAR	0.047µF	5%	50V
C2148	1-137-374-11	MYLAR	0.047µF	5%	50V
C2149	1-130-495-00	MYLAR	0.1µF	5%	50V
C2150	1-130-495-00	MYLAR	0.1µF	5%	50V
C2151	1-137-372-11	MYLAR	0.022µF	5%	50V
C2152	1-137-372-11	MYLAR	0.022µF	5%	50V
C2153	1-130-495-00	MYLAR	0.1µF	5%	50V
C2154	1-136-357-11	MYLAR	680pF	5%	50V
C2155	1-130-495-00	MYLAR	0.1µF	5%	50V
C2156	1-130-495-00	MYLAR	0.1µF	5%	50V
C2157	1-126-965-11	ELECT	22µF	20%	50V
C2158	1-126-964-11	ELECT	10µF	20%	50V
C2159	1-137-437-11	MYLAR	0.0056µF	5%	50V
C2160	1-128-549-11	ELECT	3300µF	20%	35V
C2161	1-128-549-11	ELECT	3300µF	20%	35V
C2162	1-130-495-00	MYLAR	0.1µF	5%	50V
C2163	1-130-495-00	MYLAR	0.1µF	5%	50V
C2164	1-107-698-11	ELECT	10µF	20%	25V
C2165	1-107-698-11	ELECT	10µF	20%	25V
C2166	1-126-965-11	ELECT	22µF	20%	50V
C2167	1-126-935-11	ELECT	470µF	20%	16V
C2168	1-126-933-11	ELECT	100µF	20%	16V
C2169	1-136-357-11	MYLAR	680pF	5%	50V
C2170	1-130-495-00	MYLAR	0.1µF	5%	50V
C2171	1-130-495-00	MYLAR	0.1µF	5%	50V
C2172	1-104-664-11	ELECT	47µF	20%	25V
C2173	1-104-664-11	ELECT	47µF	20%	25V
C2174	1-126-933-11	ELECT	100µF	20%	16V
C2176	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2177	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2178	1-164-161-11	CERAMIC CHIP	0.0022µF	10%	50V
C2301	1-126-960-11	ELECT	1µF	20%	50V
C2302	1-126-960-11	ELECT	1µF	20%	50V
C2303	1-126-965-11	ELECT	22µF	20%	50V
C2304	1-163-014-00	CERAMIC CHIP	0.0027µF	5%	50V
C2305	1-163-014-00	CERAMIC CHIP	0.0027µF	5%	50V
C2306	1-126-961-11	ELECT	2.2µF	20%	50V
C2307	1-130-495-00	MYLAR	0.1µF	5%	50V
C2308	1-130-495-00	MYLAR	0.1µF	5%	50V
C2309	1-130-495-00	MYLAR	0.1µF	5%	50V

K

REF. NO.	PART NO.	DESCRIPTION			REMARK
C2310	1-130-495-00	MYLAR	0.1µF	5%	50V
C2311	1-126-961-11	ELECT	2.2µF	20%	50V
C2312	1-126-965-11	ELECT	22µF	20%	50V
C2313	1-163-014-00	CERAMIC CHIP	0.0027µF	5%	50V
C2314	1-163-014-00	CERAMIC CHIP	0.0027µF	5%	50V
C2315	1-126-961-11	ELECT	2.2µF	20%	50V
C2316	1-130-495-00	MYLAR	0.1µF	5%	50V
C2317	1-130-495-00	MYLAR	0.1µF	5%	50V
C2318	1-130-495-00	MYLAR	0.1µF	5%	50V
C2319	1-130-495-00	MYLAR	0.1µF	5%	50V
C2320	1-126-961-11	ELECT	2.2µF	20%	50V
C2321	1-107-698-11	ELECT	10µF	20%	25V
C2322	1-107-698-11	ELECT	10µF	20%	25V
C2323	1-107-698-11	ELECT	10µF	20%	25V
C2324	1-107-698-11	ELECT	10µF	20%	25V
C2325	1-126-964-11	ELECT	10µF	20%	50V
C2326	1-126-964-11	ELECT	10µF	20%	50V
C2327	1-104-664-11	ELECT	47µF	20%	25V
C2328	1-104-664-11	ELECT	47µF	20%	25V
C2329	1-104-664-11	ELECT	47µF	20%	25V
C2601	1-126-960-11	ELECT	1µF	20%	50V
C2602	1-126-964-11	ELECT	10µF	20%	50V
C2605	1-126-964-11	ELECT	10µF	20%	50V
C2606	1-126-963-11	ELECT	4.7µF	20%	50V
C2607	1-130-495-00	MYLAR	0.1µF	5%	50V
C2608	1-126-960-11	ELECT	1µF	20%	50V
C2609	1-130-495-00	MYLAR	0.1µF	5%	50V
C2610	1-130-495-00	MYLAR	0.1µF	5%	50V
C2611	1-130-495-00	MYLAR	0.1µF	5%	50V
C2612	1-126-960-11	ELECT	1µF	20%	50V
C2613	1-126-963-11	ELECT	4.7µF	20%	50V
C2614	1-126-960-11	ELECT	1µF	20%	50V
C2615	1-126-964-11	ELECT	10µF	20%	50V
C2617	1-130-495-00	MYLAR	0.1µF	5%	50V
C2618	1-130-495-00	MYLAR	0.1µF	5%	50V
C2619	1-130-495-00	MYLAR	0.1µF	5%	50V
C2620	1-126-963-11	ELECT	4.7µF	20%	50V
C2621	1-126-960-11	ELECT	1µF	20%	50V
C2622	1-130-495-00	MYLAR	0.1µF	5%	50V
C2623	1-126-964-11	ELECT	10µF	20%	50V
C2624	1-126-964-11	ELECT	10µF	20%	50V
C2625	1-104-664-11	ELECT	47µF	20%	25V
C2626	1-104-664-11	ELECT	47µF	20%	25V
C2627	1-130-495-00	MYLAR	0.1µF	5%	50V
C2628	1-130-495-00	MYLAR	0.1µF	5%	50V
C2631	1-104-665-11	ELECT	100µF	20%	25V
C2632	1-104-665-11	ELECT	100µF	20%	25V
C2633	1-107-718-91	ELECT	100µF	20%	50V
C2801	1-126-960-11	ELECT	1µF	20%	50V
C2802	1-126-960-11	ELECT	1µF	20%	50V
C2803	1-126-964-11	ELECT	10µF	20%	50V
C2804	1-126-964-11	ELECT	10µF	20%	50V

<CONNECTOR>

CN2101*	1-691-757-11	PIN, CONNECTOR (PC BOARD) 8P	
CN2102*	1-564-510-11	PLUG, CONNECTOR 7P	
CN2103*	1-564-513-11	PLUG, CONNECTOR 10P	
CN2601*	1-564-507-11	PLUG, CONNECTOR 4P	
CN2602*	1-691-135-11	PIN, CONNECTOR (PC BOARD) 4P	
CN2603*	1-691-134-11	PIN, CONNECTOR (PC BOARD) 2P	

<DIODE>

D2101	8-719-073-01	DIODE	MA111-(K8).S0
D2102	8-719-073-01	DIODE	MA111-(K8).S0
D2103	8-719-073-01	DIODE	MA111-(K8).S0
D2104	8-719-073-01	DIODE	MA111-(K8).S0
D2105	8-719-073-01	DIODE	MA111-(K8).S0
D2106	8-719-073-01	DIODE	MA111-(K8).S0
D2107	8-719-073-01	DIODE	MA111-(K8).S0
D2108	8-719-073-01	DIODE	MA111-(K8).S0
D2109	8-719-073-01	DIODE	MA111-(K8).S0
D2110	8-719-073-01	DIODE	MA111-(K8).S0
D2111	8-719-073-01	DIODE	MA111-(K8).S0
D2112	8-719-073-01	DIODE	MA111-(K8).S0
D2113	8-719-977-28	DIODE	DTZ10B
D2114	8-719-977-28	DIODE	DTZ10B
D2115	8-719-977-28	DIODE	DTZ10B
D2116	8-719-073-01	DIODE	MA111-(K8).S0
D2301	8-719-977-28	DIODE	DTZ10B
D2302	8-719-977-28	DIODE	DTZ10B
D2303	8-719-977-28	DIODE	DTZ10B
D2304	8-719-977-28	DIODE	DTZ10B
D2601	8-719-073-01	DIODE	MA111-(K8).S0
D2602	8-719-402-92	DIODE	MA3220M-TX
D2603	8-719-402-92	DIODE	MA3220M-TX
D2604	8-719-402-92	DIODE	MA3220M-TX
D2605	8-719-402-92	DIODE	MA3220M-TX
D2606	8-719-402-92	DIODE	MA3220M-TX
D2607	8-719-402-92	DIODE	MA3220M-TX
D2608	8-719-402-92	DIODE	MA3220M-TX
D2609	8-719-402-92	DIODE	MA3220M-TX
D2610	8-719-402-92	DIODE	MA3220M-TX
D2611	8-719-073-01	DIODE	MA111-(K8).S0
D2612	8-719-073-01	DIODE	MA111-(K8).S0
D2613	8-719-073-01	DIODE	MA111-(K8).S0
D2614	8-719-402-92	DIODE	MA3220M-TX
D2615	8-719-402-92	DIODE	MA3220M-TX
D2616	8-719-402-92	DIODE	MA3220M-TX
D2617	8-719-402-92	DIODE	MA3220M-TX
D2618	8-719-073-01	DIODE	MA111-(K8).S0
D2620	8-719-402-92	DIODE	MA3220M-TX
D2621	8-719-977-28	DIODE	DTZ10B
D2622	8-719-977-28	DIODE	DTZ10B
D2623	8-719-977-28	DIODE	DTZ10B
D2624	8-719-977-28	DIODE	DTZ10B
D2801	8-719-400-75	DIODE	MA3091
D2802	8-719-400-75	DIODE	MA3091
D2803	8-719-400-75	DIODE	MA3091
D2804	8-719-400-75	DIODE	MA3091
D2805	8-719-400-75	DIODE	MA3091
D2806	8-719-400-75	DIODE	MA3091
D2807	8-719-400-75	DIODE	MA3091

REF. NO.	PART NO.	DESCRIPTION			REMARK
D2808	8-719-400-75	DIODE MA3091			
		<IC>			
IC2102	8-759-231-53	IC TA7805S			
IC2103	8-759-198-03	IC PQ09RF21			
IC2104	8-759-231-58	IC TA7812S			
IC2105	8-759-544-37	IC NJW1103FC3			
IC2301	8-759-634-51	IC M5218AP			
IC2302	8-759-544-72	IC TDA7312			
IC2303	8-759-544-72	IC TDA7312			
IC2601	8-759-190-89	IC TDA7265			
IC2602	8-759-072-99	IC TDA2052			
IC2603	8-759-190-89	IC TDA7265			
		<JACK>			
J2601	1-785-083-11	JACK BLOCK, PIN 2P			
J2602	1-785-083-21	JACK BLOCK, PIN 2P			
		<TRANSISTOR>			
Q2101	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2102	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2103	8-729-216-22	TRANSISTOR 2SA1162-G			
Q2104	8-729-216-22	TRANSISTOR 2SA1162-G			
Q2105	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2601	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2602	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2603	8-729-216-22	TRANSISTOR 2SA1162-G			
Q2604	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2605	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2606	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2607	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2608	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2609	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2610	8-729-216-22	TRANSISTOR 2SA1162-G			
Q2801	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2802	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2803	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2804	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2805	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q2806	8-729-422-27	TRANSISTOR 2SD601A-Q			
		<RESISTOR>			
R2104	1-216-477-11	METAL OXIDE	270	5% 3W F	
R2105	1-215-912-11	METAL OXIDE	150	5% 3W F	
R2106	1-216-295-91	SHORT	0		
R2107	1-215-912-11	METAL OXIDE	150	5% 3W F	
R2109	1-216-073-00	RES,CHIP	10K	5% 1/10W	
R2110	1-216-081-00	RES,CHIP	22K	5% 1/10W	
R2111	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2112	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2113	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2114	1-216-121-91	RES,CHIP	1M	5% 1/10W	
R2115	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2116	1-216-065-91	RES,CHIP	4.7K	5% 1/10W	
R2117	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2118	1-216-065-91	RES,CHIP	4.7K	5% 1/10W	
R2119	1-216-081-00	RES,CHIP	22K	5% 1/10W	
R2120	1-216-081-00	RES,CHIP	22K	5% 1/10W	
R2121	1-216-109-00	RES,CHIP	330K	5% 1/10W	
R2122	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2123	1-216-077-91	RES,CHIP	15K	5% 1/10W	
R2124	1-216-077-91	RES,CHIP	15K	5% 1/10W	
R2125	1-216-081-00	RES,CHIP	22K	5% 1/10W	
R2126	1-216-081-00	RES,CHIP	22K	5% 1/10W	
R2127	1-216-129-00	RES,CHIP	2.2M	5% 1/10W	
R2128	1-216-097-91	RES,CHIP	100K	5% 1/10W	
R2129	1-216-105-91	RES,CHIP	220K	5% 1/10W	
R2133	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2134	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2135	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2136	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2137	1-216-049-91	RES,CHIP	1K	5% 1/10W	
R2138	1-216-049-91	RES,CHIP	1K	5% 1/10W	
R2139	1-216-081-00	RES,CHIP	22K	5% 1/10W	
R2140	1-216-081-00	RES,CHIP	22K	5% 1/10W	
R2141	1-216-065-91	RES,CHIP	4.7K	5% 1/10W	
R2142	1-216-073-00	RES,CHIP	10K	5% 1/10W	
R2143	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2144	1-216-077-91	RES,CHIP	15K	5% 1/10W	
R2145	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2146	1-216-077-91	RES,CHIP	15K	5% 1/10W	
R2147	1-216-129-00	RES,CHIP	2.2M	5% 1/10W	
R2148	1-216-077-91	RES,CHIP	15K	5% 1/10W	
R2149	1-216-077-91	RES,CHIP	15K	5% 1/10W	
R2164	1-216-071-00	RES,CHIP	8.2K	5% 1/10W	
R2165	1-216-071-00	RES,CHIP	8.2K	5% 1/10W	
R2166	1-216-065-91	RES,CHIP	4.7K	5% 1/10W	
R2167	1-216-109-00	RES,CHIP	330K	5% 1/10W	
R2301	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2302	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2303	1-216-075-00	RES,CHIP	12K	5% 1/10W	
R2304	1-216-073-00	RES,CHIP	10K	5% 1/10W	
R2305	1-216-075-00	RES,CHIP	12K	5% 1/10W	
R2306	1-216-073-00	RES,CHIP	10K	5% 1/10W	
R2307	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2308	1-216-089-91	RES,CHIP	47K	5% 1/10W	
R2309	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R2310	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R2311	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R2312	1-216-067-00	RES,CHIP	5.6K	5% 1/10W	
R2313	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2314	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2315	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2316	1-216-025-91	RES,CHIP	100	5% 1/10W	
R2601	1-216-009-91	RES,CHIP	22	5% 1/10W	
R2602	1-216-009-91	RES,CHIP	22	5% 1/10W	
R2604	1-216-039-00	RES,CHIP	390	5% 1/10W	
R2605	1-216-085-00	RES,CHIP	33K	5% 1/10W	
R2606	1-216-039-00	RES,CHIP	390	5% 1/10W	
R2607	1-216-073-00	RES,CHIP	10K	5% 1/10W	

REF. NO.	PART NO.	DESCRIPTION			REMARK
R2608	1-216-097-91	RES,CHIP	100K	5%	1/10W
R2609	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2610	1-216-077-91	RES,CHIP	15K	5%	1/10W
R2611	1-216-085-00	RES,CHIP	33K	5%	1/10W
R2612	1-216-357-00	METAL OXIDE	4.7	5%	1W F
R2613	1-216-357-00	METAL OXIDE	4.7	5%	1W F
R2614	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2616	1-216-063-91	RES,CHIP	3.9K	5%	1/10W
R2618	1-216-295-91	SHORT	0		
R2619	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2620	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2621	1-216-009-91	RES,CHIP	22	5%	1/10W
R2622	1-216-081-00	RES,CHIP	22K	5%	1/10W
R2623	1-216-039-00	RES,CHIP	390	5%	1/10W
R2624	1-216-085-00	RES,CHIP	33K	5%	1/10W
R2625	1-216-081-00	RES,CHIP	22K	5%	1/10W
R2626	1-216-357-00	METAL OXIDE	4.7	5%	1W F
R2627	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2628	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2629	1-216-689-11	RES,CHIP	39K	5%	1/10W
R2630	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2631	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2632	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2633	1-216-097-91	RES,CHIP	100K	5%	1/10W
R2634	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2635	1-216-077-91	RES,CHIP	15K	5%	1/10W
R2636	1-216-085-00	RES,CHIP	33K	5%	1/10W
R2637	1-216-041-00	RES,CHIP	470	5%	1/10W
R2638	1-216-041-00	RES,CHIP	470	5%	1/10W
R2639	1-216-079-00	RES,CHIP	18K	5%	1/10W
R2640	1-216-041-00	RES,CHIP	470	5%	1/10W
R2641	1-216-041-00	RES,CHIP	470	5%	1/10W
R2642	1-216-079-00	RES,CHIP	18K	5%	1/10W
R2643	1-216-079-00	RES,CHIP	18K	5%	1/10W
R2644	1-216-079-00	RES,CHIP	18K	5%	1/10W
R2645	1-216-357-00	METAL OXIDE	4.7	5%	1W F
R2646	1-216-357-00	METAL OXIDE	4.7	5%	1W F
R2647	1-216-083-00	RES,CHIP	27K	5%	1/10W
R2648	1-216-083-00	RES,CHIP	27K	5%	1/10W
R2649	1-216-075-00	RES,CHIP	12K	5%	1/10W
R2650	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2651	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2652	1-216-025-91	RES,CHIP	100	5%	1/10W
R2653	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2654	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2655	1-216-049-91	RES,CHIP	1K	5%	1/10W
R2656	1-216-083-00	RES,CHIP	27K	5%	1/10W
R2657	1-216-083-00	RES,CHIP	27K	5%	1/10W
R2658	1-216-083-00	RES,CHIP	27K	5%	1/10W
R2659	1-216-085-00	RES,CHIP	33K	5%	1/10W
R2660	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2662	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2663	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2801	1-216-113-00	RES,CHIP	470K	5%	1/10W
R2802	1-216-041-00	RES,CHIP	470	5%	1/10W
R2804	1-216-113-00	RES,CHIP	470K	5%	1/10W
R2805	1-216-041-00	RES,CHIP	470	5%	1/10W
R2806	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2807	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2808	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2809	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2810	1-216-113-00	RES,CHIP	470K	5%	1/10W
R2811	1-216-041-00	RES,CHIP	470	5%	1/10W
R2813	1-216-113-00	RES,CHIP	470K	5%	1/10W
R2814	1-216-041-00	RES,CHIP	470	5%	1/10W
R2815	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2816	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2817	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R2818	1-216-089-91	RES,CHIP	47K	5%	1/10W
R2819	1-216-073-00	RES,CHIP	10K	5%	1/10W
R2820	1-216-073-00	RES,CHIP	10K	5%	1/10W

<RELAY>

RY2601	1-755-028-11	RELAY			

<TERMINAL BOARD>

TB2601	1-694-441-11	TERMINAL, PUSH			
TB2602	1-694-442-11	TERMINAL, PUSH			

<CRYSTAL>

X2101	1-577-358-21	VIBRATOR, CERAMIC			

****

* A-1390-950-A ZR BOARD, COMPLETE
****

	4-382-854-11	SCREW(M3X10), P, SW (+)			

<CAPACITOR>

C4101	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C4102	1-104-664-11	ELECT	47µF	20%	16V
C4103	1-107-667-11	ELECT	2.2µF	20%	160V
C4104	1-130-471-00	MYLAR	0.001µF	5%	50V
C4105	1-130-471-00	MYLAR	0.001µF	5%	50V
C4106	1-104-987-11	MYLAR	0.001µF	10%	200V
C4107	1-104-987-11	MYLAR	0.001µF	10%	200V
C4108	1-107-364-11	MYLAR	0.01µF	10%	200V
C4109	1-126-968-11	ELECT	100µF	20%	50V
C4110	1-107-645-11	ELECT	22µF	20%	160V
C4111	1-126-968-11	ELECT	100µF	20%	50V
C4112	1-161-830-00	CERAMIC	0.0047µF		500V
C4113	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C4114	1-161-830-00	CERAMIC	0.0047µF		500V
C4115	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C4116	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK
		<CONNECTOR>			
CN4101*	1-564-509-11	PLUG, CONNECTOR 6P			
CN4102*	1-564-506-11	PLUG, CONNECTOR 3P			
CN4104*	1-564-507-11	PLUG, CONNECTOR 4P			
CN4105*	1-564-506-11	PLUG, CONNECTOR 3P			
CN4107*	1-580-690-11	PIN, CONNECTOR (PC BOARD) 4P			
		<DIODE>			
D4102	8-719-921-86	DIODE MTZJ-13			
D4103	8-719-921-86	DIODE MTZJ-13			
		<CONNECTOR>			
DY4101⚠		1-451-510-11	DEFLECTION YOKE		
		<COIL>			
L4101	1-414-183-41	INDUCTOR	10µH		
L4102	1-414-187-11	INDUCTOR	47µH		
		<TRANSISTOR>			
Q4101	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q4104	8-729-045-04	TRANSISTOR	2SC5511		
Q4105	8-729-045-05	TRANSISTOR	2SA2005		
Q4106	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q4107	8-729-422-27	TRANSISTOR	2SD601A-Q		
Q4108	8-729-216-22	TRANSISTOR	2SA1162-G		
Q4109	8-729-216-22	TRANSISTOR	2SA1162-G		
Q4110	8-729-422-27	TRANSISTOR	2SD601A-Q		
		<RESISTOR>			
R4101	1-216-025-91	RES,CHIP	100	5%	1/10W
R4102	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R4103	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R4104	1-216-049-91	RES,CHIP	1K	5%	1/10W
R4105	1-216-475-11	METAL OXIDE	120	5%	3W F
R4106	1-216-033-00	RES,CHIP	220	5%	1/10W
R4107	1-216-475-11	METAL OXIDE	120	5%	3W F
R4109	1-216-009-91	RES,CHIP	22	5%	1/10W
R4110	1-249-414-11	CARBON	560	5%	1/4W
R4111	1-247-863-91	CARBON	22K	5%	1/4W
R4113	1-249-429-11	CARBON	10K	5%	1/4W F
R4114	1-249-414-11	CARBON	560	5%	1/4W
R4115	1-247-863-91	CARBON	22K	5%	1/4W
R4116	1-249-397-11	CARBON	22	5%	1/4W F
R4117	1-249-415-11	CARBON	680	5%	1/4W F
R4118	1-249-415-11	CARBON	680	5%	1/4W F
R4119	1-249-384-11	CARBON	1.8	5%	1/4W F
R4120	1-249-384-11	CARBON	1.8	5%	1/4W F
R4121	1-249-401-11	CARBON	47	5%	1/4W F
R4122	1-249-401-11	CARBON	47	5%	1/4W F
R4123	1-216-476-11	METAL OXIDE	180	5%	3W F
R4124	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R4125	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R4126	1-216-009-91	RES,CHIP	22	5%	1/10W

****

* A-1390-951-A ZG BOARD, COMPLETE
****

	4-382-854-11	SCREW(M3X10), P, SW (+)			
		<CAPACITOR>			
C4201	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C4202	1-107-667-11	ELECT	2.2µF	20%	160V
C4203	1-130-471-00	MYLAR	0.001µF	5%	50V
C4204	1-130-471-00	MYLAR	0.001µF	5%	50V
C4205	1-104-987-11	MYLAR	0.001µF	10%	200V
C4206	1-104-987-11	MYLAR	0.001µF	10%	200V
C4207	1-107-364-11	MYLAR	0.01µF	10%	200V
C4208	1-126-968-11	ELECT	100µF	20%	50V
C4209	1-126-968-11	ELECT	100µF	20%	50V
C4210	1-107-645-11	ELECT	22µF	20%	160V
C4211	1-161-830-00	CERAMIC	0.0047µF		500V
C4212	1-106-220-00	MYLAR	0.1µF	10%	100V
C4213	1-106-220-00	MYLAR	0.1µF	10%	100V
C4214	1-104-664-11	ELECT	47µF	20%	16V
C4215	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C4216	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C4217	1-161-830-00	CERAMIC	0.0047µF		500V
C4218	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C4219	1-161-830-00	CERAMIC	0.0047µF		500V
C4220	1-163-038-91	CERAMIC CHIP	0.1µF		25V
		<CONNECTOR>			
CN4201*	1-564-509-11	PLUG, CONNECTOR 6P			
CN4202*	1-564-509-11	PLUG, CONNECTOR 6P			
CN4203*	1-564-507-11	PLUG, CONNECTOR 4P			
CN4204*	1-564-506-11	PLUG, CONNECTOR 3P			
CN4205*	1-564-506-11	PLUG, CONNECTOR 3P			
CN4206*	1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P			
CN4207*	1-564-506-11	PLUG, CONNECTOR 3P			
		<DIODE>			
D4201	8-719-921-86	DIODE MTZJ-13			
D4202	8-719-921-86	DIODE MTZJ-13			
		<CONNECTOR>			
DY4201⚠	1-451-510-11	DEFLECTION YOKE			
		<COIL>			
L4201	1-414-187-11	INDUCTOR	47µH		
L4202	1-414-183-41	INDUCTOR	10µH		

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK
		<TRANSISTOR>			
Q4201	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q4203	8-729-045-04	TRANSISTOR 2SC5511			
Q4204	8-729-045-05	TRANSISTOR 2SA2005			
Q4205	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q4206	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q4207	8-729-422-27	TRANSISTOR 2SD601A-Q			
Q4208	8-729-216-22	TRANSISTOR 2SA1162-G			
Q4209	8-729-216-22	TRANSISTOR 2SA1162-G			
		<RESISTOR>			
R4201	1-216-025-91	RES,CHIP	100	5%	1/10W
R4202	1-216-475-11	METAL OXIDE	120	5%	3W F
R4203	1-216-049-91	RES,CHIP	1K	5%	1/10W
R4206	1-216-475-11	METAL OXIDE	120	5%	3W F
R4207	1-249-397-11	CARBON	22	5%	1/4W F
R4208	1-247-863-91	CARBON	22K	5%	1/4W
R4209	1-249-414-11	CARBON	560	5%	1/4W
R4210	1-249-415-11	CARBON	680	5%	1/4W F
R4211	1-249-414-11	CARBON	560	5%	1/4W
R4212	1-247-863-91	CARBON	22K	5%	1/4W
R4213	1-249-415-11	CARBON	680	5%	1/4W F
R4214	1-249-429-11	CARBON	10K	5%	1/4W F
R4215	1-249-384-11	CARBON	1.8	5%	1/4W F
R4216	1-249-384-11	CARBON	1.8	5%	1/4W F
R4217	1-249-401-11	CARBON	47	5%	1/4W F
R4218	1-249-401-11	CARBON	47	5%	1/4W F
R4219	1-216-476-11	METAL OXIDE	180	5%	3W F
R4221	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R4222	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W
R4223	1-208-794-11	METAL CHIP	3.3K	0.50%	1/10W
R4224	1-208-806-11	METAL CHIP	10K	0.50%	1/10W
R4225	1-216-033-00	RES,CHIP	220	5%	1/10W
R4226	1-216-009-91	RES,CHIP	22	5%	1/10W
R4227	1-216-009-91	RES,CHIP	22	5%	1/10W

****

* A-1390-952-A ZB BOARD, COMPLETE
****

4-382-854-11 SCREW(M3X10), P, SW (+)

<CAPACITOR>

C4301	1-163-038-91	CERAMIC CHIP	0.1µF		25V
C4302	1-107-667-11	ELECT	2.2µF	20%	160V
C4303	1-130-471-00	MYLAR	0.001µF	5%	50V
C4304	1-130-471-00	MYLAR	0.001µF	5%	50V
C4305	1-104-987-11	MYLAR	0.001µF	10%	200V
C4306	1-104-987-11	MYLAR	0.001µF	10%	200V
C4307	1-107-364-11	MYLAR	0.01µF	10%	200V
C4308	1-126-968-11	ELECT	100µF	20%	50V
C4309	1-126-968-11	ELECT	100µF	20%	50V
C4310	1-107-645-11	ELECT	22µF	20%	160V
C4311	1-161-830-00	CERAMIC	0.0047µF		500V
C4312	1-104-664-11	ELECT	47µF	20%	16V
C4313	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C4314	1-107-823-11	CERAMIC CHIP	0.47µF	10%	16V
C4315	1-161-830-00	CERAMIC	0.0047µF		500V
C4316	1-163-038-91	CERAMIC CHIP	0.1µF		25V

<CONNECTOR>

CN4301*	1-564-509-11	PLUG, CONNECTOR 6P
CN4302*	1-564-507-11	PLUG, CONNECTOR 4P
CN4303*	1-564-506-11	PLUG, CONNECTOR 3P
CN4304*	1-580-690-11	PIN, CONNECTOR (PC BOARD) 4P
CN4305*	1-564-506-11	PLUG, CONNECTOR 3P

<DIODE>

D4301	8-719-921-86	DIODE MTZJ-13
D4302	8-719-921-86	DIODE MTZJ-13

<CONNECTOR>

DY4301⚠1-451-510-11 DEFLECTION YOKE

<COIL>

L4301	1-414-187-11	INDUCTOR	47µH
L4302	1-414-183-41	INDUCTOR	10µH

<TRANSISTOR>

Q4301	8-729-422-27	TRANSISTOR 2SD601A-Q
Q4303	8-729-045-04	TRANSISTOR 2SC5511
Q4304	8-729-045-05	TRANSISTOR 2SA2005
Q4305	8-729-422-27	TRANSISTOR 2SD601A-Q
Q4306	8-729-422-27	TRANSISTOR 2SD601A-Q
Q4307	8-729-422-27	TRANSISTOR 2SD601A-Q
Q4308	8-729-216-22	TRANSISTOR 2SA1162-G
Q4309	8-729-216-22	TRANSISTOR 2SA1162-G

<RESISTOR>

R4301	1-216-025-91	RES,CHIP	100	5%	1/10W
R4302	1-216-049-91	RES,CHIP	1K	5%	1/10W
R4304	1-216-475-11	METAL OXIDE	120	5%	3W F
R4306	1-216-475-11	METAL OXIDE	120	5%	3W F
R4307	1-249-397-11	CARBON	22	5%	1/4W F
R4308	1-247-863-91	CARBON	22K	5%	1/4W
R4309	1-249-414-11	CARBON	560	5%	1/4W
R4310	1-249-415-11	CARBON	680	5%	1/4W F
R4311	1-249-414-11	CARBON	560	5%	1/4W
R4312	1-247-863-91	CARBON	22K	5%	1/4W
R4313	1-249-415-11	CARBON	680	5%	1/4W F
R4314	1-249-429-11	CARBON	10K	5%	1/4W F
R4315	1-249-384-11	CARBON	1.8	5%	1/4W F
R4316	1-249-384-11	CARBON	1.8	5%	1/4W F
R4317	1-249-401-11	CARBON	47	5%	1/4W F

Les composants identifies par une trame et une marque ⚠ sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.

The components identified by shading and mark ⚠ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION			REMARK
R4318	1-249-401-11	CARBON	47	5% 1/4W	F
R4319	1-216-476-11	METAL OXIDE	180	5% 3W	F
R4321	1-208-806-11	METAL CHIP	10K	0.50% 1/10W	
R4322	1-208-800-11	METAL CHIP	5.6K	0.50% 1/10W	
R4323	1-208-794-11	METAL CHIP	3.3K	0.50% 1/10W	
R4324	1-208-806-11	METAL CHIP	10K	0.50% 1/10W	
R4325	1-216-033-00	RES,CHIP	220	5% 1/10W	
R4326	1-216-009-91	RES,CHIP	22	5% 1/10W	
R4327	1-216-009-91	RES,CHIP	22	5% 1/10W	

****

MISCELLANEOUS
****

⚠	1-223-925-51	RESISTOR ASSY (HIGH-VOLTAGE) (FOCUS PACK)
	1-251-321-12	SELECTOR, ANTENNA
⚠	1-452-790-21	NECK ASSY
	1-500-021-11	CLAMP, SLEEVE FERRITE (61XBR)
	1-505-914-11	SPEAKER (10cm)
	1-505-915-11	SPEAKER (13cm) (53XBR)
	1-505-916-11	SPEAKER (5.2cm)
	1-505-917-11	SPEAKER (16cm) (61XBR)
	1-528-911-11	BATTERY, SOLAR
	1-543-653-11	CORE ASSY, BEAD(DIVISION TYPE)
*	1-556-945-21	CABLE, P-P
*	1-557-056-31	CABLE, P-P
⚠	1-783-595-11	CORD, NOISE FILTER WITH POWER
⚠	8-598-955-12	BLOCK ASSY, HIGH-VOLTAGE
⚠	8-736-087-05	CRT 07MZC2(G)
⚠	8-736-088-05	CRT 07MZC3(B) (53XBR)
⚠	8-736-089-05	CRT 07MZC3(R) (53XBR)
⚠	8-736-090-05	CRT 07MZC4(B) (61XBR)
⚠	8-736-091-05	CRT 07MZC4(R) (61XBR)

****

ACCESSORIES AND PACKING MATERIALS
****

	1-751-347-11	CORD, SPEAKER
	3-867-651-11	MANUAL, INSTRUCTION
	3-867-651-21	MANUAL, INSTRUCTION
	3-867-651-31	MANUAL, INSTRUCTION
	3-867-651-41	MANUAL, INSTRUCTION
*	4-041-428-01	BAG, POLYETHYLENE
*	4-042-463-01	SHEET, PROTECTION
*	4-063-915-01	CUSHION (UPPER) (ASSY) (61XBR)
*	4-063-916-01	CUSHION (LOWER) (ASSY) (61XBR)
*	4-063-921-01	INDIVIDUAL CARTON (61XBR)
*	4-063-922-01	BOARD, BOTTOM (61XBR)
*	4-063-923-01	TRAY (61XBR)
*	4-063-924-01	CUSHION (UPPER) (ASSY) (53XBR)
*	4-063-925-01	CUSHION (LOWER) (ASSY) (53XBR)
*	4-063-930-01	INDIVIDUAL CARTON (53XBR)
*	4-063-931-01	BOARD, BOTTOM (53XBR)
*	4-063-932-01	TRAY (53XBR)
*	4-065-746-01	BOARD, TOP (53XBR)
*	4-065-747-01	BOARD, TOP (61XBR)

REMOTE COMMANDER
****

	1-475-898-11	REMOTE COMMANDER (RM-Y902)
	9-933-736-01	COVER, BATTERY (FOR RM-Y902)

9-965-406-01

Sony Corporation
HDC. PJ Division Company

English
99IA74371-1
Printed in USA
©1999.9