



HOW TO ACCESS THE INTERNET SERVICES

Access the internet services from the standby screen by pressing the  key, then select "Internet" from the menu.



When you have finished browsing, exit the option by pressing  (long keypress).


KEYPAD LAYOUT




When you use the telephone for the first time, you'll be asked to enter your phone number in the format requested by the operator.

⁽¹⁾ Available only if provided by the network.

AVAILABLE OPTIONS

When you have accessed the Web pages, press  and the following options are available to you:

...	Can be accessed from the current page.
Help	Display on line help messages.
Bookmark	The current page may be added to your bookmarks ⁽¹⁾ .
Home page	Go back to the homepage directly.
 Alert List	Access a list of alerts ⁽¹⁾ .
Connect. status	Display the icon bar during an internet session.
Exit Internet	Stop viewing the services provided.
Quit	Close the contextual menu and go back to the current page.

ICON BAR

This icon bar is displayed as soon as you are connected to the Net, or when you access a new page, or when an alert is displayed. It is also displayed when you confirm selection of the "Connect. status" item from the available options.




One message is waiting in your outbox

There is one incoming alert

The current connection is not secure

Access time

Animation for data transmission and reception

In an edit screen, the  icon is replaced by one of the following symbols:

- A You are in alphanumerical entry mode.
- 1 You are in "Numerical" mode.
- & You are in "Symbol" mode.
- ! You are in "Smart" mode.

⁽¹⁾ Available only if provided by the network.