

* How to Enter the "Service Mode " with user remocon.

- 1) Set the TV Pr 91
- 2) Sharpness "MIN "control.
- 3) Red, Green, Yellow buttons in regular sequency within 5 seconds after setting TV power off.
- 4) You can see the Menu of "service mode "on the screen.
- 5) The PR UP/DOWN buttons on the remote controller are used to move the selection bar up or down the Menus.
- 6) The VOL UP/DOWN buttons on the remote controller are used to adjust levels.
- 7) If you want to exit from "Service Mode "then power the TV off.

SVC v1

V. Slope	005
V. Center	995
V. Size	220
S. Curve	019
H. Center	-190
H. Width	510
EW. Para	382
EW. Cor T	028
EW. CB	500
EW.Sym	021
R. b	370
G. b	311
B. b	311
R. d	330
G. d	315
B. d	330
G2	330
Sub Bri	021
DT	048
Wide	Yes

- You can see the SVC Menu by OSD in TV set.

SCHEMATIC DIAGRAM



