




5-1. BLOCK DIAGRAMS



FRAME SCHEMATIC DIAGRAM



5-3. CIRCUIT BOARDS LOCATION












Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note: Les composants identifiés per un tramé et une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- All voltages are in V.
- Readings are taken with a 10 M digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- * : Can not be measured.
- Circled numbers are waveform references.
-  : B + bus.
-  : B - bus.

Terminal name of semiconductors in silk screen printed circuit (*)

	Device	Printed symbol	Terminal name	Circuit
①	Transistor		Collector Base Emitter	
②	Transistor		Collector Base Emitter	
③	Diode		Cathode Anode	
④	Diode		Cathode Anode (NC)	
⑤	Diode		Cathode Anode (NC)	
⑥	Diode		Common Anode Cathode	
⑦	Diode		Common Anode Cathode	
⑧	Diode		Common Anode Anode	
⑨	Diode		Common Anode Anode	
⑩	Diode		Common Cathode Cathode	
⑪	Diode		Common Cathode Cathode	
⑫	Diode		Anode Anode Cathode	
⑬	Transistor (FET)		Source Gate	
⑭	Transistor (FET)		Source Gate	
⑮	Transistor (FET)		Source Gate	
⑯	Transistor		Emitter Collector Base	
—	Discrete semiconductor			

(Chip semiconductors that are not actually used are included.)

Ver.1.5

5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS


Note:

- All capacitors are in μF unless otherwise noted. (pF : μF)
- Capacitors without voltage indication are all 50 V.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm
Rating electrical power 1/4 W (CHIP : 1/10 W)

- All resistors are in ohms.
-  : nonflammable resistor.
-  : fusible resistor.
-  : internal component.
-  : panel designation, and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
-  : earth-ground.
-  : earth-chassis.
- The components identified by  in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.
- Should replacement be required, replace only with the value originally used.
- When replacing components identified by , make the necessary adjustments indicated. (See page 3-1)
- When replacing the part in below table, be sure to perform the related adjustment.


		Part replaced ()
HV Regulator Circuit Check	D Board	IC901, T902 • Mounted D board
HV Protector Circuit Check	D Board	Q660, Q661, D916, D935, C924, R665, R667, R940, R980, T902 • Mounted D board
	G Board	PH680, Q680, Q683, D680, R680, R685, R686, R687, R688, R689 • Mounted G board
Beam Current Protector Circuit Check	D Board	IC901, D904, D907, D908, R011, R908, R909, R921, R925, R926, R929, R930, T902 • Mounted D board




IC			Q528	E-4	E-2	-	D511	C-3	C-3	-
(Conductor Side) (Component Side)			Q660	E-4	E-2	②	D512	C-4	C-2	-
IC001	F-3	-	Q661	F-2	F-2	②	D513	F-1	-	③
IC002	F-3	-	Q701	E-1	E-5	-	D514	A-5	A-1	-
IC003	E-2	E-4	Q703	D-1	D-5	-	D515	E-3	E-3	③
IC004	G-3	-	Q704	D-1	D-5	-	D516	E-3	E-3	③
IC005	F-3	-	Q705	E-1	E-5	-	D517	E-3	E-3	③
IC006	G-1	G-5	Q706	E-1	E-5	-	D518	A-4	C-1	③
IC007	F-4	-	Q707	E-4	E-4	②	D519	C-5	C-2	-
IC008	E-2	E-4	Q708	E-2	E-5	- <th>D520</th> <td>B-4</td> <td>B-1</td> <td>-</td>	D520	B-4	B-1	-
IC009	F-3	-	Q901	D-2	-	①	D521	B-2	E-2	③
IC010	F-5	-	Q902	-	A-3	②	D660	E-2	E-3	③
IC011	G-1	G-5	Q904	D-2	-	①	D701	F-5	F-5	③
IC012	F-3	-	Q905	D-2	-	①	D704	-	-	-
IC013	-	G-3	Q908	E-2	E-4	-	D705	F-1	-	③
IC502	A-5	A-1	Q909	D-2	D-4	-	D706	G-5	-	③
IC505	-	E-4	DIODE				D709	G-5	G-1	-
IC701	F-1	F-5	(Conductor Side) (Component Side) *				D713	E-1	E-5	-
IC702	G-5	G-1	D004	-	G-3	⑦	D714	E-1	E-5	-
IC703	G-4	-	D007	G-2	-	③	D715	E-1	E-5	-
IC901	A-2	-	D008	G-2	-	③	D718	-	E-5	③
TRANSISTOR			D009	G-2	-	③	D720	E-2	E-4	-
(Conductor Side) (Component Side) *			D010	G-2	-	③	D721	E-1	E-5	-
Q001	-	F-5	D012	-	G-2	⑦	D901	D-2	-	③
Q003	F-1	-	D013	-	G-2	⑦	D902	A-3	-	③
Q004	-	F-4	D014	-	G-2	⑦	D903	A-3	A-3	-
Q005	G-2	-	D015	-	G-2	⑦	D904	A-3	-	③
Q006	F-4	-	D016	-	G-3	⑦	D905	A-2	-	③
Q007	-	F-4	D019	F-1	-	⑥	D906	B-2	-	③
Q501	B-4	-	D020	-	G-5	⑦	D907	A-3	-	③
Q502	B-4	-	D025	-	F-5	③	D908	A-3	-	③
Q503	B-4	-	D026	G-3	-	⑥	D909 <td>D-3</td> <td>-</td> <td>③</td>	D-3	-	③
Q504	F-5	-	D027	G-3	-	⑥	D910	C-2	C-4	-
Q505	F-5	-	D028	G-2	-	⑥	D911	D-2	-	③
Q506	F-5	F-5	D029	G-2	-	⑥	D913	-	A-3	③
Q507	B-5	B-1	D032	F-3	-	③	D915	A-3	A-3	-
Q508	D-5	D-1	D033	-	F-3	③	D916	B-3	B-3	-
Q509	E-4	-	D034	F-3	-	⑥	D917	A-2	A-4	-
Q510	E-4	-	D035	F-3	-	⑥	D919	A-3	A-3	-
Q511	A-4	A-2	D050	G-1	-	③	D921	G-3	-	③
Q512	E-3	-	D501	B-5	-	③	D922	B-2	-	③
Q513	E-3	-	D502	B-5	B-1	-	D923	A-2	-	③
Q517	E-5	-	D503	F-5	-	③	D924	-	F-2	③
Q522	E-3	E-3	D504	E-5	E-1	-	D935	B-3	-	③
Q523	E-3	E-3	D505	D-4	D-1	-	D1501	F-3	-	③
Q524	E-3	E-3	D506	B-4	B-2	-	D1502	F-3	-	③
Q525	E-4	E-2	D507	B-4	B-2	-	D1503	F-3	-	③
Q526	E-3	E-3	D508	B-4	B-2	-	CRYSTAL			
Q527	E-3	E-3	D509	E-5	E-1	-	(Conductor Side) (Component Side)			
			D510	D-4	D-2	-	X001	F-4	F-2	-

NOTE:
The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.


(1) Schematic Diagram of D Board



• D BOARD WAVEFORMS




• D BOARD IC701 LA6510



• D BOARD VOLTAGE LIST


Ref.	Pin No.	Voltage [V]	Ref.	Pin No.	Voltage [V]
IC002	5	6		11	0
	6	4.2		12	11.2
	7	0		15	0
IC004	5	4.8		16	8.4
	6	4.8		19	8.2
IC005	1	0.4	Q003	B	5.1
	3	0		C	0
	7	1.5		E	5.7
IC009	7	4.8	Q005	B	2.5
	1	-0.1		C	0
	2	4.7		E	3.1
IC010	1	4.0	Q501	B	11.2
	2	4.5		C	13.8
	3	0.3		E	10.8
IC012	5	0.6	Q502	B	0.2
	6	3.9		C	11.2
	7	4.1			
IC013	1	0	Q503	B	11.2
	2	4.9		E	10.9
	3	0.6			
IC014	8	0.6	Q504	B	2.5
	9	3.6		C	12.0
	10	4.9		E	2.5
IC015	11	0	Q505	B	2.5
	13	5.7		E	2.4
	1	3.5		Q506	B
3	3.5	C	-0.2		
5	2.7	E	-14.0		
IC016	9	0	Q507	G	197.4
	10	0.1		D	41.8
	12	4.9			
IC017	13	4.9	Q508	B	-1.4
	14	3.2		C	41.0
	15	3.9			
IC018	1	0.5	Q509	B	0
	2	4.2		C	14.1
	3	0.5			
IC019	5	0	Q510	B	4.5
	6	0		E	3.9
	7	-10.0			
IC020	1	14.2	Q511	B	3.2
	2	14.2		C	33.5
	3	0		E	2.6
IC021	3	0	Q517	B	4.6
	4	3.6		E	5.1
	6	3.0			
IC022	7	3.0	Q522	G	0
	8	-0.7		D	15.2
	9	-0.7			
IC023	2	0.4	Q523	G	4.7
	3	13.5		D	0
	4	1.2			
IC024	5	1.2	Q524	G	4.7
	7	-13.0		D	0
	1	1.2		Q525	G
2	1.6	D	0		
3	1.8	Q527	G		4.7
5	2.8		D	0	
6	2.8		Q528	G	4.7
7	2.8	D		0	
IC025	1	4.5		Q529	G
	2	0	D		0
	3	0			
IC026	5	0	Q528	G	4.7
	6	0		D	0
	7	-10.0			
IC027	1	14.2	Q660	B	4.2
	2	14.2		C	0
	3	0		E	4.2
IC028	3	0	Q661	B	0
	4	3.6		C	4.2
	6	3.0			
IC029	7	3.0	Q701	B	5.7
	8	-0.7		C	36.0
	9	-0.7		E	5.1
IC030	2	0.4	Q703	B	37.9
	3	13.5		E	37.4
	4	1.2			
IC031	5	1.2	Q704	B	37.4
	7	-13.0		E	37.0
	1	1.2		Q705	B
2	1.6	E	36.6		
3	1.8	Q706	B		36.6
5	2.8		E	37.0	
6	2.8		Q707	B	-0.6
7	2.8	C		-5.0	
IC032	1	4.5		Q708	C
	2	0	B		0.6
	3	0	C		477.0
IC033	5	0	Q901	B	0.1
	6	0		C	9.9
	7	-10.0			
IC034	1	1.2	Q902	B	9.0
	2	1.6		C	0
	3	1.8		E	9.0
IC035	5	2.8	Q904	B	8.6
	6	2.8		C	13.0
	7	2.8		E	8.4
IC036	1	9.3	Q905	B	8.6
	2	5.6		E	8.4
	3	5.0			
IC037	5	1.1	Q908	G	196.6
	6	1.1		D	40.1
	7	0.9			
IC038	8	9.3	Q909	G	8.4
	10	0		D	40.1
	1	9.3			

(2) Schematic Diagrams of G, GA, H, J and L Boards




- GA BOARD
VOLTAGE LIST

Ref.	Pin No.	Voltage [V]
IC7501	1	2.6
	2	2.5
	3	1.7
	4	0.2
	5	0
	7	8.6
Q7501	B	14.0
	C	0
	E	14.0
Q7502	B	0.7
	C	0.1
Q7503	B	0
	C	14.0
Q7504	B	13.4




- L BOARD IC5101, 5301, 5401 LA6510



- G BOARD
VOLTAGE LIST

Ref.	Pin No.	Voltage [V]
IC630	3	2.5
	4	11.6
IC660	IN	6.1
	OUT	410.0
IC690	2	5.0
	3	6.7
PH660	4	5.3
	1	16.7
PH680	1	4.5
	2	3.3
Q610	3	6.1
	4	0.1
Q615	1	1.3
	2	0.1
Q640	3	0
	4	8.7
Q645	G	8.7
	D	102.4
Q640	S	0.2
	B	13.6
Q640	C	14.2
	E	14.3
Q641	B1	–2.0
	C1	199.2
Q642	B2	196.8
	C2	408.0
Q642	E2	199.2
	B	1.1
Q642	C	–2.0
	E	2.0
Q660	B	–1.8
	C	0.9
Q680	B	0.3
	C	0.8
Q681	B	0
	C	0.3
Q682	B	0.3
	C	11.7
Q682	B	11.7
	E	11.7
Q683	B	7.5
	C	8.3
Q690	B	0
	C	15.0
Q691	B	8.6
	C	5.3
Q691	E	6.7



- L BOARD
VOLTAGE LIST

Ref.	Pin No.	Voltage [V]
GS5001	5	2.8
	6	2.8
IC5101	1	1.0
	2	1.0
	3	1.2
	4	1.2
	6	1.2
	7	1.2
	8	-0.2
IC5201	1	1.2
	2	1.2
	4	1.1
IC5301	1	-0.2
	2	-0.2
	3	1.2
	4	1.2
	6	1.2
	7	1.2
	8	0.4
IC5401	9	0.4
	1	0.6
	2	0.6
	3	3.4
	4	3.4
	6	1.8
	7	1.8
	8	0.4
	9	0.4

*: Refer to Terminal name of
semiconductors in silk screen
printed circuit (see page 5-9)

*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 5-9)

*: Refer to Terminal name of semiconductors in silk screen printed circuit (see page 5-9)

A board →



ELECTRICAL PARTS LIST

NOTE:

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

The components identified by Δ in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS

- All resistors are in ohms
- F : nonflammable
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

CAPACITORS

MF : μ F

COILS

UH : μ H

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
		* 8-933-275-00 A BOARD, COMPLETE *****					
		4-382-854-11 SCREW (M3X10), P, SW (+) (IC403)					
		<CAPACITOR>					
C101	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C301	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C102	1-104-664-11	ELECT 47MF	20% 25V	C302	1-104-664-11	ELECT 47MF	20% 25V
C103	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C303	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C104	1-104-664-11	ELECT 47MF	20% 25V	C304	1-104-664-11	ELECT 47MF	20% 25V
C105	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V				
C106	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C305	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C107	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C306	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C108	1-107-903-11	ELECT 2.2MF	20% 50V	C307	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C109	1-163-237-11	CERAMIC CHIP 27PF	5% 50V	C308	1-107-903-11	ELECT 2.2MF	20% 50V
C110	1-163-275-11	CERAMIC CHIP 0.001MF	5% 50V	C309	1-163-099-00	CERAMIC CHIP 18PF	5% 50V
C111	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V	C310	1-163-275-11	CERAMIC CHIP 0.001MF	5% 50V
C112	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C311	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C115	1-104-514-11	FILM 0.22MF	10% 250V	C312	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C120	1-107-949-11	ELECT 2.2MF	20% 200V	C315	1-104-514-11	FILM 0.22MF	10% 250V
C121	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C317	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C122	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C319	1-107-888-11	ELECT 47MF	20% 25V
C127	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C320	1-107-949-11	ELECT 2.2MF	20% 200V
C130	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C321	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C201	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C322	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C202	1-104-664-11	ELECT 47MF	20% 25V	C330	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C203	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C401	1-126-964-11	ELECT 10MF	20% 50V
C204	1-104-664-11	ELECT 47MF	20% 25V	C402	1-104-664-11	ELECT 47MF	20% 25V
C205	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C403	1-104-664-11	ELECT 47MF	20% 25V
C206	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C404	1-126-964-11	ELECT 10MF	20% 50V
C207	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C405	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V
C208	1-107-903-11	ELECT 2.2MF	20% 50V	C407	1-126-964-11	ELECT 10MF	20% 50V
C209	1-163-235-11	CERAMIC CHIP 22PF	5% 50V	C408	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C210	1-163-275-11	CERAMIC CHIP 0.001MF	5% 50V	C409	1-163-235-11	CERAMIC CHIP 22PF	5% 50V
C211	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V	C410	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C212	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C412	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C215	1-104-514-11	FILM 0.22MF	10% 250V	C414	1-163-239-11	CERAMIC CHIP 33PF	5% 50V
C217	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C415	1-128-562-11	ELECT 47MF	20% 100V
C220	1-107-949-11	ELECT 2.2MF	20% 200V	C416	1-104-664-11	ELECT 47MF	20% 25V
C221	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C417	1-115-349-51	CERAMIC 0.01MF	2KV
C222	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C419	1-162-318-11	CERAMIC 0.001MF	10% 500V
C230	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C420	1-126-967-11	ELECT 47MF	20% 50V
				C421	1-126-964-11	ELECT 10MF	20% 50V
				C424	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C429	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V
				C431	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
				C434	1-162-318-11	CERAMIC 0.001MF	10% 500V
				C435	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
				C436	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
				C438	1-163-243-11	CERAMIC CHIP 47PF	5% 50V



Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
<IC LINK>				R130	1-216-097-91	RES, CHIP	100K
PS401 Δ 1-533-590-31LINK, IC (1A/90V AC, 60V DC)				R131	1-216-057-00	RES, CHIP	2.2K
<TRANSISTOR>				R132	1-216-035-00	RES, CHIP	270
Q101	8-729-112-65	TRANSISTOR 2SA1462-Y33		R133	1-216-049-91	RES, CHIP	1.0K
Q105	8-729-041-66	TRANSISTOR 2SC4015TV2		R134	1-216-097-91	RES, CHIP	100K
Q106	8-729-200-17	TRANSISTOR 2SA1091-O		R135	1-216-037-00	RES, CHIP	330
Q201	8-729-112-65	TRANSISTOR 2SA1462-Y33		R136	1-216-097-91	RES, CHIP	100K
Q202	8-729-107-31	TRANSISTOR 2SC3545-T43		R137	1-216-097-91	RES, CHIP	100K
Q205	8-729-041-66	TRANSISTOR 2SC4015TV2		R138	1-216-673-11	METAL CHIP	8.2K 0.50%1/10W
Q206	8-729-200-17	TRANSISTOR 2SA1091-O		R139	1-216-073-00	RES, CHIP	10K
Q301	8-729-112-65	TRANSISTOR 2SA1462-Y33		R140	1-216-129-00	RES, CHIP	2.2M
Q305	8-729-041-66	TRANSISTOR 2SC4015TV2		R141	1-216-025-91	RES, CHIP	100
Q306	8-729-200-17	TRANSISTOR 2SA1091-O		R142	1-216-673-11	METAL CHIP	8.2K 0.50%1/10W
Q401	8-729-216-22	TRANSISTOR 2SA1162-G		R144	1-216-295-91	SHORT	0
Q402	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R167	1-216-121-91	RES, CHIP	1.0M
Q403	8-729-216-22	TRANSISTOR 2SA1162-G		R201	1-215-395-00	METAL	82 1% 1/4W
Q404	8-729-901-00	TRANSISTOR DTC124EK		R202	1-216-025-91	RES, CHIP	100
Q405	8-729-216-22	TRANSISTOR 2SA1162-G		R203	1-215-395-00	METAL	82 1% 1/4W
Q406	8-729-027-31	TRANSISTOR DTA124EKA-T146		R204	1-216-025-91	RES, CHIP	100
Q407	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R205	1-216-021-00	RES, CHIP	68
Q408	8-729-027-31	TRANSISTOR DTA124EKA-T146		R206	1-216-015-00	RES, CHIP	39
Q409	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R208	1-216-099-00	RES, CHIP	120K
Q410	8-729-020-07	TRANSISTOR 2SC4686A(LBSONY)		R209	1-216-107-00	RES, CHIP	270K
<RESISTOR>				R210	1-216-295-91	SHORT	0
R101	1-215-395-00	METAL	82 1% 1/4W	R211	1-216-049-91	RES, CHIP	1.0K
R102	1-216-025-91	RES, CHIP	100	R212	1-216-619-11	METAL CHIP	47 0.50%1/10W
R103	1-215-395-00	METAL	82 1% 1/4W	R213	1-216-009-00	RES, CHIP	22
R104	1-216-025-91	RES, CHIP	100	R214	1-216-035-00	RES, CHIP	270
R105	1-216-021-00	RES, CHIP	68	R215	1-216-035-00	RES, CHIP	270
R106	1-216-019-00	RES, CHIP	56	R216	1-216-017-91	RES, CHIP	47
R108	1-216-099-00	RES, CHIP	120K	R217	1-216-063-91	RES, CHIP	3.9K
R109	1-216-107-00	RES, CHIP	270K	R218	1-216-057-00	RES, CHIP	2.2K
R110	1-216-295-91	SHORT	0	R219	1-216-015-00	RES, CHIP	39
R111	1-216-049-91	RES, CHIP	1.0K	R220	1-216-097-91	RES, CHIP	100K
R112	1-216-619-11	METAL CHIP	47 0.50%1/10W	R221	1-216-097-91	RES, CHIP	100K
R113	1-216-009-00	RES, CHIP	22	R222	1-216-027-00	RES, CHIP	120
R114	1-216-035-00	RES, CHIP	270	R223	1-216-027-00	RES, CHIP	120
R115	1-216-035-00	RES, CHIP	270	R224	1-219-497-11	CARBON	22 5% 1/2W
R116	1-216-017-91	RES, CHIP	47	R225	1-216-693-11	METAL CHIP	56K 0.50%1/10W
R117	1-216-063-91	RES, CHIP	3.9K	R226	1-216-097-91	RES, CHIP	100K
R118	1-216-057-00	RES, CHIP	2.2K	R227	1-216-035-00	RES, CHIP	270
R119	1-216-015-00	RES, CHIP	39	R228	1-216-121-91	RES, CHIP	1.0M
R120	1-216-097-91	RES, CHIP	100K	R229	1-218-776-11	METAL CHIP	1M 0.50%1/10W
R121	1-216-097-91	RES, CHIP	100K	R230	1-216-097-91	RES, CHIP	100K
R122	1-216-027-00	RES, CHIP	120	R231	1-216-057-00	RES, CHIP	2.2K
R123	1-216-027-00	RES, CHIP	120	R232	1-216-035-00	RES, CHIP	270
R124	1-219-497-11	CARBON	22 5% 1/2W	R233	1-216-049-91	RES, CHIP	1.0K
R125	1-216-693-11	METAL CHIP	56K 0.50%1/10W	R234	1-216-097-91	RES, CHIP	100K
R126	1-216-097-91	RES, CHIP	100K	R235	1-216-037-00	RES, CHIP	330
R127	1-216-035-00	RES, CHIP	270	R236	1-216-097-91	RES, CHIP	100K
R128	1-216-121-91	RES, CHIP	1.0M	R237	1-216-097-91	RES, CHIP	100K
R129	1-218-776-11	METAL CHIP	1M 0.50%1/10W	R238	1-216-673-11	METAL CHIP	8.2K 0.50%1/10W
				R239	1-216-073-00	RES, CHIP	10K
				R240	1-216-129-00	RES, CHIP	2.2M
				R241	1-216-025-91	RES, CHIP	100
				R242	1-216-673-11	METAL CHIP	8.2K 0.50%1/10W



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R243	1-216-043-91	RES, CHIP	560	R417	1-216-089-91	RES, CHIP	47K
R244	1-216-295-91	SHORT	0	R418	1-260-127-11	CARBON	220K 5% 1/2W
R267	1-216-121-91	RES, CHIP	1.0M	R419	1-216-687-11	METAL CHIP	33K 0.50%1/10W
R301	1-215-395-00	METAL	82	R420	1-216-691-11	METAL CHIP	47K 0.50%1/10W
R302	1-216-025-91	RES, CHIP	100	R421	1-216-103-00	RES, CHIP	180K
R303	1-215-395-00	METAL	82				
				R422	1-216-025-91	RES, CHIP	100
R304	1-216-025-91	RES, CHIP	100	R423	1-216-089-91	RES, CHIP	47K
R305	1-216-021-00	RES, CHIP	68	R424	1-216-025-91	RES, CHIP	100
R306	1-216-015-00	RES, CHIP	39	R425	1-216-017-91	RES, CHIP	47
R308	1-216-099-00	RES, CHIP	120K	R426	1-216-025-91	RES, CHIP	100
R309	1-216-107-00	RES, CHIP	270K				
				R427	1-216-025-91	RES, CHIP	100
R310	1-216-295-91	SHORT	0	R428	1-216-049-91	RES, CHIP	1.0K
R311	1-216-049-91	RES, CHIP	1.0K	R429	1-216-025-91	RES, CHIP	100
R312	1-216-619-11	METAL CHIP	47	R430	1-216-025-91	RES, CHIP	100
R313	1-216-009-00	RES, CHIP	22	R431	1-216-025-91	RES, CHIP	100
R314	1-216-035-00	RES, CHIP	270				
				R432	1-216-025-91	RES, CHIP	100
R315	1-216-035-00	RES, CHIP	270	R433	1-216-025-91	RES, CHIP	100
R316	1-216-017-91	RES, CHIP	47	R434	1-216-065-00	RES, CHIP	4.7K
R317	1-216-063-91	RES, CHIP	3.9K	R435	1-216-121-91	RES, CHIP	1.0M
R318	1-216-057-00	RES, CHIP	2.2K	R436	1-216-067-00	RES, CHIP	5.6K
R319	1-216-015-00	RES, CHIP	39				
				R438	1-216-053-00	RES, CHIP	1.5K
R320	1-216-097-91	RES, CHIP	100K	R439	1-216-053-00	RES, CHIP	1.5K
R321	1-216-097-91	RES, CHIP	100K	R440	1-216-079-00	RES, CHIP	18K
R322	1-216-027-00	RES, CHIP	120	R441	1-216-025-91	RES, CHIP	100
R323	1-216-027-00	RES, CHIP	120	R442	1-216-659-11	METAL CHIP	2.2K 0.50%1/10W
R324	1-219-497-11	CARBON	22				
				R443	1-216-041-00	RES, CHIP	470
R325	1-216-693-11	METAL CHIP	56K	R444	1-216-057-00	RES, CHIP	2.2K
R326	1-216-097-91	RES, CHIP	100K	R446	1-216-025-91	RES, CHIP	100
R327	1-216-035-00	RES, CHIP	270	R447	1-216-041-00	RES, CHIP	470
R328	1-216-121-91	RES, CHIP	1.0M	R448	1-216-057-00	RES, CHIP	2.2K
R329	1-218-776-11	METAL CHIP	1M				
				R449	1-216-073-00	RES, CHIP	10K
R330	1-216-097-91	RES, CHIP	100K	R450	1-216-079-00	RES, CHIP	18K
R331	1-216-057-00	RES, CHIP	2.2K	R451	1-216-025-91	RES, CHIP	100
R332	1-216-035-00	RES, CHIP	270	R452	1-216-065-00	RES, CHIP	4.7K
R333	1-216-049-91	RES, CHIP	1.0K	R453	1-216-073-00	RES, CHIP	10K
R334	1-216-097-91	RES, CHIP	100K				
				R454	1-216-073-00	RES, CHIP	10K
R335	1-216-037-00	RES, CHIP	330	R456	1-216-089-91	RES, CHIP	47K
R336	1-216-097-91	RES, CHIP	100K	R457	1-219-720-11	METAL	10M 5% 1W
R337	1-216-097-91	RES, CHIP	100K	R458	1-211-885-21	METAL	2.2M 5% 1W
R338	1-216-673-11	METAL CHIP	8.2K	R459	1-219-720-11	METAL	10M 5% 1W
R339	1-216-073-00	RES, CHIP	10K				
				R461	1-249-441-11	CARBON	100K 5% 1/4W
R340	1-216-129-00	RES, CHIP	2.2M	R462	1-216-089-91	RES, CHIP	47K
R341	1-216-025-91	RES, CHIP	100	R463	1-216-099-00	RES, CHIP	120K
R342	1-216-673-11	METAL CHIP	8.2K	R464	1-216-057-00	RES, CHIP	2.2K
R344	1-216-295-91	SHORT	0	R466	1-216-675-11	METAL CHIP	10K 0.50%1/10W
R367	1-216-121-91	RES, CHIP	1.0M				
				R470	1-216-065-00	RES, CHIP	4.7K
R406	1-216-049-91	RES, CHIP	1.0K	R471	1-216-069-00	RES, CHIP	6.8K
R407	1-216-089-91	RES, CHIP	47K	R473	1-216-073-00	RES, CHIP	10K
R408	1-216-097-91	RES, CHIP	100K	R475	1-216-073-00	RES, CHIP	10K
R409	1-216-049-91	RES, CHIP	1.0K	R477	1-216-081-00	RES, CHIP	22K
R410	1-216-049-91	RES, CHIP	1.0K				
				R478	1-249-381-11	CARBON	1 5% 1/4W F
R411	1-216-065-00	RES, CHIP	4.7K	R479	1-249-381-11	CARBON	1 5% 1/4W F
R412	1-216-053-00	RES, CHIP	1.5K	R480	1-249-381-11	CARBON	1 5% 1/4W F
R413	1-216-065-00	RES, CHIP	4.7K				
R415	1-216-065-00	RES, CHIP	4.7K				
R416	1-216-049-91	RES, CHIP	1.0K				

A G A

The components identified by shading and mark are critical for safety.
Replace only with part number specified.

7-5

The components identified by shading
and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par un trame
et une marque Δ sont critiques pour la
sécurité. Ne les remplacer que par une
pièce portant le numéro spécifié.

A4576



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
C682	1-126-963-11	ELECT	4.7MF 20% 50V	<FERRITE BEAD>			
C683	1-164-646-11	CERAMIC	2200PF 10% 500V	FB610	1-410-396-41	INDUCTOR	0.45UH
C684	1-137-370-11	FILM	0.01MF 5% 50V	FB611	1-410-396-41	INDUCTOR	0.45UH
C685	1-107-909-11	ELECT	47MF 20% 50V	FB612	1-410-396-41	INDUCTOR	0.45UH
C690	1-107-888-11	ELECT	47MF 20% 25V	<IC>			
C691	1-107-888-11	ELECT	47MF 20% 25V	IC630	8-749-013-03	IC DM-60	
C692	1-111-016-11	ELECT	0.0012F 20% 10V	IC660	8-759-470-64	IC TOP223Y-BB	
C693	1-137-399-11	FILM	0.1MF 5% 50V	IC690	8-749-011-42	IC SI-3050F	
C695	1-164-644-11	CERAMIC	330PF 10% 500V	IC691	8-759-140-85	IC UPC1093J	
C697	1-136-165-00	FILM	0.1MF 5% 50V	<COIL>			
<CONNECTOR>				L610	1-416-409-11	COIL, CHOKE	
CN603*	1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P		L611	1-411-674-11	COIL, CHOKE	68UH
CN604	1-691-960-11	PIN, CONNECTOR (PC BOARD) 3P		L670	1-412-529-11	INDUCTOR	22UH
CN605	1-691-960-11	PIN, CONNECTOR (PC BOARD) 3P		L671	1-412-529-11	INDUCTOR	22UH
CN610*	1-774-511-11	CONNECTOR, BOARD TO BOARD 10P		L672	1-412-529-11	INDUCTOR	22UH
CN671*	1-564-514-11	PLUG, CONNECTOR 11P		L673	1-412-529-11	INDUCTOR	22UH
CN672*	1-564-512-11	PLUG, CONNECTOR 9P		L691	1-412-529-11	INDUCTOR	22UH
CN673*	1-564-508-11	PLUG, CONNECTOR 5P		<PHOTO COUPLER>			
<DIODE>				PH660	8-749-010-64	PHOTO COUPLER PC123F2	
D610 Δ	8-719-510-53	DIODE D4SB60L		PH680	8-749-010-64	PHOTO COUPLER PC123F2	
D611	8-719-029-04	DIODE D5L60		<IC LINK>			
D612	8-719-304-63	DIODE RM11C		PS670 Δ	1-533-593-31	LINK, IC (2A/90V AC, 60V DC)	
D613	8-719-110-49	ZENER DIODE RD18ESB2		PS671 Δ	1-533-593-31	LINK, IC (2A/90V AC, 60V DC)	
D614	8-719-977-28	ZENER DIODE DTZ10B		PS673 Δ	1-533-593-31	LINK, IC (2A/90V AC, 60V DC)	
D617	8-719-404-49	DIODE MA111		PS674 Δ	1-533-593-31	LINK, IC (2A/90V AC, 60V DC)	
D640	8-719-404-49	DIODE MA111		<TRANSISTOR>			
D660	8-719-059-23	DIODE P6KE200AG23		Q610	8-729-041-65	TRANSISTOR 2SK2195F04	
D661	8-719-979-64	DIODE UF4005PKG23		Q615	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
D662	8-719-058-91	DIODE AG01A-V0		Q640	8-729-041-12	TRANSISTOR MX0841AB-F	
D663	8-719-110-31	ZENER DIODE RD12ESB2		Q641	8-729-119-76	TRANSISTOR 2SA1175-HFE	
D666	8-719-109-93	ZENER DIODE RD6.2ESB2		Q642	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D670	8-719-064-49	DIODE D4SBL40		Q660	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D671	8-719-510-64	DIODE S2LA20F		Q680	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
D672	8-719-052-91	DIODE D4SBS4-F		Q681	8-729-230-45	TRANSISTOR 2SC2458-YGR	
D673	8-719-022-97	DIODE D2S4MF		Q682	8-729-119-76	TRANSISTOR 2SA1175-HFE	
D674	8-719-022-97	DIODE D2S4MF		Q683	8-729-119-76	TRANSISTOR 2SA1175-HFE	
D677	8-719-911-19	DIODE 1SS119-25		Q690	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D678	8-719-911-19	DIODE 1SS119-25		Q691	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
D680	8-719-404-49	DIODE MA111		<RESISTOR>			
D681	8-719-404-49	DIODE MA111		R601 Δ	1-220-825-91	CARBON	330K 5% 1/2W
D682	8-719-510-64	DIODE S2LA20F		R604	1-260-089-11	CARBON	150 5% 1/2W
D683	8-719-911-19	DIODE 1SS119-25		R610	1-216-383-11	METAL OXIDE	0.33 5% 3W F
D684	8-719-110-57	ZENER DIODE RD22ESB2		R611	1-216-383-11	METAL OXIDE	0.33 5% 3W F
D691	8-719-510-37	DIODE D5LC20U		R612	1-215-477-00	METAL	220K 1% 1/4W
D692	8-719-911-19	DIODE 1SS119-25					
D693	8-719-404-49	DIODE MA111					
<FUSE>							
F601 Δ	1-576-233-11	FUSE (H.B.C.) (6.3A/250V)					
	1-533-223-11	HOLDER, FUSE ; F601					



Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R613	1-215-477-00	METAL 220K	1% 1/4W	R687	1-216-049-91	RES, CHIP 1.0K	
R614	1-215-473-00	METAL 150K	1% 1/4W	R688	1-216-073-00	RES, CHIP 10K	
R615	1-215-473-00	METAL 150K	1% 1/4W	R689	1-216-073-00	RES, CHIP 10K	
R616	1-215-473-00	METAL 150K	1% 1/4W	R691	1-216-073-00	RES, CHIP 10K	
R617	1-215-481-00	METAL 330K	1% 1/4W				
R618	1-215-477-00	METAL 220K	1% 1/4W	R692	1-260-085-11	CARBON 68	5% 1/2W
R619	1-215-485-00	METAL 470K	1% 1/4W	R693	1-216-065-00	RES, CHIP 4.7K	
R620	1-215-485-00	METAL 470K	1% 1/4W	R694	1-216-073-00	RES, CHIP 10K	
R621	1-215-481-00	METAL 330K	1% 1/4W	R695	1-249-443-11	CARBON 0.47	5% 1/4W F
R622	1-216-049-91	RES, CHIP 1.0K		R696	1-216-633-11	METAL CHIP 180	0.50%1/10W
R623	1-216-651-11	METAL CHIP 1K	0.50%1/10W	R697	1-216-649-11	METAL CHIP 820	0.50%1/10W
R624	1-216-671-11	METAL CHIP 6.8K	0.50%1/10W	R698	1-216-073-00	RES, CHIP 10K	
R625	1-249-389-11	CARBON 4.7	5% 1/4W	R699	1-216-081-00	RES, CHIP 22K	
R626	1-249-429-11	CARBON 10K	5% 1/4W				
R627	1-215-479-00	METAL 270K	1% 1/4W	<RELAY>			
R628	1-215-481-00	METAL 330K	1% 1/4W	RY601 Δ 1-515-669-21	RELAY		
R629	1-215-461-00	METAL 47K	1% 1/4W	RY602 Δ 1-755-031-11	RELAY		
R631	1-247-807-31	CARBON 100	5% 1/4W				
R632	1-216-073-00	RES, CHIP 10K		<TRANSFORMER>			
R633	1-215-481-00	METAL 330K	1% 1/4W	T601 Δ 1-429-180-11	TRANSFORMER, LINE FILTER		
R635	1-216-073-00	RES, CHIP 10K		T640	1-431-538-11	TRANSFORMER, CONVERTER (PIT)	
R640	1-202-933-61	FUSIBLE 0.1	10% 1/2W F	T641	1-429-992-11	TRANSFORMER, CONVERTER (PRT)	
R641	1-218-642-11	METAL OXIDE 100K	5% 1W F	T660	1-431-565-11	TRANSFORMER, CONVERTER (SRT)	
R642	1-218-642-11	METAL OXIDE 100K	5% 1W F				
R643	1-247-863-91	CARBON 22K	5% 1/4W	<THERMISTOR>			
R644	1-216-105-91	RES, CHIP 220K		TH601 Δ 1-809-260-11	THERMISTOR, POWER		
R645	1-216-081-00	RES, CHIP 22K		THP601 Δ 1-809-827-11	THERMISTOR, POSITIVE		
R646	1-216-073-00	RES, CHIP 10K					
R647	1-249-441-11	CARBON 100K	5% 1/4W	<VARISTOR>			
R648	1-216-353-00	METAL OXIDE 2.2	5% 1W F	VDR601 Δ 1-801-268-51	VARISTOR TNR14V471K660		
R649	1-218-642-11	METAL OXIDE 100K	5% 1W F	VDR602 Δ 1-810-622-21	VARISTOR		
R650	1-218-642-11	METAL OXIDE 100K	5% 1W F	VDR640	1-810-974-21	VARISTOR TNR10V431K660	
R651	1-216-353-00	METAL OXIDE 2.2	5% 1W F				
R652	1-212-942-00	FUSIBLE 2.2	5% 1/2W F				
R655	1-216-073-00	RES, CHIP 10K					
R661	1-249-387-11	CARBON 3.3	5% 1/4W F				
R662	1-216-073-00	RES, CHIP 10K					
R663	1-216-073-00	RES, CHIP 10K					
R664	1-247-791-91	CARBON 22	5% 1/4W				
R665	1-216-033-00	RES, CHIP 220					
R666	1-215-441-00	METAL 6.8K	1% 1/4W				
R667	1-215-433-00	METAL 3.3K	1% 1/4W				
R668	1-249-401-11	CARBON 47	5% 1/4W				
R669	1-216-057-00	RES, CHIP 2.2K					
R671	1-216-113-00	RES, CHIP 470K					
R672	1-216-049-91	RES, CHIP 1.0K					
R673	1-249-413-11	CARBON 470	5% 1/4W F				
R674	1-249-377-11	CARBON 0.47	5% 1/4W F				
R675	1-260-292-11	CARBON 1	5% 1/2W				
R676	1-249-413-11	CARBON 470	5% 1/4W				
R680	1-216-073-00	RES, CHIP 10K					
R681	1-216-049-91	RES, CHIP 1.0K					
R682	1-216-065-00	RES, CHIP 4.7K					
R683	1-216-025-91	RES, CHIP 100					
R685	1-216-073-00	RES, CHIP 10K					
R686	1-216-049-91	RES, CHIP 1.0K					



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
<CAPACITOR>				C058	1-126-964-11	ELECT 10MF	20% 50V
C001	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C059	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C002	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C060	1-126-964-11	ELECT 10MF	20% 50V
C003	1-163-019-00	CERAMIC CHIP 0.0068MF	10% 50V	C061	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C004	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C062	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C005	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C063	1-137-399-11	FILM 0.1MF	5% 50V
C006	1-126-960-11	ELECT 1MF	20% 50V	C065	1-126-965-11	ELECT 22MF	20% 50V
C007	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C066	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C008	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C067	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
C009	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C068	1-126-964-11	ELECT 10MF	20% 50V
C010	1-163-235-11	CERAMIC CHIP 22PF	5% 50V	C069	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C011	1-163-235-11	CERAMIC CHIP 22PF	5% 50V	C070	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C012	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C072	1-126-960-11	ELECT 1MF	20% 50V
C013	1-126-967-11	ELECT 47MF	20% 50V	C074	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V
C014	1-107-914-11	ELECT 1000MF	20% 25V	C075	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C015	1-107-914-11	ELECT 1000MF	20% 25V	C076	1-163-809-11	CERAMIC CHIP 0.047MF	10% 25V
C016	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C077	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C017	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C078	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C018	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C079	1-126-967-11	ELECT 47MF	20% 50V
C019	1-126-967-11	ELECT 47MF	20% 50V	C080	1-126-967-11	ELECT 47MF	20% 50V
C020	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C081	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C021	1-163-023-00	CERAMIC CHIP 0.015MF	10% 50V	C082	1-126-964-11	ELECT 10MF	20% 50V
C022	1-126-933-11	ELECT 100MF	20% 16V	C084	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C023	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C085	1-137-399-11	FILM 0.1MF	5% 50V
C024	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C086	1-126-964-11	ELECT 10MF	20% 50V
C025	1-126-960-11	ELECT 1MF	20% 50V	C087	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C026	1-137-372-11	FILM 0.022MF	5% 50V	C088	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C027	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C089	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C028	1-164-695-11	CERAMIC CHIP 0.0022MF	5% 50V	C092	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C029	1-126-960-11	ELECT 1MF	20% 50V	C093	1-126-964-11	ELECT 10MF	20% 50V
C030	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C094	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C031	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C095	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C032	1-163-019-00	CERAMIC CHIP 0.0068MF	10% 50V	C096	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C034	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C097	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C035	1-163-253-11	CERAMIC CHIP 120PF	5% 50V	C098	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C036	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C099	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C037	1-126-934-11	ELECT 220MF	20% 16V	C501	1-107-909-11	ELECT 47MF	20% 50V
C038	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C502	1-163-259-91	CERAMIC CHIP 220PF	5% 50V
C039	1-126-964-11	ELECT 10MF	20% 50V	C503	1-136-169-00	FILM 0.22MF	5% 50V
C040	1-126-963-11	ELECT 4.7MF	20% 50V	C504	1-137-605-11	FILM 0.01MF	10% 250V
C041	1-126-960-11	ELECT 1MF	20% 50V	C505	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C042	1-126-967-11	ELECT 47MF	20% 50V	C506	1-136-169-00	FILM 0.22MF	5% 50V
C043	1-126-967-11	ELECT 47MF	20% 50V	C507	1-136-173-00	FILM 0.47MF	5% 50V
C044	1-126-967-11	ELECT 47MF	20% 50V	C508	1-163-037-11	CERAMIC CHIP 0.022MF	10% 50V
C045	1-163-137-00	CERAMIC CHIP 680PF	5% 50V	C509	1-126-941-11	ELECT 470MF	20% 25V
C046	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C510	1-137-368-11	FILM 0.0047MF	5% 50V
C047	1-126-934-11	ELECT 220MF	20% 16V	C511	1-117-398-11	ELECT 33MF	20% 250V
C048	1-164-695-11	CERAMIC CHIP 0.0022MF	5% 50V	C512	1-107-889-11	ELECT 220MF	20% 25V
C049	1-163-137-00	CERAMIC CHIP 680PF	5% 50V	C513	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C050	1-163-809-11	CERAMIC CHIP 0.047MF	10% 25V	C514	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C051	1-126-960-11	ELECT 1MF	20% 50V	C515	1-107-889-11	ELECT 220MF	20% 25V
C052	1-163-809-11	CERAMIC CHIP 0.047MF	10% 25V	C516	1-137-399-11	FILM 0.1MF	5% 50V
C054	1-126-963-11	ELECT 4.7MF	20% 50V	C517	1-104-574-11	CERAMIC 0.0047MF	10% 2KV
C055	1-126-963-11	ELECT 4.7MF	20% 50V	C518	1-117-959-11	FILM 4700PF	3% 1.8KV
C056	1-163-809-11	CERAMIC CHIP 0.047MF	10% 25V	C519	1-107-444-11	CERAMIC 100PF	5% 2KV
C057	1-107-909-11	ELECT 47MF	20% 50V	C520	1-136-553-11	FILM 0.0015MF	5% 630V



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
C521	1-162-815-11	CERAMIC 47PF	5% 500V	C747	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C522	1-107-444-11	CERAMIC 100PF	5% 2KV	C750	1-126-964-11	ELECT 10MF	20% 50V
C523	1-137-370-11	FILM 0.01MF	5% 50V	C751	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C524	1-113-694-11	FILM 0.056MF	5% 250V				
C525	1-107-846-11	FILM 0.1MF	5% 250V	C901	1-107-889-11	ELECT 220MF	20% 25V
C526	1-115-514-11	FILM 0.22MF	5% 250V	C902	1-163-809-11	CERAMIC CHIP 0.047MF	10% 25V
C527	1-115-517-11	FILM 0.39MF	5% 250V	C903	1-163-259-91	CERAMIC CHIP 220PF	5% 50V
C528	1-115-521-11	FILM 0.82MF	5% 250V	C904	1-137-605-11	FILM 0.01MF	10% 250V
C529	1-107-683-11	ELECT 2.2MF	0 250V	C905	1-104-653-11	ELECT 220MF	20% 16V
C530	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C906	1-106-220-00	MYLAR 0.1MF	10% 100V
C531	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C907	1-119-748-11	ELECT 33MF	20% 400V
C532	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C908	1-136-169-00	FILM 0.22MF	5% 50V
C533	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C909	1-106-355-12	MYLAR 0.0033MF	10% 200V
C534	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C910	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C535	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C911	1-163-275-11	CERAMIC CHIP 0.001MF	5% 50V
C536	1-128-526-11	ELECT 100MF	20% 25V	C912	1-163-275-11	CERAMIC CHIP 0.001MF	5% 50V
C537	1-115-523-21	FILM 1.2MF	5% 250V	C913	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C538	1-117-958-11	FILM 0.24MF	5% 400V	C914	1-163-275-11	CERAMIC CHIP 0.001MF	5% 50V
C539	1-107-960-11	ELECT 4.7MF	20% 250V	C915	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C540	1-106-343-00	MYLAR 0.001MF	10% 200V	C916	1-136-064-00	FILM 2200PF	3% 1.2KV
C541	1-163-243-11	CERAMIC CHIP 47PF	5% 50V	C917	1-107-889-11	ELECT 220MF	20% 25V
C542	1-163-243-11	CERAMIC CHIP 47PF	5% 50V	C919	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C544	1-137-368-11	FILM 0.0047MF	5% 50V	C920	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V
C545	1-126-967-11	ELECT 47MF	20% 50V	C921	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
C547	1-126-967-11	ELECT 47MF	20% 50V	C922	1-117-665-11	FILM 0.33MF	5% 200V
C549	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C923	1-106-359-00	MYLAR 0.0047MF	10% 100V
C550	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C924	1-106-220-00	MYLAR 0.1MF	10% 100V
C551	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C925	1-137-372-11	FILM 0.022MF	5% 50V
C553	1-126-963-11	ELECT 4.7MF	20% 50V	C926	1-106-228-00	MYLAR 0.22MF	10% 100V
C554	1-163-037-11	CERAMIC CHIP 0.022MF	10% 50V	C927	1-107-903-11	ELECT 2.2MF	20% 50V
C555	1-163-037-11	CERAMIC CHIP 0.022MF	10% 50V	C928	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C556	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C929	1-128-526-11	ELECT 100MF	20% 25V
C557	1-115-185-11	CERAMIC CHIP 0.033MF	10% 50V	C930	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C559	1-162-134-11	CERAMIC 470PF	10% 2KV	C931	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C561	1-136-173-00	FILM 0.47MF	5% 50V	C945	1-107-909-11	ELECT 47MF	20% 50V
C562	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C1003	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C563	1-117-214-11	CERAMIC 0.001MF	10% 2KV	C1004	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C564	1-126-963-11	ELECT 4.7MF	20% 50V	C1005	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C666	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C1006	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C667	1-126-967-11	ELECT 47MF	20% 50V	C1007	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C701	1-126-967-11	ELECT 47MF	20% 50V	C1008	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C702	1-137-399-11	FILM 0.1MF	5% 50V	C1009	1-126-960-11	ELECT 1MF	20% 50V
C705	1-126-942-61	ELECT 1000MF	20% 25V	C1501	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C706	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C1502	1-117-722-11	ELECT 2200MF	20% 10V
C707	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C1503	1-163-001-11	CERAMIC CHIP 220PF	10% 50V
C709	1-137-399-11	FILM 0.1MF	5% 50V				
C710	1-163-019-00	CERAMIC CHIP 0.0068MF	10% 50V				
C711	1-107-894-11	ELECT 220MF	20% 35V				
C712	1-106-228-00	MYLAR 0.22MF	10% 100V				
C713	1-126-942-61	ELECT 1000MF	20% 25V				
C714	1-126-967-11	ELECT 47MF	20% 50V				
C715	1-107-932-11	ELECT 47MF	20% 100V				
C717	1-107-930-91	ELECT 22MF	20% 100V				
C729	1-162-134-11	CERAMIC 470PF	10% 2KV				
C735	1-137-399-11	FILM 0.1MF	5% 50V				
C746	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V				

<CONNECTOR>

CN501*1-564-512-11 PLUG, CONNECTOR 9P
 CN502*1-564-514-11 PLUG, CONNECTOR 11P
 CN503*1-564-510-11 PLUG, CONNECTOR 7P
 CN504*1-564-508-11 PLUG, CONNECTOR 5P
 CN505*1-508-879-11 BASE POST

CN506*1-564-511-11 PLUG, CONNECTOR 8P
 CN507 1-764-101-11 PIN, CONNECTOR (PC BOARD) 2P
 CN508*1-778-955-11 PIN, CONNECTOR (PC BOARD) 10P
 CN509 1-564-505-11 PLUG, CONNECTOR 2P



Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
IC701	8-759-822-38	IC LA6510		Q506	8-729-820-73	TRANSISTOR 2SC3746	
IC702	8-759-444-82	IC LA7841L		Q507	8-729-035-54	TRANSISTOR 2SJ449	
IC703	8-759-100-96	IC UPC4558G2		Q508	8-729-031-87	TRANSISTOR 2SC5047-CA	
IC901	8-759-467-70	IC BA9756FS-E2		Q509	8-729-033-25	TRANSISTOR DTC114GKA	
<CHIP CONDUCTOR>				Q510	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
JR001	1-216-295-91	SHORT	0	Q511	8-729-140-50	TRANSISTOR 2SC3209LK	
JR002	1-216-295-91	SHORT	0	Q512	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
JR003	1-216-295-91	SHORT	0	Q513	8-729-901-00	TRANSISTOR DTC124EK	
JR004	1-216-295-91	SHORT	0	Q517	8-729-216-22	TRANSISTOR 2SA1162-G	
<COIL>				Q522	8-729-042-43	TRANSISTOR 2SK2098-01MR	
L001	1-406-665-11	COIL, CHOKE	100UH	Q523	8-729-042-43	TRANSISTOR 2SK2098-01MR	
L002	1-406-665-11	COIL, CHOKE	100UH	Q524	8-729-042-43	TRANSISTOR 2SK2098-01MR	
L003	1-412-537-31	INDUCTOR	100UH	Q525	8-729-042-43	TRANSISTOR 2SK2098-01MR	
L004	1-412-537-31	INDUCTOR	100UH	Q526	8-729-042-43	TRANSISTOR 2SK2098-01MR	
L006	1-410-482-31	INDUCTOR	100UH	Q527	8-729-042-43	TRANSISTOR 2SK2098-01MR	
L007	1-412-537-31	INDUCTOR	100UH	Q528	8-729-042-43	TRANSISTOR 2SK2098-01MR	
L008	1-412-537-31	INDUCTOR	100UH	Q660	8-729-033-26	TRANSISTOR DTA114GKAT146	
L501	1-412-537-31	INDUCTOR	100UH	Q661	8-729-033-25	TRANSISTOR DTC114GKA	
L502	1-406-671-11	COIL, CHOKE	1.0MMH	Q701	8-729-800-32	TRANSISTOR 2SC2362K-G	
L503	1-416-455-11	COIL, HORIZONTAL LINEARITY		Q703	8-729-178-43	TRANSISTOR 2SC2784-E	
L504	1-416-456-11	COIL, HORIZONTAL LINEARITY		Q704	8-729-207-82	TRANSISTOR 2SC3421-Y	
L505	1-406-675-11	COIL, CHOKE	4.7MMH	Q705	8-729-204-91	TRANSISTOR 2SA1049-GR	
L507	1-406-675-11	COIL, CHOKE	4.7MMH	Q706	8-729-207-89	TRANSISTOR 2SA1358-Y	
L701	1-412-537-31	INDUCTOR	100UH	Q707	8-729-216-22	TRANSISTOR 2SA1162-G	
L702	1-412-522-41	INDUCTOR	5.6UH	Q708	8-729-020-07	TRANSISTOR 2SC4686A(LBSONY)	
L901	1-412-537-31	INDUCTOR	100UH	Q901	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
L902	1-406-660-41	COIL, CHOKE	15UH	Q902	8-729-216-22	TRANSISTOR 2SA1162-G	
L903	1-412-537-31	INDUCTOR	100UH	Q904	8-729-901-87	TRANSISTOR 2SC2411K-CQ	
<IC LINK>				Q905	8-729-901-97	TRANSISTOR 2SA1036K-Q	
PS501	Δ 1-533-592-31	LINK, IC (1.6A/90V AC, 60V DC)		Q908	8-729-035-54	TRANSISTOR 2SJ449	
PS502	Δ 1-532-984-91	LINK, IC (2A/90V)		Q909	8-729-033-91	TRANSISTOR 2SK1120LBSONY2	
PS503	Δ 1-532-984-91	LINK, IC (2A/90V)		<RESISTOR>			
PS504	Δ 1-532-984-91	LINK, IC (2A/90V)		R001	1-216-025-91	RES, CHIP	100
PS701	Δ 1-533-590-31	LINK, IC (1A/90V AC, 60V DC)		R002	1-216-049-91	RES, CHIP	1.0K
PS901	Δ 1-533-592-31	LINK, IC (1.6A/90V AC, 60V DC)		R003	1-216-049-91	RES, CHIP	1.0K
<TRANSISTOR>				R004	1-216-049-91	RES, CHIP	1.0K
Q001	8-729-027-31	TRANSISTOR DTA124EKA-T146		R005	1-216-073-00	RES, CHIP	10K
Q003	8-729-216-22	TRANSISTOR 2SA1162-G		R006	1-216-049-91	RES, CHIP	1.0K
Q004	8-729-216-22	TRANSISTOR 2SA1162-G		R007	1-216-025-91	RES, CHIP	100
Q005	8-729-216-22	TRANSISTOR 2SA1162-G		R008	1-216-089-91	RES, CHIP	47K
Q006	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R009	1-216-025-91	RES, CHIP	100
Q007	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R010	1-216-081-00	RES, CHIP	22K
Q501	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R011	1-216-097-91	RES, CHIP	100K
Q502	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R012	1-216-025-91	RES, CHIP	100
Q503	8-729-901-97	TRANSISTOR 2SA1036K-Q		R013	1-216-675-11	METAL CHIP	10K
Q504	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R016	1-216-687-11	METAL CHIP	33K
Q505	8-729-901-97	TRANSISTOR 2SA1036K-Q		R017	1-216-049-91	RES, CHIP	1.0K
				R018	1-216-049-91	RES, CHIP	1.0K
				R019	1-216-683-11	METAL CHIP	22K
				R020	1-216-049-91	RES, CHIP	1.0K
				R023	1-216-025-91	RES, CHIP	100
				R024	1-216-089-91	RES, CHIP	47K
				R026	1-216-073-00	RES, CHIP	10K



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R027	1-216-073-00	RES, CHIP	10K	R083	1-216-057-00	RES, CHIP	2.2K
R028	1-216-065-00	RES, CHIP	4.7K	R084	1-216-025-91	RES, CHIP	100
R029	1-216-089-91	RES, CHIP	47K	R085	1-216-025-91	RES, CHIP	100
R030	1-216-017-91	RES, CHIP	47	R088	1-216-057-00	RES, CHIP	2.2K
R031	1-216-073-00	RES, CHIP	10K	R089	1-216-057-00	RES, CHIP	2.2K
R032	1-216-675-11	METAL CHIP	10K	R090	1-216-057-00	RES, CHIP	2.2K
R033	1-216-017-91	RES, CHIP	47	R092	1-216-057-00	RES, CHIP	2.2K
R034	1-216-025-91	RES, CHIP	100	R094	1-216-057-00	RES, CHIP	2.2K
R035	1-216-049-91	RES, CHIP	1.0K	R096	1-216-295-91	SHORT	0
R036	1-216-025-91	RES, CHIP	100	R097	1-216-057-00	RES, CHIP	2.2K
R037	1-216-061-00	RES, CHIP	3.3K	R101	1-216-049-91	RES, CHIP	1.0K
R038	1-216-065-00	RES, CHIP	4.7K	R501	1-216-065-00	RES, CHIP	4.7K
R039	1-216-049-91	RES, CHIP	1.0K	R502	1-216-057-00	RES, CHIP	2.2K
R040	1-216-049-91	RES, CHIP	1.0K	R503	1-216-041-00	RES, CHIP	470
R041	1-216-065-00	RES, CHIP	4.7K	R504	1-216-057-00	RES, CHIP	2.2K
R042	1-216-089-91	RES, CHIP	47K	R505	1-216-041-00	RES, CHIP	470
R043	1-216-065-00	RES, CHIP	4.7K	R506	1-249-397-11	CARBON	22
R044	1-216-095-00	RES, CHIP	82K	R507	1-216-065-00	RES, CHIP	4.7K
R045	1-216-073-00	RES, CHIP	10K	R508	1-216-025-91	RES, CHIP	100
R046	1-216-675-11	METAL CHIP	10K	R509	1-216-057-00	RES, CHIP	2.2K
R047	1-216-073-00	RES, CHIP	10K	R510	1-216-065-00	RES, CHIP	4.7K
R048	1-216-049-91	RES, CHIP	1.0K	R511	1-219-726-11	METAL	2.2
R049	1-216-049-91	RES, CHIP	1.0K	R512	1-216-627-11	METAL CHIP	100
R050	1-216-025-91	RES, CHIP	100	R513	1-215-860-11	METAL OXIDE	33
R051	1-216-679-11	METAL CHIP	15K	R514	1-211-796-11	FUSIBLE	1
R052	1-216-073-00	RES, CHIP	10K	R515	1-216-675-11	METAL CHIP	10K
R053	1-216-675-11	METAL CHIP	10K	R516	1-247-815-91	CARBON	220
R054	1-216-675-11	METAL CHIP	10K	R517	1-216-065-00	RES, CHIP	4.7K
R055	1-216-089-91	RES, CHIP	47K	R518	1-216-097-91	RES, CHIP	100K
R056	1-216-671-11	METAL CHIP	6.8K	R519	1-216-393-00	METAL OXIDE	2.2
R057	1-216-679-11	METAL CHIP	15K	R520	1-216-393-00	METAL OXIDE	2.2
R058	1-216-663-11	METAL CHIP	3.3K	R521	1-249-413-11	CARBON	470
R059	1-216-065-00	RES, CHIP	4.7K	R522	1-216-423-11	METAL OXIDE	27
R060	1-216-049-91	RES, CHIP	1.0K	R523	1-249-425-11	CARBON	4.7K
R061	1-216-065-00	RES, CHIP	4.7K	R524	1-215-869-11	METAL OXIDE	1K
R063	1-216-025-91	RES, CHIP	100	R525	1-216-681-11	METAL CHIP	18K
R064	1-216-025-91	RES, CHIP	100	R526	1-214-840-00	METAL	100
R065	1-216-025-91	RES, CHIP	100	R527	1-214-840-00	METAL	100
R066	1-216-025-91	RES, CHIP	100	R528	1-214-840-00	METAL	100
R067	1-216-025-91	RES, CHIP	100	R529	1-260-313-51	CARBON	56
R068	1-216-025-91	RES, CHIP	100	R530	1-249-437-11	CARBON	47K
R069	1-216-017-91	RES, CHIP	47	R531	1-249-437-11	CARBON	47K
R070	1-216-675-11	METAL CHIP	10K	R532	1-249-437-11	CARBON	47K
R071	1-216-049-91	RES, CHIP	1.0K	R533	1-249-437-11	CARBON	47K
R072	1-216-651-11	METAL CHIP	1K	R534	1-249-437-11	CARBON	47K
R073	1-216-295-91	SHORT	0	R535	1-216-049-91	RES, CHIP	1.0K
R074	1-216-675-11	METAL CHIP	10K	R536	1-216-049-91	RES, CHIP	1.0K
R075	1-216-049-91	RES, CHIP	1.0K	R537	1-216-049-91	RES, CHIP	1.0K
R076	1-216-049-91	RES, CHIP	1.0K	R538	1-216-049-91	RES, CHIP	1.0K
R077	1-216-049-91	RES, CHIP	1.0K	R539	1-216-049-91	RES, CHIP	1.0K
R078	1-216-049-91	RES, CHIP	1.0K	R540	1-216-073-00	RES, CHIP	10K
R079	1-216-017-91	RES, CHIP	47	R541	1-260-314-11	CARBON	68
R080	1-216-017-91	RES, CHIP	47	R542	1-215-863-11	METAL OXIDE	100
R081	1-216-675-11	METAL CHIP	10K	R543	1-216-640-11	METAL CHIP	360
R082	1-216-049-91	RES, CHIP	1.0K	R544	1-260-085-11	CARBON	68



REF.NO.	PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTION		REMARK
R545	1-216-683-11	METAL CHIP	22K	0.50%1/10W	R705	1-249-385-11	CARBON	2.2	5% 1/4W
R546	1-260-288-11	CARBON	0.47	5% 1/2W	R706	1-216-093-00	RES, CHIP	68K	
R547	1-216-663-11	METAL CHIP	3.3K	0.50%1/10W	R707	1-249-421-11	CARBON	2.2K	5% 1/4W
R548	1-215-443-00	METAL	8.2K	1% 1/4W	R708	1-216-073-00	RES, CHIP	10K	
R549	1-216-675-11	METAL CHIP	10K	0.50%1/10W	R709	1-216-473-11	METAL OXIDE	56	5% 3W F
R550	1-260-288-11	CARBON	0.47	5% 1/2W	R710	1-216-073-00	RES, CHIP	10K	
R551	1-216-659-11	METAL CHIP	2.2K	0.50%1/10W	R715	1-216-077-00	RES, CHIP	15K	
R552	1-216-057-00	RES, CHIP	2.2K		R719	1-249-383-11	CARBON	1.5	5% 1/4W F
R553	1-216-655-11	METAL CHIP	1.5K	0.50%1/10W	R720	1-260-292-11	CARBON	1	5% 1/2W
R554	1-216-675-11	METAL CHIP	10K	0.50%1/10W	R721	1-216-667-11	METAL CHIP	4.7K	0.50%1/10W
R555	1-216-065-00	RES, CHIP	4.7K		R722	1-216-691-11	METAL CHIP	47K	0.50%1/10W
R556	1-216-674-11	METAL CHIP	9.1K	0.50%1/10W	R723	1-216-663-11	METAL CHIP	3.3K	0.50%1/10W
R557	1-218-760-11	METAL CHIP	220K	0.50%1/10W	R724	1-214-798-21	METAL	1.8	1% 1/2W
R558	1-216-683-11	METAL CHIP	22K	0.50%1/10W	R725	1-214-798-21	METAL	1.8	1% 1/2W
R561	1-216-683-11	METAL CHIP	22K	0.50%1/10W	R726	1-216-675-11	METAL CHIP	10K	0.50%1/10W
R562	1-249-401-11	CARBON	47	5% 1/4W F	R727	1-260-292-11	CARBON	1	5% 1/2W
R563	1-216-662-11	METAL CHIP	3K	0.50%1/10W	R728	1-249-381-11	CARBON	1	5% 1/4W F
R564	1-216-697-91	METAL CHIP	82K	0.50%1/10W	R729	1-215-865-11	METAL OXIDE	220	5% 1W F
R565	1-216-671-11	METAL CHIP	6.8K	0.50%1/10W	R730	1-219-746-11	CARBON	1K	5% 1/2W
R566	1-260-311-11	CARBON	39	5% 1/2W	R731	1-216-073-00	RES, CHIP	10K	
R567	1-216-627-11	METAL CHIP	100	0.50%1/10W	R732	1-216-073-00	RES, CHIP	10K	
R568	1-216-655-11	METAL CHIP	1.5K	0.50%1/10W	R733	1-219-746-11	CARBON	1K	5% 1/2W
R571	1-216-381-11	METAL OXIDE	0.22	5% 3W F	R734	1-215-881-11	METAL OXIDE	15	5% 2W F
R572	1-216-097-91	RES, CHIP	100K		R737	1-249-377-11	CARBON	0.47	5% 1/4W F
R573	1-216-097-91	RES, CHIP	100K		R738	1-249-377-11	CARBON	0.47	5% 1/4W F
R574	1-216-097-91	RES, CHIP	100K		R739	1-249-413-11	CARBON	470	5% 1/4W F
R575	1-216-097-91	RES, CHIP	100K		R741	1-249-430-11	CARBON	12K	5% 1/4W
R576	1-216-097-91	RES, CHIP	100K		R742	1-249-419-11	CARBON	1.5K	5% 1/4W
R577	1-216-057-00	RES, CHIP	2.2K		R743	1-216-049-91	RES, CHIP	1.0K	
R578	1-216-025-91	RES, CHIP	100		R748	1-216-683-11	METAL CHIP	22K	0.50%1/10W
R579	1-216-672-11	METAL CHIP	7.5K	0.50%1/10W	R749	1-216-025-91	RES, CHIP	100	
R580	1-216-073-00	RES, CHIP	10K		R750	1-216-057-00	RES, CHIP	2.2K	
R581	1-216-073-00	RES, CHIP	10K		R751	1-216-065-00	RES, CHIP	4.7K	
R582	1-216-073-00	RES, CHIP	10K		R752	1-216-083-00	RES, CHIP	27K	
R583	1-216-677-11	METAL CHIP	12K	0.50%1/10W	R753	1-219-720-11	METAL	10M	5% 1W
R584	1-216-081-00	RES, CHIP	22K		R754	1-219-754-11	CARBON	680K	5% 1/2W
R585	1-216-081-00	RES, CHIP	22K		R755	1-219-754-11	CARBON	680K	5% 1/2W
R586	1-216-049-91	RES, CHIP	1.0K		R756	1-220-824-91	CARBON	270K	5% 1/2W
R587	1-216-049-91	RES, CHIP	1.0K		R759	1-218-754-11	METAL CHIP	120K	0.50%1/10W
R588	1-216-097-91	RES, CHIP	100K		R776	1-216-049-91	RES, CHIP	1.0K	
R589	1-216-097-91	RES, CHIP	100K		R777	1-216-681-11	METAL CHIP	18K	0.50%1/10W
R590	1-216-675-11	METAL CHIP	10K	0.50%1/10W	R778	1-216-667-11	METAL CHIP	4.7K	0.50%1/10W
R591	1-216-675-11	METAL CHIP	10K	0.50%1/10W	R779	1-216-049-91	RES, CHIP	1.0K	
R594	1-249-437-11	CARBON	47K	5% 1/4W	R784	1-216-081-00	RES, CHIP	22K	
R595	1-249-437-11	CARBON	47K	5% 1/4W	R900	1-216-399-00	METAL OXIDE	6.8	5% 3W F
R596	1-216-683-11	METAL CHIP	22K	0.50%1/10W	R901	1-216-057-00	RES, CHIP	2.2K	
R663	1-215-482-00	METAL	360K	1% 1/4W	R902	1-216-065-00	RES, CHIP	4.7K	
R664	1-215-459-00	METAL	39K	1% 1/4W	R903	1-216-073-00	RES, CHIP	10K	
R665	1-216-049-91	RES, CHIP	1.0K		R904	1-216-057-00	RES, CHIP	2.2K	
R667	1-216-041-00	RES, CHIP	470		R905	1-216-025-91	RES, CHIP	100	
R669	1-216-671-11	METAL CHIP	6.8K	0.50%1/10W	R906	1-216-065-00	RES, CHIP	4.7K	
R701	1-249-383-11	CARBON	1.5	5% 1/4W F	R907	1-216-025-91	RES, CHIP	100	
R702	1-216-057-00	RES, CHIP	2.2K		R908	1-216-091-00	RES, CHIP	56K	
R703	1-216-085-00	RES, CHIP	33K		R909	1-216-689-11	RES, CHIP	39K	
R704	1-249-383-11	CARBON	1.5	5% 1/4W F	R910	1-216-073-00	RES, CHIP	10K	



REF.NO.	PART NO.	DESCRIPTION	REMARK			REF.NO.	PART NO.	DESCRIPTION	REMARK		
R911	1-216-049-91	RES, CHIP	1.0K					<RELAY>			
R912	1-218-772-11	METAL CHIP	680K	0.50%	1/10W						
R913	1-219-748-11	CARBON	4.7K	5%	1/2W	RY501	1-755-137-11	RELAY			
R914	1-219-510-11	CARBON	470K	5%	1/2W						
R915	1-249-437-11	CARBON	47K	5%	1/4W			<SPARK GAP>			
R916	1-249-429-11	CARBON	10K	5%	1/4W						
R917	1-216-073-00	RES, CHIP	10K			SG701	1-519-422-11	GAP, SPARK			
R918	1-216-097-91	RES, CHIP	100K			SG702	1-519-422-11	GAP, SPARK			
R919	1-216-025-91	RES, CHIP	100			SG901	1-517-499-21	GAP, SPARK			
R920	1-249-401-11	CARBON	47	5%	1/4W F						
R921	1-216-668-11	METAL CHIP	5.1K	0.50%	1/10W			<TRANSFORMER>			
R922	1-216-041-00	RES, CHIP	470								
R923	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	T501	1-429-303-21	TRANSFORMER, FERRITE (HDT)			
R924	1-249-397-11	CARBON	22	5%	1/4W F	T502	1-416-401-11	COIL, CHOKE 5MMH			
						T503	1-431-413-11	TRANSFORMER, FERRITE (HST)			
R925	1-216-653-11	METAL CHIP	1.2K	0.50%	1/10W	T504	1-416-257-11	COIL, CHOKE (HCC) 2.0MH			
R926	1-216-653-11	METAL CHIP	1.2K	0.50%	1/10W	T701	1-431-414-11	TRANSFORMER, FERRITE (DFT)			
R927	1-216-073-00	RES, CHIP	10K								
R928	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W						
R929	1-216-033-00	RES, CHIP	220			T901	1-416-402-11	COIL, CHOKE 500UH			
						T902	△ X-4035-170-1 TRANSFORMER ASSY, FLYBACK (NX-4142//J1D4)				
R930	1-216-033-00	RES, CHIP	220								
R933	1-216-683-11	METAL CHIP	22K	0.50%	1/10W						
R934	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W			<THERMISTOR>			
R937	1-219-727-11	METAL	68	5%	10W						
R940	1-249-393-11	CARBON	10	5%	1/4W F	TH501	1-807-796-11	THERMISTOR			
						TH502	1-807-796-11	THERMISTOR			
R980	1-216-049-91	RES, CHIP	1.0K								
R981	1-216-025-91	RES, CHIP	100								
R1001	1-216-073-00	RES, CHIP	10K					<CRYSTAL>			
R1003	1-216-049-91	RES, CHIP	1.0K								
R1004	1-216-049-91	RES, CHIP	1.0K			X001	1-567-781-61	VIBRATOR, CRYSTAL			
R1005	1-216-049-91	RES, CHIP	1.0K								
R1006	1-216-049-91	RES, CHIP	1.0K								
R1007	1-216-049-91	RES, CHIP	1.0K								
R1011	1-216-073-00	RES, CHIP	10K								
R1012	1-216-049-91	RES, CHIP	1.0K					* 8-933-283-00 H BOARD, COMPLETE			

R1013	1-216-049-91	RES, CHIP	1.0K								
R1014	1-216-049-91	RES, CHIP	1.0K								
R1015	1-216-295-91	SHORT	0					<CAPACITOR>			
R1016	1-216-049-91	RES, CHIP	1.0K								
R1017	1-216-065-00	RES, CHIP	4.7K			C805	1-124-589-11	ELECT 47MF 20% 16V			
						C811	1-124-589-11	ELECT 47MF 20% 16V			
R1020	1-216-049-91	RES, CHIP	1.0K								
R1021	1-216-049-91	RES, CHIP	1.0K								
R1022	1-216-295-91	SHORT	0					<CONNECTOR>			
R1023	1-216-295-91	SHORT	0								
R1024	1-216-295-91	SHORT	0			CN801	*1-564-526-11	PLUG, CONNECTOR 11P			
R1025	1-249-389-11	CARBON	4.7	5%	1/4W F						
R1026	1-249-389-11	CARBON	4.7	5%	1/4W F			<DIODE>			
R1027	1-216-065-00	RES, CHIP	4.7K								
R1028	1-216-049-91	RES, CHIP	1.0K			D820	8-719-064-11	DIODE SPR-325MVW			
R1501	1-216-057-00	RES, CHIP	2.2K								
R1502	1-216-073-00	RES, CHIP	10K					<TRANSISTOR>			
R1503	1-216-125-00	RES, CHIP	1.5M								
R1504	1-216-097-91	RES, CHIP	100K			Q801	8-729-119-78	TRANSISTOR 2SC2785-HFE			
R1513	1-216-049-91	RES, CHIP	1.0K			Q802	8-729-119-78	TRANSISTOR 2SC2785-HFE			
R1514	1-216-049-91	RES, CHIP	1.0K								



Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
<RESISTOR>				C5003	1-126-933-11	ELECT 100MF	20% 16V
R801	1-215-433-00	METAL 3.3K	1% 1/4W	C5004	1-104-664-11	ELECT 47MF	20% 25V
R802	1-215-409-00	METAL 330	1% 1/4W	C5005	1-104-664-11	ELECT 47MF	20% 25V
R803	1-215-409-00	METAL 330	1% 1/4W	C5008	1-104-664-11	ELECT 47MF	20% 25V
R804	1-215-413-00	METAL 470	1% 1/4W	C5009	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
R805	1-215-413-00	METAL 470	1% 1/4W	C5101	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
R806	1-215-417-00	METAL 680	1% 1/4W	C5103	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
R807	1-215-421-00	METAL 1K	1% 1/4W	C5104	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
R808	1-215-421-00	METAL 1K	1% 1/4W	C5105	1-104-664-11	ELECT 47MF	20% 25V
R809	1-215-429-00	METAL 2.2K	1% 1/4W	C5106	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
R810	1-215-433-00	METAL 3.3K	1% 1/4W	C5107	1-137-399-11	FILM 0.1MF	5% 50V
R814	1-249-429-11	CARBON 10K	5% 1/4W	C5108	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
R815	1-249-429-11	CARBON 10K	5% 1/4W	C5109	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
R818	1-215-445-00	METAL 10K	1% 1/4W	C5110	1-104-664-11	ELECT 47MF	20% 25V
R819	1-249-441-11	CARBON 100K	5% 1/4W	C5111	1-137-399-11	FILM 0.1MF	5% 50V
R826	1-249-408-11	CARBON 180	5% 1/4W	C5201	1-104-664-11	ELECT 47MF	20% 25V
R827	1-249-407-11	CARBON 150	5% 1/4W	C5202	1-104-664-11	ELECT 47MF	20% 25V
<SWITCH>				C5203	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
S802	1-692-431-21	SWITCH, TACTILE (CONT+)		C5204	1-137-399-11	FILM 0.1MF	5% 50V
S803	1-692-431-21	SWITCH, TACTILE (CONT-)		C5205	1-164-489-11	CERAMIC CHIP 0.22MF	10% 16V
S804	1-692-431-21	SWITCH, TACTILE (MENU)		C5206	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
S805	1-692-431-21	SWITCH, TACTILE (BRT+)		C5301	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
S806	1-692-431-21	SWITCH, TACTILE (BRT-)		C5303	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
S818	1-692-431-21	SWITCH, TACTILE (ASC)		C5304	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
S820	1-692-431-21	SWITCH, TACTILE (RESET)		C5305	1-104-664-11	ELECT 47MF	20% 25V
<THERMISTOR>				C5306	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
TH801	1-807-796-11	THERMISTOR		C5307	1-137-399-11	FILM 0.1MF	5% 50V
*****				C5308	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
* 8-933-279-00 J BOARD, COMPLETE				C5309	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
*****				C5310	1-104-664-11	ELECT 47MF	20% 25V
<CONNECTOR>				C5311	1-137-399-11	FILM 0.1MF	5% 50V
CN891	*1-691-961-11	PIN, CONNECTOR (PC BOARD) 2P		C5401	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
<SWITCH>				C5403	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
S891	Δ 1-571-433-31	SWITCH, PUSH (AC POWER)		C5404	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
*****				C5405	1-104-664-11	ELECT 47MF	20% 25V
* 8-933-263-00 L BOARD, COMPLETE				C5406	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
*****				C5407	1-137-399-11	FILM 0.1MF	5% 50V
<CAPACITOR>				C5408	1-163-003-11	CERAMIC CHIP 330PF	10% 50V
C5002	1-126-964-11	ELECT 10MF	20% 50V	C5409	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C5410	1-104-664-11	ELECT 47MF	20% 25V
				C5412	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C5501	1-126-923-11	ELECT 220MF	20% 10V
				<CONNECTOR>			
				CN5001	*1-564-512-11	PLUG, CONNECTOR 9P	
				CN5002	*1-564-509-11	PLUG, CONNECTOR 6P	
				CN5003	1-564-513-11	PLUG, CONNECTOR 10P	
				CN5004	*1-564-507-11	PLUG, CONNECTOR 4P	
				<DIODE>			
				D5002	8-719-801-78	DIODE 1SS184	
				D5101	8-719-800-76	DIODE 1SS226	
				D5103	8-719-800-76	DIODE 1SS226	
				D5201	8-719-800-76	DIODE 1SS226	
				D5301	8-719-800-76	DIODE 1SS226	

