













ПЛАТА СИСТЕМЫ УПРАВЛЕНИЯ ЛПМ


STATE DETECTION	
START . SENSOR	
END . SENSOR	
REEL . SENSOR	
CASSETTE START	
CASSETTE IN	
CASSETTE OUT	
MODE SW1	
MODE SW2	
MODE SW3	
MODE SW4	
REC SAFETY SW	




ОСНОВНАЯ ПЛАТА ПЛАТА УПРАВЛЕНИЯ И ИНДИКАЦИИ

MECHANISM CONTROL
MICROPROCESSOR
MB86525 (4K)














Рис. 3.7 Структурная схема канала звука













- PN882
- 1 PB C.S.L
 - 2 GND
 - 3 REC C.S.L
 - 4 RF SWP
 - 5 REC Y-FM
 - 6 GND
 - 7 PB Y-FM

- ◀ PB Y SIGNAL
- ◀ PB CHROMA SIGNAL
- ◀◀ REC Y SIGNAL
- ◀◀ REC CHROMA SIGNAL
- ◀ CONTROL SIGNAL
- ◀◀◀ AUDIO (PB) SIGNAL
- ◀◀◀ AUDIO (REC) SIGNAL












B SERVO / SYSCON C. B.








TO POWER C. B-2 CN102	
1	EVER +9V
2	REG GND
3	REG +12V
4	REG +9V
5	UNREG +9V
6	NC

WB482	
1	PON
2	TU SCR
3	TU S1
4	TU RST
5	TU CS
6	TU S0
7	A MUTE
8	REG GND
TO YCHROMA SECTION (5A)	
AUDIO MUTE	5A

Q901 - Q908
DTC144E

D901 - D908,
D910 - D920
D922 - D934, D937,
D939 - D941
1SS133 X 36





E POWER SW C. B


D909
1SS133

SW901

POWER

CN904





POWER C. B. - 2

POWER C. B. - 4

Per symbol
Indication
12.2 B

9

