



FUNAI


SERVICE MANUAL

F1/F2

VIDEO CASSETTE PLAYER

F1/F2

VHS
PAL



K289024/822A

FUNAI ELECTRIC CO., LTD.

CONTENTS

1. SPECIFICATIONS	1-1
2. SAFETY CHECK AFTER SERVICING	2-1
3. IMPORTANT SAFETY PRECAUTIONS	3-1
4. DISASSEMBLY INSTRUCTIONS (SET)	4-1
5. DISASSEMBLY INSTRUCTIONS (DECK)	5-1
6. STANDARD MAINTENANCE	6-1
7. BLOCK DIAGRAM	7-1
8. WIRING DIAGRAM	8-1
9. SERVICE FIXTURES AND TOOLS	9-1
10. MECHANICAL ADJUSTMENTS	10-1
11. ELECTRICAL ADJUSTMENTS	11-1
12. ALIGNMENT AND TEST POINTS	12-1
13. P.C. BOARD TOP AND BOTTOM VIEWS	13-1
14. SCHEMATIC DIAGRAMS	14-1
15. WAVEFORMS	15-1
16. IC PIN FUNCTION DESCRIPTIONS	16-1
17. SYSTEM CONTROL TIMING CHARTS	17-1
18. LEAD IDENTIFICATIONS	18-1
19. EXPLODED VIEWS	19-1
20. MECHANICAL PARTS LIST	20-1
21. DECK PARTS LIST	21-1
22. ELECTRICAL PARTS LIST	22-1

1. SPECIFICATIONS

Test Items	Mode	Nominal	Limit	Test Tape
1. Video Section				
1-1 Output Level	PB	1.0 Vp-p	1.0 ± 0.2 Vp-p	F6-A
1-2 S/N Ratio (Luminance)	PB	45 dB	40 dB	F6-D
1-3 S/N Ratio (Chroma AM)	PB	44 dB	35 dB	F6-E
1-4 S/N Ratio (Chroma PM)	PB	38 dB	31 dB	F6-E
1-5 Resolution	PB	240 Line	230 Line	F6-M
2. Servo Section				
2-1 Wow & Flutter WTD	PB	0.2 %	0.6 %	F6-M
2-2 Jitter Low	PB	0.04 μ sec	0.12 μ sec	F6-N
3. Audio Section				
3-1 Output Level	PB	-6 dBV	-6 ± 4 dBV	F6-A
3-2 S/N Ratio	PB	40 dB	36 dB	F6-A
3-3 Distortion	PB	1.5 %	4.0 %	F6-A
3-4 Freq. resp at 100Hz	PB	-3 dB	-6 dB	F6-K
(-20dBV ref. 1KHz) at 6kHz	PB	-2 dB	-6 dB	F6-K

NOTE : Nominal specs represent the designing specs; all units should be able to approximate these-some will exceed and some may drop slightly below these specs. Limit specs represent the absolute worst condition that still might be considered; in no case should a unit perform to less than within any limit spec.

2. SAFETY CHECK AFTER SERVICING

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts and wires have been returned to original positions. Afterwards, perform the following tests and confirm the specified values in order to verify compliance with safety standards.

1. Insulation resistance test
Confirm the specified insulation resistance or greater between power cord plug prongs and externally exposed parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table below.
2. Dielectric strength test
Confirm specified dielectric strength or greater between power cord plug prongs and exposed accessible parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See table below.
3. Clearance distance
When replacing primary circuit components, confirm specified clearance distance (d), (d') between soldered terminals, and between terminals and surrounding metallic parts. See table below.




Table 1. : Ratings for selected areas

AC Line Voltage	Region	Insulation Resistance	Dielectric Strength	Clearance Distance (d) (d')
110 to 130 V	USA & Canada	---	900 V 1minute	≥ 3.2 mm
* 110 to 130 V	Europe	≥ 10 M Ω	3 kV 1minute	≥ 4 mm (d)
200 to 240 V	Australia	/500 V DC		≥ 6 mm (d')

* Class II model only.

Note: This table is unofficial and for reference only. Be sure to confirm the precise values for your particular country and locality.

4. Leakage current test

Confirm specified or lower leakage current between B (earth ground, power cord plug prongs) and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).

Measuring Method : (Power ON)

Insert load Z between B (earth ground, power cord plug prongs) and exposed accessible parts.
Use an AC voltmeter to measure across both terminals of load Z.
See figure and following table.







Table 2 : Leakage current ratings for selected areas

AC Line Voltage	Region	Load Z	Leakage Current(i)	Earth Ground (B) to:
110 to 130 V	USA & Canada	 0.15 μF 1.5 k	$I \leq 0.5 \text{ mA rms}$	Exposed accessible parts
110 to 130 V 200 to 240 V	Europe Australia	 2 kΩ	$I \leq 0.7 \text{ mA peak}$ $I \leq 2 \text{ mA dc}$	Antenna terminals
		 50 kΩ	$I \leq 0.7 \text{ mA peak}$ $I \leq 2 \text{ mA dc}$	Other terminals



Note: This table is unofficial and for reference only. Be sure to confirm the precise values for your particular country and locality.


3. IMPORTANT SAFETY PRECAUTIONS

Prior to shipment from the factory, our products are strictly inspected to conform the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

● Precautions during Servicing

- 1. Locations requiring special caution are denoted by labels and inscribed on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.
- 2. Parts identified by the  symbol parts are critical for safety. Replace only with specified part numbers.
- 3. Use specified internal wiring. Note especially :
 - 1) Wires covered with PVC tubing
 - 2) Double insulated wires
 - 3) High voltage leads
- 4. Use specified insulating materials for hazardous live parts. Note especially :
 - 1) Insulation Tape
 - 2) PVC tubing
 - 3) Spacers
 - 4) Insulation sheets for transistors






5. When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.) wrap ends of wires securely around the terminals before soldering.
6. Observe that wires do not contact heat producing parts (heat sinks, oxide metal film resistors, fusible resistors, etc.)
7. Check that replaced wires do not contact sharp edged or pointed parts.
8. When a power cord has been replaced, check that 10-15 kg of force in any direction will not loosen it.
9. Also check areas surrounding repaired locations.

4. DISASSEMBLY INSTRUCTIONS (SET)

1. Top Case Removal


- Remove 3 screws (A).



(Fig. 1 Rear)

2. Bottom Panel Removal


- Remove 7 screws (B).




(Fig. 2 Bottom View)

3. Front Ass'y Removal

- Unfasten 6 hooks (C) from Cabinet top and bottom.




(Fig. 3 Bottom View)



(Fig. 4 Top View)

4. MCV-A P.C. Board Removal

- Remove 3 screws (D).
- Remove 2 screws (E).
- Unfasten 4 hooks (F) from Cabinet. (Fig. 5)




(Fig. 5 Top View)

5. Power Supply Ass'y Removal

- Remove 1 screw (G).
- (Fig. 5)

6. MCV-B P.C. Board Removal

- Unfasten 2 hooks (H).
- (Fig. 6)




(Fig. 6 Top View)

7. Deck Ass'y Removal

- Remove 3 screws (I).
- (Fig. 6)

8. MCV-C P.C. Board Removal

- Unfasten 2 hooks (J) from Main Cabinet. (Fig. 7)




5. DISASSEMBLY INSTRUCTIONS (DECK)

(1) Front Loading Unit (Fig. 2-1)

1. Remove Front Loading Belt (A) from Front Loading Clutch Ass'y (A').
2. Remove 4 screws (B).
3. Take off Left side hook (C) and Right side hook (D).
(To unfasten the hook, lift up front edge of the Front Loading Unit and take it forward.)

(2) Cassette Load Bracket Ass'y (Fig. 2-1)

1. Remove screw (E).
2. Take off the Cassette Load Bracket Ass'y (F).



(3) Photo Sensor (Fig. 2-2)

1. Replacement of Lamp Holder Ass'y (A).

- (1) Remove screw (B), move away the Take-up Soft Brake Ass'y (D).
- (At this time, do not take off the spring (C).)

- (2) Hold Lamp Holder Ass'y (A) and pull up to remove the hook (E) from the chassis.

- (3) Turn the Lamp Holder Ass'y (A) counterclockwise and take out the Lamp Holder Ass'y (A).

2. Start Sensor replacement of sensor PCB PM Ass'y (H).

- (1) Remove screw (F) and take off the Front Loading PCB Ass'y (I).

- (2) Remove screw (G) and take off the Sensor PCB RM Ass'y (H).

3. End Sensor replacement of sensor PCB LM Ass'y (J).

- (1) Remove screw (G) and take off the Sensor PCB LM Ass'y (J).




Fig. 2-2

(4) Full Erase Head / Audio Control Head (Fig. 2-3)

1. Erase Head

- (1) Remove Nut (A).

- (2) Remove Spring (B).

- (3) Take out the Impedance Roller (C), and pull up the Full Erase Head Plate Ass'y (D).

(Take care not to lose parts (E) (F) (G) (H) at the time of the Full Erase plate removal.)

- (4) Remove screw (I) and take off the Full Erase Head (J).

2. Audio / Control Head

- (1) Remove screw (K), (L) and Azimuth Spring (M).

- (2) Remove Audio/Control Head (N).

Note: When reinstalling the Full Erase Head/Audio Control Head Unit, mechanical adjustments should be performed for proper operation. (Fig. 2-3)




Fig. 2-3

(8) Drum Ass'y (Fig. 2-7)

1. Remove the Front Loading Unit (2. (1) on page 2-1).
2. Disconnect the Drum Motor PCB Ass'y (A) from the stator (B).
3. Remove screw (E) and take off the Drum Ground (F).
4. Remove 3 screws (C) and take off the Drum Ass'y (D).

Note:

Take off the Drum Ass'y (D) carefully so as not to scratch or damage. (Fig. 2-7)




Fig. 2-7

(9) Upper Drum / Reinstallation Upper, Lower Drums and Rotor (Fig. 2-8)

1. Remove the Front Loading Unit (2. (1) on page 2-1).
2. Remove screw (A) and take off the Drum Ground Bracket (B).
3. Remove 2 screws (C) and take off the Upper Drum (D).

Note:

1. Use gloves and do not touch the drum surface with bare fingers.
2. If the Video Head is defective, replace the upper drum along with the Head. (Fig. 2-8)






Fig. 2-8



≡Note≡


For Upper Drum point-A, Lower Drum point-B and Rotor point-C, theses Point A, B, C, must lineup each other.
If not so, the problem may cause.

(10) Drum Motor (Fig. 2-10)

1. Disconnect the Drum Motor PCB Ass'y (A) from the Stator (F).
2. Remove 2 screws (C), and take off the Rotor (D).
3. Remove 3 screws (E), and take off the Stator (F).

Note:

When you reinstall the Rotor, You must align the Rotor magnet (N) with the white CH-1 video head. (See Page 2-8.)




(11) Capstan Motor / Tape Loading Motor (Fig. 2-11)

1. Capstan Motor

- (1) Take off the Drive Belt (A) and Main Belt (B) from the Capstan Motor's Pulley (H).
- (2) Remove 2 screws (C), and take off the Capstan Motor (D).

2. Tape Loading Motor

- (1) Take off the Tape Loading Belt (E) from the Tape Loading Motor's Pulley (I).
- (2) Remove 2 screws (F), and take off the Tape Loading Motor (G).



(12) Loading Cam Gear (Fig. 2-12)

1. Take off the Loading Belt (A) from the Loading Pulley (B).
2. Remove Polyslider Washer (C), and take off the Loading Pulley (B).
3. Remove Polyslider Washer (D), and take off the Loading Gear (E).
4. Remove Polyslider Washer (F), and take off the Eject Actuator (H) and the Brake Actuator (G).
5. Remove 2 screws (I), and take off the Loading Protector (J) and the Loading Lever (K).
6. Take off the Loading Cam Gear (L).




Fig. 2-12

(13) Capstan Flywheel / Return Arm (Fig. 2-13)

1. Remove the Washer (A).
2. Take off the Drive Belt (B) and Main Belt (C).
3. Remove 2 screws (D), and Take off the Flywheel Angle Ass'y (E).
4. Take off the Capstan Flywheel (F).
5. Remove Polyslider Washer (H).
6. Take off the Middle Pulley Ass'y (I).
7. Remove Polyslider Washer (J).
8. Take off the Return Gear (K) and Return Arm (L).

Note:

Do not lose the Washer (A) and (G) when pulling out the Capstan Flywheel. (Fig. 2-13)




Fig. 2-13

(14) Reel Sensor (Fig. 2-14)

1. Remove Front Loading Unit (2. (1) on page 2-1) and the Gear Holder Ass'y (2. (5) on page 2-4).
2. Remove Take-up Reel (A).
3. Remove Reel Sensor (B).
(Unsolder (C), (D) from bottom.)




Fig. 2-14

(15) Loading Base (Fig. 2-15)

1. Remove Drum Ass'y, Tension Arm Ass'y and Photo Sensor. (Sensor Lamp)
2. Remove screw (A) and Loading Gear Plate Collar (B), Loading Gear Plate (C).
3. Remove 2 screws (D).
4. Take off the Loading Base (E).




Fig. 2-15

(16) Front Loading Wormwheel Unit (Fig. 2-16)

1. Disassembly

- (1) Remove Front Loading Belt and Bracket Ass'y. (See the Page 2-1 (2))
- (2) Remove E-Ring (A).
- (3) Remove Wormwheel Ass'y (B). (Wormwheel, Friction Spring, Friction Gear)

2. Assembly

- (1) Turn the Lift Gear (C) fully counterclockwise.
- (2) Restore Wormwheel Ass'y (B) to the stud.

Note:

Align the Lift Gear (C) Hole with Wormwheel Hole as illustrated. (Fig. 2-17)




Fig. 2-16




Fig. 2-17

6. STANDARD MAINTENANCE

1. Service schedule of components ○:Check ●:Change

D e c k		Periodic Service Schedule			
Ref. No.	Parts Name	1000 hr.	2000 hr.	3000 hr.	4000 hr.
2	Upper Drum	○	●	○	●
134	Pinch Roller (A)		●		●
171	Capstan Motor Assembly		●		●
229	Clutch Assembly		●		●
281	LM Assembly			●	
173	Main Belt		●		●
196	Back Tension Band		●		●
233	Drive Belt		●		●
251	Brake Shoe		●		●
285	Loading Belt		●		●
373	Front Loading Belt		●		●
14 19	Flat Spring, Drum Ground Drum Ground			● ●	
82	ACE Head			●	
92	Full Erase Head (except Play Only Model)			●	
121	Reel Assembly			●	

- Note:**
- 1. Clean all parts for the tape transport.
Upper Drum with video head / Pinch Roller
Audio Control Head / Full Erase Head
 - 2. After cleaning the parts, perform all DECK ADJUSTMENTS.
 - 3. Must replace two parts No.14 and No.19 at a time.

2. Cleaning

1. Cleaning of Video Head


Head cleaning by using a Head Cleaning Stick.

■ Procedure ■

- (1) Remove the top cabinet.
- (2) Put on a glove(thin type) to avoid touching the upper drum and lower drum with bare hand.
- (3) Put a few drops of alcohol on the Cleaning Stick, and by slightly placing it against the head tip, allow the upper drum to turn the right and left.

■ Note ■

- (1) The video head is very hard material, but since it is very thin, avoid cleaning it vertically.
- (2) Wait for the cleaned part to dry out before operating the unit.
- (3) Do not reuse the stained Head Cleaning Stick.



2. Cleaning of Audio Control Head


Head cleaning by using a Head Cleaning Stick.

■ Procedure ■


- (1) Remove the Top Cabinet.
- (2) Put a few drops of alcohol on the Cleaning Stick. Clean up the audio control head, being careful not to damage the upper drum and other tape running parts.

■ Note ■


- (1) Avoid cleaning audio control head vertically.
- (2) Wait for the cleaned part to dry well, before operating the unit.



7. BLOCK DIAGRAM




8. WIRING DIAGRAM



10. MECHANICAL ADJUSTMENTS

1. Tape Transport Adjustment Flow Chart



Note : Before these Mechanical Adjustments, you must complete the Video Head Switching Position Adjustment of 11. ELECTRICAL ADJUSTMENTS on page 11-1.

2. Tape Running Position Adjustment (Guide Roller / Tape Guide / Impedance Roller)

1. Perform the height adjustment for the following items to obtain the proper tape running position.

- ① Impedance Roller
- ② Guide Roller (Supply side)
- ③ Guide Roller (Take-up side)
- ④ Tape Guide




Fig. 1

2. Load a blank tape and set the VCR to the PLAY mode. Check the tape transport at points "A" and "B" as shown in Fig. 1.
3. Operate the VCR between the PLAY and STOP modes several times.
4. Observe the tape transport at the lead surface of the cylinder during the PLAY mode, and confirm that the tape runs smoothly along the lead surface of the cylinder without slipping downward or upward. (Refer to Fig. 2.)




Fig. 2

5. During loading, play and unloading, observe the tape at the supply and take-up guide rollers, tape guide and impedance roller. Confirm that there is no curling or creasing etc., as shown in Fig. 3.




Fig. 3

6. If any curling or creasing is noted, adjust tape guide roller and impedance roller first. In this case, adjust the impedance roller in both PLAY and REV modes so that tape runs as shown in Fig. 4.




Fig. 4.

7. Next, adjust the guide roller height. Insert the adjustment driver into the guide roller top. (Refer to Fig. 5.)
Adjust the height by turning the driver slightly so that the tape runs on the guide roller as shown in Fig. 3, and the lower edge of the tape runs along the lead surface of the cylinder.




Fig. 5

8. After completion of the supply side guide roller adjustments, adjust tape guide so that tape runs as shown in Fig. 6, and adjust the take-up side guide roller by using the same procedures as for the supply side adjustments. In this case, adjust the guide roller height first.




Fig. 6

9. Confirm that there is no curling or creasing at the impedance roller. (Both PLAY and REV modes.) If there is any curling or creasing at the impedance roller, adjust the same procedures of Fig. 6.
10. Finally, confirm that there is no curling or creasing at the take-up side guide roller and tape guide. If there is any curling or creasing between the take-up side guide roller and the audio control erase head, adjust the audio control erase head.

3. Audio Control Erase Head Adjustment

1. Load a recorded tape and set the VCR to PLAY mode.
2. Adjust the height of the edge of the audio track on the audio control head by using the height adjustment nut (A) and the tilt adjustment screw (C) so that the tape transport is smooth at the take-up guide pole. Align the audio control head height. (Refer to Fig. 7.)




Fig. 7

3. The fine adjustment is not required at this time. The following conditions are sufficient :
- (a) Proper tape transport between the audio control head and the take-up guide pole.
 - (b) Stable SERVO system operation. (proper pickup of tape's recorded control signal.)

4. X Value Adjustment (PB FM Peak Adjustment)

Measuring Method

Measuring Point	Measuring Equip.	ADJ. Condition
TP 2 (C-PB) TP 1 (RF-SW)	Oscilloscope	PLAY MODE Test tape F8-NW
ADJ. Location		ADJ. Value
X value adjustment nut ⑤ (Refer to Fig. 7)		Maximum level (CH1 PB FM Signal)

Test Equipment Connecting Diagrams
Oscilloscope




Fig. 8

1. Connect the equipment as shown in Fig. 8.
2. Set Tracking Control to its center position.
3. Adjust the X value adjustment nut ⑤ for maximum PB FM envelope for CH1 playing the test tape. (Refer to Fig. 9)
4. After adjusting the X value, check that the output level of the PB FM envelope signal for CH1 changes symmetrically by rotating Tracking Control.

Note: 1. X value adjustment above should be done so that the noise can be kept out on the TV screen with Tracking Control set to its center.




Fig. 9

5. Envelope Waveform Adjustment

Measuring Method

Measuring Point	Measuring Equip.	ADJ. Condition
TP 2 (C-PB) TP 1 (RF-SW)	Oscilloscope	PLAY MODE Test tape F8-NW
ADJ. Location		ADJ. Value
Guide rollers ② ③ (Refer to Fig. 1)		Maximum level and correct waveform (PB FM Signal)

Test Equipment Connecting Diagrams




Fig. 10

1. Connect the equipment as shown in Fig. 10.
2. Playback the test tape.
3. The envelope waveform can be performed by adjusting the height of both the supply side and take-up side guide rollers. Finely adjust the height of guide rollers so that the envelope waveform becomes as flat as possible.
4. Set Tracking Control to the fixed(center) position and confirm that a nearly maximum level is obtained. Then rotate the Tracking Control in both directions while adjusting the height of guide rollers ② and ③, in order to obtain the envelope waveform which is as flat as possible. If the tape is above or lower than helical tape position, the envelope waveforms will take the shape as shown in Fig. 11 and Fig. 12.
5. Adjust for maximum flatness of the envelope waveform according to the Fig. 11 and Fig. 12.
6. Confirmation of the correct adjustment can be made by alternately rotate tracking Control, and check the symmetry of the envelope.
7. Check the tape curl. (Refer to Section 2.)




	Tape is too high	
	Supply side	Take-up side
When the tracking control is rotated counterclockwise and clockwise directions.		
		
Adjustment	Supply side guide roller rotated clockwise direction (lowers guide roller) to flatten envelope.	Take-up side guide roller rotated clockwise direction (lowers guide roller) to flatten envelope.

Fig. 11

	Tape is too low	
	Supply side	Take-up side
When the tracking control is rotated counterclockwise and clockwise directions.		
		
Adjustment	Supply side guide roller rotated counterclockwise direction (raises guide roller) to flatten envelope.	Take-up side guide roller rotated counterclockwise direction (raises guide roller) to flatten envelope.

Fig. 12

6. Audio Control Erase Head Height / Audio Control Erase Head Tilt Adjustment

Measuring Method

Measuring Point	Measuring Equip.	ADJ. Condition
TP301 (A-OUT)	Oscilloscope AC voltmeter	PLAY MODE Test tape F6-A
ADJ. Location		ADJ. Value
Height adjustment nut ① Azimuth adjustment screw ② Tilt adjustment screw ③ (Refer to Fig. 7)		Maximum level (AC voltmeter)

Test Equipment Connecting Diagrams




Fig. 13

1. Connect the equipment as shown in Fig.13.
2. Confirm that the tape running between the take-up guide roller and the audio control erase head has no slack. If the tape has slack, take it up by turning the tilt adjustment screw ③. Then readjust GUIDE ROLLER HEIGHT in section 2 and the X value in section 4.
3. After confirming on the oscilloscope that a 1 kHz audio signal is being output by playing back the test tape, adjust the height adjustment nut ① so that the AC voltmeter's reading is brought to its maximum level.
4. Adjust the azimuth adjustment screw ② so that the AC voltmeter's reading is brought to its maximum level.

7. Audio Control Erase Head Azimuth Adjustment

Measuring Method

Measuring Point	Measuring Equip.	ADJ. Condition
TP301 (A-OUT)	Oscilloscope AC voltmeter	PLAY MODE Test tape F6-N
ADJ. Location		ADJ. Value
Azimuth adjustment screw ⑧ (Refer to Fig. 7)		Maximum level (AC voltmeter)

1. Connect the equipment as shown in Fig.13.
2. After confirming on the oscilloscope that an audio signal is being output by playing back the test tape, adjust the azimuth adjustment screw ⑧ so that the AC voltmeter's reading or osilloscope waveform is brought to its maximum level.

Note: Fix Tilt adjustment screw ⑨ with lock paint after readjustment (Refer to Fig. 7).


11. ELECTRICAL ALIGNMENT INSTRUCTIONS

Preparation
Electrical adjustments are required after replacing circuit components and certain mechanical parts. It is important to perform these adjustments only after all repairs and replacements have been completed. Also, do not attempt these adjustments unless the proper equipment is available.


- Test Equipment Required**
1. Oscilloscope : Dual-trace with 10:1 probe.
 2. TV Monitor
 3. Test tape : F6-A, F8-A

1. PAL Head Switching Point Adjustment

Test Point	Adjustment Point	Mode	Test Tape
TP55 (V-OUT) TP401 (RF-SW)	VR402 (Switching Point) (MCV-A P. C. B.)	PLAY	F6-A




1. Connect the equipment as shown in Fig. 1.
2. Set the "PAL MESECAM/NTSC" select switch to "PAL MESECAM" side.
3. Playback the test tape and adjust VR402 so that the V-sync front edge of CH1 video output waveform is delayed 6.5H (412.7μs) from the rising of CH2 Head Switching Pulse waveform.




2. PAL CTL Preset Adjustment

Test Point	Adjustment Point	Mode	Test Tape
TP402 (CTL) TP401 (RF-SW)	VR401 (CTL) (MCV-A P. C. B.)	PLAY	F6-A




1. Connect the equipment as shown in Fig. 2.
2. Set the "PAL MESECAM/NTSC" select switch to "PAL MESECAM" side.
3. Set the tracking volume to the center click position.
4. Playback the test tape and adjust VR401 to make a position of CH1 signal where delayed 4.0 msec. from the rising of CH2 RF Switching Pulse.




3. PB Output Level Adjustment

Test Point	Adjustment Point	Mode	Test Tape
TP55 (V-OUT)	VR51 (PB Level) (MCV-A P. C. B.)	PLAY	F6-A




1. Connect the equipment as shown in Fig. 3.
2. Set the "PAL MESECAM/NTSC" select switch to "PAL MESECAM" side.
3. Playback the test tape and adjust VR51 so that the video level becomes 1.0 Vp-p±0.05V.




4. Noise Cancel Adjustment

Test Point	Adjustment Point	Mode	Test Tape
TP52 TP53	VR52 (Noise Cancel) (MCV-A P. C. B.)	PLAY	F6-A




1. Connect the equipment as shown in Fig. 4.
2. Set the "PAL MESECAM/NTSC" select switch to "PAL MESECAM" side.
3. Playback the test tape and adjust VR52 so that the output levels (A, B) of both channels become the same.




5. NTSC Head Switching Point Adjustment

Test Point	Adjustment Point	Mode	Test Tape
TP55 (V-OUT) TP401 (RF-SW)	VR962 (Switching Point) (SWV P. C. B.)	PLAY	F8-A




1. Connect the equipment as shown in Fig. 5.
2. Set the "PAL MESECAM/NTSC" select switch to "NTSC" side.
3. Playback the test tape and adjust VR962 so that the V-sync front edge of CH1 video output waveform is delayed 6.5H (412.7μs) from the rising of CH2 Head Switching Pulse waveform.




6. NTSC CTL Preset Adjustment

Test Point	Adjustment Point	Mode	Test Tape
TP402 (CTL) TP401 (RF-SW)	VR961 (CTL) (SWV P. C. B.)	PLAY	F8-A




- 1. Connect the equipment as shown in Fig. 6.
- 2. Set the "PAL MESECAM/NTSC" select switch to "NTSC" side.
- 3. Set the tracking volume to the center click position.
- 4. Playback the test tape and adjust VR401 so that the falling of CH1 CTL signal becomes the same position with rising of CH2 RF switching pulse.



7. Free-run Frequency Adjustment


Test Point	Adjustment Point	Mode	Test Tape
TP241 TP242 TP243	VR241 (SWV P. C. B.)	PLAY	F8-A




- 1. Connect the equipment as shown in Fig. 7.
- 2. Set the "PAL MESECAM/NTSC" select switch to "NTSC" side.
- 2. Playback the test tape and adjust VR241 so that the Frequency Counter becomes 15.734 ±0.2KHz.

12. ALIGNMENT AND TEST POINTS

MCV-A P.C. BOARD (TOP VIEW)






A horizontal number line with 14 equal segments, labeled A through N above the line.



BOTTOM VIEW



TOP VIEW

[illegible]

TOP VIEW


BK2 590Z01001-E

A B C D E F G H I J K L M N


1
2
3
4
5
6
7
8
9
10

SWV P. C. BOARD


TOP VIEW



BOTTOM VIEW



PSV P.C. BOARD TOP VIEW



14. SCHEMATIC DIAGRAM

STANDARD NOTES

Temperature character of mark

Mark	Capacity change rate	Standard temperature	Use temperature of extent
Ⓑ	$\pm 10 \%$	20 °C	-25 ~ +85°C
Ⓕ	+30-80%	20 °C	-25 ~ +85°C
(SR)	$\pm 15 \%$	20 °C	-25 ~ +85°C
(Z)	+30-80%	20 °C	-10 ~ +70°C

WARNING

Replacement parts which special safety characteristics are identified by $\triangle$ showing on this schematic diagram. Replace these critical components with recommended replacement parts. Don't degrade the safety of this set through improper servicing. Service personnel to make leakage current or resistance measurement to determine that exposed parts are acceptably insulated from the supply circuit before returning the appliance to the customer.

NOTES

- ① Do not use the part number shown on this drawing for ordering. The correct part number is shown in the parts list, and may be slightly different or amended since this drawing was prepared.
- ② All resistance values are indicated in ohm ($K=10^3$, $M=10^6$).
- ③ Resister wattage without mentioned are 1/5W.
- ④ All capacitance values are indicated in μF ($P=10^{-6} \mu F$).

VOLTAGE CHARTS

Note

* Condition (A) : PAL MESECAM/NTSC Select Switch = PAL MESECAM
Test Tape = F6-A

* Condition (B) : PAL MESECAM/NTSC Select Switch = NTSC
Test Tape = F8-A

* All transistors are condition (A).

* All voltages are DC mesured and indicatied in volt.

CN-1 (Pins 6) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6
PLAY	11.7	0	4.8	17.5	11.7	0

IC 1 (Pins 22) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	~	4.6	1.9	0	0	0	0	0	0	0

Mode \ Pin No.	11	12	13	14	15	16	17	18	19	20
PLAY	0	0	0	0	1.8	0.6	0	0	0.6	1.8

Mode \ Pin No.	21	22
PLAY	0	0

IC 51 (Pins 30) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	0	0.4	0	2.6	4.7	1.0	2.1	0	3.3	3.3

Mode \ Pin No.	11	12	13	14	15	16	17	18	19	20
PLAY	0	2.8	3.1	3.1	3.9	3.3	0.2	2.4	0	0.1

Mode \ Pin No.	21	22	23	24	25	26	27	28	29	30
PLAY	2.3	4.7	3.3	3.1	3.8	3.4	0.9	0	4.7	4.1

IC 52 (Pins 8) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8
PLAY	8.7	0	8.7	3.2	3.1	2.2	1.5	4.7

IC101 (Pins 24) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	0.2	1.6	3.0	2.3	2.5	0	3.0	2.6	4.7	2.6

Mode \ Pin No.	11	12	13	14	15	16	17	18	19	20
PLAY	2.5	1.8	4.4	0.3	2.3	4.7	4.7	2.1	3.8	4.7

Mode \ Pin No.	21	22	23	24
PLAY	1.6	~	1.8	3.2

IC241 (Pins 20) Condition (B)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	0	0.2	2.1	2.8	3.3	2.8	1.9	2.6	3.6	4.6

Mode \ Pin No.	11	12	13	14	15	16	17	18	19	20
PLAY	2.1	0	0.3	2.1	1.9	2.6	0.3	2.7	2.1	2.1

IC281 (Pins 16) Condition (B)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	3.9	0	4.7	0.3	3.9	0	0	2.2	4.7	0

Mode \ Pin No.	11	12	13	14	15	16
PLAY	3.5	2.2	4.6	0	2.3	0.5

IC301 (Pins 8) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8
PLAY	1.4	0.8	3.9	10.5	0	4.3	0.9	1.4

IC401 (Pins 28) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	4.7	~	4.8	4.8	2.4	0	0	0	0	~

Mode \ Pin No.	11	12	13	14	15	16	17	18	19	20
PLAY	2.5	2.4	2.3	~	0	2.4	2.4	2.4	2.4	2.4

Mode \ Pin No.	21	22	23	24	25	26	27	28
PLAY	2.0	2.4	0	2.4	2.4	4.9	2.5	1.7

IC402 (Pins 8) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8
PLAY	2.7	2.4	2.4	0	2.4	2.4	2.4	4.7

IC501 (Pins 42) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	0	3.6	4.6	4.8	4.8	0	4.8	4.8	0	4.8

Mode \ Pin No.	11	12	13	14	15	16	17	18	19	20
PLAY	4.7	4.8	4.8	4.8	4.8	4.7	4.6	0.3	4.8	4.8

Mode \ Pin No.	21	22	23	24	25	26	27	28	29	30
PLAY	0	4.7	0	0	0	4.7	0	4.7	4.7	0

Mode \ Pin No.	31	32	33	34	35	36	37	38	39	40
PLAY	4.7	~	4.8	4.8	4.8	4.8	2.1	2.3	1.4	2.4

Mode \ Pin No.	41	42
PLAY	4.8	4.8

IC502 (Pins 8) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8
PLAY	4.8	2.4	4.3	0	4.3	2.4	4.8	4.8

IC503 (Pins 3) Condition (A)

Mode \ Pin No.	1	2	3
PLAY	4.8	0	4.8

IC505 (Pins 10) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	0	0.5	0.9	0.4	1.9	1.9	11.7	11.7	0.9	0.5

IC554 (Pins 10) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	0	0.1	0.2	2.9	0	3.6	17.1	17.1	5.0	3.2

IC701 (Pins 16) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	1.4	0	11.7	4.9	1.1	9.5	7.4	0.6	2.3	9.5

Mode \ Pin No.	11	12	13	14	15	16
PLAY	7.4	10.6	10.7	10.2	0	0

IC903 (Pins 8) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8
PLAY	15.7	0.3	2.3	0	2.4	2.4	2.9	17.1

IC961 (Pins 28) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	4.7	0.7	4.8	4.8	2.2	0	0.1	0	0	2.3

Mode \ Pin No.	11	12	13	14	15	16	17	18	19	20
PLAY	2.4	2.3	2.3	2.4	0	2.4	2.3	2.3	2.3	2.3

Mode \ Pin No.	21	22	23	24	25	26	27	28
PLAY	1.8	2.3	0	2.3	2.3	4.7	2.0	1.6

IC962 (Pins 16) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	~	2.3	2.3	2.3	3.5	0	0	0	4.2	4.2

Mode \ Pin No.	11	12	13	14	15	16
PLAY	4.2	4.7	2.3	2.3	2.4	4.7

IC963 (Pins 16) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	~	~	~	~	0.5	0	0	0	4.2	4.2

Mode \ Pin No.	11	12	13	14	15	16
PLAY	4.2	~	2.4	2.4	~	4.7

IC964 (Pins 16) Condition (A)

Mode \ Pin No.	1	2	3	4	5	6	7	8	9	10
PLAY	0.1	0.1	0	0	0	0	0	0	4.2	4.2

Mode \ Pin No.	11	12	13	14	15	16
PLAY	4.2	0.1	0.1	0.1	0.1	4.7

Q 1

Mode \ Pin	E	C	B
PLAY	1.1	3.5	1.9

Q 2

Mode \ Pin	E	C	B
PLAY	0.4	4.3	1.1

Q 3

Mode \ Pin	E	C	B
PLAY	3.7	4.6	4.4

Q51

Mode \ Pin	E	C	B
PLAY	3.1	0	2.4

Q52

Mode \ Pin	E	C	B
PLAY	4.8	4.8	4.1

Q53

Mode \ Pin	E	C	B
PLAY	0.3	3.8	1.0

Q54

Mode \ Pin	E	C	B
PLAY	3.2	4.8	3.8

Q55

Mode \ Pin	E	C	B
PLAY	1.5	0	0.9

Q56

Mode \ Pin	E	C	B
PLAY	2.6	8.7	3.2

Q57

Mode	Pin	E	C	B
PLAY		8.7	11.7	9.4

Q104

Mode	Pin	E	C	B
PLAY		1.2	2.6	1.9

Q142

Mode	Pin	E	C	B
PLAY		1.0	4.8	0

Q401

Mode	Pin	E	C	B
PLAY		2.4	2.5	3.2

Q502

Mode	Pin	E	C	B
PLAY		11.7	11.7	11.0

Q505

Mode	Pin	E	C	B
PLAY		0	4.8	0

QR61

Mode	Pin	E	C	B
PLAY		1.9	4.7	2.3

QR401

Mode	Pin	E	C	B
PLAY		~	4.7	0

QR701

Mode	Pin	E	C	B
PLAY		4.7	0	4.8

QR704

Mode	Pin	E	C	B
PLAY		4.8	0	4.8

Q101

E	C	B
3.1	4.7	3.8

Q105

E	C	B
1.4	3.3	2.1

Q241

E	C	B
4.6	0	4.1

Q402

E	C	B
0	2.1	0

Q503

E	C	B
4.6	4.7	~

Q901

E	C	B
2.3	2.4	2.3

QR51

E	C	B
4.7	0.1	4.7

QR501

E	C	B
0	0	4.8

QR702

E	C	B
4.7	4.7	0

Q103

E	C	B
1.7	4.7	2.3

Q141

E	C	B
1.0	4.8	1.6

Q301

E	C	B
0	0	0

Q501

E	C	B
4.8	4.8	5.5

Q504

E	C	B
0	2.9	0.6

Q911

E	C	B
0	2.4	0

QR52

E	C	B
0	0	4.7


QR502

E	C	B
4.8	0.3	4.8


QR703

E	C	B
4.7	0	4.8


15. WAVEFORM




WF1 Point:TP 2 20mV/div. X10
TP 1 0.5V/div. X10
5 ms/div. Mode: PB(SP) Test Tape: F6-N




WF2 Point:TP402 0.1V/div. X10
TP401 0.5V/div. X10
5 ms/div. Mode: PB(SP) Test Tape: F6-A




WF3 Point:TP301 50mV/div. X10
0.5 ms/div. Mode: PB(SP) Test Tape: F6-A



WF4 Point:TP 55 20mV/div. X10
20 μs/div. Mode: PB(SP) Test Tape: F6-A




WF5 Point:TP 52 20mV/div. X10
TP 53 20mV/div. X10
20 μs/div. Mode: PB(SP) Test Tape: F6-A




WF6 Point:TP401 0.2V/div. X10
TP402 0.1V/div. X10
5 ms/div. Mode: PB(SP) Test Tape: F8-A

SUB



PSV




16. IC PIN FUNCTION DESCRIPTION

14DN486 (System Control IC)

Pin No	IN/OUT	Signal name	Function
1	IN	Vss	GND
2	OUT	SYNC	IC Internal Clock
3	IN	REMOCON	Remote Control Serial Signal Input
4	IN	FL-A	Cassette In Start Detector
5	IN	FL-B	Cassette In Start Detector
6	IN	FL-C	Cassette In Start Detector
7	IN	LD-A	Tape Loading Position Detector
8	IN	LD-B	Tape Loading Position Detector
9	IN	LD-C	Tape Loading Position Detector
10	IN	LD-D	Tape Loading Position Detector
11	IN	P 10	Key Scan Signal Input
12	IN	P 11	Key Scan Signal Input
13	IN	P 12	Key Scan Signal Input
14	IN	P 13	Key Scan Signal Input
15	OUT	P 20	Key Scan Signal Output
16	OUT	P 21	Key Scan Signal Output
17	OUT	P 22	Key Scan Signal Output
18	OUT	P 23	Key Scan Signal Output
19	OUT	REW	Rew Display
20	OUT	F.F	F.F Display
21	OUT	PLAY	Play Display
22	OUT	D-PB	Play Control
23	OUT	D-ON	Drum Rotation Output
24	OUT	C-FAST	Capstan Motor High Speed Control Output
25	OUT	C-REV	Capstan Motor Reverse Control Output
26	OUT	C-FWD	Capstan Motor Forward Control Output
27	OUT	A-MUTE	Sound Mute Output
28	OUT	LD-REV	Tape Loading / Cassette Loading Motor Control
29	OUT	LD-FWD	Tape Loading / Cassette Loading Motor Control
30	OUT	PAUSE	Pause Signal Output
31	OUT	P-ON	Power On Control
32	0	REEL	Reel Pulse Input Check
33	IN	END-S	Tape End Position Detector
34	IN	START-S	Tape Start Position Detector
35	OUT	S-DATA	Servo IC Data



17. SYSTEM CONTROL TIMING CHART

1. OFF → CASSETTE INSERT → F.F. → STOP → REW → STOP → PLAY




18. LEAD IDENTIFICATIONS


2. PLAY → F.F. → REW (RS) → PLAY → STOP → EJECT





FRONT PANEL EXPLODED VIEW



DECK EXPLODED VIEW






20. MECHANICAL PARTS LIST

MODEL NO. F1

NOTE
(A):SERIAL NO. D48010001~D48011985
(B):SERIAL NO. D48011985~



REF. NO.	DESCRIPTION	PART NO.
A- 1X	FRONT ASS'Y	OVM200603
A- 1	FRONT	OVM200603X
A- 2	PLATE, MODE	OVM401645
A- 3	BADGE	6D52254
A- 4	FOOT	6E50453
A- 5	CUSHION, DOOR	OVM400346
A- 6	DOOR, CASSETTE	OVM402107
A- 7	SPRING, DOOR	6V50109
A- 8	KNOB, AUTO REPEAT	6D52263
A- 9	CASE, TOP	6G50092
A-10	PANEL, BOTTOM	OVM200019
A-11	FILM, INSULATOR	OVM402167
A-12	⚠ LABEL, RATING	(A) OVM402322
A-12	⚠ LABEL, RATING	(B) OVM402108
A-13	SPACER	OVM400719
B1- 1	DECK ASS'Y	OVDK00082
B2- 1	CABINET, MAIN SSC-P/B	6C50587
B2- 2	METAL GROUND (L) (V3)	6S50356
B2- 3	PLATE, GRAND	OVM400227
B2- 4	HOLDER, PCB	OVM300683
B2- 5	SPACER, PCB	OVM401598
B2- 6	SPACER, DECK	OVM401389
B2- 7	SHIELD, BOTTOM	OVM200561
B2- 8	SHIELD, TOP	(A) OVM200562
B2- 8	SHIELD, TOP	(B) OVM200653
B2- 9	ANGLE	OVM401935
B2-10	HOLDER	OVM402185
B2-11	HEAT SINK, IC	OVM402223
M 1	JACK BOARD ASS'Y	OVM300230
M 2	SHIELD, BOTTOM P/B	OVM400068
M 3	PLATE, TOP SHIELD	6S50372
M 4	HOLDER, LED (LEVEL)	6D52258
M 5	HOLDER, L. E. D.	OVM300426
M 6	HEATSINK, IC	6S50527
M604	HOLDER, AC CORD	6S50286

REF. NO.	DESCRIPTION	PART NO.
L202	SCREW, P-TIGHT, WASHER HEAD M3X10	GCMP3100
L205	SCREW, P-TIGHT, BIND HEAD M4X12	GBKP4120
L2011	SCREW, B-TIGHT, BIND HEAD M3X10	GBMB3100
L2012	SCREW, P-TIGHT, BIND HEAD M3X10	GBMP3100
L2032	SCREW, P-TIGHT, BIND HEAD M4X12	GBMP4120
L2033	SCREW, TAPPING, BIND HEAD M3X10	DBM13100
L2A11	SCREW, P-TIGHT, BIND HEAD M3X10	GBMP3100
L2P02	SCREW, A-TIGHT, BIND HEAD M3X8	DBM13080
L2Q01	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
L2Q02	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
L2Q03	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
L2Q04	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
△	OWNER'S MANUAL	(A) OVMN00631
△	OWNER'S MANUAL	(B) OVMN00556
	REMOTE CONTROL UNIT	1813571
	RF CABLE	1750762 5750109

MODEL NO. F2

NOTE

(A):SERIAL NO. D48010001~D48011985

(B):SERIAL NO. D48011985~

REF. NO.	DESCRIPTION	PART NO.
A- 1X	FRONT ASS'Y	OVM200611
A- 1	FRONT	OVM200611X
A- 2	PLATE, MODE	OVM401645
A- 3	BADGE	6D52254
A- 4	FOOT	6E50453
A- 5	CUSHION, DOOR	OVM400346
A- 6	DOOR, CASSETTE	OVM402107
A- 7	SPRING, DOOR	6V50109
A- 8	KNOB, AUTO REPEAT	6D52263
A- 9	CASE, TOP	6G50092
A-10	PANEL, BOTTOM	OVM200019
A-11	FILM, INSULATOR	OVM402167
A-12 △	LABEL, RATING	(A) OVM402323
A-12 △	LABEL, RATING	(B) OVM402155
A-13	SPACER	OVM400719
B1- 1	DECK ASS'Y	OVDK00082
B2- 1	CABINET, MAIN SSC-P/B	6C50587
B2- 2	METAL GROUND (L) (V3)	6S50356
B2- 3	PLATE, GRAND	OVM400227
B2- 4	HOLDER, PCB	OVM300683
B2- 5	SPACER, PCB	OVM401598
B2- 6	SPACER, DECK	OVM401389
B2- 7	SHIELD, BOTTOM	OVM200561
B2- 8	SHIELD, TOP	(A) OVM200562
B2- 8	SHIELD, TOP	(B) OVM200653
B2- 9	ANGLE	OVM401935
B2-10	HOLDER	OVM402185
B2-11	HEAT SINK, IC	OVM402223
M 1	JACK BOARD ASS'Y	OVM300103
M 2	SHIELD, BOTTOM P/B	OVM400068
M 3	PLATE, TOP SHIELD	6S50372
M 4	HOLDER, LED (LEVEL)	6D52258
M 5	HOLDER, L. E. D.	OVM300426
M 6	HEATSINK, IC	6S50527
M604	HOLDER, AC CORD	6S50286

REF. NO.	DESCRIPTION	PART NO.
L202	SCREW, P-TIGHT, WASHER HEAD M3X10	GCMP3100
L205	SCREW, P-TIGHT, BIND HEAD M4X12	GBKP4120
L2011	SCREW, B-TIGHT, BIND HEAD M3X10	GBMB3100
L2012	SCREW, P-TIGHT, BIND HEAD M3X10	GBMP3100
L2032	SCREW, P-TIGHT, BIND HEAD M4X12	GBMP4120
L2033	SCREW, TAPPING, BIND HEAD M3X10	DBM13100
L2A11	SCREW, P-TIGHT, BIND HEAD M3X10	GBMP3100
L2P02	SCREW, A-TIGHT, BIND HEAD M3X8	DBM13080
L2Q01	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
L2Q02	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
L2Q03	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
L2Q04	SCREW, S-TIGHT, BIND HEAD M3X5	GBMS3050
△	OWNER'S MANUAL	(A) OVMN00632
△	OWNER'S MANUAL	(B) OVMN00568
	REMOTE CONTROL UNIT	1813571
	RF CABLE	1750762 5750109

21. DECK PARTS LIST

Ref No.	Description	MFR' Part No.	Q' ty
1	Cylinder Assembly	8059-82-40A	1
2	Drum, Upper	8059-01-18	1
3	Drum Assembly, Lower	8059-01-304	1
4	Mount, Cylinder	8059-01-01	1
5	P.C.B. Assembly, Video Out	8059-01-305	1
6	Screw, W Sems, M2.6 × 6	9973-00-00	1
7	Motor TM84	6004-09-02	1
8	Screw, C-tight, M2.6 × 20	9055-00-00	3
9	Screw, Sems, M2.6 × 6	9098-00-00	2
10	Screw, Bind Sems, M3 × 8	9972-00-00	2
11	Screw, C-tight, M3 × 10	9205-00-00	3
12	Screw, B-tight M2 × 6	9999-18-18	1
13	Screw, Cap, M2.6 × 3	9665-00-00	1
*14	Flat Spring, Drum Ground	8059-01-54	1
15	Screw, C-tight, M2.6 × 5	9192-00-00	1
16	Bracket, Drum Ground	8059-01-02	1
17	P.C.B. Assembly, DM	8059-01-347	1
18	Screw, C-tight, M2.6 × 5	9192-00-00	1
*19	Drum Ground	8059-01-23	1
20	Washer, Toothed Lock, M2.6	9715-00-00	1
23	Connector Bracket	8059-01-71	1
32	Open Angle	8059-02-301	1
33	Screw, C-tight, M2.6 × 4	9191-00-00	1
34	Adjuster, Tracking	8059-02-29	1
35	Guide, Tape	8000-03-14	1
36	Spring, Tape Guide	8059-02-26	1
37	Cap, Guide	8000-03-19	1
38	Flange (C), Tape Guide	8000-03-28	1
39	Flange (D), Tape Guide	8000-03-29	1
40	Nut M3.0	9453-00-00	1
41	Rubber, Damper	8059-02-23	1
51	Loading Base	8059-03-501	1
52	Block (L), Loading	8059-03-04	1
53	Block (R), Loading	8059-03-05	1
54	Roller Post ST	8000-03-37	1
55	Roller Post ST	8000-03-37	1
56	Screw, Cup, M2.6 × 3	9665-00-00	2
57	Screw, Set, M2.0 × 3 (Plane Type)	9550-00-00	2
58	Screw, C-tight, M2.6 × 5	9192-00-00	2
59	Plate (L), Loading	8059-03-502	1
60	Boss, Loading	8059-03-14	2
61	Spring (L), Loading Gear	8059-03-08	1
62	Gear (L), T Loading	8059-03-06	1
63	Plate (R), Loading	8059-03-503	1
64	Spring (R), Loading Gear	8059-03-09	1
65	Gear (R), T Loading	8059-03-07	1
66	Washer, Polyslider, $\phi 2.6 \times \phi 6 \times t 0.5$	9884-00-00	2
67	Loading Base Assembly	8059-03-301	1
68	Loading Gear (L) Assembly	8059-03-302	1
69	Loading Gear (R) Assembly	8059-03-303	1

* Replace these parts in pairs.

Ref No.	Description	MFR' Part No.	Q' ty
81	Head Base Assembly	8059-04-307	1
82	Head, ACE	6204-15-08	1
83	Base, Head	8059-04-502	1
84	Screw, Azimuth Spring	8000-06-26	1
85	Spring, Azimuth	8000-06-04	1
86	Nut, Nylon M3	9953-00-00	1
88	Screw, M2.6 X7	9705-00-00	1
89	Screw, Set, M3X6	9999-20-25	1
90	Spring, Head	8059-04-15	1
91	Plate Assembly, Full Erase	8059-04-302	1
92	Head, Full Erase	6204-15-03	1
93	Plate, Full Erase	8059-04-04	1
94	Screw, Flange Bind, M2X3	9114-00-00	1
95	Nut, Nylon M3	9953-00-00	1
96	Roller, Impedance	8059-04-05	1
97	Sleeve, Impedance Roller	8059-04-06	1
98	Flange (A), Tape Guide	8059-04-07	1
99	Spring, Tape Guide Flange	8059-04-09	1
100	Washer, Plane $\phi 3 \times \phi 8 \times t 0.5$	9337-00-00	1
101	Spring, FE Plate	8059-04-08	1
102	Plate, FE Slide	8059-04-10	1
103	Spring, FE Actuate	8059-04-12	1
104	Lever, FE Actuate	8059-04-11	1
105	Washer, Polyslider, $\phi 2.1 \times \phi 5 \times t 0.5$	9876-00-00	1
121	Reel Assembly	8059-05-301	2
122	Washer, $\phi 3.1 \times \phi 6 \times t 0.5$	9912-00-00	2
131	Arm Assembly, Pinch Roller	8059-06-301	1
132	Arm Pinch Roller	8059-06-501	1
133	Screw, M2.6 X4	9038-00-00	1
134	Roller (A), Pinch	8000-09-22	1
135	Washer, Polyslider, $\phi 5 \times \phi 8 \times t 0.5$	9999-03-11	1
136	Screw, Sems, M2.6 X4	9096-00-00	1
137	Collar	8059-06-18	1
138	Angle, P Actuate	8059-06-05	1
139	Holder, P Angle	8059-06-19	1
140	Spring, P Roller	8059-06-20	1
141	Plate (A), P Slide	8059-06-24	1
142	Collar	8059-06-18	1
143	Screw, C-tight, M2.6X5	9192-00-00	1
144	Joint Plate	8059-06-06	1
145	Arm, P Actuate	8059-06-04	1
146	Spring, P Actuate Arm	8059-06-09	1
147	Crank, P	8059-06-12	1
148	Collar, P Crank	8059-06-13	1
149	Screw, C-tight FH (For Camera), M2.6X4	9999-18-10	1
150	Slider, P	8059-06-10	1
151	Spring, P Slider	8059-06-23	1
152	Collar, P Slider	8059-06-11	1
153	Screw, C-Tapping, M2.6X5	9192-00-00	1
154	Lever, P Cam	8059-06-502	1
155	Collar, P Cam Lever	8059-06-17	1
156	Screw, C-tight, M2.6X5	9192-00-00	1
157	Plate (B), P Slide	8059-06-25	1

Ref No.	Description	MFR' Part No.	Q' ty
171	Motor Assembly, Capstan	8059-07-302	1
172	Capstan, Flywheel	8059-07-14	1
173	Belt, Main	8059-07-10	1
174	Angle Assembly, Flywheel	8059-07-303	1
175	Screw, C-tight, M3X5	9202-00-00	2
176	Washer, $\phi 3.1 \times \phi 6 \times t 0.5$	9912-00-00	1
177	Housing Assembly, Metal	8059-07-301	1
178	Screw, C-tight, M2.6X8	9195-00-00	3
179	Screw, Sems, M3 X4	9105-00-00	2
180	Nylon Washer 2.92 X5 X0.5	9999-06-03	1
191	Arm, Back Tension	8059-08-501	1
192	Screw, C-tight, M2.6X4	9191-00-00	1
193	Support, Back Tension	8059-08-09	1
194	Screw, C-tight, M2.6X4	9191-00-00	1
195	Collar, Band Holder	8059-08-15	1
196	Band, BT	8059-08-302	1
197	Spring, Band Holder	8059-08-17	1
198	Spring, Back Tension	8059-08-13	1
199	Washer, Polyslider, $\phi 2.1 \times \phi 4 \times t 0.5$	9999-03-15	1
200	Plate, BT Change	8059-08-10	1
202	Lever, BT Return	8059-08-23	1
203	Collar	8059-06-18	1
204	Screw, C-tight, M2.6X5	9192-00-00	1
205	Plate, BT Actuate	8059-08-19	1
206	Lever, BT Actuate	8059-08-18	1
207	Collar, BT Actuate Plate	8059-08-21	2
208	Spring, BT Actuate Plate	8059-08-20	1
209	Collar	8059-06-18	1
210	Screw, S-tight (For Camera) M2.6X3.5	9840-00-00	2
211	Screw, C-tight M2.6 X5	9192-00-00	1
221	Plate Assembly	8059-09-312	1
222	Plate Semi Assembly	8059-09-503	1
223	Screw, Sems, M2 X4	9077-00-00	2
224	Screw, C-tight, M2.6X4	9192-00-00	1
226	Gear, Reel Drive	8059-09-06A	2
228	Washer, Nylon, $\phi 3.1 \times \phi 6 \times t 0.3$	9853-00-00	1
229	Clutch Assembly	8059-09-311	1
230	Washer, Nylon, $\phi 2.98 \times \phi 6 \times t 0.3$	9999-06-04	1
231	Pulley Assembly, Middle	8059-09-301	1
232	Washer, Polyslider, $\phi 2.6 \times \phi 6 \times t 0.5$	9884-00-00	1
233	Belt, Drive	8059-09-17	1
234	Arm Assembly, P Gear	8059-09-303	1
235	Gear, Play	8059-09-20A	1
236	Arm Assembly, RF Gear	8059-09-304	1
237	Gear, FF	8059-09-22A	1
238	Washer, Polyslider, $\phi 1.6 \times \phi 3.8 \times t 0.3$	9743-00-00	3
239	Gear Assembly, P	8059-09-314	1
240	Gear Assembly, RF	8059-09-315	1
241	Return Gear Assembly	8059-09-313	1
242	Retrun Arm	8059-09-53	1
251	Shoe, Brake	8059-10-19	2
252	Arm, S Brake	8059-10-01	1
253	Spring, Brake Arm	8059-10-02	2

Ref No.	Description	MFR' Part No.	Q' ty
254	Arm, T Brake	8059-10-03	1
255	Arm Assembly, S Brake	8059-10-301	1
256	Arm Assembly, T Brake	8059-10-302	1
257	Lifter, Brake	8059-10-16	1
258	Actuator, L Brake	8059-10-17	1
259	Hook, Trigger	8059-10-14	1
260	Lever, Trigger	8059-10-13	1
261	Plate, Brake	8059-10-11	1
262	Brake Actuate, Base	8059-10-09	1
263	Brake, Take-up soft	8059-10-303	1
264	Brake, S Soft	8059-10-304	1
265	Screw, SL FH (For Camera), M2 X3	9974-00-00	1
266	Collar, Take-up Soft Brake Arm	8059-10-07	1
267	Spring, L Brake Actuator	8059-10-18	1
268	Spring, Take-up Soft Brake Arm	8059-10-06	1
269	Spring, S Soft Brake	8059-10-22	1
270	Washer, Polyslider, $\phi 2.1 \times \phi 5 \times t 0.5$	9876-00-00	1
271	Spring, Trigger Lever	8059-10-23	1
272	Brake Actuate Base Spring	8059-10-10	1
273	Brake Plate Spring	8059-10-12	1
281	LM Assembly	8059-11-301	1
282	Bearing Assembly, Trigger	8059-11-302	1
283	Pulley, Loading	8059-11-03	1
284	Washer, Polyslider, $\phi 1.6 \times \phi 3.8 \times t 0.3$	9743-00-00	1
285	Belt, Loading	8059-11-06	1
286	Arm (B), Search	8059-11-12	1
287	Washer, Polyslider, $\phi 2.6 \times \phi 6 \times t 0.5$	9884-00-00	1
288	Gear, Loading	8059-11-04	1
289	Washer, Polyslider, $\phi 2.1 \times \phi 5 \times t 0.5$	9876-00-00	1
290	Arm, Brake Actuate	8059-11-13	1
291	Arm, Eject Actuate	8059-11-14	1
293	Cam, Loading	8059-11-01	1
294	Brush, S	8059-11-02	1
295	Screw, C-tight, M3X4	9105-00-00	2
296	Washer, Polyslider, $\phi 2.6 \times \phi 8 \times t 0.5$	9999-03-10	1
312	Lever Semi Assembly, Loading	8059-12-501	1
313	Roller, Cam	8059-12-13	1
314	Plate, Loading Gear	8059-12-09	1
315	Collar, Loading Gear Plate	8059-12-10	1
316	Screw, C-tight, M3X6	9203-00-00	1
317	Lever Semi Assembly, Loading Actuate	8059-12-502	1
318	Plate, Semi Assembly, Loading Actuate	8059-12-503	1
319	Spring, Loading Actuate	8059-12-05	1
320	Plate, Loading Lever Reinforce	8059-12-11	1
321	Screw, Sems, M2 X5	9078-00-00	2
322	Spring, L Gear Plate	8059-12-12	1
331	Not Used		
332	Not Used		
333	Not Used		
334	Not Used		
335	Not Used		
336	Sensor, DEW	6808-08-04	1
337	Screw, Sems, M2.6 X4	9096-00-00	1

Ref No.	Description	MFR' Part No.	Q' ty
338	Plate, Base	8059-13-307	1
339	Screw, S-tight (For Camera), M2.6X5	9691-00-00	1
341	Not Used		
342	Not Used		
343	Not Used		
344	Not Used		
345	Lamp Holder Assembly	8059-13-306	1
346	Not Used		
347	Collar, Screw	8059-13-17	1
361	Actuator, Eject	8059-15-08	1
362	Collar	8059-06-18	1
363	Screw, C-tight, M2.6X5	9192-00-00	1
364	Plate, L Brake	8059-15-07	1
365	Collar	8059-06-18	1
366	Screw, C-tight, M2.6X5	9192-00-00	1
367	Arm Assembly, E Idler	8059-15-303	1
368	Arm Semi Assembly, E Idler	8059-15-502	1
369	Pulley, Eject	8059-15-15	1
370	Washer, Polyslider, $\phi 1.6 \times \phi 3.8 \times t 0.3$	9743-00-00	1
371	Spring, Idler Arm	8059-15-11	1
372	Washer, Polyslider, $\phi 2.1 \times \phi 6 \times t 0.5$	9876-00-00	1
373	Belt, Front Loading	8059-15-06	1
390	Loading Assembly, Front	8059-16-337	1
391	Bracket Assembly, Cassette Load	8059-16-318	1
392	Clutch Assembly, Front Loading	8059-16-319	1
393	P.C.B. Assembly, Front Loading	8059-16-320	1
394	Sensor, P.C.B. (RM)	8059-16-316	1
395	Bracket Semi Assembly, Cassette Load	8059-16-506	1
396	Lever, IN SW	8059-16-34	1
397	Lever, S SW	8059-16-33	1
398	Bearing (A), F Worm	8059-16-06	1
399	Washer, Polyslider, $\phi 1.6 \times \phi 3.8 \times t 0.3$	9743-00-00	1
400	Screw, Sems, M2.6 X4	9096-00-00	2
401	Screw, Sems, M2 X5	9078-00-00	1
411	Holder Assembly, Cassette	8059-16-306	1
412	Holder, Cassette	8000-22-03	1
413	Plate, Slide	8000-22-13	1
414	Plate (A), C Lock	8000-22-12	1
415	Collar	8059-06-18	1
416	Spring, Lock	8059-16-29	1
417	Screw, SL (For Camera), M2.6 X3	9968-00-00	1
420	Angle Assembly, Front	8059-16-307	1
421	Angle, Front	8059-16-18	1
422	Guide (R), Tape	8059-16-25	1
423	Guide (L), Tape	8059-16-24	1
430	Plate (R) Assembly, Side	8059-16-308	1
431	Plate (R), Side	8059-16-502	1
432	Plate, Cassette Push	8059-16-28	1
433	Screw (For Camera), M2.3X2	9833-00-00	1
434	Lever, Open	8000-22-25	1
435	Spring, Open Lever	8000-22-44	1
436	Lever Collar, Open	8000-22-42	1
437	Screw, SL (For Camera), M2X4	9967-00-00	1

Ref No.	Description	MFR' Part No.	Q' ty
438	Lever, Lock Release	8000-22-16	1
439	Roller, Guide	8000-22-75	2
440	Roller, Guide	8000-22-23	1
445	Plate (L) Assembly, Side	8059-16-309	1
446	Plate (L), Side	8059-16-503	1
447	Plate, Cassette Push	8059-16-28	1
448	Screw (For Camera), M2.3×2	9833-00-00	1
449	Plate (L), C Lock	8000-22-66	1
450	Spring (L), Lock Plate	8059-16-30	1
451	Collar, Lock Plate	8000-19-63	1
452	Screw (For Camera), M2×2.5	9966-00-00	1
453	Roller, Guide	8000-22-75	2
460	Frame (R) Assembly	8059-16-339	1
461	Frame (R)	8059-16-507	1
462	Wheel Assembly, Worm	8059-16-321	1
463	Wheel, Worm	8059-16-36	1
464	Gear, Friction	8059-16-45	1
465	Spring, Friction	8059-16-31	1
466	Gear (R) Assembly, Lift	8059-16-312	1
467	Gear (R), Lift	8000-22-15	1
468	Arm, Lift	8000-22-11	1
469	Spring, LP	8000-22-45	1
470	Guide, Open Lever	8000-22-26	1
471	Sleeve, Guide	8000-22-24	1
472	E Ring S 2.5	9504-00-00	2
480	Frame (L) Assembly	8059-16-338	1
481	Frame (L)	8059-16-508	1
482	Sensor, P.C.B. (LM)	8059-16-301	1
483	Gear (L) Assembly, Lift	8059-16-314	1
484	Gear, Lift	8000-22-14	1
485	Arm, Lift	8000-22-11	1
486	Spring, LP	8000-22-45	1
487	Lever, Lift	8059-16-67	1
488	Spring, Lift Lever	8059-16-68	1
489	E Ring S 2.5	9504-00-00	1
490	Screw, Sems, M2.6 ×7	9099-00-00	1
491	Sleeve, Guide	8000-22-24	1
498	Stay, Top	8000-22-65	1
499	Wire, End Sensor	8059-16-19	1
500	Angle, Rear	8059-16-09	1
501	Plate, Upper	8059-16-66	1
502	Shaft, Synchronize	8059-16-60	1
503	Gear (A), Synchronize	8059-16-17	2
504	E Ring S 2.5	9504-00-00	2
505	Screw, Sems, M2.6 ×4	9096-00-00	10
506	Screw (For Camera), M2.6×3	9556-00-00	2
507	Screw (For Camera), M2.3×2.5	9991-00-00	2
508	Screw, C-Tight, M2.6×5	9192-00-00	4
531	Plate, RG Slide	8059-17-03	1
532	Spring, RG Slide	8059-17-11	1
533	Collar, RG Slide Plate	8059-17-10	1
534	Screw, Sems, M2 ×4	9077-00-00	1
535	Base, RG Slide	8059-17-09	1

Ref No.	Description	MFR' Part No.	Q' ty
536	Arm Semi Assembly, RG	8059-17-502	1
537	Washer, Polyslider, $\phi 2.6 \times \phi 6 \times t 0.5$	9884-00-00	1
538	Arm, RG Actuate	8059-17-01	1
539	Washer, Polyslider, $\phi 2.1 \times \phi 5 \times t 0.5$	9876-00-00	1
540	RG Actuator	8059-17-02	1

22. ELECTRICAL PARTS LIST

PRINTED CIRCUITBOARD ASSEMBLY	MODEL NO. F1	MODEL NO. F2
MCV C. B. A. (CONSISTS OF MCV-A ~E, SWV C. B. A.)	OVSA03470	OVSA02660
MCV-A C. B. A.	OVSA03470-A	OVSA02660-A
MCV-B C. B. A.	OVSA03470-B	OVSA02660-B
MCV-C C. B. A.	OVSA03470-C	OVSA02660-C
MCV-D C. B. A.	OVSA03470-D	OVSA02660-D
MCV-E C. B. A.	OVSA03470-E	OVSA02660-E
SWV C. B. A.	OVSA02662	OVSA02662
PSV C. B. A.	OVSA03449	OVSA03449

MCV-A C. B. A.

REF. NO.	DESCRIPTION	PART NO.
C 51	CERAMIC CAP.	Y M 0. 01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0. 01UF/16V 1220842T
C 52	ELECTROLYTIC CAP.	2. 2UF/50V M 126F225S
C 53	CERAMIC CAP.	F Z 0. 022UF/25V 122Z122T
	CERAMIC CAP.	F Z 0. 022UF/25V 1220843T
C 54	ELECTROLYTIC CAP.	47UF/6. 3V M 126A476S
C 55	CERAMIC CAP.	Y M 0. 01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0. 01UF/16V 1220842T
C 56	CERAMIC CAP.	Y M 0. 01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0. 01UF/16V 1220842T
C 57	SEMICONDUCTOR CAP.	SR K 0. 068UF/25V 12Y2683S
C 58	ELECTROLYTIC CAP.	10UF/16V M 126C106S
C 59	ELECTROLYTIC CAP.	1000UF/6. 3V M 126A108S
C 60	ELECTROLYTIC CAP.	330UF/16V M 126C337S
C 61	ELECTROLYTIC CAP.	4. 7UF/25V M 126D475S
C 62	CERAMIC CAP.	Y M 0. 01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0. 01UF/16V 1220842T
C 63	ELECTROLYTIC CAP.	1UF/50V M 126F105
C 64	ELECTROLYTIC CAP.	0. 47UF/50V M 126F474S
C 65	CERAMIC CAP.	B J 82PF/50V 3B41820T
C 66	ELECTROLYTIC CAP.	0. 47UF/50V M 126F474S
C 67	CERAMIC CAP.	B J 150PF/50V 3B41151T
C 69	ELECTROLYTIC CAP.	2. 2UF/50V M 126F225S
C 70	ELECTROLYTIC CAP.	2. 2UF/50V M 126F225S
C 71	CERAMIC CAP.	B J 560PF/50V 3B41561T
C 72	CERAMIC CAP.	B J 390PF/50V 3B41391T
C 73	CERAMIC CAP.	SL J 22PF/50V 3S41220T
C 74	CERAMIC CAP.	B J 82PF/50V 3B41820T
C 75	CERAMIC CAP.	SL J 22PF/50V 3S41220T
C 76	ELECTROLYTIC CAP.	10UF/16V M 126C106S
C 77	CERAMIC CAP.	B J 220PF/50V 3B11221
	CERAMIC CAP.	B J 220PF/50V 3B11221
C 78	SEMICONDUCTOR CAP.	F Z 0. 1UF/25V 1220520S
C 81	CERAMIC CAP.	B J 180PF/50V 3B11181
C101	CERAMIC CAP.	Y M 0. 01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0. 01UF/16V 1220842T
C102	CERAMIC CAP.	Y M 0. 01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0. 01UF/16V 1220842T

REF. NO.	DESCRIPTION	PART NO.
C103	ELECTROLYTIC CAP.	47UF/6.3V M 126A476S
C104	CERAMIC CAP.	F Z 0.022UF/25V 122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V 1220843T
C105	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C106	CERAMIC CAP.	B J 100PF/50V 3B41101T
C107	CERAMIC CAP.	SL J 39PF/50V 3S41390T
C108	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C110	CERAMIC CAP.	F Z 0.047UF/12V 32F1473S
C111	CERAMIC CAP.	F Z 0.022UF/25V 122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V 1220843T
C112	ELECTROLYTIC CAP.	1UF/50V M 126F105S
C113	ELECTROLYTIC CAP.	1UF/50V M 126F105S
C114	CERAMIC CAP.	F Z 0.022UF/25V 122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V 1220843T
C115	CERAMIC CAP.	B J 82PF/50V 3B41820T
C118	CERAMIC CAP.	F Z 0.022UF/25V 122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V 1220843T
C119	ELECTROLYTIC CAP.	1UF/50V M 126F105S
C120	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C121	SEMICONDUCTOR CAP.	SR K 0.047UF/25V 12Y2473S
C122	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C123	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C124	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C125	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C126	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C127	CERAMIC CAP.	B J 220PF/50V 3B41221T
C128	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C129	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C141	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C142	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C143	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C144	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
C314	ELECTROLYTIC CAP.	10UF/16V M 126C106S
C401	SEMICONDUCTOR CAP.	SR K 0.047UF/25V 12Y2473S
C402	ELECTROLYTIC CAP.	100UF/6.3V M 126A107S
C403	SEMICONDUCTOR CAP.	SR K 0.047UF/25V 12Y2473S
C404	ELECTROLYTIC CAP.	0.22UF/50V M 126F224S
C411	MYLAR CAP.	0.033UF/50V J 1254333S
C412	CERAMIC CAP.	F Z 0.047UF/12V 32F1473S
C413	ELECTROLYTIC CAP.	47UF/6.3V M 126A476S
C415	ELECTROLYTIC CAP.	8.2UF/16V M 126C825S
C416	ELECTROLYTIC CAP.	2.2UF/50V M NP 126X225S

REF. NO.	DESCRIPTION	PART NO.
C417	ELECTROLYTIC CAP.	10UF/16V M 126C106S
C418	ELECTROLYTIC CAP.	10UF/16V M 126C106S
C419	CERAMIC CAP.	F Z 0.047UF/12V 32F1473S
C420	SEMICONDUCTOR CAP.	SR K 0.047UF/25V 12Y2473S
C421	CERAMIC CAP.	F Z 0.022UF/25V 122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V 1220843T
C424	ELECTROLYTIC CAP.	1UF/50V M 126F105S
C425	SEMICONDUCTOR CAP.	SR K 0.047UF/25V 12Y2473S
C426	MYLAR CAP.	0.18UF/50V J 1254184S
C501	ELECTROLYTIC CAP.	100UF/16V M 126C107S
C502	ELECTROLYTIC CAP.	47UF/6.3V M 126A476S
C504	ELECTROLYTIC CAP.	47UF/6.3V M 126A476S
C506	ELECTROLYTIC CAP.	100UF/16V M 126C107S
C507	SEMICONDUCTOR CAP.	F Z 0.1UF/25V 1220520S
C508	SEMICONDUCTOR CAP.	F Z 0.1UF/25V 1220520S
C511	CERAMIC CAP.	Y M 0.01UF/16V 3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V 1220842T
CL-1	CONNECTOR ASS'Y	JP150/2500 0VE400280
CL-2	JUMPER WIRE, 6P	AWG26#2468/P2.0/160 WX1K2590-002
CL-3	JUMPER WIRE, 10P	AWG26#2468/P2.0/140 WX1K2590-003
CL-4	JUMPER WIRE, 9P	AWG26#2468/P2.0/180 WX1K2590-004
CL-5	JUMPER WIRE, 6P	AWG26#2468/P2.0/90 5750483
CL-7	JUMPER WIRE, 8P	AWG26#2468/P2.0/120 5750433
CL-8	JUMPER WIRE, 11P	AWG26#2468/P2.0/120 WX1K2590-001
CONV-1	(*) RF CONVERTOR	MDLK5D053A 1813266
	(*) RF CONVERTOR	MCB9-VG3404 1813275
	(*) RF CONVERTOR	MDF33-VE3404 1813288
	(*) RF CONVERTOR	MDF33-UD3620 1813289
	(*) RF CONVERTOR	MDLK6E063A 1813309
D403	DIODE	1SS254 A1SS254T77**
	DIODE	US1040M US1040MT
	DIODE	GMB01B GMB01BT
D404	DIODE	1SS254 A1SS254T77**
	DIODE	US1040M US1040MT
	DIODE	GMB01B GMB01BT
D504	DIODE	1SS254 A1SS254T77**
	DIODE	US1040M US1040MT
	DIODE	GMB01B GMB01BT
D505	DIODE	1SS254 A1SS254T77**
	DIODE	US1040M US1040MT
	DIODE	GMB01B GMB01BT
DL101	COMB FILTER	4.433619MHZ 1813274
	COMB FILTER	4.433619MHZ 1812112
	COMB FILTER	4.433619MHZ 1813193
DL102	COMB FILTER	ADL-FN1344F 1813025
IC 51	IC	LA7326 14LQ487
IC 52	IC	LC8992 14LQ489
	IC	MSM7401RS GMSM7401RS**
IC101	IC	LA7331N 14LQ488
IC401	IC, SERVO	MN6748FVAP-1 14DN363
IC402	IC	BA728 BA728
IC501	IC, SYSCON	MN15542FVBG 14DN486
IC502	IC	BA10393N 14LF519
IC503	IC, RESET	PST529D-2 14DM763
IC505	IC, MOTOR DRIVER	BA6209N 14LF492

NOTE: (*)=MODEL NO. F1 (*)=MODEL NO. F2

REF. NO.	DESCRIPTION	PART NO.
JK1	RCA JACK (WHITE)	JPJ2023-01-0300
JK2	RCA JACK (YELLOW)	JPJ2023-01-0400
L 51	INDUCTOR	68UH-K-26T
	INDUCTOR	68UH-K-26T
L 52	INDUCTOR	68UH-K-26T
	INDUCTOR	68UH-K-26T
L101	INDUCTOR	3.3UH-K-26T
	INDUCTOR	3.3UH-K-26T
L102	INDUCTOR	18UH-K-26T
	INDUCTOR	18UH-K-26T
L103	INDUCTOR	100UH-K-26T
	INDUCTOR	100UH-K-26T
L105	INDUCTOR	15UH-K-26T
	INDUCTOR	15UH-K-26T
M 1	(*1) JACK BOARD	K2500
	(*2) JACK BOARD	K2500/P/B-D1
Q 51	TRANSISTOR	2SA1317 (S)
	TRANSISTOR	2SA1317 (T)
Q 52	TRANSISTOR	2SA933 (Q)
	TRANSISTOR	2SA933 (R)
	TRANSISTOR	2SA608SP (E)
	TRANSISTOR	2SA608SP (F)
Q 53	TRANSISTOR	2SC2058 (P)
	TRANSISTOR	2SC2058 (Q)
	TRANSISTOR	2SC2839 (E)
	TRANSISTOR	2SC2839 (F)
Q 54	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q 55	TRANSISTOR	2SA933 (Q)
	TRANSISTOR	2SA933 (R)
	TRANSISTOR	2SA608SP (E)
	TRANSISTOR	2SA608SP (F)
Q 56	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q 57	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q101	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q103	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q104	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)

NOTE: (*1)=MODEL NO. F1 (*2)=MODEL NO. F2

REF. NO.	DESCRIPTION	PART NO.
Q105	TRANSISTOR	2SC2058 (P)
	TRANSISTOR	2SC2058 (Q)
	TRANSISTOR	2SC2839 (E)
	TRANSISTOR	2SC2839 (F)
Q141	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q142	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q401	TRANSISTOR	2SA933 (Q)
	TRANSISTOR	2SA933 (R)
	TRANSISTOR	2SA608SP (E)
	TRANSISTOR	2SA608SP (F)
Q402	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
Q501	TRANSISTOR	2SD1384 (Q)
	TRANSISTOR	2SD1384 (R)
	TRANSISTOR	2SD1207 (S)
	TRANSISTOR	2SD1207 (T)
Q502	TRANSISTOR	2SB1010 (Q)
	TRANSISTOR	2SB1010 (R)
	TRANSISTOR	2SB892 (S)
	TRANSISTOR	2SB892 (T)
Q503	TRANSISTOR	2SC1740 (Q)
	TRANSISTOR	2SC1740 (R)
	TRANSISTOR	2SC536SP (E)
	TRANSISTOR	2SC536SP (F)
QR 51	RES. BUILT-IN TRANSISTOR	DTA124ES
	RES. BUILT-IN TRANSISTOR	2SA1346
QR 52	RES. BUILT-IN TRANSISTOR	DTC124ES
	RES. BUILT-IN TRANSISTOR	2SC3400
QR401	RES. BUILT-IN TRANSISTOR	DTC124ES
	RES. BUILT-IN TRANSISTOR	2SC3400
QR501	RES. BUILT-IN TRANSISTOR	DTC124ES
	RES. BUILT-IN TRANSISTOR	2SC3400
QR502	RES. BUILT-IN TRANSISTOR	DTA124ES
	RES. BUILT-IN TRANSISTOR	2SA1346
R 51	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R 52	CARBON RES.	1/5W J 470K OHM
	CARBON RES.	1/6W J 470K OHM
R 54	CARBON RES.	1/5W J 560 OHM
	CARBON RES.	1/6W J 560 OHM
R 55	CARBON RES.	1/5W J 1.2K OHM
	CARBON RES.	1/6W J 1.2K OHM
R 56	CARBON RES.	1/5W J 33K OHM
	CARBON RES.	1/6W J 33K OHM
R 57	CARBON RES.	1/5W J 47K OHM
	CARBON RES.	1/6W J 47K OHM
R 58	CARBON RES.	1/5W J 4.7K OHM
	CARBON RES.	1/6W J 4.7K OHM

REF. NO.	DESCRIPTION	PART NO.
R 59	CARBON RES.	1/5W J 150 OHM 1324151T
	CARBON RES.	1/6W J 150 OHM 132A151T
R 60	CARBON RES.	1/5W J 120 OHM 1324121T
	CARBON RES.	1/6W J 120 OHM 132A121T
R 61	CARBON RES.	1/5W J 68 OHM 1324680T
	CARBON RES.	1/6W J 68 OHM 132A680T
R 62	METAL RES.	1W J 330 OHM 1330419
	METAL RES.	1W J 330 OHM 1330363
R 63	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R 65	CARBON RES.	1/5W J 1M OHM 1324105T
	CARBON RES.	1/6W J 1M OHM 132A105T
R 66	CARBON RES.	1/5W J 1M OHM 1324105T
	CARBON RES.	1/6W J 1M OHM 132A105T
R 67	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R 68	CARBON RES.	1/5W J 330 OHM 1324331T
	CARBON RES.	1/6W J 330 OHM 132A331T
R 69	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R 70	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R 71	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R 72	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R 73	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R 74	CARBON RES.	1/5W J 470 OHM 1324471T
	CARBON RES.	1/6W J 470 OHM 132A471T
R 75	CARBON RES.	1/5W J 910 OHM 1324911T
	CARBON RES.	1/6W J 910 OHM 132A911T
R 76	CARBON RES.	1/5W J 220 OHM 1324221T
	CARBON RES.	1/6W J 220 OHM 132A221T
R 77	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R 81	CARBON RES.	1/5W J 1K OHM 1324102
	CARBON RES.	1/6W J 1K OHM 132A102
R101	CARBON RES.	1/5W J 3.3K OHM 1324332T
	CARBON RES.	1/6W J 3.3K OHM 132A332T
R102	CARBON RES.	1/5W J 100K OHM 1324104T
	CARBON RES.	1/6W J 100K OHM 132A104T
R103	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R104	CARBON RES.	1/5W J 6.8K OHM 1324682T
	CARBON RES.	1/6W J 6.8K OHM 132A682T
R105	CARBON RES.	1/5W J 22K OHM 1324223T
	CARBON RES.	1/6W J 22K OHM 132A223T
R106	CARBON RES.	1/5W J 1.2K OHM 1324122T
	CARBON RES.	1/6W J 1.2K OHM 132A122T
R109	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R110	CARBON RES.	1/5W J 680 OHM 1324681T
	CARBON RES.	1/6W J 680 OHM 132A681T
R111	CARBON RES.	1/5W J 3.3K OHM 1324332T
	CARBON RES.	1/6W J 3.3K OHM 132A332T

REF. NO.	DESCRIPTION	PART NO.
R112	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R113	CARBON RES.	1/5W J 100K OHM 1324104T
	CARBON RES.	1/6W J 100K OHM 132A104T
R114	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R115	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R116	CARBON RES.	1/5W J 100K OHM 1324104T
	CARBON RES.	1/6W J 100K OHM 132A104T
R117	CARBON RES.	1/5W J 470 OHM 1324471T
	CARBON RES.	1/6W J 470 OHM 132A471T
R119	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R121	CARBON RES.	1/5W J 5.6K OHM 1324562T
	CARBON RES.	1/6W J 5.6K OHM 132A562T
R122	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R123	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R124	CARBON RES.	1/5W J 120 OHM 1324121T
	CARBON RES.	1/6W J 120 OHM 132A121T
R125	CARBON RES.	1/5W J 560 OHM 1324561T
	CARBON RES.	1/6W J 560 OHM 132A561T
R126	CARBON RES.	1/5W J 22K OHM 1324223T
	CARBON RES.	1/6W J 22K OHM 132A223T
R127	CARBON RES.	1/5W J 270 OHM 1324271T
	CARBON RES.	1/6W J 270 OHM 132A271T
R128	CARBON RES.	1/5W J 560 OHM 1324561T
	CARBON RES.	1/6W J 560 OHM 132A561T
R141	CARBON RES.	1/5W J 3.9K OHM 1324392T
	CARBON RES.	1/6W J 3.9K OHM 132A392T
R142	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R143	CARBON RES.	1/5W J 270 OHM 1324271T
	CARBON RES.	1/6W J 270 OHM 132A271T
R144	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R145	CARBON RES.	1/5W J 33K OHM 1324333T
	CARBON RES.	1/6W J 33K OHM 132A333T
R146	CARBON RES.	1/5W J 1.2K OHM 1324122T
	CARBON RES.	1/6W J 1.2K OHM 132A122T
R402	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R403	CARBON RES.	1/5W J 56K OHM 1324563T
	CARBON RES.	1/6W J 56K OHM 132A563T
R404	CARBON RES.	1/5W J 56K OHM 1324563T
	CARBON RES.	1/6W J 56K OHM 132A563T
R405	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R406	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R407	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R408	CARBON RES.	1/5W J 22K OHM 1324223T
	CARBON RES.	1/6W J 22K OHM 132A223T

REF. NO.	DESCRIPTION	PART NO.
R409	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R410	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R411	CARBON RES.	1/5W J 150K OHM 1324154T
	CARBON RES.	1/6W J 150K OHM 132A154T
R412	CARBON RES.	1/5W J 39K OHM 1324393T
	CARBON RES.	1/6W J 39K OHM 132A393T
R413	CARBON RES.	1/5W J 10K OHM 1324103T
	CARBON RES.	1/6W J 10K OHM 132A103T
R414	CARBON RES.	1/5W J 8.2K OHM 1324822T
	CARBON RES.	1/6W J 8.2K OHM 132A822T
R421	CARBON RES.	1/5W J 3.9K OHM 1324392T
	CARBON RES.	1/6W J 3.9K OHM 132A392T
R422	CARBON RES.	1/5W J 15K OHM 1324153T
	CARBON RES.	1/6W J 15K OHM 132A153T
R425	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R426	CARBON RES.	1/5W J 22K OHM 1324223T
	CARBON RES.	1/6W J 22K OHM 132A223T
R436	CARBON RES.	1/5W J 33K OHM 1324333T
	CARBON RES.	1/6W J 33K OHM 132A333T
R438	CARBON RES.	1/5W J 100 OHM 1324101T
	CARBON RES.	1/6W J 100 OHM 132A101T
R439	CARBON RES.	1/5W G 10K OHM 1354103T
R440	CARBON RES.	1/5W G 10K OHM 1354103T
R441	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R442	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R443	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R444	CARBON RES.	1/5W J 39K OHM 1324393T
	CARBON RES.	1/6W J 39K OHM 132A393T
R445	CARBON RES.	1/5W J 39K OHM 1324393T
	CARBON RES.	1/6W J 39K OHM 132A393T
R447	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R448	CARBON RES.	1/5W J 150 OHM 1324151T
	CARBON RES.	1/6W J 150 OHM 132A151T
R449	CARBON RES.	1/5W J 22K OHM 1324223T
	CARBON RES.	1/6W J 22K OHM 132A223T
R501	CARBON RES.	1/5W J 1.2K OHM 1324122T
	CARBON RES.	1/6W J 1.2K OHM 132A122T
R502	CARBON RES.	1/5W J 100K OHM 1324104T
	CARBON RES.	1/6W J 100K OHM 132A104T
R503	CARBON RES.	1/5W J 1.2K OHM 1324122T
	CARBON RES.	1/6W J 1.2K OHM 132A122T
R504	CARBON RES.	1/5W J 100K OHM 1324104T
	CARBON RES.	1/6W J 100K OHM 132A104T
R505	CARBON RES.	1/5W J 10K OHM 1324103T
	CARBON RES.	1/6W J 10K OHM 132A103T
R506	CARBON RES.	1/5W J 10K OHM 1324103T
	CARBON RES.	1/6W J 10K OHM 132A103T
R507	CARBON RES.	1/5W J 470K OHM 1324474T
	CARBON RES.	1/6W J 470K OHM 132A474T

REF. NO.	DESCRIPTION	PART NO.
R508	CARBON RES.	1/5W J 470K OHM 1324474T
	CARBON RES.	1/6W J 470K OHM 132A474T
R509	CARBON RES.	1/5W J 10K OHM 1324103T
	CARBON RES.	1/6W J 10K OHM 132A103T
R510	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R528	CARBON RES.	1/5W J 6.8K OHM 1324682T
	CARBON RES.	1/6W J 6.8K OHM 132A682T
R529	CARBON RES.	1/5W J 6.8K OHM 1324682T
	CARBON RES.	1/6W J 6.8K OHM 132A682T
T 51	L. P. F. 3MHZ	LPF-U30-A 1810994
	L. P. F. 3MHZ	ELB-4M031N 1810805
	L. P. F.	3MHZ 1813270
T101	B. P. F.	5E-4296-01 1813269
TP 52	TEST PIN	RT-08T-1.3BT 1770482
TP 53	TEST PIN	RT-08T-1.3BT 1770482
TP 55	TEST PIN	RT-08T-1.3BT 1770482
TP301	TEST PIN	RT-08T-1.3BT 1770482
TP402	TEST PIN	RT-08T-1.3BT 1770482
VR 51	P. O. T.	1KOHM B 138J777
	P. O. T.	1KOHM B 138N777
VR 52	CARBON P. O. T.	1K OHM 238A390Y
	CARBON P. O. T.	1K OHM 238N489Y
	CARBON P. O. T.	1K OHM 238A419Y
VR401	CARBON P. O. T.	220K OHM 238A404Y
	CARBON P. O. T.	200K OHM 238N498Y
	CARBON P. O. T.	200K OHM 238A428Y
VR402	METAL P. O. T.	220K OHM 238A377Y
	METAL P. O. T.	200K OHM 238N531Y
	METAL P. O. T.	200K OHM 238A445Y
X101	X' TAL	4.433619MHZ 1811366
	X' TAL	4.433619MHZ 1811388
X501	CERAMIC RESONATOR	3.58MHZ 1812206
	CERAMIC RESONATOR	FCR3.58MC3T 1811368
	CERAMIC RESONATOR	3.58MHZ 1811211

MCV-B C. B. A.

C 1	CERAMIC CAP.	F Z 0.022UF/25V	122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V	1220843T
C 2	CERAMIC CAP.	F Z 0.033UF/16V	122Z790T
	CERAMIC CAP.	F Z 0.033UF/12V	1220887T
C 3	CERAMIC CAP.	F Z 0.033UF/16V	122Z790T
	CERAMIC CAP.	F Z 0.033UF/12V	1220887T
C 4	CERAMIC CAP.	F Z 0.022UF/25V	122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V	1220843T
C 5	ELECTROLYTIC CAP.	47UF/6.3V M H7	526R476S
C 6	CERAMIC CAP.	F Z 0.022UF/25V	122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V	1220843T
C 7	CERAMIC CAP.	SL J 22PF/50V	3S41220T

REF. NO.	DESCRIPTION	PART NO.
C 8	CERAMIC CAP.	SL J 22PF/50V 3S41220T
C 9	CERAMIC CAP.	SL J 22PF/50V 3S41220T
C 10	CERAMIC CAP.	B J 470PF/50V 3B41471T
C 11	CERAMIC CAP.	SL J 22PF/50V 3S41220T
C 12	CERAMIC CAP.	SL J 33PF/50V 3S41330T
C 13	CERAMIC CAP.	F Z 0.022UF/25V 122Z122T
	CERAMIC CAP.	F Z 0.022UF/25V 1220843T
C301	SEMICONDUCTOR CAP.	SR K 0.001UF/25V 12Y2102S
C302	ELECTROLYTIC CAP.	10UF/16V M 126C106S
C303	ELECTROLYTIC CAP.	22UF/6.3V M 126A226S
C304	MYLAR CAP.	0.033UF/50V J 1254333S
C307	CERAMIC CAP.	B J 100PF/50V 3B41101T
C308	SEMICONDUCTOR CAP.	SR K 0.022UF/25V 12Y2223S
C309	ELECTROLYTIC CAP.	220UF/16V M 126C227S
C310	ELECTROLYTIC CAP.	2.2UF/50V M 126F225S
C312	ELECTROLYTIC CAP.	47UF/6.3V M 126A476S
C315	ELECTROLYTIC CAP.	4.7UF/25V M 126D475S
C422	ELECTROLYTIC CAP.	1UF/50V M 126F105S
C423	ELECTROLYTIC CAP.	1UF/50V M NP 126X105S
C503	SEMICONDUCTOR CAP.	F Z 0.1UF/25V 1220520S
C509	ELECTROLYTIC CAP.	1UF/50V M 126F105S
CL-6	JUMPER WIRE, 6P	AWG26#2468/P2.0/100 WX1K2500-001
CN-A	ANGLE SOCKET CONNECTOR,	11L-SDD-17S-S2L2-FM 1700762
CN-G	ANGLE SOCKET CONNECTOR,	1L-SDA-6S-S2L2 1770601
D301	DIODE	1SS254 1SS254T
	DIODE	US1040M US1040MT
	DIODE	GMB01B GMB01BT
IC 1	IC	LA7320 14LQ486
IC301	IC	BA328LN BA328LN
L 1	INDUCTOR	2.2UH-K-26T LLAXKATTU2R2
L 2	INDUCTOR	18UH-K-26T LLAXKATTU180
	INDUCTOR	18UH-K-26T LLAXKDTKA180
L 3	INDUCTOR	68UH-K-26T LLAXKATTU680
	INDUCTOR	68UH-K-26T LLAXKDTKA680
L 4	INDUCTOR	22UH-K-26T LLAXKATTU220
	INDUCTOR	22UH-K-26T LLAXKDTKA220
L 5	INDUCTOR	150UH-K-26T LLAXKATTU151
	INDUCTOR	150UH-K-26T LLAXKDTKA151
L 6	INDUCTOR	33UH-K-26T LLAXKATTU330
	INDUCTOR	33UH-K-26T LLAXKDTKA330
L 7	INDUCTOR	100UH-K-26T LLAXKATTU101
	INDUCTOR	100UH-K-26T LLAXKDTKA101
M 2	SHIELD, BOTTOM P/B	K2500 QVM400068
M 3	PLATE, TOP SHIELD	VD7991 6S50372
Q 1	TRANSISTOR	2SC2058 (P) C2058PZ
	TRANSISTOR	2SC2058 (Q) C2058QZ
	TRANSISTOR	2SC2839 (E) C2839EZ
	TRANSISTOR	2SC2839 (F) C2839FZ
Q 2	TRANSISTOR	2SC2058 (P) C2058PZ
	TRANSISTOR	2SC2058 (Q) C2058QZ
	TRANSISTOR	2SC2839 (E) C2839EZ
	TRANSISTOR	2SC2839 (F) C2839FZ
Q 3	TRANSISTOR	2SC1740 (Q) C1740QZ
	TRANSISTOR	2SC1740 (R) C1740RZ
	TRANSISTOR	2SC536SP (E) C536SEZ
	TRANSISTOR	2SC536SP (F) C536SFZ

REF. NO.	DESCRIPTION	PART NO.
Q301	TRANSISTOR	2SD1468 (S) D1468SZ
	TRANSISTOR	2SD1468 (R) D1468RZ
	TRANSISTOR	2SD1012 (F) D1012FZ
	TRANSISTOR	2SD1012 (G) D1012GZ
Q504	TRANSISTOR	2SC1740 (Q) C1740QZ
	TRANSISTOR	2SC1740 (R) C1740RZ
	TRANSISTOR	2SC536SP (E) C536SEZ
	TRANSISTOR	2SC536SP (F) C536SFZ
Q505	TRANSISTOR	2SC1740 (Q) C1740QZ
	TRANSISTOR	2SC1740 (R) C1740RZ
	TRANSISTOR	2SC536SP (E) C536SEZ
	TRANSISTOR	2SC536SP (F) C536SFZ
R 1	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R 2	CARBON RES.	1/5W J 1.8K OHM 1324182T
	CARBON RES.	1/6W J 1.8K OHM 132A182T
R 3	CARBON RES.	1/5W J 390 OHM 1324391T
	CARBON RES.	1/6W J 390 OHM 132A391T
R 4	CARBON RES.	1/5W J 3.3K OHM 1324332T
	CARBON RES.	1/6W J 3.3K OHM 132A332T
R 5	CARBON RES.	1/5W J 390 OHM 1324391T
	CARBON RES.	1/6W J 390 OHM 132A391T
R 6	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R 7	CARBON RES.	1/5W J 560 OHM 1324561T
	CARBON RES.	1/6W J 560 OHM 132A561T
R 8	CARBON RES.	1/5W J 680 OHM 1324681T
	CARBON RES.	1/6W J 680 OHM 132A681T
R 9	CARBON RES.	1/5W J 330 OHM 1324331T
	CARBON RES.	1/6W J 330 OHM 132A331T
R 10	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R 11	CARBON RES.	1/5W J 3.9K OHM 1324392T
	CARBON RES.	1/6W J 3.9K OHM 132A392T
R301	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R302	CARBON RES.	1/5W J 100 OHM 1324101T
	CARBON RES.	1/6W J 100 OHM 132A101T
R303	CARBON RES.	1/5W J 120 OHM 1324121T
	CARBON RES.	1/6W J 120 OHM 132A121T
R304	CARBON RES.	1/5W J 100K OHM 1324104T
	CARBON RES.	1/6W J 100K OHM 132A104T
R305	CARBON RES.	1/5W J 3.9K OHM 1324392T
	CARBON RES.	1/6W J 3.9K OHM 132A392T
R307	CARBON RES.	1/5W J 120K OHM 1324124T
	CARBON RES.	1/6W J 120K OHM 132A124T
R308	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R309	CARBON RES.	1/5W J 220 OHM 1324221T
	CARBON RES.	1/6W J 220 OHM 132A221T
R311	CARBON RES.	1/5W J 33K OHM 1324333T
	CARBON RES.	1/6W J 33K OHM 132A333T
R312	CARBON RES.	1/5W J 5.6K OHM 1324562T
	CARBON RES.	1/6W J 5.6K OHM 132A562T
R313	CARBON RES.	1/5W J 100K OHM 1324104T
	CARBON RES.	1/6W J 100K OHM 132A104T

REF. NO.	DESCRIPTION	PART NO.
R314	CARBON RES.	1/5W J 3.3K OHM 1324332T
	CARBON RES.	1/6W J 3.3K OHM 132A332T
R315	CARBON RES.	1/5W J 5.6K OHM 1324562T
	CARBON RES.	1/6W J 5.6K OHM 132A562T
R520	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R521	CARBON RES.	1/5W J 470K OHM 1324474T
	CARBON RES.	1/6W J 470K OHM 132A474T
R522	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
R523	CARBON RES.	1/5W J 47K OHM 1324473T
	CARBON RES.	1/6W J 47K OHM 132A473T
R524	CARBON RES.	1/5W J 4.7K OHM 1324472T
	CARBON RES.	1/6W J 4.7K OHM 132A472T
R525	CARBON RES.	1/5W J 1.2K OHM 1324122T
	CARBON RES.	1/6W J 1.2K OHM 132A122T
R526	CARBON RES.	1/5W J 82K OHM 1324823T
	CARBON RES.	1/6W J 82K OHM 132A823T
R530	CARBON RES.	1/5W J 180 OHM 1324181T
	CARBON RES.	1/6W J 180 OHM 132A181T
TP 1	TEST PIN	RT-08T-1.3BT 1770482
TP 2	TEST PIN	RT-08T-1.3BT 1770482

MCV-C C. B. A.

C701	ELECTROLYTIC CAP.	47UF/6.3V M	126A476S
C702	ELECTROLYTIC CAP.	10UF/16V M	126C106S
C703	ELECTROLYTIC CAP.	100UF/16V M	126C107S
D701	DIODE	1SS254	A1SS254T77**
	DIODE	US1040M	US1040MT
	DIODE	GMB01B	GMB01BT
D702	DIODE	1SS254	A1SS254T77**
	DIODE	US1040M	US1040MT
	DIODE	GMB01B	GMB01BT
D703	DIODE	1SS254	A1SS254T77**
	DIODE	US1040M	US1040MT
	DIODE	GMB01B	GMB01BT
D704	DIODE	1SS254	A1SS254T77**
	DIODE	US1040M	US1040MT
	DIODE	GMB01B	GMB01BT
D705	DIODE	1SS254	A1SS254T77**
	DIODE	US1040M	US1040MT
	DIODE	GMB01B	GMB01BT
D706	DIODE	1SS254	A1SS254T77**
	DIODE	US1040M	US1040MT
	DIODE	GMB01B	GMB01BT
D707	DIODE	1SS254	A1SS254T77**
	DIODE	US1040M	US1040MT
	DIODE	GMB01B	GMB01BT
D708	LED	SLR-34DU5F AMBER	1401438

REF. NO.	DESCRIPTION	PART NO.
D709	LED	SLR-34MG5 GREEN 1401231
D710	LED	SLR-34DU5F AMBER 1401438
D711	LED	SLR-34VR5 RED 1401230
D713	LED	SLR-34MG5 GREEN 1401231
D714	LED	SLR-34MG5 GREEN 1401231
D715	LED	SLR-34MG5 GREEN 1401231
D716	LED	SLR-34MG5 GREEN 1401231
D717	LED	SLR-34MG5 GREEN 1401231
D718	LED	SLR-34VR5 RED 1401230
D719	LED	SLR-34VR5 RED 1401230
D720	LED	SLR-34VR5 RED 1401230
IC701	IC	LB1408 14LQ520
M 4	HOLDER, LED (LEVEL)	VD30412 6D52258
M 5	HOLDER, L. E. D.	K2590ZA 0VM300426
QR701	RES. BUILT-IN TRANSISTOR	DTA124ES A124ESZ
	RES. BUILT-IN TRANSISTOR	2SA1346 A1346Z
QR702	RES. BUILT-IN TRANSISTOR	DTA124ES A124ESZ
	RES. BUILT-IN TRANSISTOR	2SA1346 A1346Z
QR703	RES. BUILT-IN TRANSISTOR	DTA124ES A124ESZ
	RES. BUILT-IN TRANSISTOR	2SA1346 A1346Z
QR704	RES. BUILT-IN TRANSISTOR	DTA124ES A124ESZ
	RES. BUILT-IN TRANSISTOR	2SA1346 A1346Z
R701	CARBON RES.	1/5W J 10K OHM 1324103T
	CARBON RES.	1/6W J 10K OHM 132A103T
R702	CARBON RES.	1/5W J 100 OHM 1324101T
	CARBON RES.	1/6W J 100 OHM 132A101T
R703	CARBON RES.	1/5W J 680 OHM 1324681T
	CARBON RES.	1/6W J 680 OHM 132A681T
R704	CARBON RES.	1/5W J 680 OHM 1324681T
	CARBON RES.	1/6W J 680 OHM 132A681T
R705	CARBON RES.	1/5W J 680 OHM 1324681T
	CARBON RES.	1/6W J 680 OHM 132A681T
R706	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R708	CARBON RES.	1/5W J 3.3K OHM 1324332T
	CARBON RES.	1/6W J 3.3K OHM 132A332T
R709	CARBON RES.	1/5W J 1K OHM 1324102T
	CARBON RES.	1/6W J 1K OHM 132A102T
R711	CARBON RES.	1/5W J 7.5K OHM 1324752T
	CARBON RES.	1/6W J 7.5K OHM 132A752T
R712	CARBON RES.	1/5W J 2.2K OHM 1324222T
	CARBON RES.	1/6W J 2.2K OHM 132A222T
RS701	REMOTE SENSOR UNIT	SFN-RQ011 1812501
SW701	PUSH SWITCH	EVQ2150SR 5622158Y
	PUSH SWITCH	SKHVBE KHV-902 5622160Y
	PUSH SWITCH	R66-441Q 5622161
SW702	PUSH SWITCH	EVQ2150SR 5622158Y
	PUSH SWITCH	SKHVBE KHV-902 5622160Y
	PUSH SWITCH	R66-441Q 5622161
SW703	PUSH SWITCH	EVQ2150SR 5622158Y
	PUSH SWITCH	SKHVBE KHV-902 5622160Y
	PUSH SWITCH	R66-441Q 5622161
SW704	PUSH SWITCH	EVQ2150SR 5622158Y
	PUSH SWITCH	SKHVBE KHV-902 5622160Y
	PUSH SWITCH	R66-441Q 5622161

REF. NO.	DESCRIPTION	PART NO.
SW705	PUSH SWITCH	EVQ2150SR
	PUSH SWITCH	SKHVBE KHV-902
	PUSH SWITCH	R66-441Q
SW706	PUSH SWITCH	EVQ2150SR
	PUSH SWITCH	SKHVBE KHV-902
	PUSH SWITCH	R66-441Q
SW707	SLIDE SWITCH	1C-2P
SW708	SLIDE SWITCH	1C-2P
VR701	VOLUME	250KOHM B
	VOLUME	250KOHM B
VR702	VOLUME	20KOHM B
	VOLUME	20KOHM B

MCV-D C. B. A.

CN-D	ANGLE SOCKET CONNECTOR, 1L-SDA- 9S-S2L2	1770604
------	---	---------

MCV-E C. B. A.

CN-D	ANGLE PIN CONNECTOR, 6P 1L-SDA- 6P-S2L2	1770617
------	---	---------

SWV C. B. A.

C241	ELECTROLYTIC CAP.	470UF/6.3V M	126A477S
C242	CERAMIC CAP.	Y M 0.01UF/16V	3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V	1220842T
C243	MYLAR CAP.	0.001UF/50V J	1254102S
C244	CERAMIC CAP.	Y M 0.01UF/16V	3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V	1220842T
C245	ELECTROLYTIC CAP.	3.3UF/50V M	126F335S
C246	MYLAR CAP.	0.0033UF/50V J	1254332S
C247	MYLAR CAP.	0.0022UF/50V J	1254222S
C248	CERAMIC CAP.	Y M 0.01UF/16V	3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V	1220842T
C249	CERAMIC CAP.	SL J 47PF/50V	3S41470T
C250	CERAMIC CAP.	Y M 0.01UF/16V	3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V	1220842T
C251	CERAMIC CAP.	SL J 56PF/50V	3S41560T
C252	CERAMIC CAP.	Y M 0.01UF/16V	3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V	1220842T
C253	CERAMIC CAP.	SL J 56PF/50V	3S41560T
C254	CERAMIC CAP.	Y M 0.01UF/16V	3Y4D103T
	CERAMIC CAP.	F Z 0.01UF/16V	1220842T
C281	ELECTROLYTIC CAP.	220UF/6.3V M	126A227S

REF. NO.	DESCRIPTION	PART NO.
C282	ELECTROLYTIC CAP.	10UF/16V M
C283	ELECTROLYTIC CAP.	3.3UF/50V M
C284	ELECTROLYTIC CAP.	3.3UF/50V M
C285	CERAMIC CAP.	Y M 0.01UF/16V
	CERAMIC CAP.	F Z 0.01UF/16V
C533	ELECTROLYTIC CAP.	100UF/25V M
C551	SEMICONDUCTOR CAP.	F Z 0.1UF/25V
C552	SEMICONDUCTOR CAP.	F Z 0.1UF/25V
C901	CERAMIC CAP.	F Z 0.047UF/12V
C902	CERAMIC CAP.	Y M 0.01UF/16V
	CERAMIC CAP.	F Z 0.01UF/16V
C903	ELECTROLYTIC CAP.	100UF/6.3V M
C904	CERAMIC CAP.	F Z 0.022UF/25V
	CERAMIC CAP.	F Z 0.022UF/25V
C905	CERAMIC CAP.	F Z 0.047UF/12V
C911	CERAMIC CAP.	Y M 0.01UF/16V
	CERAMIC CAP.	F Z 0.01UF/16V
C912	ELECTROLYTIC CAP.	33UF/6.3V M
C961	ELECTROLYTIC CAP.	47UF/6.3V M
C962	SEMICONDUCTOR CAP.	SR K 0.015UF/25V
C963	CERAMIC CAP.	F Z 0.022UF/25V
	CERAMIC CAP.	F Z 0.022UF/25V
C964	ELECTROLYTIC CAP.	1UF/50V M NP
C965	ELECTROLYTIC CAP.	1UF/50V M
C966	ELECTROLYTIC CAP.	1UF/50V M
C967	CERAMIC CAP.	F Z 0.022UF/25V
	CERAMIC CAP.	F Z 0.022UF/25V
C968	SEMICONDUCTOR CAP.	SR K 0.047UF/25V
C969	CERAMIC CAP.	F Z 0.047UF/12V
C970	ELECTROLYTIC CAP.	10UF/16V M
C971	ELECTROLYTIC CAP.	10UF/16V M
C972	ELECTROLYTIC CAP.	2.2UF/50V M NP
C973	ELECTROLYTIC CAP.	8.2UF/16V M
C974	ELECTROLYTIC CAP.	47UF/6.3V M
C975	MYLAR CAP.	0.033UF/50V J
C976	ELECTROLYTIC CAP.	47UF/6.3V M
C977	CERAMIC CAP.	F Z 0.047UF/12V
C978	CERAMIC CAP.	SL J 10PF/50V
C979	ELECTROLYTIC CAP.	47UF/6.3V M
C980	CERAMIC CAP.	B J 330PF/50V
C981	MYLAR CAP.	0.15UF/50V J
C982	CERAMIC CAP.	B J 820PF/50V
C983	CERAMIC CAP.	B J 390PF/50V
C984	ELECTROLYTIC CAP.	47UF/6.3V M
CN-9	CONNECTOR ASS'Y	JP150/2590
CN-10	PIN HEADER, ANGLE, 17P	6030B-1-17Z027-T
CN-11	PIN HEADER, ANGLE, 17P	6030B-1-17Z027-T
CN-12	PIN HEADER, ANGLE, 10P	6030B-1-10Z027-T
D281	DIODE	1SS254
	DIODE	US1040M
	DIODE	GMB01B
D282	DIODE	1SS254
	DIODE	US1040M
	DIODE	GMB01B

REF. NO.	DESCRIPTION	PART NO.
D901	DIODE	1SS254
	DIODE	US1040M
	DIODE	GMB01B
D902	DIODE	1SS254
	DIODE	US1040M
	DIODE	GMB01B
IC241	IC	M52063SP
IC281	IC	LA7311
IC554	IC, MOTOR DRIVER	BA6219B
IC903	IC	BA728
IC961	IC, SERVO CONTROL	MN6748FVAN
IC962	IC	BU4053B
	IC(SWITCHING)	NJU4053BD
IC963	IC	BU4053B
	IC(SWITCHING)	NJU4053BD
IC964	IC	BU4053B
	IC(SWITCHING)	NJU4053BD
L241	INDUCTOR	100UH-K-26T
	INDUCTOR	100UH-K-26T
L961	INDUCTOR	100UH-K-26T
	INDUCTOR	100UH-K-26T
L2033	SCREW, TAPPING, BIND HEAD	M3X10
M 6	HEATSINK, IC	VD40308/K1000U6
Q241	RES. BUILT-IN TRANSISTOR	DTA114ES
Q901	TRANSISTOR	2SC1740(Q)
	TRANSISTOR	2SC1740(R)
	TRANSISTOR	2SC536SP(E)
	TRANSISTOR	2SC536SP(F)
Q911	TRANSISTOR	2SC1740(Q)
	TRANSISTOR	2SC1740(R)
	TRANSISTOR	2SC536SP(E)
	TRANSISTOR	2SC536SP(F)
Q961	TRANSISTOR	2SC2058(P)
	TRANSISTOR	2SC2058(Q)
	TRANSISTOR	2SC2839(E)
	TRANSISTOR	2SC2839(F)
R242	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R243	CARBON RES.	1/5W J 15K OHM
	CARBON RES.	1/6W J 15K OHM
R244	CARBON RES.	1/5W J 33K OHM
	CARBON RES.	1/6W J 33K OHM
R245	CARBON RES.	1/5W J 18K OHM
	CARBON RES.	1/6W J 18K OHM
R246	CARBON RES.	1/5W J 6.8K OHM
	CARBON RES.	1/6W J 6.8K OHM
R247	CARBON RES.	1/5W J 33K OHM
	CARBON RES.	1/6W J 33K OHM
R248	CARBON RES.	1/5W J 2.7K OHM
	CARBON RES.	1/6W J 2.7K OHM
R249	CARBON RES.	1/5W J 220 OHM
	CARBON RES.	1/6W J 220 OHM
R250	CARBON RES.	1/5W J 2.7K OHM
	CARBON RES.	1/6W J 2.7K OHM
R251	CARBON RES.	1/5W J 680 OHM
	CARBON RES.	1/6W J 680 OHM

REF. NO.	DESCRIPTION	PART NO.
R252	CARBON RES.	1/5W J 680 OHM
	CARBON RES.	1/6W J 680 OHM
R253	CARBON RES.	1/5W J 47K OHM
	CARBON RES.	1/6W J 47K OHM
R254	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R281	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
R282	CARBON RES.	1/5W J 820 OHM
	CARBON RES.	1/6W J 820 OHM
R283	CARBON RES.	1/5W J 18K OHM
	CARBON RES.	1/6W J 18K OHM
R284	CARBON RES.	1/5W J 22K OHM
	CARBON RES.	1/6W J 22K OHM
R285	CARBON RES.	1/5W J 1M OHM
	CARBON RES.	1/6W J 1M OHM
R551	CARBON RES.	1/5W J 2.7K OHM
	CARBON RES.	1/6W J 2.7K OHM
R552	CARBON RES.	1/5W J 2.7K OHM
	CARBON RES.	1/6W J 2.7K OHM
R553	METAL RES.	2W J 1.5 OHM
	METAL RES.	2W J 1.5 OHM
R901	CARBON RES.	1/5W J 56K OHM
	CARBON RES.	1/6W J 56K OHM
R902	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R903	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R904	CARBON RES.	1/5W J 56K OHM
	CARBON RES.	1/6W J 56K OHM
R905	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
R906	CARBON RES.	1/5W J 56K OHM
	CARBON RES.	1/6W J 56K OHM
R907	CARBON RES.	1/5W J 47K OHM
	CARBON RES.	1/6W J 47K OHM
R908	CARBON RES.	1/5W J 100K OHM
	CARBON RES.	1/6W J 100K OHM
R911	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
R912	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
R913	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
R914	CARBON RES.	1/5W J 3.9K OHM
	CARBON RES.	1/6W J 3.9K OHM
R915	CARBON RES.	1/5W J 100 OHM
	CARBON RES.	1/6W J 100 OHM
R916	CARBON RES.	1/5W J 22K OHM
	CARBON RES.	1/6W J 22K OHM
R917	CARBON RES.	1/5W J 3.3K OHM
	CARBON RES.	1/6W J 3.3K OHM
R918	CARBON RES.	1/5W J 100K OHM
	CARBON RES.	1/6W J 100K OHM
R919	CARBON RES.	1/5W J 680 OHM
	CARBON RES.	1/6W J 680 OHM

REF. NO.	DESCRIPTION	PART NO.
R961	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
R962	CARBON RES.	1/5W J 2.2K OHM
	CARBON RES.	1/6W J 2.2K OHM
R963	CARBON RES.	1/5W J 4.7K OHM
	CARBON RES.	1/6W J 4.7K OHM
R964	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R965	CARBON RES.	1/5W J 2.2K OHM
	CARBON RES.	1/6W J 2.2K OHM
R966	CARBON RES.	1/5W G 10K OHM
R967	CARBON RES.	1/5W G 10K OHM
R968	CARBON RES.	1/5W J 100 OHM
	CARBON RES.	1/6W J 100 OHM
R969	CARBON RES.	1/5W J 33K OHM
	CARBON RES.	1/6W J 33K OHM
R970	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R971	CARBON RES.	1/5W J 1K OHM
	CARBON RES.	1/6W J 1K OHM
R972	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
R973	CARBON RES.	1/5W J 10K OHM
	CARBON RES.	1/6W J 10K OHM
TP241	TEST PIN	RT-08T-1.3BT
TP242	TEST PIN	RT-08T-1.3BT
TP243	TEST PIN	RT-08T-1.3BT
TP961	TEST PIN	RT-08T-1.3BT
TP962	TEST PIN	RT-08T-1.3BT
VR241	CARBON P. O. T.	10K OHM
	CARBON P. O. T.	10 KOHM
VR961	CARBON P. O. T.	100K OHM
	CARBON P. O. T.	100 KOHM
VR962	METAL P. O. T.	200KOHM B
	METAL P. O. T.	200K OHM B
X961	X' TAL	3.579545MHZ
	X' TAL	3.58MHZ

REF. NO.	DESCRIPTION	PART NO.
PSV C. B. A.		
AC601	AC CORD	EP-549-E17
B2- 7	SHIELD, BOTTOM	U1-SSC K2590
B2- 8	SHIELD, TOP	U1-SSC K2590
	PLATE, SHIELD	K2590ZA
B2- 9	ANGLE	U1-SSC K2590
B2-10	HOLDER	K2590ZA
	SHIELD	K2590ZA
B2-11	HEATSINK, IC	K2590ZA
C601	SAFTY CAP.	0.047UF/250V
	SAFTY CAP.	0.047UF/250V
	MATALLIZED FILM CAP.	0.047UF/250V M
C602	SAFTY CAP.	0.047UF/250V
	SAFTY CAP.	0.047UF/250V
	MATALLIZED FILM CAP.	0.047UF/250V M
C603	SAFETY CAP.	0.0022UF/400V
	SAFETY CAP.	0.0022UF/400V
C604	SAFETY CAP.	0.0022UF/400V
	SAFETY CAP.	0.0022UF/400V
C605	SAFETY CAP.	0.0022UF/400V
	SAFETY CAP.	0.0022UF/400V
C607	ELECTROLYTIC CAP.	68UF/400V
C608	MP CAP.	0.01UF/630V(K)
	METALLIZED FILM CAP.	B K 0.01UF/630V
C609	CERAMIC CAP.	SL J 330PF/1KV
	CERAMIC CAP.	R K 330PF/1KV
C610	ELECTROLYTIC CAP.	100UF/16V M
C611	MYLAR CAP.	0.0047UF/50V J
C612	ELECTROLYTIC CAP.	10UF/50V M
C613	ELECTROLYTIC CAP.	1000UF/25V M
C614	ELECTROLYTIC CAP.	100UF/16V M
C615	ELECTROLYTIC CAP.	2200UF/16V M W/F
C616	ELECTROLYTIC CAP.	100UF/10V M
C617	MYLAR CAP.	0.033UF/50V J
CN-1	ANGLE PIN HEADER, 6P	173979-6
D601	DIODE	SIWB60
D602	DIODE	AP01C
D604	DIODE	AU01Z
D605	DIODE	AU01Z
D606	DIODE	AU01Z
D607	DIODE	RL-2Z
D608	DIODE	AU01Z
F601	FUSE	T1.00A/250V
IC601	IC	STR11006
IC602	VOLTAGE REGULATOR IC	AN7812F
	VOLTAGE REGULATOR IC	NJM7812FA
IC603	VOLTAGE REGULATOR IC	AN7805F
	VOLTAGE REGULATOR IC	NJM7805FA
L2P02	SCREW, A-TIGHT, BIND HEAD	M3X8
L2Q01	SCREW, S-TIGHT, BIND HEAD	M3X5
L2Q02	SCREW, S-TIGHT, BIND HEAD	M3X5
L2Q03	SCREW, S-TIGHT, BIND HEAD	M3X5
L2Q04	SCREW, S-TIGHT, BIND HEAD	M3X5
M601	FUSE HOLDER	1790424
M602	FUSE HOLDER	1790424

REF. NO.		DESCRIPTION		PART NO.
M604		HOLDER, AC CORD	VD5853	6S50286
Q601		TRANSISTOR	2SD1384 (Q)	D1384QZ
		TRANSISTOR	2SD1384 (R)	D1384RZ
		TRANSISTOR	2SD1207 (S)	D1207SZ
		TRANSISTOR	2SD1207 (T)	D1207TZ
R601	⚠	WIREWOUND RES.	2W 3.9 OHM	5330518
R602	⚠	METAL RES.	2W J 82K OHM	1330513
R603		CARBON RES.	1/5W J 240K OHM	1324244T
		CARBON RES.	1/6W J 240K OHM	132A244T
R604		CARBON RES.	1/5W J 240K OHM	1324244T
		CARBON RES.	1/6W J 240K OHM	132A244T
R605	⚠	METAL RES.	1W J 0.27 OHM	1330382
R606		CARBON RES.	1/5W J 1K OHM	1324102T
		CARBON RES.	1/6W J 1K OHM	132A102T
R607		CARBON RES.	1/5W J 1K OHM	1324102T
		CARBON RES.	1/6W J 1K OHM	132A102T
R608	⚠	METAL RES.	2W J 100 OHM	5330001
		METAL RES.	2W J 100 OHM	5330171
R609	⚠	METAL RES.	2W J 33 OHM	1330988
		METAL RES.	2W J 33 OHM	5330159
R610		CARBON RES.	1/5W J 4.7 OHM	1324479T
		CARBON RES.	1/6W J 4.7 OHM	132A479T
T601	⚠	POWER TRANS	TE0049T	LTT**ZPMS001
T602		LINE FILTER	ELF180290C	LLBE***MS005
	⚠	CORD STOPPER	SR-4N-4	1790173

