

Trium

Aria @

Menu Map

Network Serv. * - - - - ->	<ul style="list-style-type: none">• Applications *• Services *• Information *	Broadcast * - - - - ->	<ul style="list-style-type: none">• On/Off *• Message types *• Alert *
Voice Mail * - - - - ->	<ul style="list-style-type: none">• Call *• Number *• Alert *	Settings - - - - ->	<ul style="list-style-type: none">• Language *• Keypad lock• Language *• Edition• Tones• Display• Keys• Auto features• Security• Time & date• Default settings
Phone Book - - - - ->	<ul style="list-style-type: none">• Recall• Store• Remaining• Own numbers• Fixed dialling *• Phone book tones	Office Tools - - - - ->	<ul style="list-style-type: none">• Scratchpad• Currency converter• Alarm clock• Auto-switch
Messages - - - - ->	<ul style="list-style-type: none">• Inbox *• Outbox *• Write new• Settings *• Alert	Diary - - - - ->	<ul style="list-style-type: none">• Calendar• New event• Delete old events• View events
Calls & Times - - - - ->	<ul style="list-style-type: none">• Calls log• Call timers• Call costs *• Line selection *	Calculator	
GSM Services * - - - - ->	<ul style="list-style-type: none">• Call diverting *• Call waiting *• Sending my ID *• Receiving caller ID *• Network *• Call barring *• CUG *	Games - - - - ->	<ul style="list-style-type: none">• Reshape• Push• Options
		Internet - - - - ->	<ul style="list-style-type: none">• Home page• Bookmarks• Other site• Settings

* The availability and appearance of these features in the menu are dependent upon your subscription and the services provided by your network operator

ENGLISH ARIA-@

Trium

Aria-mémoire

Basic operations

Turning your phone on or off	Press and hold down 
Making a call	Enter the number and press 
Answering a call	Press 
Ending a call	Press 
Adjusting the earpiece volume	Press  or 
Muting the incoming ring tone	Press No ring 
Turning keylock on/off	Press  plus 
Turning the microphone on/off	Press and hold down 

General operations

Holding/retrieving a call	Press 
Viewing the last dialled numbers	Press  and press  or  and 
Calling the voice mail centre	Press and hold down 
Reading a new SMS message	Press Read 
Choosing another ring tone	Select Ring tone from the Settings - Tones menu. Press  or  and  to choose the ring tone and press Select 

Phonebook operations

Storing a number	Press Menu  , select Phone Book , select Store , select Phone names or SIM names , enter the number and name
Dialling a stored number	Press Names  or Menu  /Phone Book , select the entry, press 

User Guide

Aria @
I

USER OPERATIONS

This guide describes the operation of the Trium
dual band GSM telephone the ARIA-@

Edition 1, 2000.

© Mitsubishi Electric Telecom Europe, 2000

Whilst every effort has been made to ensure the accuracy of the instructions contained in this guide, Mitsubishi Electric reserves the right to make improvements and changes to the product described in this guide and/or to the guide itself, without prior notice.

Introduction

Thank you for purchasing the Trium Aria-@ dual band mobile telephone. The mobile telephone described in this guide is approved for use on both the GSM 900 and 1800 networks. Services and display messages may be different dependant upon your operators implementation.

As with all types of radio transceivers this mobile telephone emits electromagnetic waves and conforms to international regulations in so far as it is used under normal conditions and in accordance with the safety and warning messages given below and on pages 12 - 14 and 18.

General safety

It is important to follow any special regulations regarding the use of radio equipment, due to the possibility of radio frequency, RF, interference. Please follow the safety advice given below.



Switch off phone and remove the battery when in an aircraft. The use of mobile telephones in an aircraft may endanger the operation of the aircraft, disrupt the cellular mobile phone network and is illegal. Failure to observe this instruction may lead to suspension or denial of mobile telephone services to the offender, or legal action, or both.



Switch off phone when at any refuelling point or near inflammable material.



Switch off phone in hospitals and any other place where medical equipment may be in use.



Respect restrictions on the use of radio equipment in fuel depots, chemical plants or where blasting operations are in progress.



There may be a hazard associated with the operation of phones close to inadequately protected personal medical devices such as hearing aids and pacemakers. Consult your doctor or the manufacturers of the medical device to determine if it is adequately protected.



Operation of phone close to other electronic equipment may also cause interference if the equipment is inadequately protected. Observe any warning signs and manufacturers recommendations.




Avoid prolonged contact between the antenna and your skin when the phone is switched on.


This apparatus is intended for use only when supplied with power from AC/DC adaptor chargers (FZA-0033A, FZA-0034A, FZA-0035A, FZA-0036A, FZA-0037A or FZA-0038A), desk top charger (FZA-0043A), and vehicle kits (FZA-0040A, FZA-0024A, FZA-0047A, FZA-0041A, FZA-0042A).

Use of any other charger or adaptors will invalidate any approval given to this apparatus and may be dangerous.

The phone at glance



Keypad layout



List of keys



Softkeys or selection keys.

Perform the functions indicated by the text above it.



End key. Press to end or reject a call.



Send key. Press to make or answer a call.



Short press during a menu operation will exit to the standby display.

Press in standby display recalls last dialled numbers.

Multi-function key. In the standby mode selects the Ring tone setting. During menu operation used for scrolling down and level adjustment.

Short press for step by step scrolling or level adjustment. Press and hold down for continuous scrolling. Also used in 'Edit Mode' to move the cursor through the displayed text or number.



On/Off key. Long press to turn the phone on or off.



Options key. In the standby display used with the # key to lock the keypad. Otherwise used in conjunction with other menu functions to store, delete, edit, copy, move or call action etc.



Programmable Hotkey. Can be programmed for a shortcut to your most often used feature.

By default, this key gives access to the **Internet** menu.




Volume key. Quick access to adjust the volume levels of the various tones used in the phone.




Alphanumeric keys, 0 - 9, *, #.



Enters numbers, characters and punctuation marks.



①, or press and hold down to call the voice mail number.



② to ⑨ keys. Press and hold to speed dial preferred numbers.

* or #, or press and hold down to enter international + prefix, 'P' symbol or '_' underscore wildcard. During menu operation used for scrolling down.

#. Used with keypad lock softkey to lock/unlock the keypad. During menu operation used for scrolling up.

Table of contents

1. Using this guide	6
2. Getting started	8
Preparing to make your first calls	8
Basic operations	9
3. Safety information	12
Vehicle safety	12
Care and maintenance	12
Your responsibility	13
Security codes	13
Code supplied by the airtime service provider ..	14
Code supplied by the manufacturer	14
Emergency calls	14
Disposing of waste packaging	14
4. Preparing the phone for operation	15
SIM card	15
Battery	16
5. Basic operations	20
Turning on the phone, the standby display and turning off the phone	20
Making and receiving calls	21
Unanswered call, voice mail and new SMS message indicators	24
6. General operations	25
Dialling from memory	25
Last dialled numbers	25
Speed dialling	26
Vibrate alert mode	26
Muting	26
Volume adjustment	27
Sending DTMF tones	27
Pause feature	27
7. In-call options	28
Holding and retrieving a call	28
Call waiting, swapping and multi-party conference calls	28
8. The menu (MMI) system	30
Access to the menus	30
Menu map	30
Entering text	32
Network services	35
Voice mail	35
Phone Book	36
Messages (SMS)	40
Calls & Times	44
GSM services	48
Broadcast - cell broadcast (CB) messages	53
Phone settings - customising your phone .	55
Using the office tools	64
Diary	67
Calculator	70
Games	71
Internet	71
GSM man machine interface codes	75
9. Appendix	76
Accessories list	76
Glossary	76
Trouble shooting	78
Error messages	79

Using this guide

Please take time to read this user guide. It contains a lot of useful information about your phone and the way that it operates on the network. The GSM network is now worldwide and allows you to make and receive calls to and from other countries (called roaming) as if you were in your home country. Some features included in this guide are called network features and are supplied by service providers. However before you can take advantage, or even activate many of the network features offered by the networks, you must subscribe to the services you require. For a full list and explanation of network features please consult with your service provider.

Some networks may provide you with Data & Fax services. To use these special services the Data & Fax kit is needed (see "Accessories list" on page 76). For further information please refer to the instructions contained in the Data & Fax kit and/or contact your service provider for details.

Using the keys to follow the actions described in this guide

To help you quickly understand your way around this manual we have used symbols and expressions that are present on the keys and in the display itself

-  means the left softkey.
-  means the right softkey.
-  means the SEND key.
-  means the END key.
-  means the Multi-function key.
-  means the On/Off key.
-  means the Options key.
-  means the Programmable Hotkey.
-  means the Volume key.

Function  means the softkey with the corresponding function name. For example, **Names**  means press the softkey under the word **Names**.

Messages words seen in this format are the actual words seen in the display.

Select means use  or  and  to scroll to the required item in the menu and validate by pressing **Select** . For example, select **Phone Book** means scroll to the menu item **Phone Book** and validate by pressing **Select** .

Press means press the corresponding key.
Press  means press the SEND key.

Understanding the Graphic Display Indicators (Icons)

The graphic display has a main area capable of displaying up to four lines of characters plus one row of special display indicators or icons.

These icons are used to display the phone's operational condition during use.



The display also shows alphabet characters and numbers as well as the phones menu list and instructions to the user.

The special icons which appear in the display during operation have the following meaning:

-  **SIM memory in use**
-  **Phone memory in use**
-  **Roaming.** Is displayed when the phone is logged on to a network different from its home network.
-  **Short message service (SMS).** Is displayed when one or many short messages have been received and have not been read. It flashes  when the SMS message bank is full and cannot store new messages. The availability of this feature is network dependent.
-  **Voice mail.** Is displayed when a voice mail message has been received and stored by the networks voice mail centre. The availability of this feature is network dependent.
-  **Call diverting.** Indicates whether incoming calls are permanently being diverted. The availability of this feature is network dependent.
-  **Battery level indicator.** Is permanently displayed to indicate the current charge level of the battery. Three levels are shown.  low,  medium,  full. It flashes  when the battery is almost empty.
-  **Arrow keys.** These icons are seen during menu operation to indicate that more items in the menu can be displayed if  or  and  are pressed. More than one arrow may show at any one time.
-  **Line 2.** It indicates the second line is in use. The availability of this feature is network and subscription dependent.
-  **Unanswered call.** Is displayed when an incoming call is unanswered.
-  **Signal strength level.** There are four levels. It indicates the strength of the received signal. The more bars the stronger the signal. If no network is available the display remains blank.
-  **Keypad lock.** Indicates whether keypad lock is on or off.
-  **CUG.** Indicates this service active.
-  **Alarm clock icon**
-  **Vibrator alert icon**
-  **Ring tone off.** All tones are off.
-  **Tegic edit mode icon**

Getting started


In order to become familiar with the phone straightaway follow these simple steps.

Preparing to make your first calls

Inserting the SIM card

Unpack the phone and insert the SIM card into the holder.

- 1 Pull open the protective rubber cap covering the SIM card holder.
- 2 Insert the SIM card gently as shown, gold contacts facing down, with the bevelled corner of the card at the top right. Push the SIM card fully home with your fingertip (the card should push the SIM ejector knob all the way to the left).
- 3 Push the protective rubber cap back into position.




If the SIM card has been inserted the wrong way round or is damaged **Check SIM!** will be displayed. Remove the SIM card, check that it is the right way round and re-insert it as described.

Fitting the battery

Connect the battery as shown below.

- ❶ Position the battery onto the phone as shown
- ❷ Push down the opposite end of the battery onto the phone until the battery catch 'clicks' shut. Check the battery is securely in place.



- ✓ If there is not enough charge in the battery to power the phone follow the instructions for battery charging on page 17.

Basic operations

Turning on the phone

- ❶ Press and hold down $\text{\textcircled{0}}$. A switch on tone will be heard.
- ❷ If the mobile is locked, **Enter lock code:** will be displayed. Enter the 4 digit phonelock code and press either **OK** $\text{\textcircled{<}}$ or $\text{\textcircled{\#}}$.
- ❸ If your SIM is PIN protected, **Enter PIN:** will be displayed. Enter the PIN code and press either **OK** $\text{\textcircled{<}}$ or $\text{\textcircled{\#}}$.

- ✓ See pages 13 and 60 for more details on your PIN and lock codes.

An animated power on screen icon will be displayed.

Standby display

This is followed by a registration tone after which the name of the network and/or service provider will be displayed together with the time and date, signal and battery level indicators and the **Names** and **Menu** softkey functions.

See page 63 on how to set the time and the date.

This is the normal standby display:



Making a call

- 1 Enter the desired telephone number using the numeric keys (1 - 9 and 0).
A maximum of 46 digits can be entered. Correct any mistakes by pressing **Clear** >. Holding down this key will clear the whole display.
- 2 To dial (send) the number press <.

When the call is connected the conversation will be heard in the ear-piece and a call timer will be displayed.

Extending the antenna

Pull up the antenna until you hear a click.

For best results use the antenna fully extended when making or receiving calls.



Receiving a call

When a call is received the phone will ring. The LED on the top of the phone will flash green and the flashing  will be shown. The back-light will also come on, even if switched off (see **Settings** menu,

page 58), and flash if the ring tone volume is set to zero. To accept (answer) the call,

Press .

- If the ring tone volume is set to zero (off) or if the phone has been set to 'Vibrate' mode, no audible sound will be heard.

To reject and return the busy signal to the caller,

Press .


Ending a call

Press .

- Closing the flip does not end a call. Waiting a few seconds or pressing the Exit softkey will return to the standby display.

Replacing the antenna

Hold the antenna near the bottom and push down until it clicks into position. If pressed from the top, you may bend the antenna and it will not go back into the body of the phone.



Turning off the phone

Press and hold down .

A switch off tone will sound to confirm your action. During switch off a display animation will be shown. The mobile will then turn off.

- Do not turn off the phone by removing the battery as data which may need to be saved in the SIM will be lost. See also page 55 for more 'customising your phone' details.

Safety information

Vehicle safety

- Respect national regulations on the use of mobile telephones in vehicles.
- Road safety always comes first! Always give your full attention to driving.
- Do not use a handheld phone whilst driving. If you don't have a handsfree car kit, stop and park your vehicle safely before using your phone.
- If equipped with a correctly installed vehicle kit allowing "hands free" operation and you need to make or receive a call ensure that it is done sensibly and safely. Use pre-programmed numbers where possible and keep calls short and routine.
- If incorrectly installed in a vehicle the operation of mobile telephones could interfere with the correct operation of the vehicle electronics, such as ABS anti-lock brakes or air bags. To avoid such problems ensure that only qualified personnel carry out the installation. Verification of the protection and operation of the vehicle electronics should form part of the installation. If in doubt consult with the manufacturer.
- Do not place the phone on the passenger seat or where it could break loose during sudden braking or a collision. Always use the holder.
- The use of an alert device to operate a vehicle's lights or horn on public roads is not permitted.

Care and maintenance

This mobile telephone is the product of advanced engineering, design and craftsmanship and should be treated with care. The suggestions below will help you to enjoy this product for many years.

- Do not expose the phone to any extreme environment where the temperature or humidity is high.
- Do not expose or store in cold temperatures. When the phone warms up after switch on, to its normal temperature, moisture can form inside where it may damage the electrical parts.
- Do not attempt to disassemble the phone. There are no user serviceable parts inside.
- Do not expose the phone to water, rain or spilt beverages. It is not waterproof.
- Do not abuse this phone by dropping, knocking or violent shaking. Rough handling can damage it.
- Do not clean the phone with strong chemicals or solvents. Wipe it only with a soft, slightly dampened cloth.
- Do not place the telephone alongside computer discs, credit or travel cards or other magnetic media. The information contained on discs or cards may be affected by the phone.

- Do not connect incompatible products. The use of third party equipment or accessories, not made or authorised by Mitsubishi Electric, may invalidate the warranty of your phone and may be a safety risk.
- Do not remove the labels. The numbers on it are important for service and other related purposes.
- Do contact an authorised service centre in the unlikely event of a fault.

Your responsibility

This GSM mobile telephone is under your responsibility. Please treat it with care respecting all local regulations. It is not a toy therefore keep it in a safe place at all times and out of the reach of children.

Try to remember the phonelock and PIN codes associated with the use of this phone.

Become familiar with and use the security features to block unauthorised use. If your phone and/or SIM card are lost or stolen, call your service provider immediately to prevent illegal use.

When not in use lock, turn off the phone and remove the battery.

Security codes

The phone and SIM card are delivered to you pre-programmed with codes that protect the phone and SIM card against unauthorised use.

When requested to enter any of the codes, key in the number (appears as * asterisks in the display) and press **OK**  or .

Keying mistakes can be erased by pressing **Clear** .

If you enter the wrong code an appropriate message will be displayed.

Codes supplied with the SIM card are:

PIN and PIN2 codes (4-8 digits)

The PIN (Personal Identity Number) is supplied with all SIM cards and protects the card against unauthorised use.

The PIN2 code, supplied with some SIM cards, is required to gain access to some features in the phone (such as fixed dialling numbers) for which another level of security is required.

If **Enter PIN** appears in the display, enter the code and press **OK** .

Entering the wrong PIN code three times in succession will disable the SIM card and the message **SIM Blocked. Enter PUK:** will appear in the display. To unblock the SIM you will need the PUK (PIN Unblock Key) code, obtainable only from your service provider.

PUK and PUK2 codes (8 digits)

The PUK code is supplied with the SIM card and is used to unblock a disabled SIM card.

When requested enter the PUK code and press **OK** . You will be requested to reset the PIN code. Follow the instruction in the display.

The PUK2 code is required to unblock the PIN2 code.

Code supplied by the airtime service provider

Call barring password (4 digits)

This password is used to bar various types of calls, made or received, from the phone. See page 52 for more details.

Code supplied by the manufacturer

Phonelock code (4 digits)

This code is set to all zeros on delivery and is user re-settable. Once changed it cannot be identified by the manufacturer over the phone. See page 60 for more details.

It is strongly recommended that you remember and make yourself familiar with the purpose and operation of these codes.

Emergency calls

In Europe, provided the phone has GSM service, emergency calls can be made using the European standard emergency number, 112. Emergency calls can even be made if the phone is PIN or electronically locked or call barred. In some countries local emergency numbers can still be used for emergency purposes but the phone may have to contain a valid SIM card.

When making an emergency call remember to give all the necessary information as accurately as possible. The phone may be the only means of communication at the scene of an emergency therefore do not cut off the call until told to do so.

Mobile phones rely on wireless and landline networks which cannot be guaranteed in all conditions. Therefore you should never rely solely on wireless phones for essential emergency communications.

Disposing of waste packaging

The packaging used for this phone is made of recyclable materials and as such should be disposed of in accordance with your national legislation on the protection of the environment.

Please take care to separate the cardboard and plastic elements and to dispose of them in the correct manner.

Preparing the phone for operation

SIM card

Before you can use your phone a valid SIM card must be inserted into the SIM card holder.


If a SIM card is not inserted, or inserted incorrectly **Check SIM!** will be displayed when the phone is turned on.

Fitting

See "Inserting the SIM card", page 8.

Removing

- 1 Turn off the phone.
- 2 Open the protective rubber cap.
- 3 Push the SIM ejector knob to the right and pull out the card.
- 4 Push the protective rubber cap back into position.




Battery

Fitting

Connect the battery as shown below.


- 1 Position the battery onto the phone as shown
- 2 Push down the opposite end of the battery onto the phone until the battery catch 'clicks' shut. Check the battery is securely in place.



If there is not enough charge in the battery to power the phone follow the instructions for battery charging on page 17.

Removing

- 1 Push up and hold the battery catch.
- 2 Lift the end of the battery up and away from the catch and the phone. Release the catch.



Low battery warning


When the battery power falls to its lowest level the message **Low Battery!** will be displayed and a low battery warning tone will sound. If you are on a call terminate the call and turn off the phone by pressing and holding down **Ⓜ**.

Recharge the battery as shown below or swap it for a charged one.

Do not turn off the phone by removing the battery. Data that needs to be saved by the SIM may be lost.

Charging

To ensure a long life for your battery, re-charge it only when the **Low Battery!** warning is displayed and the 'low battery' tone is heard. Remove the cover from the bottom of the phone and connect the charger to the phone as shown.



Plug the charger into the wall socket and turn on the mains. The battery will start to charge. The phone can be used whilst charging but it will increase the charging time.

Charging indicators when the mobile is off



During charging **Charging...** will be displayed. The LED will be red. When charging is finished, **Battery full** will be displayed and the LED will change to green.

Charging indicators when the mobile is on



During charging the three section battery icon will flash 1-2-3 bars continuously. When charging is completed the battery indicator will show three solid bars. The LED is not used as a charging indicator when the mobile is on. If a call is received during charging the LED will flash rapidly green.

It is normal for the battery to get warm during charging. At the end of charging disconnect the charger from the phone (by pushing and holding the two buttons on the sides), switch off and remove the plug from the mains.

Typical charging times using the AC adaptor, FZA-0034A

Battery type	Typical charging time
Battery Pack LP, FZ-2538A	1 hrs 30

Battery use and safety information

A battery can be charged hundreds of times but will gradually wear out. When the operating time (standby and talk time) is noticeably shorter than normal it is time to buy a new one.

- Do not leave batteries connected to a charger longer than necessary, overcharging will shorten battery life.
- Disconnect battery chargers from the power source when not in use.
- Do not expose batteries to high temperatures or humidity.
- Do not dispose of the batteries in fire. They may explode.
- Avoid putting the batteries into contact with metal objects which

may short circuit the battery terminals (e.g. keys, paper clips, coins, chains etc).

- Do not drop or subject the batteries to strong physical shocks.
- Do not try to disassemble any of the battery packs.
- Use only the recommended battery chargers (see pages 2 and 76)
- If the battery terminals become soiled, clean them with a soft cloth.
- It is normal for batteries to become warm during charging.
- Old batteries must be returned to the place of purchase or to a place where used batteries are properly disposed of. Do not dispose of old batteries together with household waste.

Battery disposal

Please dispose of your old batteries in accordance with your national legislation on the protection of the environment. If in doubt please consult with your local authorities environmental department who will be able to offer you advice on disposal.

Basic operations

Turning on the phone, the standby display and turning off the phone

Turning on the phone

- 1 Press and hold down . A switch on tone will be heard.
- 2 If the mobile is locked, **Enter lock code** will be displayed. Enter the 4 digit phonelock code and press either **OK**  or .
- 3 If your SIM is PIN protected, **Enter PIN:** will be displayed. Enter the PIN code and press either **OK**  or .

 See pages 13 and 14 for more details on your PIN and lock codes.

A display power on animation will be briefly shown. This is followed by a registration tone after which the name of the network and/or service provider will be displayed together with the time and date, signal and battery level indicators and the **Names** and **Menu** softkey functions.

See page 63 for setting the time and date.

This is the normal standby display:



In this condition the phone is ready to receive or make calls or perform many of the operations contained in its feature list. From the standby display pressing  will allow you to silence the incoming ring tone or set the vibrate options (see page 56) and pressing  will allow you to set the volume levels of the various ring, key and alert tones (see page 57). Pressing any of the number keys (1 - 9 and 0) will enter that number in the display (see also "Speed dialling", page 40). Pressing  will dial a displayed number whilst pressing  will stop the dialling or end a call.

Menu

Pressing **Menu**  in the standby display will give you access to all the main features and functions of the phone.

Use  or  and  to navigate up and down the menu.

Names

Pressing **Names**  in the standby display gives you direct access to all your stored phonebook entries with all the same functions as when accessing the Phone Book from the main menu.

Keypad lock

When activated (turned on) keypad lock prevents accidental calls or actions being made by user when the phone is carried in a pocket, briefcase or handbag. When on keypad lock does not prevent calls being received, which are answered in the normal way. On completion of a received call keypad lock is automatically reactivated. To turn keypad lock on:

Press  plus .

 will be displayed.

To turn keypad lock off:

Press either  or **Unlock**  plus .

 See page 55 for more keypad lock details.

Backlight operation

The backlight is normally off. When a key is pressed the display and keypad backlight will come on for 10 seconds. If an incoming call is received the backlight will come on and remain on for 10 seconds after the call has been answered.

 See pages 58 for backlight adjustment.

Turning off the phone

Press and hold down .

A switch off tone will sound to confirm your action. During switch off a display animation will be shown. The mobile will then turn off.

 Do not turn off the phone by removing the battery as data which may need to be saved in the SIM will be lost.

Making and receiving calls

The phone can only make and receive calls when it is switched on, unlocked, has a valid SIM card inserted and is located in an area that has GSM network service coverage. If the phone cannot find a network the display remains blank. For best results use the antenna fully extended when making or receiving calls.

Making calls

1 Enter the desired telephone number using the numeric keys (1 - 9 and 0).

International calls must be prefixed with either 00 or the + symbol and the country code followed by the number. To enter the + symbol before a number press and hold down . See "International dialling codes" below if you don't know the code for the country you wish to call.

A maximum of 46 digits can be entered. Correct any mistakes by pressing **Clear** . Holding down this key will clear the whole display.

2 Press  to dial (send) the number.

The dialled number together with the animated  icon will be shown in the display. When the call is connected a ringing tone will be heard in the earpiece and a call timer will be displayed. When answered proceed with the call in the normal way.

- **Busy** in the display indicates that the called party is engaged. If Auto Retry is on, the phone will attempt to call again (see page 60 for details).
- **Not allowed (fixed dialling)** in the display means that the number dialled is not authorised by the FDN list (see page 39 for details).
- If the dialled number matches one stored in the phonebook then the associated name of the called person will appear in the display.
- The line 2 icon () will appear once the call is established (if this service is active) indicating that the call was made using this line (see page 48 for details).

International dialling codes

If you wish to dial an international number and you don't know the country dialling code,

- 1** Enter the + symbol in the display as the first character by pressing and holding down .
- 2** Press **Codes** .
- 3** Choose from any one of the over 40 countries listed and press **Select** .
The correct country code will appear after the + symbol in the display.
- 4** Add the number to be dialled and press .

 The + symbol and country code can be stored together with the number in the phonebook.

Ending calls

Press .

The call timer will stop and  will disappear. Waiting a few seconds or pressing **Exit**  will return to the standby display.
NB: closing the flip does not end a call.

Receiving calls

When a call is received the phone will ring. The LED on the top of the phone will flash green, the backlight will come on and the flashing  will be shown. If the ring tone volume is set to zero (off) or any of the Vibrate options, no audible sound will be heard (see page 57 on how to set the incoming ring tone).

To accept (answer) the call,

Press .

Pressing the **No ring**  softkey will stop the sound of the ring tone allowing you to silence the phone and go out of a room before pressing .

NB: opening the flip does not answer a call.

To reject and return the busy signal to the caller,

Press .

If accepted  will be displayed. Proceed with the call in the normal way.

- If the caller's number is not available **Unknown number** will be displayed during call presentation; then **Call1** will be displayed during call connection.
- If the caller's number is available but does not match one stored in your phonebook it will appear in the display. If it does match a stored number then the associated name will appear instead.
- If the caller has withheld their number **Withheld number** will be displayed during call presentation; then **Call 1** will be displayed during connection.
- A call timer will also appear.
-  will appear if the call has been received on your line 2 number (see page 48 for details).

To end the call,

Press .

The caller's number, if available will be stored in the received calls log (see page 44 for details).

NB: closing the flip does not end a call.

Unanswered call, voice mail and new SMS message indicators

- If any received calls remain unanswered, ☒ will be displayed. Press **Read** ⏪ to view the callers' numbers if available and the date and time the call was received. Press ☎ to call the number. Unanswered call numbers will be stored in the unanswered calls log (see page 44 for details).
- When you receive notification that a voice message has been deposited in your voice mail box an alert tone will sound and 📞 will appear in the display. Press **Read** ⏪ to view the message or press ① to speed dial your voice mail message centre (see pages 7 and 35 for details).
NB: If more than one indicator (e.g. **Messages:2** and **Voice mail:1**) is shown, pressing **Read** ⏪ will display a menu allowing you to choose between different items (in our example: **Messages** and **Voice mail**).
- When a new SMS message is received an alert tone will sound and 📧 will be displayed. Then press **Read** ⏪ to view the SMS inbox messages.
If 📧 is flashing you will have to delete at least one old received message to be able to receive new ones (see page 40 for details).

The display will show the quantity and type of messages:



Press **Read** ⏪ to view the types of messages to be read. Use ⏴ or ⏵ and 📧 to scroll to the message type and press **Select** ⏪ to read the message.

- ☑ When a Message, Voice Mail or Unanswered call indicator is displayed the time and date is temporarily cleared from the display.

General operations

Dialling from memory

Any number stored in the SIM, or the phone memory, which can be recalled to the display can be dialled

...from the phonebook

- 1 Press **Names** to enter the phonebook list.
- 2 Use or and to scroll to the number required.
- 3 Press to dial the number.

See "Phone Book", page 36.

...from the last dialled numbers list

The last 10 numbers dialled are stored in the phone.

- 1 Press to display the last numbers dialled.
- 2 Use or and to scroll to the number required.
- 3 Press to dial the number.

...from the calls log memory list

The last 10 numbers dialled, the last 10 unanswered call numbers (if available) and the last 10 received answered numbers (if available) are stored by the phone in the calls log memory location menu.

- 1 Press **Menu** . Select **Calls & Times**.
- 2 Select **Calls log**.
- 3 Select **Last dial, Unanswered** or **Received**.
- 4 Use or and to scroll to the number required.
- 5 Press to dial the number.

See "Calls & Times", page 44.

Last dialled numbers

Quick access to the last 10 dialled numbers can also be obtained by pressing .

- 1 In the standby mode pressing will display a list of the last dialled numbers.
- 2 Use or and to scroll to the number required.
- 3 Press to dial the number.

Last dialled numbers are stored in the phone, not in the SIM.

Speed dialling

Any number stored in the SIM can be allocated to the speed dialling keys of 1-9.

Press and hold down the required key (1 to 9). The number will be recalled to the display and be dialled in the normal way.

By default, ① is always allocated to the voice mail number. See page 40 on how to allocate numbers to the speed dialling keys.

Vibrate alert mode

To avoid disturbing others you can silence the incoming ring and alert tones.

Turning on

- 1 Press .
- 2 Select **Vibrate**, **Vibrate & ring** or **Vibrate then ring**.
 is shown in the display when this feature is turned on.

Turning off

- 1 Press .
- 2 Select **Ring**.

If the ring tone volume is set to 0 a warning message will appear in the display.
See also "Tones - Alert mode", page 56.

Muting

When engaged on a call the microphone can be muted (turned off) to allow you to confer privately with people nearby without being heard by the other party.

Turning the microphone off

During conversation,

- 1 Press and hold down .
- 2 Select **Yes**.
The flashing  icon will appear in the display.

Turning the microphone on

Press and hold down .

The flashing  icon will disappear and the microphone will turn back on.

The microphone is automatically restored on receiving a new call.

Volume adjustment

To adjust the received audio level during conversation,

- 1 Press and use either **Vol.-** or **Vol.+** or and to increase or decrease the volume through the eight levels as shown in the display.
- 2 Wait 2 seconds to return back to the previous display.

See also "Volume adjustments", page 57.

Sending DTMF tones

DTMF tones are used to access answer phones, voice mail boxes and computerised home banking, etc. These tones are a method to communicate passwords and callback numbers.

Manually

To send individual DTMF tones directly from the keypad during conversation,

Press the required keys.

The tones will be heard in the earpiece and sent immediately.

Automatically

To send a consecutive string of DTMF tones during conversation,

- 1 Press .
- 2 Select **Auto-DTMF**.
- 3 Enter the DTMF numbers into the display either directly using the keypad or from a number stored in the phone-book (under **Names**).
- 4 Press **OK** . After the tones have been sent the normal conversation display will be shown.

DTMF tones cannot be sent when a call is on hold.

Pause feature

Telephone numbers and a sequence of DTMF tones can be entered in the display or stored in memory together provided they are separated by a 'pause'. A pause is entered between numbers by pressing and holding down . The letter **p** will appear in the display. Any number of pauses can be stored together with a maximum of 20-46 characters (dependent upon the SIM and the phones memory capacity).

In-call options

Holding and retrieving a call

To put a call on hold during conversation,

Press .

To retrieve a call,

Press .

To make a second call when one call is on hold,

- 1 Enter a number in the display. Press  to dial the number.
- 2 After the second call has been established press  to swap between the two calls.
- 3 To end either the current call or the held call, press  and select either **End held** or **End active** from the menu. The remaining call is automatically retrieved.
- 4 Press  to end the remaining call.

Both calls can be ended at the same time either by pressing  or choosing End all in the Options menu.

The alternative way to hold, retrieve and make a second call during conversation is to use  to display a menu of the features described above. Scroll to the required feature and press **Select**  (see also "Multi-party or Conference calls", page 29).

Call waiting, swapping and multi-party conference calls

Call waiting

Call waiting is a network feature that allows you to receive a second incoming call when already engaged on a call. This means that you can put an existing call 'on hold' whilst you answer or make a second call. To turn on or off the call waiting service,

- 1 Press **Menu** . Select **GSM Services**.
- 2 Select **Call waiting**.
- 3 Select **Activate** or **Cancel**. After some time (your request is sent to the network) the display will confirm your request.
- 4 Press **Exit**  or  to return to the standby display.

Action when receiving a second call

When a second incoming call is received you will hear a 'double beep'; an animated phone icon will be displayed as well as the phone number if available. Either press  to answer the call and put the first

call on hold or press **Reject**  to reject the call and return a busy signal to the caller. Press  to swap between the two calls. Use  and  to end one or both of the calls as described above.

Multi-party or conference calls

This network dependent feature gives you the ability to make or receive between 2 to 5 calls at the same time with all parties being able to hear and talk with each other.

- 1 Make and establish a call in the normal way and press 
- 2 Enter another number into the display and press . The first call will be put on hold whilst the second call becomes active.
- 3 Press  for the following menu:

Option	Description
Auto-DTMF	Allows a DTMF string to be entered to the active call only
Swap	Swaps between active and call on hold
Join	Joins active and call on hold to make a multi-party or conference call
Mute/Unmute	Turns on or off the microphone
End held	Ends the call on hold
End active	Ends the active call and connects with the call on hold
End all	Ends all the calls
* Private with	Allows you to select and have a private conversation with one of the conference callers whilst putting all the other calls on hold
Hold/Retrieve	Holds or retrieves the conference call
* End one	Allows you to select and end one of the conference call participants

* These items in the Options menu will appear if more than 2 calls are joined in the conference call.

Throughout the conference call the display will confirm and show the actions you have selected from the options menu.

- For alternate line service (ALS) subscribers conference calls cannot be made between Line 1 and Line 2. For further information see "Phone settings - customising your phone", pages 55-63.

The menu (MMI) system

The phone contains many functions and features that can be seen and entered through the easy to use menu system.


Through your SIM card the phone is also able to detect and display, in the menu, features that have been requested from your service provider as well as suppress ones that have not been subscribed too.

Access to the menus

From the standby display and for convenience all stored telephone numbers in the phonebook can be viewed immediately by pressing **Names** . To enter the main menu from the standby display press **Menu** .  and  can then be used to navigate up and down the menu. The desired function and features can then be selected by a press on **Select** . To return to a previous menu press **Exit** . To exit from the menu press and hold down **Exit**  or press  if no call is in progress.

Menu map

Names 	Menu 
List of the phonebook names in the SIM and the phone	Network Serv. *  <ul style="list-style-type: none">•Applications *•Services *•Information *
	 or  / 
	Voice Mail *  <ul style="list-style-type: none">•Call *•Number *•Alert *
	 or  / 
	Phone Book  <ul style="list-style-type: none">•Recall•Store•Remaining•Own numbers•Fixed dialling *•Phone book tones
	 or  / 
	Messages  <ul style="list-style-type: none">•Inbox *•Outbox *•Write new•Settings *•Alert *
	 or  / 
	Calls & Times  <ul style="list-style-type: none">•Calls log•Call timers•Call costs *•Line selection *
	 or  / 



* The availability and appearance of these features in the menu are dependent upon your subscription and the services provided by your network operator

Entering text

Some features and functions, e.g. storage of names into memory or sending SMS text messages, require you to know how to enter and edit text in the display. In the display this will be indicated by  in lower case mode and by  in upper case mode. Text and alphabet characters can then be entered or edited directly from the keypad. The characters available, which are language dependent, are shown below:

Key	Character	
	Lower case	Upper case
	1 . , - ' @ : ?	
	a b c 2	A B C 2
	d e f 3	D E F 3
	g h i 4	G H I 4
	j k l 5	J K L 5
	m n o 6	M N O 6
	p q r s 7	P Q R S 7
	t u v 8	T U V 8
	w x y z 9	W X Y Z 9
	0	0
	Short press changes next letter from upper to lower case or vice versa. Long press changes all next letters to upper or lower case or vice versa.	
	Short press, enters space. Long press gives access to special characters. () % ! ; " _ @ \$ + # * / & = < > ¥ \$ £ i ÷	
	Short press moves the cursor through the text one place to the right. Long press moves the cursor down the text to the next line.	
	Swap between Multitap/Multipress method and T9 text input.	

There are two methods of entering text characters and numbers in the display. The Multitap or Multipress key method or the quicker intuitive method, called T9 text input, which involves less key presses than the multitap method.

The Multitap/Multipress method

This is the default method.

A brief press on any key will display the first character associated with that key as well as show all the other available characters at the top of the display.

To enter text or a number digit, press the key with the required character repeatedly until it appears in the display.

A long press on any key will directly enter the number digit corresponding to that key.

If two characters are on the same key wait for the display at the top of the screen to clear or press  before pressing the same key again.

Correct mistakes by a short press on **Clear** . A long press on this key will delete all the text.

Use  to locate the cursor in the text to insert characters or make corrections.

A long press on  gives access to 22 special characters spread over 3 pages. Display and selection of the characters is as follows:



To select and insert a character into the text:

- 1 The characters are arranged as the 1 - 9 characters of the keypad.
In this example pressing 2 would select) and insert it directly into the text.
- 2 Use # or * to scroll to the next page.

Example

To enter 'Card' in the display,

- Press **Menu**  and select **Messages**.
- Select **Write new**. Select **Message**.
- Press and hold * until  is displayed. Press 2 briefly three times, **C** will appear in the display.
- Wait for the available characters to go from the display, press and hold * until  is displayed. Press 2 briefly once, **a** will appear.
- Press 7 briefly three times, **r** will appear.
- Press 3 briefly once, **d** will appear. The word **Card** will now be in the display.
- Press  to exit from this example.

T9 text entry

A press on  will swap between T9 text entry and the Multitap method.

Operation when in T9 mode text entry :

- 1 Press the key with the required letter only once.
Do not be put off if the character you want is not immediately displayed.
- 2 The "active" word changes as you type, so type to the end of the word.
- 3 If your word is not displayed, press  for other matching words.
- 4 If your word is not recognised, press  to swap to the multitap method to complete the word.
- 5 Use  to locate the cursor in the text to insert characters or make corrections.

Tips and Operation

Key	Action
	Shift - upper/lower case
Clear 	Clear or backspace
Long press	Numbers
	Space
	Another matching word
	Smart punctuation
	Swap between T9 and Multitap method.

Example

To enter 'card' in the display,

- Press **Menu**  and select **Messages**.
- Select **Write New**. Select **Message**.
- Press  until  is displayed.
- Press . **a** will appear in the display.
- Press . **ca** will be displayed.
- Press . **car** will be displayed.
- Press . **case** will be displayed.
If the displayed word is not the one you want, press  as many times as necessary to view **card**.
- Press **Exit**  or  to exit from this example and return to the standby display.

Description of menu functions & features

Network services



Your network operator may provide value added services and contact phone numbers. These services and phone numbers will be stored in your SIM and if available will modify the menu of the phone to be included under the item **Network Serv.** at the beginning of the menu (contact your service provider for details).

There will be three possible ways in which an operator may present these value added services and contact phone numbers:

SIM application tool kit

An automatic way to provide services related to your network and not to your phone. These services will be SIM dependent.

SDN numbers stored in the SIM

Up to 32 numbers may be stored in the SIM which cannot be changed by the user.

Information numbers

A list or a menu to enable you to call network or information services offered by your network.

Some operators will be able to provide two of the above services on the same SIM in which case the **Network Serv.** item in the main menu will provide two menu items, **Applications** and **Services** or **Information**.

Voice mail



Your network provider may offer a voice mail service which operates like an answering machine. Contact your service provider for details.

Storing a voice mail centre number

If your SIM does not automatically include the voice mail centre number it will have to be manually stored:

- 1 Press **Menu** . Select **Voice Mail**.
- 2 Select **Number**. When prompted enter the number manually or from a stored memory.
- 3 Press **OK** to validate your entry.
- 4 Press **Exit** to return to the previous display or press to return to the standby display.

If you subscribe to the 'Line 2' service the voice mail centre number will need to be stored separately for that line. The voice mail number is automatically assigned to speed dial location number 1 (see "Speed dialling" on page 40).

Turning on/off the voice mail alert tone

If you wish a tone to sound alerting you of the receipt of a voice mail message,

- 1 Press **Menu** . Select **Voice Mail**.
- 2 Select **Alert**. Select **On** or **Off**.
- 3 Press **Exit**  to return to a previous display or  to return to the standby display.

Calling the voice mail centre to check for messages

There are two ways:

- To dial the voice mail centre directly after the receipt of a message,

Press and hold down .

- Alternatively,

- 1 Press **Menu** . Select **Voice Mail**.
- 2 Select **Call**.

Dialling will proceed as for a normal call.

- If a voice mail number has not been stored when Call is selected you will be asked to enter the voice mail number. Proceed as described in "Storing a voice mail centre number", page 35.

Phone Book



The SIM and the phone have areas of memory used for storing names and telephone numbers known as the phonebook.

The phone has the capacity to store up to 20 digits and 16 alphabet characters in each of its 200 memory locations. The phone also supports SIM cards with up to 255 memories but the actual number and capacity is dependent upon the SIM itself. The phone and SIM memory locations are interconnected. Both the SIM and the phone memories are searched when the recall function is used.

Storing names and telephone numbers

Names and numbers can be stored directly in the phonebook or moved from other stored areas such as from SMS messages, scratch-pad or last dialled number list, etc.

It is advisable to store numbers in international format using the '+' prefix before the country code followed by the telephone number. This will ensure that the number can be dialled from within your home country as well as abroad (See page 22 for entering and identifying International dialling code numbers).

Text entry is as described on page 32.

There are three ways to store numbers into the phonebook:

- Directly from the standby display,

- 1 Enter the number. Press **Store** .
- 2 Select **Phone names** or **SIM names**.
- 3 Confirm the number by pressing **OK** .
- 4 Enter the name (if required) and press **OK** . Confirmation of your entry and the remaining locations will be briefly displayed.
- 5 Press **Exit**  or  to return to the standby display.

- Using the menu,

- 1 Press **Menu** . Select **Phone Book**.
- 2 Select **Store**. Select **Phone names** or **SIM names**.
- 3 Enter the number and press **OK** . Enter the name and press **OK** . Confirmation of your entry and the remaining locations will be briefly displayed.
- 4 Press **Exit**  or  to return to the standby display.

- From other stored locations,

Numbers stored in the last dialled, received, unanswered, scratchpad and SMS message locations can all be stored into the phonebook:

- 1 Display a number from one of the above, press .
- 2 Follow the display instructions as for point 2 in the previous item.

 During number and name entry a short press on Clear will clear the last character. A long press will clear the whole display.

The characters *, +, P (pause), # and _ can be stored together with numbers. If the SIM or phone's memory is full a warning message will be displayed when selecting the phonebook.

Free space in the phonebooks

To see how many empty phonebook spaces remain in the SIM or the phone,

- 1 Press **Menu** . Select **Phone Book**.
- 2 Select **Remaining** and use  or  and  to display the remaining memories in the phone or SIM.
- 3 Press **Exit**  or  to return to the standby display.

 If available the free memories in the FDN list will also be shown.

Viewing and calling numbers in the phonebook

Phonebook entries can be recalled into the display to be edited, deleted, copied, moved or called to or from either the phone or SIM. There are two ways to view and call numbers in the phonebook:

- Directly from the standby display,

- 1 Press **Names** to display the phonebook list.
- 2 Use or and to scroll through the list.

- Using the menu,

- 1 Press **Menu** and select **Phone Book**.
- 2 Select **Recall**.
- 3 Either press **OK** or enter up to the first 3 initials of the name required and then press **OK** .

If no initial was entered the display will show the first alphabet entry in the phonebook. The list of phonebook entries will be displayed in alphabetical order together with the telephone number and whether stored in the SIM or the phone memory.

- 4 Press to dial the number.

Pressing or and will scroll through the phonebook. To go directly to another entry press the corresponding alphabet key. For example to go directly to entries starting with 'N' press twice and use the scrolling keys to select your entry. Pressing will display the following menu choices:

Item	Function
Edit	Edits the name and number entry
Delete	Deletes the entry
Copy	Copies the entry to the SIM or the phone or vice versa. Editing allowed before copying
Move	Moves the entry to another position. Editing allowed before moving
Call	Calls the number displayed

- 5 Press **Exit** or to return to the normal display.

Own number display

If available in the SIM the phone can display your main 'Line 1' voice mobile number, the voice mobile number for Line 2 (Alternate Line Service) and your data and fax numbers. If not then they can be entered manually. Numbers can be given names. Line 1 for example can be named 'Office' etc.

To view, name and edit your own number(s),

- 1 Press **Menu** . Select **Phone Book**.
- 2 Select **Own numbers**. The mobile number for Line 1 will be displayed.
- 3 Use or and to view your Line 2, data and fax numbers (if available in the SIM).

- 4 To add or edit a name or number press **Edit** .
- 5 Press **Exit**  or  to return to the standby display.

Fixed dialling numbers (FDN)

Fixed dialling is a feature that restricts outgoing calls to 'fixed' numbers or 'prefixes' contained in SIMs that support this feature. When turned on, dialling numbers not in the FDN list will not be allowed. The maximum number of FDN numbers that can be stored is dependent upon the capacity of the SIM. Call diverting and sending SMS messages to numbers not in the FDN list will be prevented. Turning on or entering numbers into the FDN list is PIN 2 protected.

To turn on or off FDN operation,

- 1 Press **Menu** . Select **Phone Book**.
- 2 Select **Fixed dialling**. Select **Status**.
- 3 Select **On** or **Off**. Enter the PIN2 number.
- 4 Press **OK**  to validate and confirm the setting.

To view the numbers in the list,

- 1 Press **Menu** . Select **Phone Book**.
- 2 Select **Fixed dialling**.
- 3 Select **View** and use  or  and  to view all the entries. Pressing  will allow you to edit, delete and copy numbers to the phone or SIM.

To enter, edit or delete numbers in the FDN list,

- 1 Press **Menu** . Select **Phone Book**.
- 2 Select **Fixed dialling**.
- 3 Select **Add new**. You will be prompted to enter the PIN2 number if it has not been entered yet. It is now possible to add new numbers as well as edit, delete and copy numbers to the phone or SIM.

Wild card spaces can be used with the numbers stored in the FDN list. For example the number +441707 278 __ 9 will allow calls to all numbers between 278009 to 278999 to be dialled. The number can be edited and dialled in the standby display.

Giving your Phone Book different ring tones

To help you to identify incoming calls you can give your two Phone Books different ring tones,

- 1 Press **Menu** . Select **Phone Book**.
- 2 Select **Phone book tones**.
- 3 Select either **Phone names** or **SIM names**.
- 4 A list of different ring tone names will appear.
- 5 Use  or  and  to choose the required tone and press **Select**  (pausing on each tone will allow you to hear the

tone before selection).

- 6 Press **Exit**  or  to return to the standby display.

Speed dialling

Phonebook numbers can be assigned to keys 2 - 9 which when pressed and held down will dial, 'speed dial', those numbers directly from memory. ① is reserved exclusively for the voice mail number and is assigned automatically when the voice mail number is stored (see "Voice mail", page 35). Numbers stored in the SIM and in the phone (fixed dialling numbers excepted) can be selected.

To assign phonebook numbers to the speed dialling keys,

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Keys**.
- 3 Select **Speed dial**.
- 4 Use  or  and  to scroll to the desired key, 2 - 9.
- 5 Select **Names**  to choose from your phonebook entries and press **Select**  to validate your choice.
- 6 Press **Exit**  or  to return to the standby display.

- If a number which has been assigned to a speed dial key is deleted from the phonebook the corresponding number is automatically deleted from the speed dial key.

Messages (SMS)



The SMS message service enables you to send or receive short text messages of up to 160 characters to or from other mobile phones provided with the same capability. The messages are not sent directly to the other mobile phone but go via a message centre provided by your network operator. You can also store, edit and forward messages as well as saving any of the numbers they may contain.

Some networks also offer an SMS E:mail service through a gateway address which enables mobile users to send and receive messages to and from E:mail internet addresses.

Contact your service provider for availability and details.

Reading a received standard SMS or e:mail message

When the phone receives a new SMS or e:mail type message a 'double beep' SMS alert tone will sound and  will be displayed. The message is automatically stored in the SIM. If  is flashing there is no more space to store messages in the SIM. Delete previously read and stored messages to make space for new ones.

- 1 Press **Read**  to read all new received messages (inbox).
- 2 Use  or  and  to scroll between messages.
- 3 Press **Text**  to read all the text. Press **Delete**  to delete the message.

- 4 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

Reading stored SMS/e:mail messages

- 1 Press **Menu** \triangleright . Select **Messages**.
- 2 Select **Inbox** to display the first message header.
- 3 Press **Text** \triangleleft to read the message texts.

It is now possible to read all stored messages.

Use \leftarrow or \rightarrow to scroll between pages or between messages.

Unread messages are indicated by \square , previously read messages are shown by \square .

Managing received and stored SMS/e:mail messages

After reading the SMS message press \rightarrow for the following menu:

Item	Function
Read text	Displays the remainder of the text
Delete or Store	Deletes or stores the message
Reply	Reply to the sender of the message
Forward	Forwards the message to another user
Numbers	Stores or calls the number(s) contained in the SMS header or text

The items of this menu may vary and are dependent upon the type of message received.

Some messages are automatically deleted after being read, i.e. notification of a voice mail message for example.

In these cases the 'Delete' option changes to 'Store' giving the user the choice of keeping the message.

Turning on or off the message alert tone

Each time a new SMS message is received a 'double beep' alert tone will sound. To turn on or off this tone,

- 1 Press **Menu** \triangleright . Select **Messages**.
- 2 Select **Alert**.
- 3 Select **On** or **Off**.
- 4 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

Preparing the phone to send SMS/e:mail messages

You can write and send text messages to other suitably equipped mobiles or to internet e:mail addresses. Before doing so the networks SMS message centre number and e:mail gateway address (obtainable from your service provider) needs to be stored in the phone:

- 1 Press **Menu** \triangleright . Select **Messages**.
- 2 Select **Settings**.
- 3 Select **Message centre**.

If empty, enter the number manually (in international format) or from a stored memory and press **OK** \leftarrow .

If a number appears it means that it was taken directly from the information stored in your SIM, press **OK** \leftarrow .

- 4** Select **Gateway address**.
- 5** If an address (usually a telephone number) appears press **OK** \leftarrow . If not enter the number and then press **OK** \leftarrow .
- 6** Press **Exit** \rightarrow or \curvearrowright to return to the standby display.

If your SIM does not have the ability to store pre-programmed Message Templates (see the Re-usable message templates section below) then the **Settings** menu will also contain the options to enter the Validity period, Format, Paid reply request and request a Delivery report. If you don't wish to enter any values then default settings are assumed as per the table below.

The phone is now ready to send SMS/E:mail messages.

If required you can also choose the validity period, format, paid reply request and request a Delivery report. Default settings are assumed if not set.

Option	Description	Default
Validity Period	Time held at message center. 12 hrs, 1 day, 2 days or Maximum (defined by operator)	Maximum
Format	Selects format of message, text, e-mail, voice, fax or pager	Text
Paid Reply to	Reply requested	Off
Status report to	Delivery report	Off

Sending a new SMS message

- 1** Press **Menu** \rightarrow . Select **Messages**.
- 2** Select **Write new**. Select **Message**.
- 3** Enter the message text and press **OK** \leftarrow .
- 4** Select **Send or Store**.
- 5** If you selected **Send** enter the destination number or select **Names** \leftarrow to choose a number from a phonebook entry and press **Select** \leftarrow to validate your choice. Press **OK** \leftarrow . Sent confirmation will be given.
- 6** Select whether to Store or Send another message.
- 7** Press **Exit** \rightarrow or \curvearrowright to return to the standby display.

Messages in the outbox

The outbox contains unsent draft messages, stored sent messages as well as sent but undelivered messages, identified by their headers. These messages can be selected from the outbox menu and can be modified and resent as new SMS messages in the normal way.

To select an outbox message,

- 1 Press **Menu** \triangleright . Select **Messages**.
- 2 Select **Outbox** and use \blacktriangledown or $\#$ and \ast to scroll to the desired message. (Messages will be marked either "transmitted" - ✉ - or "to be sent" - ✉ -)
- 3 Press \blacktriangleright to read, delete, request a status report, send (or re-send) and edit a sent message.
- 4 Follow the instructions displayed on the screen.

Status request on outbox messages

If the status is requested on a delivered message the date and time of delivery may be shown. If the status is requested on a sent message a status request will be sent to the network (must be network supported). The network will answer by sending a status report (SR) back to the phone which can be acknowledged by pressing **OK** \blacktriangleleft . To action a status request on outbox messages,

- 1 Press \blacktriangleright . The following menu will be displayed:

Item	Action
Delete Msg.	Deletes the corresponding sent SMS message and the status report
Clear	To acknowledge the status report and clear the display
Associated msg	Displays the corresponding sent SMS message

- 2 Select the action required and press **OK** \blacktriangleleft .

Re-usable message templates

If your network operator provide SIMs that allow users to store pre-programmed message templates, then **Msg. templates** will appear in the **Messages - Settings** menu. Templates are sets of pre-programmed settings to be used when sending messages. Each of these templates can be given a name for easy identification and can be selected and used whenever required.

To create a message template,

- 1 Press **Menu** \triangleright . Select **Messages**.
- 2 Select **Settings**.

- 3 Select **Msg. templates**. Choose any blank [...] template and press **Edit** .
- 4 The display will prompt you to enter the template Name, Msg Centre number, Validity period and Format.

Default settings for pay reply and status are assumed 'off' unless set. If only one template is set it is automatically used by default. If more than one template is programmed any one can be selected for use when writing new messages.

Calls & Times

Details of the incoming and outgoing calls as well as the time duration of the last and accumulated total of all calls made are stored by the phone under the **Calls & Times** menu.

Calls log

This feature stores details (identity, time and date and call duration) of the last 10 numbers dialled, the last 10 received unanswered calls and the last 10 received (answered) calls. The call logs are common for both Line 1 and Line 2.

- 1 Press **Menu** . Select **Calls & Times**.
- 2 Select **Calls log**.
- 3 Select **Last dial**, **Unanswered** or **Received**.
- 4 Use  or  to scroll through the call lists.

The last number dialled or received is displayed first. For unanswered and received calls if the calling parties number is known it will be shown otherwise **Unknown number** will be displayed.

- 5 Pressing  on a highlighted number will call that number.
- 6 Pressing  will give access to the following menu:

Item	Action
Store	Stores the number into phonebook
Delete	Deletes the entry
Delete all	Deletes all the entries
Edit	Edits the displayed number
Details	Views the details - name, number, time and date and call duration of the highlighted number
Call	Makes a call to the number

Use  or  and  to select the required option and follow the display prompts.

Press **Exit**  or  to return to the standby display.

- In the standby display 'One Touch' access for the 10 last dialled calls may be available by pressing .


Call times

The duration time of the last call, total accumulated time of all calls and total time for Line 1 and Line 2 are stored.

Times for calls made and received through the home subscription network and through other (national and international) networks are displayed under the **Details** \leftarrow sub-menu.

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call timers**.
- 3 Select **Show**.
- 4 Use \downarrow or $\#$ and \ast to view all the timer information.

The call type and the accumulated times of outgoing and incoming calls will be displayed.



Pressing **Details** \leftarrow will display details of roaming and international calls etc.

Press **Exit** \triangleright to return to the previous display.

Press and hold **Exit** \triangleright or \ast to return to the standby display.

- If Line 2 is subscribed too 'All Calls' for Line 1 and Line 2 will be displayed separately.

Balance information (subscription service only)

This is a subscription service provided by some networks and enables you to ask for your remaining airtime balance. This information is sent by the network.

Contact your service provider on availability and details.

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call timers**.
- 3 Select **Balance information**.
- 4 Select **Call** or **Set number**.

If **Call** is selected and the balance information number has already been entered a call will be made to the balance information centre. If a number has not been entered select **Set number** and enter the number. Press **OK** \leftarrow to store your number or \ast to store and call the information centre to listen to your balance information.

- 5 Press \ast when the call is completed.

Reminder - Call duration

A call duration reminder beeps to remind you of the duration of a call. It can be set in multiples of 1 minute (1 - 59 mins) intervals.

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call timers**.
- 3 Select **Reminder**.
- 4 Select **On** (or **Off**).
- 5 Select the period (between 1 and 59 mins).
- 6 Press **OK** \triangleleft to validate the entry. Press **Exit** \triangleright or \odot to return to the standby display.

Call timer - reset

This feature enables you to reset all the call timers. You will need the 4 digit lock code to operate this feature.

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call timers**.
- 3 Select **Reset**.
- 4 Select **Yes** or **No**.
- 5 Enter the phone lock code and press **OK** \triangleleft . The action will be confirmed.
- 6 Press **Exit** \triangleright or \odot to return to the standby display.

Call costs - management (subscription service only)

Some networks offer an Advice of Charge (AoC) subscription service in which it is possible to see the cost of the last call made, the accumulated total cost of all calls and the remaining balance in units or currency of any 'cost limit' set by the user.

To display these costs in the currency of your choice you must first select the currency and cost per unit otherwise call costs in units will be displayed.

To set currency and cost per unit,

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call costs**.
- 3 Select **Display cost type**.
- 4 Select **Currency**. The present currency settings will be displayed.
- 5 Press **Edit** \triangleleft . Enter the PIN 2 code and press **OK** \triangleleft .
- 6 Enter the abbreviated letters of the currency. Press **OK** \triangleleft to validate.
- 7 Enter the cost per unit in the selected currency. Press **OK** \triangleleft to validate. The display will confirm your selection.
- 8 Press **Exit** \triangleright or \odot to return to the standby display.

To set call cost type to units,

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call costs**.
- 3 Select **Display cost type**.
- 4 Select **Units**.
- 5 Press **Exit** \triangleright or \odot to return to the standby display.

When the cost type is set to units the credit limit and the remaining credit are shown in units.

Setting the credit limit - in units or currency

After setting the currency and cost per unit, if required and available on your subscription, you are also able to set a credit limit in units or an amount in the currency of your choice. When the credit limit is reached the phone will be prevented from making and receiving all chargeable calls. This will not prevent the phone from making emergency calls.

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call costs**.
- 3 Select **Credit limit**. The display will show the present credit limit setting.
- 4 Press **Edit** \triangleleft . Enter the PIN 2 code and press **OK** \triangleleft .
- 5 Enter the credit limit (use $\#$ to enter a decimal point). Press **OK** \triangleleft to validate.
- 6 Press **Exit** \triangleright or \odot to return to the standby display.

When a credit limit is entered the selection from the 'Credit Limit' display will be Edit or Set No Limit.

Show costs

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call costs**.
- 3 Select **Show**.
- 4 Use \downarrow or $\#$ and \ast to display the cost of the **Last call**, **All calls** and the **Remaining credit**.
- 5 Press **Exit** \triangleright or \odot to return to the standby display.

The remaining credit is shown in either units or currency as set by Cost Type menu above.

Call costs - resetting all costs to zero

To reset all the call costs to zero,

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Call costs**.
- 3 Select **Reset**.
- 4 Select **Yes** to reset the costs or **No** to exit.
If **Yes** is selected, enter the PIN 2 number and press **OK** \triangleleft .
All Costs Reset will briefly be displayed.
- 5 Press **Exit** \triangleright or \odot to return to the standby display.

Line selection - Alternate line service - selecting line 2 (subscription service)

Some GSM 1800 operators support the use of a second line which can be made available to existing users. This is normally a subscription service and allows, for example, the separation of incoming and outgoing calls for business or private use. The second line will have its own mobile number. To select the line for outgoing calls,

- 1 Press **Menu** \triangleright . Select **Calls & Times**.
- 2 Select **Line selection**.
- 3 Use \blacktriangledown or $\#$ and \star to scroll to the line required and press **Select** \triangleleft to validate your choice.
- 4 Press **Exit** \triangleright or \blacktriangleleft to return to the standby display.

Names can be given to Line 1 (Office) and Line 2 (Home) for example. Refer to the Own Number menu (see page 38 for details). Whichever line is selected to make outgoing calls, incoming calls are still able to be received on either line.

GSM services



Diverting incoming calls (network service)

Call diverting is a service which diverts incoming calls, whether voice, fax or data, to another number.

To turn on a call divert,

- 1 Press **Menu** \triangleright . Select **GSM Services**.
- 2 Select **Call diverting**.
- 3 Select **Voice, Fax, Data** or **Cancel all**. The following menu will be displayed:

Divert options	Action
Always	Diverts all incoming voice calls unconditionally
When not reachable	Diverts all voice calls when the phone cannot be reached, i.e. out of service
On no reply	Diverts all voice calls when the phone does not answer
When busy	Diverts all voice calls when the phone is busy
All conditions	Diverts all voice calls when Not Reachable, No Reply and When Busy

- 4 Use \blacktriangledown or $\#$ and \star to select the divert condition and validate by pressing **Select** \triangleleft .
- 5 Select **Activate**.
- 6 Select **Voice Mail, Names** or **Number**.
- 7 Enter the number to divert your incoming calls either from a stored memory or directly into the display and press **Select** \triangleleft . The display will confirm your request.

8 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

- 1. If the 'On No Reply' option is selected you will be requested to enter a delay period of 5, 15 or 30 seconds.
- 2. Call diverts for both Line 1 and Line 2 must be set for each line. During call divert programming, only the line currently selected is affected by the call divert selected. To carry out a call divert on the other line you must select this other line first (see Line selection, page 48).

To turn off or check the status of individual call diverts,

- 1** Press **Menu** \triangleright . Select **GSM Services**.
- 2** Select **Call diverting**.
- 3** Select **Voice, Fax or Data**.
- 4** Use \downarrow or \uparrow and \ast to select the divert condition and validate by pressing **Select** \triangleleft .
- 5** Select **Cancel** or **Status**.
Your selection will be confirmed.
- 6** Press **Exit** \triangleright or \curvearrowright to return to the standby display.

To cancel all (multiple) diverts,

- 1** Press **Menu** \triangleright . Select **GSM Services**.
- 2** Select **Call diverting**.
- 3** Select **Cancel all**.
Confirmation will be displayed.
- 4** Press **Exit** \triangleright or \curvearrowright to return to the standby display.

- This action cancels all voice diverts (for voice, faxes and data calls) for the line currently in use. To cancel call diverts for the other line you must select this other line first (see Line selection, page 48).

Caller Line Identity - showing/hiding your mobile number

Most networks allow the Caller Line Identity feature (CLI) i.e. the feature which shows the incoming number (ID) while receiving a call. Selecting **Receiving caller ID** will allow you to check the availability of such a feature.

Receiving caller ID

This feature enables you to find out whether a network presents the ID of incoming calls.

- 1** Press **Menu** \triangleright . Select **GSM Services**.
- 2** Select **Receiving caller ID**. A **Requesting** display will be shown after which the network will return **Presentation available** or **Presentation unavailable**.
- 3** Press **Exit** \triangleright or \curvearrowright to return to the standby display.

On networks which allow caller line identity you can disable the sending of your own number, on a call by call basis, by adding **#31#** before the number you are calling. Alternatively you can ask your service operator to always disable the sending of your mobile number. In this

case if you wish to reveal your number, on a call by call basis, you can do so by adding *31# before the number you wish to call.

Standard network setting

To reset the standard network setting for sending your mobile ID,

- 1 Press **Menu** . Select **GSM Services**.
- 2 Select **Sending my ID**.
- 3 Select **My settings**.
- 4 Select **Preset**. The phone will reset to the network setting agreed with your service provider.
- 5 Press **Exit**  or  to return to the standby display.

Hiding or showing your number

- 1 Press **Menu** . Select **GSM Services**.
- 2 Select **Sending my ID**.
- 3 Select **My settings**.
- 4 Select **Hide my ID** or **Show my ID**.
- 5 Press **Exit**  or  to return to the standby display.

Finding out your current ID setting

- 1 Press **Menu** . Select **GSM Services**.
- 2 Select **Sending my ID**.
- 3 Select **Status**.
The phone will display your current setting taking into account both network and phone settings.
- 4 Press **Exit**  or  to return to the standby display.

Network

When the phone is turned on, it automatically searches for the last network it was registered on (usually the home network). If this is not available, the phone will automatically search and select a network from the preferred network list contained in the SIM.

Editing the preferred list

The phone contains a list of networks which can be selected and transferred to the preferred networks list stored in the SIM.

This list can be changed to suite your travel arrangements.

The order and name of the networks in the preferred networks list can be changed and edited.

- 1 Press **Menu** . Select **GSM Services**.
- 2 Select **Network**.
- 3 Select **Preferred list**. A list of networks will be displayed.
- 4 Use  or  and  to view the list.
- 5 Press **Edit**  to place your selection in the preferred list.

- 6 Press  to change it. The following items are displayed:

Option	Description
Modify by list	Displays the general list of all known networks contained in the phone in alphabetical order
Modify by code	Edits or enters a network number (MCC MNC) if you know this information.
Delete	Deletes an entry

- 7 Press **Select**  to confirm the selection.

- 8 Press **Exit**  or  to return to the standby display.

Your SIM may contain a forbidden list of networks which cannot be used. To view the forbidden list or show the home network,

- 1 Press **Menu** . Select **GSM Services**.

- 2 Select **Network**.

- 3 Select either **Forbidden** or **Home network**.

A list of the forbidden networks or the home network will be displayed.

- 4 Press **Exit**  or  to return to the standby display.

Selecting manual search

There may be occasions when you wish to select a specific network, which has better coverage in your current location for example.

- 1 Press **Menu** . Select **GSM Services**.

- 2 Select **Network**.

- 3 Select **Search**.

- 4 Select **Manual**. A confirmation screen and **Scanning for Networks** will be displayed followed by a list of the networks found.

- 5 Choose the network and press **Select** . **Requesting** followed by the name of the network will be shown after which the phone will return to the standby display.

You cannot delete a network from the forbidden list. This list will be automatically updated when the manual network selection is performed.

Selecting automatic search (normal default setting)

To perform an automatic search from the preferred list proceed as follows:

- 1 Press **Menu** . Select **GSM Services**.

- 2 Select **Network**.

- 3 Select **Search**.

- 4 Select **Automatic**.

An automatic search will be performed.

- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

Call barring (network service)

This is a network service which allows you to stop different types of calls being made and received on the phone.

It requires the use of a network barring password available only from your service provider.

To put on a call bar,

- 1 Press **Menu** \triangleright . Select **GSM Services**.
- 2 Select **Call barring**.
- 3 Select **Outgoing calls** or **Incoming calls**.
The following options will be displayed:

Select	Meaning
Outgoing - All outgoing	All outgoing calls will be barred
- Int'nal calls	All outgoing international calls only will be barred
- Int'nal excl. home	All outgoing international calls except to other subscribers within the users home network
Incoming - All incoming	All incoming calls will be barred
- Roaming only	All incoming calls when not on the home network

- 4 Scroll to the required option and press **Select** \triangleleft .
- 5 Select **Activate**.
- 6 Enter the call barring password and press **OK** \triangleleft .
The network will confirm the selection.
- 7 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

To take off or check the status of a call bar,

- 1 Press **Menu** \triangleright . Select **GSM Services**.
- 2 Select **Call barring**.
- 3 Select **Outgoing calls** or **Incoming calls**.
- 4 Select **All outgoing**, **Int'nal calls** or **Int'nal excl. home**.
- 5 Select **Cancel** or **Status**. If choosing to take off a call bar the password will be required.
- 6 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

The 'Cancel all' option will remove all the call bars from both all outgoing calls and all incoming call options.

To change the password,

- 1 Press **Menu** \triangleright . Select **GSM Services**.
- 2 Select **Call barring**.

- 3 Select **Change password**.
The old password will be requested followed by two requests to enter the new password. Confirmation will be displayed.
- 4 Press **Exit** \triangleright or \triangleleft to return to the standby display.

Closed user group, CUG (subscription service only)

This is a network service feature and allows the phone to make or receive calls only from selected groups of people. The groups, level of access and whether one of the groups has preferential calling access is set up at the time of subscription. This is not a single user feature and is mainly for businesses wishing to benefit from closed, internal communications.

Up to 10 groups may be set up. Unless authorised calls made or received to or from numbers outside the group are not permitted.

To turn on and off CUG and select type of CUG service,

- 1 Press **Menu** \triangleright . Select **GSM Services**.
- 2 Select **CUG**. The current CUG status will be displayed.
- 3 Pressing **Set** \triangleleft will display the following options:

Options	Meaning
No CUG	CUG is off. No groups active. Calls can be made outside the group
Partial CUG	Limited calls to and from users outside the group and from users within the group
CUG Only	Only able to make and receive calls from users within the group

- 4 Scroll to the required option by using \downarrow or \leftarrow and $\#$ and press **Select** \triangleleft (your selection will be confirmed).
- 5 Press **Exit** \triangleright or \triangleleft to return to the standby display.

'No CUG' is the setting for normal use.

Broadcast - cell broadcast (CB) messages

These are messages broadcast by the networks to all GSM users and may provide general information about local area dialling codes, weather reports and traffic news etc. Each type of message is numbered enabling you to select the type of information you want to receive. Up to 5 different types of messages can be programmed into your selection list but only one can be displayed at any one time.

There are 16 standard message types pre-programmed into the phone to select from. New message types can be programmed into the 'selected types' list using **Edit** \triangleleft . Contact your service provider for details on the types of CB broadcast messages available.

Before you can turn on the broadcast service you have to put at least one message type in the Selected types list.

To enter a message type in the 'Select types' list

Up to 5 message types can be entered into the selection list.

- 1 Press **Menu** \triangleright . Select **Broadcast**.
- 2 Select **Message types**.
- 3 Press **Edit** \triangleleft and use \blacktriangledown or \ast and $\#$ to scroll to any one of the 16 message types and press **Select** \triangleleft to confirm your choice.
Alternatively press \blacktriangleright to enter a message type by code number if known.
- 4 Press **Edit** \triangleleft again to enter another message type in the Selected types list.
- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

To turn on or off the broadcast service

- 1 Press **Menu** \triangleright . Select **Broadcast**.
- 2 Select **On/Off**.
- 3 Select **On** or **Off**.
- 4 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

Reading broadcast messages

Broadcast messages are shown in the standby display only and are suppressed during conversation or menu operation. A message can be up to 93 characters in length and cover several pages. Pages will change automatically approximately every five seconds or by a press on \blacktriangledown .

Options during message display

A press on **Exit** \triangleright will clear the CB currently displayed.

Pressing \blacktriangleleft will dial the number shown in the display within the message.

Pressing \blacktriangleright will display the following menu:

Option	Action
Delete All	Deletes all messages stored in the queue
Numbers	Displays all phone numbers found in the message text and allows to dial or store them in the scratchpad if required
Broadcast Off	Turns off cell broadcast
Delete	Delete the current message

To turn on or off the alert tone

If required an alert tone can be turned on to 'beep' every time a new or updated broadcast message is received.

- 1 Press **Menu** . Select **Broadcast**.
- 2 Select **Alert**.
- 3 Select **On** or **Off**.
- 4 Press **Exit**  or  to return to the standby display.

To delete or change a message type in the 'Selected types' list by name or code

Message types put into the 'Selected types' list can be deleted or modified using the named message types or by using codes.

- 1 Press **Menu** . Select **Broadcast**.
- 2 Select **Message types**.
- 3 Press  and select **Modify by list**, **Modify by code** or **Delete**.
(if **Modify by code** is selected see the code table hereafter or consult with your service provider for further codes if available).
- 4 Press **Exit**  or  to return to the standby display.

Broadcast language

All the broadcast messages can be shown in several languages. To select the language of your choice,

- 1 Press **Menu** . Select **Broadcast**.
- 2 Select **Language**.
- 3 Use  or  and  to select a language from the displayed list. Press **Select**  to validate.
- 4 Press **Exit**  or  to return to the standby display.

Phone settings - customising your phone

Keypad lock

When keypad lock is turned on it prevents accidental operation of the keys and access into the menus. The key tones are also silenced. Keypad lock is suspended during incoming calls and resumed when the call is terminated. Emergency calls can still be made. If a key is pressed the display will give a reminder that keypad lock is on. There are two ways to turn keypad lock on and off:

- Directly from the keypad in the standby display,

- 1 Press  plus  to turn keypad lock on.
The display will show .

- 2 Press either or **Unlock** plus to turn keypad lock off.
- Using the menu,

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Keypad lock** to turn keypad lock on.
- 3 Press either or **Unlock** plus to turn keypad lock off.

Keypad lock is cancelled when connected to the handsfree car kit.

Language selection

All the display messages can be shown in several languages.
To select the language of your choice,

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Language**.
- 3 Use or and to scroll to the required language and press **Select** to validate your choice.
- 4 Press **Exit** or to return to the standby display.

To reset the phone to the language of the SIM enter *#0000#.
To reset the phone language to English enter *#0044#.

Tones - Alert mode

To avoid disturbing others you can turn off the audible incoming ring tone, key tones and all alert and alarm tones.

If any of the 'Vibrate' options are chosen all the alert and alarm tones are replaced by the vibrating action.

There are two ways:

- Directly from the standby display,

- 1 In the standby display, pressing will display **Ring**, **Vibrate**, **Vibrate & ring** or **Vibrate then ring**.
- 2 Use or and to scroll to the desired settings. Press **Select** to validate your choice. (If any of the vibrate options are selected the phone will briefly vibrate) will appear in the display.

1. If Ring is selected but the ring tone volume has been set to off the icon will appear in the display. A warning that the ring tone volume is off will also be displayed when the mobile is switched on.
2. The icon will appear in the display if Vibrate, Vibrate & ring or Vibrate then ring is selected. It takes precedence over the icon.

- Using the menu,

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Tones**.
- 3 Select **Alert tones**.

- ④ Select **Ring, Vibrate, Vibrate & ring** or **Vibrate then ring** to validate your choice.
- ⑤ Press **Exit** \triangleright or \curvearrowright to return to the standby display.

If Ring is selected but the ring tone volume has been set to off, the  icon will appear in the display. A warning that the ring tone volume is off will also be displayed when the mobile is switched on. When the phone is connected to either the Desk Top Charger, HF kit, CLA or AC adaptor the vibrator mode selection is temporarily inhibited and the phone will ring instead.

Ring tone selection

You can choose the sound of the incoming ring tone from a selection of 20 ring tone melodies stored in the phone.

To hear your chosen ring tone melody, wait several seconds before confirming your choice. The melody will be played.

Ring tone selection is made through the **Settings** menu:

- ① Press **Menu** \triangleright . Select **Settings**.
- ② Select **Tones**.
- ③ Select **Ring tone**.
- ④ Use \downarrow or \ast and $\#$ to listen to the different ring tones. Press **Select** \triangleleft to select the current tone.
- ⑤ Press **Exit** \triangleright or \curvearrowright to return to the standby display.

Separate tones must be selected for Line 1 and Line 2.

Volume adjustments

The volume levels of the ring tone, key tones, alarm tones (alarm clock and low battery alarm) and the incoming audio can all be individually adjusted from the standby display by pressing \oplus or in the **Settings** menu:

- ① Press **Menu** \triangleright . Select **Settings**.
- ② Select **Tones**.
- ③ Select **Volume**.
- ④ Select **Ring, Keys, Conversation** or **Alarm** tones.

The display will confirm the selection naming the volume to be adjusted.



- ⑤ Use \ast or $\#$ to adjust the setting.
- ⑥ Press **OK** \triangleleft to validate the setting.
- ⑦ Press **Exit** \triangleright or \curvearrowright to return to the standby display.

During a call you can adjust the earpiece volume by pressing  and pressing **Vol.-**  and **Vol.+** .

- If the ring tone volume level is set to Off the  warning icon will appear in the display. A warning will also be displayed when the mobile is switched on.

Ramping

Ramping is a feature that when turned on will cause the incoming ring tone to gradually increase to the maximum volume level if the call is not answered after the first ring.

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Tones**.
- 3 Select **Volume**.
- 4 Select **Ramping**.
- 5 Select **On** or **Off**.
- 6 Press **Exit**  or  to return to the standby display.

- When turned on the volume of the incoming ring tone will start from the minimum and rise to the maximum volume until answered.

Edition

This feature, which is network, SIM and language dependent, changes the "accented" character set to suite the language in use on the phone. Not applicable to English.

Display - Backlight setting

This option allows the user to control the operation of the backlight during key entry or incoming ring tone.

There are two settings:

- **On for 10 sec.:** the display and key backlight will stay on for 10 seconds after the last key press or incoming call.
- **Off:** the backlights will stay off.

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Display**.
- 3 Select **Backlight**.
- 4 Select either of the two settings. Press **Select**  to validate.
- 5 Press **Exit**  or  to return to the standby display.

- When the phone is connected to either the Desk Top Charger, HF Car Kit, CLA or the AC Adaptor the backlight is always on.

Display contrast

The contrast of the display can be adjusted to suit the surrounding light conditions.

To modify the display contrast,

- 1 Press **Menu** . Select **Settings**.

- 2 Select **Display**.
- 3 Select **Contrast**.
- 4 Adjust the contrast using  or .
- 5 Press **OK**  to validate the setting.
- 6 Press **Exit**  or  to return to the standby display.

Hotkey - programming the hotkey

The purpose of this key is to provide a shortcut to the users most frequently used feature and can be changed (programmed) to suite the user. The options available are shown in the menu during selection.

There are two ways:

- Directly from the standby display,

- 1 Press and hold down .
- 2 Use  or  and  to scroll through the choice of hotkey options.
- 3 Press **Select**  to validate your choice.
- 4 The screen will confirm your selection and return to the standby display showing your new softkey function.

- Using the menu,

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Keys**.
- 3 Select **Hotkey programming**.
- 4 Use  or  and  to scroll through the choice of hotkey options.
- 5 Press **Select**  on the softkey option of your choice.
- 6 Press **Exit**  or  to return to the standby display.

Any key answer

This feature enables any key (except  and **No ring** ) to be pressed to answer an incoming call.

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Keys**.
- 3 Select **Any key answer**.
- 4 Select **On** or **Off**.
- 5 Press **Exit**  or  to return to the standby display.

Auto answer

This feature only works when the phone is connected to a handsfree car kit or headset and enables the phone to automatically answer an incoming call after approximately 5 seconds without having to press any keys.

- 1 Press **Menu** \triangleright . Select **Settings**.
- 2 Select **Auto features**.
- 3 Select **Auto-answer**.
- 4 Select **On** or **Off**.
- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

Auto retry

This feature enables the phone to automatically redial the number of a failed call, due to a system busy or unavailable signal from the network, for up to 10 times after which it will stop.

- 1 Press **Menu** \triangleright . Select **Settings**.
- 2 Select **Auto features**.
- 3 Select **Auto-retry**.
- 4 Select **On** or **Off**.
- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

When activated, **Auto-retry** and a countdown timer to the next call attempt will appear in the display. An auto-retry warning tone will sound each time a new call attempt is made.

If the automatic redialling is successful proceed with the call as normal. Pressing **Exit** \triangleright or any key during the retrying process will cancel auto-retry and end the dialling process for that call.

Security features

The security features described in this section protects your phone from unauthorised use.

When requested, enter the code, which appear as asterisks (*) and press **OK** \curvearrowleft .

If you make a mistake press **Clear** \triangleright and enter the correct digit(s).

- Avoid using codes similar to emergency numbers such as 999 or 112 to prevent accidental dialling of these numbers.

KEEP A RECORD OF YOUR CODES AND KEEP THEM IN A SAFE PLACE.
FAILURE TO DO SO WILL CAUSE YOU CONSIDERABLE
INCONVENIENCE.

Phone lock code

A phone lock code is supplied with the phone for security purposes. It prevents unauthorised access to the phone and to the WAP™ settings. The factory setting is **0000**. We suggest that you reset this code and keep it in a safe place, separate from the phone.

The phone lock code is also required to reset the call timers. When enabled the code will be asked for each time the phone is turned on.

To change the phone lock code,

- 1 Press **Menu** \triangleright . Select **Settings**.
- 2 Select **Security**. Select **Phone lock**.
- 3 Select **Change Code** and follow the display prompts.
- 4 Press **OK** \triangleleft to validate the new code.
- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

To turn on or off the phone lock code,

- 1 Press **Menu** \triangleright . Select **Settings**.
- 2 Select **Security**. Select **Phone lock**.
- 3 Select **On** or **Off**.
- 4 The phone lock code will be requested to authorize your selection.
- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

When phone lock is on emergency calls can still be made.

PIN code

Your SIM is provided with a 4-8 digit PIN code to protect it from unauthorised usage. When enabled the PIN code will be asked for each time the phone is turned on. If you enter the wrong PIN code three times in succession your SIM card will be blocked and you will need the 8 digit PUK code from your service provider (see page 62).

To turn on and off the PIN,

- 1 Press **Menu** \triangleright . Select **Settings**.
- 2 Select **Security**.
If already off, **PIN enable** will be shown.
If already on, **PIN disable** and **PIN change** will be shown.
- 3 Press **Select** \triangleleft and follow the display prompts.
- 4 Press **OK** \triangleleft to validate your entry.
PIN enabled or **PIN disabled** briefly displayed will confirm your action.
- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

To change the PIN code (PIN must first be enabled),

- 1 Press **Menu** \triangleright . Select **Settings**.
- 2 Select **Security**.
- 3 Select **PIN change** and follow the display prompts.
- 4 Press **OK** \triangleleft to validate your new PIN. Confirmation will be displayed.
- 5 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

PIN2 code

The PIN2 code prevents unauthorised access to some features of the phone such as turning on or off FDN operations, modifying the FDN phonebook, setting calls costs to zero, modifying the costs display features. It can be changed but not turned on or off.

To change the PIN2 code,

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Security**.
- 3 Select **PIN2 change** and follow the display prompts.
- 4 Press **OK**  to validate your new PIN2 code.
- 5 Press **Exit**  or  to return to the standby display.

PUK code

The PUK (PIN unblock key) is an 8 digit code supplied by your service provider. It is used to 'unblock' a PIN whose code has been entered incorrectly three times. A PUK code cannot be read or changed.

When requested enter the PUK code and press **OK** . You will then be asked to enter a new PIN code. Follow the display prompts to reset the PIN code.

- If you enter the wrong PUK code 10 times in succession your SIM card cannot be used again. Contact your service provider for a new card.

PUK2 code

The PUK2 is an 8 digit code supplied by your service provider. It is used to unblock a PIN2 whose code has been entered incorrectly three times. A PUK2 code cannot be read or changed. When requested enter the PUK2 code. You will then be asked to enter a new PIN2 code. Follow the display prompts to reset the PIN2.

- If you enter the wrong PUK2 code 10 times in succession you will be unable to use the features requiring the PIN2 code. Contact your service provider for a new card.

Call barring password

The call barring password is used to select the call barring levels outlined in the **Services - Call barring** menu (see page 52). It is obtained from your service provider.

To change the password,

- 1 Press **Menu** . Select **GSM Services**.
- 2 Select **Call barring**.
- 3 Select **Change password** and follow the display prompts.
- 4 Press **OK**  to validate.
- 5 Press **Exit**  or  to return to the standby display.

Summary of code/password entry chart

Password	Length	Number of tries allowed	If blocked or forgotten
Unlock code	4 digits	Unlimited	Return phone to manufacturer
PIN	4-8 digits	3 tries	Unblocked by use of PUK code
PIN2	4-8 digits	3 tries	Unblocked by use of PUK2
PUK	8 digits	10 tries	Contact your service provider
PUK2	8 digits	10 tries	Contact your service provider
Call barring password	4 digits	Network determined	Contact your service provider

Time & Date setting

To set either the current time and/or date:

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Time & date**.
- 3 Select **Set time** or **Set date**.
- 4 Enter the time (in 24 hour format) or date in the format shown. (If required use to move the cursor left or right)
- 5 Press **OK** to validate your selection.
- 6 Press **Exit** or to return to the standby display.

- 1. An error message is displayed if a wrong entry is made.
- 2. The time/date is permanently displayed whilst the phone is on. The year is not shown.
- 3. An internal battery is provided inside the phone to maintain the date and time setting for up to 3 hours when the phone is switched off and without a battery, or with a completely discharged battery attached. After this 3 hour period you may need to reset the clock when you again switch on the phone.

Default (factory) settings

Use the **Settings** menu to return the phone settings back to the factory settings. This has no effect on the phonebook entries or phone lock code.

- 1 Press **Menu** . Select **Settings**.
- 2 Select **Default settings**.
- 3 Select **Yes** or **No**.
- 4 Press **Exit** or to return to the standby display.

The following are the factory default settings:

Feature	Factory setting
Alert Tones	Ring
Ring Tones	Trium
Volumes, Ring, Key, Speech and Alarm.	Mid values
Backlight and Contrast	On for 10 sec. and mid value
Any Key, Auto-retry, Auto answer and Speed dialling settings.	Off
Ramping	Off

Using the office tools



The **Office Tools** menu contains a scratchpad, a currency converter calculator, an alarm clock and an auto switch on/off feature.

Scratchpad

Up to 10 separate entries containing 16 characters can be stored in the scratchpad

- 1 Press **Menu** \triangleright . Select **Office Tools**.
- 2 Select **Scratchpad**.
- 3 Select **Read**. Use \blacktriangledown or \blacktriangleleft and $\#$ to scroll through the entries.
Select **Write** to make a new scratchpad entry.

Pressing \blacktriangleright when reading entries will give access to the following menu:

Item	Action
Store *	To save a number to the phonebook
Edit	Modifies an entry
Delete	Deletes an entry
Delete All	Deletes all entries
Call *	Calls the number displayed in the entry

* These items will only appear if the scratchpad entry is a telephone number.

Currency-converter

This useful feature converts currencies. However to use the converter the currencies and the exchange rate have first to be set up. The conversion is calculated on the per unit exchange rate of the second currency selected.

To select the currencies and the exchange rate,

- 1 Press **Menu** \triangleright . Select **Office Tools**.
- 2 Select **Currency converter**.

- 3 Select **Settings**.
- 4 Enter the first currency name (e.g. Dollar). Press **OK** .
Enter the second currency name (e.g. Yen). Press **OK** .
- 5 Enter the exchange rate using  to enter a comma.
Press **OK**  to validate the entry.
- 6 Press **Exit**  or  to return to the standby display.

If you wish to use your Currency-converter as a Euro converter for participating currencies to the European Monetary Union ("Euroland currencies"), please enter the complete Euro exchange rate with six significant figures. For example: 1 Euro = £ 1.52.

To calculate the conversion between the chosen currencies,

- 1 Press **Menu** . Select **Office tools**.
- 2 Select **Currency converter**.
- 3 Select one of the two first options.
In our example: either **Dollar->Yen** or **Yen->Dollar**.
- 4 Enter the amount to be converted.
Press  to insert a comma, if needed.
Press **OK** . The converted amount will be displayed.
- 5 Press **New**  to make another conversion or **Exit**  or  to return to the standby display.

Conversion from one Euroland currency to another, or to non-Euroland currencies, should normally follow "triangulation" rules (i.e. conversion of local currency to Euro and then Euro to other local currency). Your Currency-converter does not provide this possibility. Accordingly, the result you obtain will only be a close approximation.

Alarm clock

This feature enables the user to set a daily 'Reminder Alarm'.

To set a time and turn on the alarm,

- 1 Press **Menu** . Select **Office Tools**.
- 2 Select **Alarm clock** (If a previous alarm time has been entered this time will be displayed).
- 3 Select **On** and enter the alarm time (in 24 hour format) or press **OK**  to accept the displayed time.
Confirmation will be displayed.
- 4 Press **Exit**  or  to return to the standby display.
 will be displayed next to the time in the display.

When 'on' the alarm will operate at the same time every day until turned off.



When the alarm time is reached an audible alert sounds for up to 1 minute and the LED will flash red. **Alarm clock** and a vibrating bell symbol will appear in the display together with the current time and the softkeys, **Valid.** ⏪ and **No ring** ⏩.

If the phone is off at the time of the alarm, the phone will automatically 'power on' and operate the audible and visual alerts described above.

To use as a Reminder or Snooze Alarm,

Press **No ring** ⏩, or any other key (except **Valid.** ⏪) to stop the alarm. The alarm icons remain in the display and the alarm will ring again 3 minutes later.

or

Press **Valid.** ⏪ to acknowledge and switch off the alarm.

If 'off' before the time of the alarm the phone remains 'on'. If the phone is locked or the PIN setting is on it remains in this locked condition until actioned by the user.

If the alarm is acknowledged but not validated the alarm indicators will remain in the display for up to 15 minutes after which time the phone will either turn off, or, if 'on' at the time of the alarm, will revert back to the normal standby display.

- ☑ 1. Until acknowledged the alarm will ring for 1 minute. Pressing any key (other than the Valid. softkey) will stop the alarm sounding but not switch off the alarm, it will be repeated 3 minutes later. If the Valid. softkey is not pressed after the 3rd (and final) time the alarm rings it will not be repeated but the phone remains on, in the alarm display mode, for up to 15 minutes after which it will revert back to the state it was in before the alarm time was reached.
- 2. If a call is in progress, or the phone is in a transitory state (during power off for example) at the time of an alarm it will be delayed until after the call or the transitory state has finished.
- 3. If the alarm time is reached during a call a special 'In Call' alert beep will sound every 20 seconds. The alarm can be validated in the normal way.
- 4. If the alarm time is reached during an outgoing, or incoming call setup sequence, the alarm is suspended until the call is established and the mobile behaves as in 3 above.
- 5. If the battery is detached within 15 minutes of the alarm time the alarm will sound immediately. If later than 15 minutes only the visual indicators will be shown. Press the Valid. softkey to validate and stop the alarm.

To turn off the alarm,

- ① Press **Menu** ⏪. Select **Office Tools**.
- ② Select **Alarm clock**.
- ③ Select **Off**. Confirmation will be displayed.
- ④ Press **Exit** ⏩ or ⏪ to return to the standby display.

Caution - Please remember to turn off the alarm feature when boarding an aircraft where the use of a mobile phone is not permitted and is illegal. Alternatively you can remove the battery after turning off the phone.
See the General safety warnings on page 2.

Auto Switch On/Off

This feature enables the user to automatically program the phone to switch On or Off at pre-determined times.

To set a Switch On or Off time,

- 1 Press **Menu** . Select **Office Tools**.
- 2 Select **Auto-switch**.
- 3 Select **Auto-switch-off** or **Auto-switch-on**.
- 4 Select **On** or **Off**.
(If a previous time has been entered it will be displayed)
- 5 Enter a new time or accept the previous one. Press **OK** .
Stored will briefly be displayed.
- 6 Press **Exit** or to return to the standby display.

At the switch-on time the phone comes on in the normal way. Enter the lock or PIN code if required.

If the phone is already on at the switch-on time no action occurs.

If the phone is set to switch-off, 1 minute before the switch-off time is reached, the display will show a warning message **Switch off in** with a countdown timer showing the time to switch off. Pressing **Cancel** will cancel the switch off process.

If the mobile is already off at the switch-off time no action occurs.

- The Auto Switch-off and Switch-on times cannot be the same.
If a call is connected at the time of switch-off, the switch-off process is postponed until after the call is finished.

Caution - Please remember to turn off the Switch-on alarm feature when boarding an aircraft where the use of mobile phones is not permitted and is illegal. Alternatively you can remove the battery after turning off the phone.
See the General safety warnings on page 2.

Diary



This feature enables you to store up to 20 timed diary events to occur either once, daily or weekly. Entries can be of up to 28 characters of text in length, with or without a reminder alarm, set for the entry time or 15, 30 or 60 minutes before the time.

Entries can be viewed individually or on a scrolling weekly basis.

To enter a diary event

- 1 Press **Menu** \triangleright . Select **Diary**.
- 2 Select **New event**.
- 3 Select **Once**, **Daily** or **Weekly**.
- 4 Enter the date and press **OK** \triangleleft .
Enter the time and press **OK** \triangleleft .
- 5 Enter the text and press **OK** \triangleleft .
- 6 Choose whether you wish to have a reminder alarm and press **Select** \triangleleft . (**Stored** will briefly be displayed)
- 7 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

If set the reminder alarm will sound for 5 seconds, the red LED and backlight will come on and the diary entry will appear in the display.

Press **Exit** \triangleright to acknowledge the alarm.

If the diary entry contains a telephone number, pressing \odot acknowledges the alarm and initiates a call to that number.

If the alarm is not immediately acknowledged the diary entry will remain in the display and the reminder alarm will ring at intervals.

After the third time the alarm will not sound again but the diary entry will remain in the display for up to 15 minutes or until acknowledged.

If the diary event occurs during a call the diary reminder alarm will be heard in the background. If the mobile is off at the time of the reminder alarm it will switch the mobile on. In both cases the alarm can be acknowledged and silenced in the normal way.

To view diary entries

- 1 Press **Menu** \triangleright . Select **Diary**.
- 2 Select **View events**.
- 3 Entries will be shown in time and date order and include the time of the entry, whether an alarm \odot has been set, the first part of the text and the number of the entry (maximum 20).
- 4 To read the complete text entry press **Read** \triangleleft .
- 5 Use \downarrow to scroll down the entries.
- 6 Press **Exit** \triangleright or \curvearrowright to return to the standby display.

To delete and/or edit entries

- 1 Press **Menu** \triangleright . Select **Diary**.
- 2 Select **View events**.

- 3 Scroll to the diary entry you wish to delete or edit and press .
- 4 Select **Read text**, **Edit** or **Delete**.
- 5 Press **Exit**  or  to return to the standby display.

To delete old events

- 1 Press **Menu** . Select **Diary**.
- 2 Select **Delete old events**.
All past entries will automatically be deleted.
- 3 Press **Exit**  or  to return to the standby display.


Using the Calendar

The calendar item in the diary menu can be used to:

- view entries on a weekly basis,
- enter new events,
- read, edit and delete events:

- 1 Press **Menu** . Select **Diary**.
- 2 Select **Calendar**.

The current calendar week will be shown.



The current date will be highlighted. If any events have been scheduled for that week they will be shown in the display as . To view an event directly press keys ① to ⑦ corresponding to the day of the week, i.e. press ① for Monday, ② for Tuesday etc.

To scroll forward or backwards on a weekly basis use  or  and . To view all the individual entries in chronological order press **Events**  and use the scrolling keys to view the entries. Press  to read, edit or delete an entry.

To select any one of the days to make a new entry for that week press and hold down the corresponding day of the week key, 1 to 7. Follow the instructions as for entering a new diary even above.

Press **Exit**  or  to return to the standby display.

Caution - Please remember to turn off the Switch-on alarm feature when boarding an aircraft where the use of mobile phones is not permitted and is illegal. Alternatively you can remove the battery after turning off the phone. See the General safety warnings on page 2.

Calculator



This feature enables you to make simple calculations using +(plus), -(minus), *(multiplication), /(division) and %(percentage) functions.

To use the calculator,

Press **Menu** \triangleright . Select **Calculator**.

The calculator icon () and **0** will be shown in the display. The phone is now ready to make simple calculations.

Numbers are entered by pressing $\textcircled{1}$ to $\textcircled{9}$. The **+**, **-**, ***** and **/** symbols are entered using the multitap $\textcircled{*}$. Decimal points and the **%** symbol are entered using the multitap $\textcircled{\#}$.

Press **Clear** \triangleright during a calculation to correct an entry. Press **=** \triangleleft to obtain a result.

Example: $144 \times 12 = 1728$

Key sequence	Display
$\textcircled{1}$ $\textcircled{4}$ $\textcircled{4}$	144
$\textcircled{*}$ $\textcircled{*}$ $\textcircled{*}$	*
$\textcircled{1}$ $\textcircled{2}$	12
= \triangleleft	1728

Pressing **=** \triangleleft again after obtaining the first result will continue the calculation using the result and last operator (**+**, **-**, *****, **/**) symbol. In the example, pressing **=** \triangleleft again will calculate, $1728 \times 12 = 20736$. Pressing **Clear** \triangleright will erase the result.

Enter another calculation or press **Exit** \triangleright or $\textcircled{\#}$ to return to the standby display.

The % function can only be used (entered) as the last operator during a calculation.
For example $250 - 10\% = 225$

Calculations are kept if a call occurs during operation.

Games



There are two games in the phone, **Reshape** and **Push**.

The instructions to play each game is shown when the game selection is made.

The **Options** item in the menu enables you to select the sound effects - no sound, music or electronic sound effects.

To select a game,

- 1 Press **Menu** \triangleright . Select **Games**.
- 2 Choose the game you wish to play and press **Select** \triangleleft .
- 3 Select **Help** for instructions on how to play the game and the controls to be used.
- 4 Select **Code** to enter and play the game at your skill level.
- 5 Select **Play** to start the game.

Reshape has 250 skill levels, **Push** has 50. When each level has been successfully played within the allowed time you will play at the next level.

After successfully playing 'X' amount of levels you will be given a code to enable you to re-enter the game at your previously attained skill level.

Scores can also be recorded against the name of the player.

If a call is received whilst a game is being played the normal received call display will be shown and the call is answered in the normal way.

When the call is finished the game will be resumed.

To exit from the games menu press **Exit** \triangleright or press \odot to return to the standby display.

Internet



The Aria-@ has an internet browser allowing you access to services, such as News, Sports, Weather, TV Listings etc, supplied by your operator and/or by your internet provider via the internet.

The types of services offered will be dependent upon the internet provider of that service or your network operator.

To gain access to these services via your phone make sure you have a DATA subscription.

Also check with your network operator whether the connection settings have been pre-programmed into the phone prior to delivery or whether you have to manually enter and store the settings yourself.

In either case once the settings have been stored you can start using this feature as required and described below.

- Access to the connection settings may depend upon whether the settings have been pre-programmed into the phone prior to shipment from the factory. In some cases and to avoid errors these settings may be 'Locked' and not be user programmable.

Storing/editing the connection settings (obtainable from your network operator)

Before proceeding and if you have not already done so please enter the current time and date as described on page 63.

To enter and store the PPP Access and Proxy details,

- ➊ Press **Menu** . Select **Internet**.
- ➋ Select **Settings**.
- ➌ Select **Access parameters** and, if active, enter the 4 digit lock code (default code **0000**) and press **OK** .
- ➍ Select **PPP Access** and select **Phone number**. Enter the number and press **OK** .
- ➎ Select **Login name**. Enter the name and press **OK** .
- ➏ Select **Login password**. Enter the password. Each character will turn into a star (*) after a short while.
- ➐ Select **Mode**. Select the connection type (**Numeric** or **Analog**) and press **Select** .
- ➑ Select **Speed**. Select the speed (**9600** or **14400**) and press **Select** . Press **Exit** .
- ➒ Select **Proxy**. Enter the **Proxy name** and press **OK** . Enter the **IP address** and press **OK** . Enter the **Home page** address and press **OK** .
- ➓ Select **Auto-disconnect** (disconnects the mobile from the internet after a set period of inactivity), enter the period (0 - 60 minutes) and press **OK** .
0 deactivates the auto-disconnect function.
- ➔ Press **Exit** or to return to the standby display.

- ✔ 1. You can also access the Internet menu directly by pressing the programmable hotkey from the standby display (provided you haven't personalised it).
- 2. If the PPP access phone number, login names and password, Home page http address and IP address are not predefined, these are obtainable from your network operator and/or internet provider.
- 3. Selecting PPP Access or Proxy again will allow you to change and/or modify any of your settings.

Personalising your connection settings

The following user settings are available enabling you to optimise the behaviour of your phone whilst connected to the internet.

- ➊ Press **Menu** . Select **Internet**.
- ➋ Select **Settings**.
- ➌ Select **User preferences**, scroll to the following items and turn on or off as required:

Option	Action
Clear cache	During an live internet session some of the information and services you have accessed have been 'stored' in an area of memory called the cache. To clear this memory, press and select the Yes option
Download pictures	Some of the internet pages may have pictures attached which will take time to download. Selecting the Off option will reject the pictures thereby speeding up the text downloading time
Default settings	Choosing the Yes option will restore all the factory default settings (Scripting On, Download pictures On, Auto-disconnect: 5 minutes)
Scripting	Used to allow or forbid the execution of scripts within a page allowing entering data or computations to be performed when the page is loaded

④ Press **Exit**  or  to return to the standby display.

You can also access the Internet menu directly by pressing the programmable hotkey from the standby display (provided you haven't personalised it).

Going online and onto the Net

To gain access to the online services offered by your network operator,

- ① Press **Menu** . Select **Internet**.
- ② Select **Home page**.
- ③ An animated screen will be displayed. **Connecting to** followed by your proxy name will then be displayed whilst access is taking place followed by the word **Loading...** (of the home page).

You can also access the Internet menu directly by pressing the programmable hotkey from the standby display (provided you haven't personalised it).

Once connected you will be presented with your internet or operator's choice of menu options. The  icon at the bottom of the display indicates a 'live' connection.

Use  or  and  and/or the softkeys to move up and down the menu, to make selections as well as move backwards and forwards through the menu. Use the left and the right softkeys when selected topics in a menu are highlighted.

Use of whilst online

Pressing  during a live connection will present an options menu as follows:

Item	Action
Back	Returns to the previous page or card
Zoom +/-	Increases or decreases the displayed text size
Disconnect	Disconnects the browser from the network but leaves the current page locally active with the phone browser
Clear cache *	Clears the cache memory
Add bookmark *	Adds a current card or page to the list of bookmarks
Go to bookmarks *	Goes to a previously stored bookmark
Home page	Reloads and returns to the home page
Reload	Reloads the current page
Close session	Disconnects the phone from the internet

* The appearance of these items in the above options menu may be operator dependent and/or the settings in the **User preferences** menu.

Ending the online connection

To end the internet connection,

Press .

 You can also select Close session item under the options menu.

Creating bookmarks

There may be some services that you wish to revisit or return to more frequently than others. These services (or pages) can be stored as *bookmarks* which then provide direct access links into the internet. They can only be used if available on the current connection settings of your network operator and/or internet provider.

There are two ways to add up to a maximum of 5 bookmarks:

- Directly from the standby display,

- 1 Press **Menu** . Select **Internet**.
- 2 Select **Bookmarks**.
- 3 Press **Options** , select **Modify** and enter the following:

Option	Action
Alias	Name you wish to give to your bookmark
Home page	Home page address (if known)

- 4 Press **OK**  to validate each entry.
- 5 Press **Exit**  or  to return to the standby display.

You can also access the Internet menu directly by pressing the programmable hotkey from the standby display (provided you haven't personalised it).

- During a live connection whilst viewing a page,

- 1 Press  to display the options menu.
- 2 Select **Add bookmark**, enter the Alias name and press **OK** .

Bookmarks can only be Edited or Deleted from the Bookmarks item under the Internet menu options whilst offline.

Using bookmarks

Bookmarks can be used:

- directly from standby display,

- 1 Press **Menu** . Select **Internet**.
- 2 Select **Bookmarks**.
- 3 Select the bookmark name you require.

You can also access the Internet menu directly by pressing the programmable hotkey from the standby display (provided you haven't personalised it).

- whilst you are browsing the internet:

- 1 Press  to display the options menu.
- 2 Select **Go to bookmarks**.
- 3 Select the bookmark name you require.

Other site

Use of this option within the **Internet** menu allows the user to enter a known internet address site and to go to this site directly from dial up. However unlike the Bookmark feature addresses are not stored and must be entered each time this feature is used.

GSM man machine interface codes

The phone supports the standard GSM key sequences using the * and # characters sent directly from the keypad to the network. These sequences are used to activate all the supplementary services provided by the network.

Consult your service provider for a complete list.

Appendix

Accessories list

The following are the main accessories available for the phone:

Vehicle kits	Part numbers
CLA car adaptor	FZA-0040A
Headset	FZA-0024A
Simple holder	FZA-0047A
Simple handsfree adaptor	FZA-0041A
Full handsfree adaptor	FZA-0042A
Chargers and batteries	Part numbers
AC adaptor (UK)	FZA-0034A
AC adaptor (Europe)	FZA-0033A
AC adaptor (Australia)	FZA-0035A
AC adaptor (Asia)	FZA-0036A
AC adaptor (China)	FZA-0037A
AC adaptor (Taiwan)	FZA-0038A
Desktop charger	FZA-0043A
Battery pack LP	FZ-2538A
Battery pack LT	FZ-2567A
Data and miscellaneous	Part numbers
Contact Trium Data software kit	FZA-0044A
Handstrap	FZA-0051A

Glossary

Expression

AC/DC charger

Active call

ALS

AoC

CB

Meaning

Alternating Current/Direct Current charger

The call currently in conversation

Alternate Line (Line 2) Service

Advise of Charge - subscription service

Cell Broadcast

CLA	Cigarette Lighter Adaptor
CLI	Caller Line Identity - displays callers telephone number
Conversation mode	When the phone is making or receiving a call
CUG	Closed User Group - requires network support
Diverting	Diverts incoming calls to the phone to another number
DTC	Desk Top Charger
DTMF	Dual Tone Multifrequency Tones
FDN	Fixed Dialling Number
GSM	Global System for Mobile communications
HF	Handsfree Car Kit
http	HyperText Transfer Protocol
IN	Information Numbers of your operator or service provider
IP	Internet Protocol
LCD	Liquid Crystal Display
LED	Light Emitting Diode
MMI	Man machine Interface
PIN/PIN2	Personal Identification Number. Supplied by your network/service provider
PUK/PUK2	PIN Unblocking Key. Used to unlock PIN and PIN2. Supplied by your network/service provider
Roaming (Rm)	The ability to use your telephone on networks other than your home network at home or abroad.
SDN	Service Dialling Number. Of your operator or service provider
SIM	Subscriber Identity Module. Supplied by your network/service provider
SMS	Short Message Service
SR	Status Report - relates to SMS messages
Standby mode	When the phone is on, registered onto a network but not making or receiving a call
URL	Uniform Resource Locator
WAP™	Wireless Application Protocol

Trouble shooting

Problem

Possible cause and solution

Phone will not switch on

Check that the battery is fully charged and correctly connected to the phone.

Charging LED not lit red and no flashing battery icon

There may be no mains supply. Check mains supply. The AC/DC charger may be faulty. Return to your dealer and try substitution with another Mitsubishi adaptor. If faulty contact your dealer.

Short standby and talk times

Cell broadcast is permanently on, using more battery power.
Phone is in a poor signal area and therefore always on full power.
Incorrect charging and discharging. Always charge and discharge your battery fully.
The battery is wearing out. Replace the battery

Calls cannot be made or received

Check that you have at least one signal strength bar (). Try in a stronger signal strength area.
If the name of a network is not displayed, check your SIM is OK, check registration with your network/service provider.
Call barring option is turned on. Turn it off (see page 52).
Call cost limit is reached (see page 47).

Stored telephone numbers cannot be recalled

Fixed Dialed Number or Call Barring features are turned on. Check features and turn them off (see pages 39 and 52).

Numbers cannot be entered in the display

Keypad lock is on (is displayed). Press **Unlock** () and () to turn off.

Phone switches on but there is no display

Display contrast is turned down to low. Reset contrast (see page 58).

Battery icon () not flashing 1-2-3 during charging

Indicates a charging or battery problem. Turn off and disconnect the charger. Reconnect and try again. If the problem remains contact your dealer.

Flashing ()

There is not enough memory to store another SMS message. You must delete one or more of the existing stored messages (see page 40).

Error messages

Problem	Possible cause and solution
Allowed credit reached!	You are trying to place an outgoing call and the allowed credit is already reached. The allowed credit limit is reached during an outgoing call (the call is then aborted).
Busy	You are trying to make a call and the call fails because the destination number is already engaged in conversation.
Call failed	The user is unreachable. The outgoing call fails due to: CUG is in use and the call is not allowed/unrecognised by the network or the network cannot take the call due to system busy or the number is out of order or the number is unreachable or the network does not answer or the option to hide your phone number when calling is not supported by the network Control and verification of CUG parameters not confirmed, CUG availability on network. Control the ability to hide your ID when making a call (service availability in network).
Cancelled. No type selected	Cell broadcast activation has been requested but no message type has been selected.
Cannot execute command	You have made a request which is impossible to be executed in the current call situation.
Can't display message	The short message text cannot be displayed (characters not recognised, incorrect format etc...)
Check SIM!	There is no SIM present or the SIM is incorrectly inserted. See page 8 for more details.
Check your password	You changed the call barring password or You changed the call barring service status. The entered password seems to be wrong or incorrect.
Check your request	You made a request for a service that seems to be impossible to fulfil.
Check your subscription	You tried to activate a GSM service. You are requested to check your subscription regarding the related service rights of use/access.

CUG call failed	You tried to make a call in a CUG (Closed user group) and the call is rejected by the network because the network does not recognise the CUG parameters or the called user is not in the same CUG or the called user has no CUG association.
Error!	The network cannot perform your request and generates an error result.
Failed	An SMS sending process failed (the short message cannot be sent).
Incorrect entry	You entered a character string with a syntax error.
Invalid number	You tried to make a call and the call is rejected by the network because the network does not recognise the phone number structure or you tried to store a phone number that is too long to be stored in the selected location or you tried to move a phone entry to a location that is unable to receive the phone number (phone number too long)
Keypad locked "Unlock" # to unlock	A press on any key is made with keypad locked.
Low battery!	This text is displayed when the battery becomes too low and the mobile will soon be switched off automatically.
Network busy	You tried to make a call. The call is rejected by the network due to congestion problems.
Network not allowed	When selecting network manual search, you have selected a network that rejects the connection.
New PIN incorrect. Try again	Changing PIN: the new PIN code values differ (value control).
New PIN2 incorrect. Try again	Changing PIN2: the new PIN2 code values differ (value control).
No action performed	When a copy/move operation is made on memories but no conditions have been changed (same memory, number and name).
No response	You made a call to a remote user and no response has been received.
Not allowed	Your number/character entry is not allowed.
Not allowed (fixed dialling)	A call is tried, but cancelled due to fixed dialling control (the number dialled does not match with one of the fixed dialling numbers in memory).
Not Available	There is no more SIM storage.
Number changed	The called number has changed.

PIN blocked	A wrong PIN code has been entered 3 times.
PIN2 blocked	A wrong PIN2 code has been entered 3 times.
PUK2 blocked	A wrong PUK2 code has been entered 10 times. The SIM services protected by the PIN2 code have now been permanently disabled.
Reaching allowed credit!	The cost limit is about to be reached. The connected call will end automatically when the limit is reached.
Ring volume Off	The ring volume is set to 0 (no volume).
Service not available	Activating some GSM services that are not available on the network
SIM blocked. Contact provider	A wrong PUK has been entered 10 times. The SIM card has been permanently disabled and needs to be replaced by a new one.
SIM blocked. Enter PUK:	A wrong PIN code has been entered 3 times. Enter the PUK code to unblock the SIM card.
SIM fixed full	The corresponding memory is full.
SIM names full	
Phone names full	
SMS memory locations are full	The storage of new messages (when writing a new SMS) is impossible.
Wrong code. Try again	A wrong phone lock code has been entered.
Wrong new code. Try again	The new phone lock codes do not match (value control).
Wrong PIN, try again	The wrong code has been entered.
Wrong PIN2, try again	
Wrong PUK, try again	
Wrong PUK2, try again	

Index

A

Access parameters	72
Accessories	76
Alarm clock	65
Alert mode	56
Alert tone	
Turning on/off	41
Any key answer	59
Auto answer	60
Auto retry	60
Auto Switch On/Off	67
Automatic search	51

B

Backlight	21, 58
Balance Info	45
Balance information	45
Barring password	
Call	62
Basic operations	20
Calling	21
Making a call	21
Receiving a call	21
SMS	24
Unanswered call	24
Voice Mail	24
Battery	9, 16
Alarm volume	57
Charging	17
Disposal	19
Fitting	16
Low battery warning	17
Removing	16
Safety information	18
Use	16
Bookmarks	
Creating	74
Deleting	75
Using	75
Broadcast	53
Language	55
Message types	54, 55
On/Off	54

C

Cache memory	
Clearing	73, 74
Calculator	70
Calendar	
Using	69
Call	
Holding	28
Multi-party Conference	29
Retrieving	28
Call barring	52
Password	14
Call costs	
Reset	47
Call duration	46
Call reminder	46
Call timer	
Reset	46
Call times	44
Call waiting	28
Caller line identity	49
Calling	10, 21
Calling phonebook numbers	38
Calls & Times	44
Call costs	46, 47
Call timers	45, 46
Calls Log	44
Costs	46
Calls Log	44
Care and maintenance	12
CB	53
CB messages	
Changing	55
Editing	55
Reading	54
Cell broadcast	53
CLI	49
Closed user group	53
Conference call	29
Connection settings	72
Copying phonebook numbers ...	38
Cost management	46

Credit limit	47
CUG	53
Currency-converter	64
D	
Default settings	63, 73
Deleting phonebook numbers ..	38
Dialling	
Calls Log memory	25
Last dialled numbers	25
Phonebook	25
Dialling from memory	25
Diary	67
Calendar	69
Delete old events	69
New event	68
View events	68
Diary entries	
Deleting	68
Editing	68
Viewing	68
Diary event	
entering	68
Display contrast	59
Diverting	48
DTMF tones	27
E	
e-mail messages	
Managing	41
Preparing your phone	41
Receiving	40
Sending	40
e-mail service	40
Editing phonebook numbers	38
Emergency calls	14
Ending a call	11, 22
Entering text	32
Error messages	79
Extending the antenna	10
F	
FDN	39
Fixed dialling numbers	39

G	
Games	71
General operations	25
General safety	2
Getting started	8
Glossary	76
Graphic display icons	6
GSM man machine interface	
codes	75
GSM Services	48
Call barring	52, 62
Call diverting	48
Call waiting	28
CUG	53
Network	51
Receiving ID	49
Send ID	50
H	
Holding a call	28
Hotkey	4, 6
Programming	59
I	
Icons	6
In-call options	28
Incoming Calls	
Diverting	48
Information numbers	35
International code prefixes	22
Internet	71
Access parameters	72
Bookmarks	74, 75
Default settings	73
Going online	73
Home page	73
IP address	72
Login name	72
Login password	72
Other site	75
Personalising	72
Proxy name	72
Settings	72
IP address	72

K	
Keypad	4
Keypad lock	21, 55
Keys	4
L	
Language selection	56
Last dialled numbers	25
Line 1 or 2 selection	48
Line selection	48
Login name	72
Login password	72
M	
Making a call	10, 21
Managing e-mail messages	41
Managing SMS messages	41
Menu	30
Menu map	30
Menu softkey	20
Message templates	43
Messages	40
Alert	41
Broadcast	53
In Box	41
Msg. Templates	44
Outbox	43
Settings	41
Write new	42
Mobile number	
Hiding	49
Showing	49
Moving phonebook numbers ...	38
Multi-party call	29
Multipress method	33
Multitap method	33
Muting	26
N	
Names softkey	21
Network	50
Network Serv.	35
Network services	35
O	
Office Tools	
Alarm clock	65, 66
Auto-switch	67
Currency converter	64
Scratchpad	64
Office tools	64
Old events	
deleting	69
Online connection	73
Bookmarks	74, 75
Ending	74
Personalising	72
Options key	4
Outbox	43
P	
Pause feature	27
Phone Book	
Calling numbers	37
Fixed Dialling	39
Free space	37
Own Numbers	38
Phone book tones	39
Recall	38
Remaining	37
Store	37
Viewing numbers	37
Phone customising	55
Phone diagram	3
Phone lock	60
Phone lock code	14, 60
Phone settings	55
Phonebook	36
Tone setting	39
Phonebook numbers	
Calling	38
Copying	38
Deleting	38
Editing	38
Moving	38
PIN code	61
PIN/PIN2 codes	13
PIN2 code	62
PPP Access	72

Preparing the phone for operation	15	Internet	72
Problems	78, 79	Keypad lock	56
Programmable		Keys	40, 59
hotkey	59	Language	55, 56
speed dialling	26	Security	61
Programming the hotkey	59	Time & date	63
Proxy	72	Tones	57
Proxy name	72	Show costs	47
PUK code	62	SIM application tool kit	35
PUK/PUK2 Codes	13	SIM card	8, 15
PUK2 code	62	SMS	40
Push	71	SMS e-mail messages	
R		Reading	40
Ramping	58	SMS messages	
Reading an SMS e-mail message	40	Managing	41
Reading an SMS message	40	Preparing your phone	41
Receiving a call	10, 23	Reading	40
Reminder - call time	46	Sending	42
Replacing the antenna	11	Solutions	78, 79
Reshape	71	Solving problems	78
Responsibility	13	Speed dialling	26, 40
Retrieving a call	28	Standby display	9, 20
Ring tone	57	Storing names and numbers	36
S		T	
Safety information	2	T9 text entry	34
Battery	18	Tegic (T9)	34
Care and maintenance	12	Text entry	
Emergency calls	12	Multipress mode	33
Responsibility	12	Multitap mode	33
Security codes	12	Time & date	63
Vehicle safety	12	Trouble shooting	78
Scratchpad	64	Turning off	11, 21
Scripting	73	Turning on	9, 20
SDN numbers	35		
Second call	28		
Security	60		
Security codes	13		
Security features	60		
Sending an SMS message	42		
Settings	55		
Auto features	60		
Display	58, 59		
Edition	58		

V

Vehicle safety	12
Vibrate	56
Vibrate & ring	56
Vibrate alert mode	26
Vibrate then ring	56
Vibrator	56
Voice Mail	
Alert Tone	36
Call	36
Number	35
Voice mail	35
Volume	26
alert mode	57
keys tones	57
ring tone	57
Volume adjustment	26

Pan European Service

If you require service then in the first instance, you should contact your supplier.
Should you experience any difficulty then please contact your nearest MITSUBISHI location listed below for information on other service centers.

UNITED KINGDOM
Tel: +44 (0)1707 278708

SVERIGE
Tel : +46(8) 625 10 00
Fax : +46 (8) 625 10 86

FRANCE
Tel : 0825 868 283

DEUTSCHLAND
Tel: +49 (01803) 337184

SPAIN
Tel : +34 (91) 5560503
Fax : +34 (91) 5563497

ITALIA
Tel : +39 (39) 60531
Fax : +39 (39) 6057694

IRELAND
Tel : +353 (1) 4505007
Fax : +353 (1) 4561337

GSM Service Card

To obtain warranty Service, you will require your original equipment purchase invoice or irrefutable proof of purchase, plus this card, please fill in missing information:
Please see warranty terms and conditions for in warranty service.

Date of purchase:

.....

Invoice number:

.....

Dealer name:

.....

Location:

.....

Dealer tel. number:

.....



Pan-european GSM End-user Guarantee Conditions

1. You can benefit from this guarantee only if you are the original end-user purchaser.
2. MITSUBISHI guarantees that for a period of twelve (12) months from the date of purchase from your dealer, the Product shall be free from defects in materials and workmanship. Subject to the conditions below, Mitsubishi will indemnify you against all cost of parts and labour for repairs to or replacement of the product or parts (which may include equipment of similar type) where conducted by an authorised MITSUBISHI GSM service centre. MITSUBISHI shall be entitled to retain product which has been replaced.
3. Any claims must be made to an authorised MITSUBISHI GSM service centre in the countries mentioned in the service card enclosed with the product. In case of difficulty you can contact the Mitsubishi companies listed in the service card to obtain details of your nearest authorised MITSUBISHI GSM service centre. As a condition of this guarantee, the date of your purchase must be confirmed by producing your original invoice from your supplier or your sales receipt, showing the serial number, together with the service card. Final determination of guarantee claim eligibility shall be made by MITSUBISHI. MITSUBISHI shall not be liable for shipment costs to and from an authorised GSM MITSUBISHI service centre and the product travels at your risk.
4. This guarantee does not cover:
 - a) battery defects of any nature;
 - b) non-compliance with directions for use;
 - c) installation or removal charges where the product is installed in a vehicle;
 - d) defects or failures caused by accident, misuse, improper installation or improper repair by an unauthorized repairer, alteration or modification, neglect, failure to use for normal purpose, Acts of God, water ingress, use in adverse environmental conditions (humidity or temperature);
 - e) cost of or performance of modifications to product to adapt or adjust to conform to national or local safety laws, where such safety laws go beyond harmonised European Union standards;
 - f) loss of use of the product or consequential loss of any nature;
 - g) loss of use of air-time, loss of use of any loaned equipment or ancillary equipment;
 - h) provision of incorrect or insufficient signal on air-time network, upgrading of product software to changes in network operating parameters, mains supply voltage fluctuations, incorrect SIM card (memory card) parameters for connection to airtime retailer;
 - i) damage caused by non-MITSUBISHI accessories.
5. Any guarantee claim or service does not extend the original guarantee period unless so required by prevailing national law.
6. This guarantee is valid only if the product is purchased and used in the European Union, Norway, Iceland or Switzerland.

THIS GUARANTEE DOES NOT AFFECT YOUR STATUTORY RIGHTS.

The logo for Trium, featuring the word "Trium" in a bold, italicized, sans-serif font. A curved line arches over the letters "i" and "u", resembling a stylized "T" or a bridge.